

U.S. Department of Transportation Federal Aviation Administration Washington, DC

# Master Minimum Equipment List (MMEL)

Revision: 32 Date: XX/XX/XXXX

# **Airbus SAS** A318, A319, A320, and A321 Series All Models

Flight Operations Evaluation Board (FOEB)

Approved by the Aircraft Evaluation Division Federal Aviation Administration (FAA) Air Carrier Branch, AFS-110 800 Independence Avenue, S.W. Washington, DC 20591

AED Email: 9-AVS-AFS-100@faa.gov

#### MASTER MINIMUM EQUIPMENT LIST

### **REVISION NO. 32**

DATE: XX/XX/XXXX

PAGE NO. I

#### AIRCRAFT:

Airbus A320

#### TABLE OF CONTENTS AND CONTROL PAGE

| SYSTEM NO. | SYSTEM                             | PAGE NO.      | REV NO. | DATE       |
|------------|------------------------------------|---------------|---------|------------|
|            | Cover Page                         |               | 32      | XX/XX/XXXX |
|            | Table of Contents and Control Page | 1             | 32      | XX/XX/XXXX |
|            | Log of Revisions                   | II thru III   | 32      | XX/XX/XXXX |
|            | Highlights of Change               | IV thru V     | 32      | XX/XX/XXXX |
|            | FAA MMEL Policy Application Record | VI thru XI    | 32      | XX/XX/XXXX |
|            | Definitions and Preamble           | XII           | 32      | XX/XX/XXXX |
|            | List of Acronyms                   | XIII thru XXV | 32      | XX/XX/XXXX |
| 21         | Air Conditioning                   | 21-1 thru 29  | 30      | 03/03/2023 |
| 22         | Autoflight                         | 22-1 thru 13  | 32      | XX/XX/XXXX |
| 23         | Communications                     | 23-1 thru 29  | 32      | XX/XX/XXXX |
| 24         | Electrical Power                   | 24-1 thru 25  | 31      | 08/13/2024 |
| 25         | Equipment/Furnishings              | 25-1 thru 31  | 32      | XX/XX/XXXX |
| 26         | Fire Protection                    | 26-1 thru 18  | 31      | 08/13/2024 |
| 27         | Flight Controls                    | 27-1 thru 37  | 32      | XX/XX/XXXX |
| 28         | Fuel                               | 28-1 thru 53  | 32      | XX/XX/XXXX |
| 29         | Hydraulic Power                    | 29-1 thru 7   | 30      | 03/03/2023 |
| 30         | Ice and Rain Protection            | 30-1 thru 14  | 32      | XX/XX/XXXX |
| 31         | Indicating/Recording Systems       | 31-1 thru 12  | 31      | 08/13/2024 |
| 32         | Landing Gear                       | 32-1 thru 26  | 32      | XX/XX/XXXX |
| 33         | Lights                             | 33-1 thru 11  | 31      | 08/13/2024 |
| 34         | Navigation                         | 34-1 thru 34  | 32      | XX/XX/XXXX |
| 35         | Oxygen                             | 35-1 thru 6   | 32      | XX/XX/XXXX |
| 36         | Pneumatic                          | 36-1 thru 25  | 31      | 08/13/2024 |
| 38         | Water/Waste                        | 38-1 thru 2   | 30      | 03/03/2023 |
| 46         | Information Systems                | 46-1 thru 3   | 32      | XX/XX/XXXX |
| 47         | Inert Gas System                   | 47-1          | 30      | 03/03/2023 |
| 49         | Airborne Auxiliary Power           | 49-1 thru 3   | 30      | 03/03/2023 |
| 52         | Doors                              | 52-1 thru 10  | 31      | 08/13/2024 |
| 71         | Powerplant                         | 71-1 thru 2   | 31      | 08/13/2024 |
| 73         | Engine Fuel and Control            | 73-1 thru 16  | 31      | 08/13/2024 |
| 74         | Ignition                           | 74-1 thru 2   | 30      | 03/03/2023 |
| 75         | Bleed Air                          | 75-1 thru 2   | 30      | 03/03/2023 |
| 76         | Engine Control                     | 76-1          | 30      | 03/03/2023 |
| 77         | Engine Indicating                  | 77-1          | 30      | 03/03/2023 |
| 78         | Engine Exhaust                     | 78-1 thru 10  | 31      | 08/13/2024 |
| 79         | Engine Oil                         | 79-1 thru 18  | 31      | 08/13/2024 |
| 80         | Starting                           | 80-1 thru 2   | 31      | 08/13/2024 |

|                        | RTMENT OF TRANSPORTATION<br>AVIATION ADMINISTRATION | MASTER MINIMUM EQUIPMENT LIST |
|------------------------|---|-------------------------------|
| REVISION               |   | PAGE NO. II                   |
| DATE: XX/              |   |                               |
| AIRCRAFT<br>Airbus A32 |   | LOG OF REVISIONS              |
|                        |   |                               |
| REV NO.<br>Original    | DATE<br>06/14/1989                                  |                               |
|                        |   |                               |
| 1                      | 08/14/1989  |                               |
| 2                      | 09/14/1990  |                               |
| 3                      | 06/21/1991  |                               |
| 3a                     | 06/11/1992  |                               |
| 4                      | 01/28/1993  |                               |
| 5                      | 07/28/1993  |                               |
| 6                      | 08/30/1995  |                               |
| 7                      | 12/03/1996  |                               |
| 8                      | 05/05/1997  |                               |
| 9                      | 07/03/1997  |                               |
| 9a                     | 03/24/1998  |                               |
| 9b                     | 04/08/1998  |                               |
| 10                     | 12/07/1998  |                               |
| 10a                    | 02/08/1999  |                               |
| 11                     | 03/29/1999  |                               |
| 11a                    | 05/24/1999  |                               |
| 12                     | 08/06/2001  |                               |
| 12a                    | 10/15/2001  |                               |
| 13                     | 05/15/2002  |                               |
| 14                     | 07/30/2002  |                               |
| 14a                    | 02/06/2003  |                               |
| 15                     | 06/24/2003  |                               |
| 16                     | 11/17/2004  |                               |
|                        |   |                               |

|                      | ARTMENT OF TRANSPORTATION<br>AVIATION ADMINISTRATION | MASTER MINIMUM EQUIPMENT LIST |
|----------------------|--|-------------------------------|
| REVISION<br>DATE: XX |  | PAGE NO. III                  |
| AIRCRAF              |  |                               |
| Airbus A32           | 20   | LOG OF REVISIONS              |
| REV NO.              | DATE   |                               |
| 17                   | 02/22/2005   |                               |
| 18                   | 04/27/2005   |                               |
| 19                   | 07/11/2006   |                               |
| 20                   | 03/19/2008   |                               |
| 21                   | 06/17/2009   |                               |
| 21a                  | 03/23/2010   |                               |
| 22                   | 05/15/2012   |                               |
| 22a                  | 02/07/2013   |                               |
| 23                   | 12/20/2013   |                               |
| 24                   | 01/16/2014   |                               |
| 25                   | 06/23/2014   |                               |
| 25a                  | 12/12/2014   |                               |
| 25b                  | 05/18/2015   |                               |
| 26                   | 03/11/2016   |                               |
| 26a                  | 09/07/2016   |                               |
| 26b                  | 11/22/2016   |                               |
| 27                   | 07/18/2018   |                               |
| 28                   | 11/22/2019   |                               |
| 29                   | 05/18/2021   |                               |
| 30                   | 03/03/2023   |                               |
| 31                   | 08/13/2024   |                               |
| 32                   | XX/XX/XXXX   |                               |

#### MASTER MINIMUM EQUIPMENT LIST

# REVISION NO. 32

DATE: XX/XX/XXXX

PAGE NO. IV

## AIRCRAFT:

Airbus A320

#### **HIGHLIGHTS OF CHANGE**

The following changes are the Highlights of Changes for **Revision 32**.

| ITEM NO. | EXPLANATION OF CHANGE   |
|----------|---|
| General  | Minor editorial corrections and formatting changes were made throughout the document, indicated with change bars. These editorial corrections may be adopted in Minimum Equipment Lists (MEL) at the operator's discretion. |
| General  | Updated FAA MMEL Policy Application Record.   |
| General  | Multiple instances of removing "no." (i.e., number) for simplicity and consistency. (For example, "VHF no. 2" becomes "VHF 2".)   |
| ATA 22   | Autoflight  |
| 22-73-01 | Removed reference to item moved in Revision 30.   |
| 22-73-02 | Removed reference to item moved in Revision 30.   |
| ATA 23   | Communications  |
| 23-13-01 | Modified applicability and provisos. Deleted redundant dispatch cases.  |
| 23-14-01 | Modified applicability.   |
| 23-24-01 | Added note.   |
| ATA25    | Equipment/Furnishings   |
| 25-00-00 | Added relief for CLASS II ECAM Message.   |
| 25-60-12 | Removed outdated reference to sequence number change.   |
| ATA27    | Flight Controls   |
| 27-14-01 | Modified applicability.   |
| 27-64-01 | Added A321neo XLR specific dispatch cases.  |
| 27-64-05 | Added item.   |
| 27-92-07 | Added item.   |
| 27-93-04 | Added item.   |
| 27-94-01 | Added item.   |
|          |   |

| -                  | IENT OF TRANSPORTATION  | MASTER MINIMUM EQUIPMENT LIST                     |
|--------------------|---|---|
| FEDERAL AVI        | ATION ADMINISTRATION  | · · · · · · · · · · · · · · · · · · ·             |
| <b>REVISION NO</b> |   | PAGE NO. V  |
| DATE: XX/XX/       | XXXX  |   |
| AIRCRAFT:          |   | HIGHLIGHTS OF CHANGE                              |
| Airbus A320        |   |   |
| ITEM NO.           |   | ON OF CHANGE                                      |
| ATA 28             | B Fuel  |   |
| 28-20-01           | Restored missing sequence number.   |   |
| 28-21-04           | Added item.   |   |
| 28-25-03           | Added item.   |   |
| 28-25-07           | Added item.   |   |
| 28-25-08           | Added item.   |   |
| 28-40-01           | Added item.   |   |
| 28-40-03           | Added item.   |   |
| 28-40-05           | Added item.   |   |
| 28-40-06           | Deleted sub-item Fuel Quantity Wing Ta<br>Tank. Re-sequenced subsequent sub-ite | nk. Deleted sub-item Fuel Quantity Center<br>ems. |
| 28-40-09           | Added item.   |   |
| ATA 30             | Ice and Rain Protection   |   |
| 30-11-01           | Modified applicability by separating A32  | 1neo XLR into separate dispatch cases.            |
| ATA32              | Landing Gear  |   |
| 32-31-00           | Removed item(s) moved in Revision 31.   |   |
| ATA 34             | Navigation  |   |
| 34-55-04           | Removed item deleted in Revision 28.  |   |
| ATA 46             | Information Systems   |   |
| 46-20-01           | Aligned with PL-121.  |   |
| 46-21-01           | Added note.   |   |
| 46-21-04           | Added note.   |   |
|                    |   |   |

#### MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. VI

## AIRCRAFT:

Airbus A320

#### FAA MMEL POLICY APPLICATION RECORD

With this MMEL **Revision 32**, stated policy from the following list of FAA MMEL Policy Letters (PL) has been applied to the appropriate items listed on this MMEL, as applicable. Any PL, either new or revised, with an issue date later than **01/14/2025** (most recent listing on this record) has not been considered for application in this revision.

| PL No. | Subject   | PL Revision and Date      | Affected Item<br>Sequence<br>Number(s)       | Change<br>Bar |
|--------|---|---------------------------|--|---------------|
| PL-001 | Wide-Body Passenger Airplane Door/Slide Relief  | Revision 4<br>02/27/2010  | N/A  |               |
| PL-002 | Aural and Visual Speed Warning Policy   | Revision 1<br>08/15/1997  | N/A  |               |
| PL-003 | DME Systems MMEL Policy   | Revision 1<br>08/15/1997  | 34-51-01                                     |               |
| PL-005 | Takeoff Warning Systems   | Revision 1<br>08/15/1997  | N/A  |               |
| PL-009 | Public Address System, Crewmember Interphone<br>and Alerting Systems                  | Revision 12<br>10/23/2015 | 23-31-01<br>23-42-02<br>23-43-01<br>23-43-02 | I             |
| PL-013 | Oil Temperature and Pressure Instrument MEL Policy                                    | Revision 1<br>08/15/1997  | N/A  |               |
| PL-024 | Lavatory Fire Protection  | Revision 5<br>10/23/2015  | 26-25-01                                     |               |
| PL-025 | MMEL and MEL Definitions  | Revision 23<br>06/12/2023 | As Applicable                                |               |
| PL-026 | Thrust Reversers on Small Turbojet Airplanes  | Revision 1<br>08/15/1997  | N/A  |               |
| PL-029 | Master Minimum Equipment List (MMEL)<br>Requirements for Cockpit Voice Recorder (CVR) | Revision 5<br>08/10/2010  | 23-71-01                                     |               |
| PL-031 | MMEL Format Specification   | Revision 3<br>01/20/2011  | As Applicable                                |               |
| PL-032 | Traffic Alert and Collision Avoidance System (TCAS)                                   | Revision 7<br>07/07/2006  | 34-43-01                                     |               |
| PL-034 | MMEL and MEL Preamble   | Revision 5<br>04/23/2024  | As Applicable                                |               |

#### MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. VII

#### AIRCRAFT:

Airbus A320

| PL No. | Subject   | PL Revision and Date      | Affected Item<br>Sequence<br>Number(s)   | Change<br>Bar |
|--------|---|---------------------------|--|---------------|
| PL-036 | FAR Part 91 MEL Approval & Preamble   | Revision 3<br>06/16/2020  | N/A  |               |
| PL-038 | Policy Regarding MMEL Relief for Primary Thrust<br>Setting Instruments on Two-Engine Airplanes                | Revision 1<br>08/15/1997  | N/A  |               |
| PL-038 | Policy Regarding MMEL Relief for Primary Thrust<br>Setting Instruments on Two-Engine Airplanes                | Revision 1<br>08/15/1997  | N/A  |               |
| PL-039 | Altitude Alerting Systems   | Revision 5<br>01/29/2010  | 34-42-04   |               |
| PL-040 | ETOPS and Polar Operations  | Revision 3<br>11/10/2020  | 23-28-01<br>24-20-01<br>24-20-02<br>26-12-01<br>26-13-01<br>30-11-01<br>30-11-02<br>30-31-02<br>30-31-03<br>30-31-03<br>30-31-05<br>30-42-01<br>30-42-03<br>49-10-01<br>49-10-02<br>49-30-01<br>49-70-05 |               |
| PL-045 | Time Limited Dispatch (TLD) Authorization for Full<br>Authority Digital Electronic Control (FADEC)<br>Engines | Revision 2<br>03/04/2004  | 71-00  |               |
| PL-054 | Terrain Awareness and Warning System (TAWS)   | Revision 10<br>10-31-2005 | 34-48-01   |               |
| PL-056 | Flight Deck FWD Observer Seat   | Revision 5<br>01/01/2012  | 25-11-06   |               |
| PL-058 | Flight Deck Headsets and Hand Microphones   | Revision 4<br>03/24/2012  | 23-51-04   |               |
| PL-063 | Instrument and Equipment Items Required for<br>Emergency Procedures   | Revision 4<br>07/05/2012  | As Applicable  |               |

#### MASTER MINIMUM EQUIPMENT LIST

### **REVISION NO. 32**

PAGE NO. VIII

DATE: XX/XX/XXXX

#### AIRCRAFT:

Airbus A320

| PL No. | Subject   | PL Revision and<br>Date   | Affected Item<br>Sequence<br>Number(s) | Change<br>Bar |
|--------|---|---------------------------|--|---------------|
| PL-064 | Electrical Power MMEL Policy - Four Engine<br>Cargo Airplanes   | Revision 1<br>08/15/1997  | N/A                                    |               |
| PL-065 | Policy Regarding Cargo Provisions in the MMEL for Cargo Operations                                      | Revision 1<br>08/15/1997  | N/A                                    |               |
| PL-067 | Windshear Warning and flight Guidance System<br>(RWS) Windshear Detection and Avoidance<br>System (PWS) | Revision 4<br>01/15/2012  | 22-66-03                               |               |
| PL-069 | External Door Indication System   | Revision 2<br>09/24/2003  | 52-70-01                               |               |
| PL-072 | Wing Icing Detection Lights   | Revision 4<br>03/12/2012  | 33-40-07                               |               |
| PL-076 | ATC Transponders and Automatic Altitude<br>Reporting Systems  | Revision 7<br>12/04/2017  | 34-52-01                               |               |
| PL-077 | Cockpit and Instrument Lighting Systems   | Revision 4<br>12/17/2012  | 33-10-01                               |               |
| PL-079 | Passenger Seat Relief   | Revision 9<br>12/05/2017  | 25-21-01                               |               |
| PL-083 | Water and Waste Systems on Air Carrier Aircraft   | Revision 8<br>05/11/2015  | 38-10-01<br>38-30-01                   |               |
| PL-084 | Master Minimum Equipment List (MMEL) for<br>Reduced Separation Minimum (RVSM)<br>Operations             | Revision 1<br>08/15/1997  | 34-42-04                               |               |
| PL-087 | Flight Data Recorder (FDR)  | Revision 10<br>08/10/2010 | 31-30-02                               |               |
| PL-089 | FASTEN SEAT BELT WHILE SEATED Signs or<br>Placards  | Revision 2<br>01/31/2009  | 25-60-07                               |               |
| PL-090 | Pitot Heat Indicating System  | Revision 1<br>09/20/2001  | 30-31-02                               |               |
| PL-093 | Autopilot Disconnect MMEL Policy  | Revision 1<br>09/11/2006  | 22-10-03                               |               |

#### MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. IX

### AIRCRAFT:

Airbus A320

| PL No. | Subject  | PL Revision and<br>Date  | Affected Item<br>Sequence<br>Number(s) | Change<br>Bar |
|--------|--|--------------------------|--|---------------|
| PL-094 | Liquid or Paste Propeller Deicer   | Revision 1<br>10/08/2004 | N/A                                    |               |
| PL-095 | VHF Communications MMEL Requirements                                     | Revision 2<br>01/15/2012 | 23-12-01                               |               |
| PL-096 | Galley/Cabin Waste Receptacles Access<br>Doors/Covers                    | Revision 2<br>01/29/2010 | 25-45-01                               |               |
| PL-097 | Flight Attendant Seat(s)   | Revision 4<br>09/06/2007 | 25-22-01                               |               |
| PL-098 | Navigation Databases   | Revision 1<br>06/01/2017 | 34-61-01                               |               |
| PL-099 | Door/Slide Relief Policy   | Revision 2<br>02/26/2010 | N/A                                    |               |
| PL-100 | MMEL/MEL Relief for Cargo Restraint<br>Components                        | Revision 3<br>10/02/2020 | 25-50-04                               |               |
| PL-101 | Autopilot Relief   | Revision 2<br>12/15/2011 | 22-10-01                               |               |
| PL-102 | Cargo Compartment Smoke Detection and Fire Suppression Systems           | Revision 2<br>12/17/2012 | 26-16-03<br>26-23-01                   |               |
| PL-104 | Storage Bins/Cabin, Galley, and Lavatory Storage<br>Compartments/Closets | Revision 7<br>06/24/2020 | 25-28-01                               |               |
| PL-105 | Automatic Dependent Surveillance-Broadcast<br>(ADS-B) System             | Revision 4<br>02/08/2021 | 34-57-02                               |               |
| PL-106 | High Frequency (HF) Communications                                       | Revision 5<br>06/06/2014 | 23-11-01                               |               |
| PL-107 | MMEL Relief for Inoperative APU Generator                                | Revision 1<br>05/22/2001 | 24-20-02                               |               |

#### MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. X

#### AIRCRAFT:

Airbus A320

| Allbus Ac |  |                          |  |               |
|-----------|--|--------------------------|--|---------------|
| PL No.    | Subject  | PL Revision and<br>Date  | Affected Item<br>Sequence<br>Number(s)   | Change<br>Bar |
| PL-108    | Carriage of Empty Cargo Handling Equipment                     | Revision 1<br>10/17/2011 | 25-50-02<br>25-50-03<br>25-50-04<br>26-16-03<br>26-16-04<br>26-17-02<br>26-23-01<br>26-23-02<br>26-23-03<br>26-23-04<br>26-23-05 |               |
| PL-109    | Supplemental Type Certificate (STC) MMEL/MEL<br>Relief Process | Revision 1<br>11/07/2019 | As Applicable  |               |
| PL-111    | MMEL Policy for Inoperative Standby Attitude<br>Indicator      | Revision 1<br>01/29/2004 | 34-22-01<br>34-22-03   |               |
| PL-112    | Relief for 14 CFR 25.795 Compliant Flight Deck<br>Doors        | Revision 2<br>01/18/2012 | N/A  |               |
| PL-113    | MMEL Relief for Anti-Skid Inoperative                          | Revision 0<br>12/20/2002 | N/A  |               |
| PL-114    | Nose Gear Steering Systems                                     | Revision 1<br>10/09/2012 | N/A  |               |
| PL-117    | Selective Call System (SELCAL)                                 | Revision 0<br>10/07/2005 | 23-51-01   |               |
| PL-119    | Two-Section MMELs  | Revision 6<br>08/21/2024 | N/A  |               |
| PL-120    | Emergency Locator Transmitters (ELT)                           | Revision 4<br>03/10/2023 | 25-61-01   |               |
| PL-121    | (EFB) Electronic Flight Bag                                    | Revision 1<br>05/03/2021 | 46-20-01   |               |
| PL-122    | Flight Deck Door Surveillance Systems                          | Revision 1<br>10/09/2012 | 23-72-01   |               |
| PL-123    | Passenger Notice System (Lighted Information Signs)            | Revision 1<br>04/30/2010 | 33-20-02   |               |

#### MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. XI

#### AIRCRAFT:

Airbus A320

| PL No. | Subject  | PL Revision and Date     | Affected Item<br>Sequence<br>Number(s)   | Change<br>Bar |
|--------|--|--------------------------|--|---------------|
| PL-124 | Damaged Window/Windshield Relief                                   | Revision 0<br>01/20/2009 | N/A  |               |
| PL-125 | Equipment Relief without Passengers                                | Revision 1<br>11/27/2012 | 25-22-01<br>25-60-08<br>25-60-09<br>25-61-02<br>25-90-01<br>33-50-01<br>33-50-03<br>33-50-09 |               |
| PL-126 | Chelton FlightLogic Electronic Flight Instrument<br>Systems (EFIS) | Revision 0<br>05/28/2010 | N/A  |               |
| PL-127 | Night Vision Imaging Systems (NVIS)                                | Revision 0<br>06/07/2010 | N/A  |               |
| PL-129 | Cockpit Smoke Vision Systems (CSVS)                                | Revision 0<br>03/12/2012 | N/A  |               |
| PL-130 | Flightcrew Rest Facilities (FCRF)                                  | Revision 2<br>03/12/2021 | 25-75-02   |               |
| PL-131 | Radar (Radio) Altimeters for Rotorcraft                            | Revision 0<br>10/23/2019 | N/A  |               |
| PL-132 | Portable Emergency Equipment                                       | Revision 0<br>05/03/2021 | 25-60-08<br>25-60-09<br>25-60-13<br>26-26-24<br>35-31-01<br>35-32-01                         |               |

MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. XII

#### AIRCRAFT: Airbus A320

#### **DEFINITIONS AND PREAMBLE**

#### DEFINITIONS

For Definitions, refer to the current FAA MMEL Policy Letter PL-25, MMEL and MEL Definitions, found on the FAA Dynamic Regulatory System (DRS) website at https://drs.faa.gov.

#### PREAMBLE

For the Preamble used for operations under 14 CFR Parts 121, 125, 129, and 135, refer to the current FAA Policy Letter PL-34, MMEL and MEL Preamble, found on the FAA Dynamic Regulatory System (DRS) website at https://drs.faa.gov.

|               | IENT OF TRANSPORTATION MASTER MINIMUM EQUIP             | MENT LIST  |
|---------------|---|------------|
| REVISION NO.  |   | GE NO. XII |
| DATE: XX/XX/X | XXX   |            |
| AIRCRAFT:     |   |            |
| Airbus A320   | LIST OF ACRONYMS  |            |
| ACRONYM       | DEFINITION  | Change     |
| A             |   | Bar        |
| A/BRK         | Autobrake   |            |
| A/THR         | Autothrust  |            |
| AAP           | Additional Attendant Panel                              |            |
| AAT           | Aircraft Allocation Table                               |            |
| ABSELV        | Alternate Brake Selector Valve                          |            |
| AC            | Alternating Current                                     |            |
| ACARS         | Aircraft Communications Addressing and Reporting System |            |
| ACCU          | Accumulator   |            |
| ACFT          | Aircraft  |            |
| ACMS          | Aircraft Condition Monitoring System                    |            |
| ACP           | Audio Control Panel                                     |            |
| ACS           | Air Conditioning System                                 |            |
| ACT           | Additional Center Tank                                  |            |
| ADF           | Automatic Direction Finder                              |            |
| ADGB          | Active Differential Gearbox                             |            |
| ADHF          | Adaptive Dropped Hinge Flap                             |            |
| ADIRS         | Air Data Inertial Reference System                      |            |
| ADIRU         | Air Data Inertial Reference Unit                        |            |
| ADLU          | Aircraft Data Loading Unit                              |            |
| ADR           | Air Data Reference                                      |            |
| ADS           | Aircraft Documentation System                           |            |
| ADS-B         | Automatic Dependent Surveillance                        |            |
| ADS-C         | Automatic Dependent Surveillance Contract               |            |
| AECM          | Alternate Extension Control Module                      |            |
| AED           | Automatic Emergency Descent                             |            |
| AED           | Automatic External Defibrillator                        |            |
| AEFO          | All Engine Flame Out                                    |            |
| AESS          | Aircraft Environment Surveillance System                |            |
| AFDX          | Avionics Full Duplex Switched Ethernet                  |            |
| AFM           | Airplane Flight Manual                                  |            |
| AFS           | Automatic Flight System                                 |            |
| AGL           | Above Ground Level                                      |            |
| AGS           | Air Generation System                                   |            |
| AIP           | Attendant Indication Panel                              |            |
| ALT           | Altitude  |            |
| ALTN          | Alternate   |            |
| AMM           | Aircraft Maintenance Manual                             |            |
| ANF           | Airport Navigation Function                             |            |
| AOA           | Angle of Attack   |            |
| AOC           | Airline Operational Control                             |            |
| AP            | Autopilot   |            |
| APCH          | Approach  |            |
| APP           | Alternate Power Pack                                    |            |
| APPR          | Approach  |            |
| APU           | Auxiliary Power Unit                                    |            |

| -              | ENT OF TRANSPORTATION MASTER MINIMUM EQUIPME          | ENT LIST      |
|----------------|---|---------------|
| REVISION NO. 3 |   | NO. XIV       |
| DATE: XX/XX/X  |   |               |
| AIRCRAFT:      |   |               |
| Airbus A320    | LIST OF ACRONYMS                                      |               |
| ACRONYM        | DEFINITION  | Change<br>Bar |
| APU LP         | APU Low Pressure valve                                |               |
| AR             | Authorization Required                                |               |
| ARA            | Approaching Runway Advisory                           |               |
| ARV            | Alternate Refill Valve                                |               |
| ASCU           | Air System Control Unit                               |               |
| ASFC           | Avionics Server Function Cabinet                      |               |
| ASV            | Alternate Servo Valve                                 |               |
| ATA            | Air Transport Association                             |               |
| ATC            | Air Traffic Control                                   |               |
| ATSAW          | Airborne Traffic Situation Awareness                  |               |
| ATSU           | Air Traffic Service Unit                              |               |
| ATT            | Attitude  |               |
| ATQC           | Airbus Temporary Quick Change                         |               |
| ATU            | Auto Transformer Unit                                 |               |
| AUTO           | Automatic   |               |
| AUTO/BRK       | Auto Brake  |               |
| AVNCS          | Avionics  |               |
| B              | Avionics  |               |
|                | Deskup  |               |
| B/UP           | Backup  |               |
| BAM            | Bleed Air Monitoring                                  |               |
| BAS            | Bleed Air System                                      |               |
| BAT            | Battery   |               |
| BBAND          | Broadband   |               |
| BCF            | Brake Cooling Fan                                     |               |
| BCL            | Battery Charge Limiter                                |               |
| BCM            | Backup Control Module                                 |               |
| BCS            | Braking Control System                                |               |
| BITE           | Built-In Test Equipment                               |               |
| BKUP           | Backup  |               |
| BMD            | Backup Motor Driver                                   |               |
| BOMU           | Bleed and Overheat Monitoring Unit                    |               |
| BPS            | Backup Power Supply                                   |               |
| BPT            | Bogie Pitch Trimmer                                   |               |
| BPTMS          | Bogie Pitch Trimmer Monitoring System                 |               |
| BPTU           | Brake Pedal Transmitter Unit                          |               |
| BRT            | Bright  |               |
| BSCU           | Braking and Steering Control Unit                     |               |
| BSCU-LRU       | Brake and Steering Control Unit-Line-Replacement Unit |               |
| BSV            | Brake Shuttle Valve                                   |               |
| BTCM           | Brake Temperature Control Module                      |               |
| BTMS           | Brake Temperature Monitoring System                   |               |
| BTMU           | Brake Temperature Monitoring Unit                     |               |
| BTS            | Brake Temperature Sensor                              |               |
| BTV            | Brake To Vacate                                       |               |
| ·              |   |               |
| С              |   |               |

| _   | IENT OF TRANSPORTATION MASTER MINIMUM EQUIPM                  | IENT LIST   |  |
|---|---|-------------|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX<br>AIRCRAFT:<br>Airbus A320 |   | PAGE NO. XV |  |
|   |   |             |  |
| ACRONYM   |   | Bar         |  |
| C/L   | Checklist   |             |  |
| CAB   | Cabin   |             |  |
|   | Controller Area Network                                       |             |  |
|   | Captain   |             |  |
| CAT   | Category  |             |  |
| CAV   | Cold Air Valve  |             |  |
| CBMU  | Circuit Breaker Monitoring Unit                               |             |  |
| CCD   | Cursor Control Device   |             |  |
| CCRC  | Cabin Crew Rest Compartment                                   |             |  |
| CDL   | Configuration Deviation List                                  |             |  |
| CDLS  | Cockpit Door Locking System                                   |             |  |
| CDM   | Coolant Distribution Module                                   |             |  |
| CDS   | Control and Display System                                    |             |  |
| CDSS  | Cockpit Door Surveillance System                              |             |  |
| CED   | Cooling Effect Detector                                       |             |  |
| CELLI   | Ceiling Emergency LED Lights                                  |             |  |
| CEV   | Commercial Equipment Ventilation                              |             |  |
| CFDS  | Centralized Fault Display System                              |             |  |
| CFP   | Computerized Flight Plan                                      |             |  |
| CG  | Center of Gravity   |             |  |
| CIDS  | Cabin Intercommunication Data System                          |             |  |
| CIDS-SDF  | Cabin Intercommunication Data System-Smoke Detection Function |             |  |
| CIU   | Camera Interface Unit   |             |  |
| CKPT  | Cockpit   |             |  |
| CLS   | Cargo Loading System  |             |  |
| CMC   | Central Maintenance Computer                                  |             |  |
| CMS   | Central Maintenance System                                    |             |  |
| CMV   | Concentrator and Multiplexer for Video                        |             |  |
| COM   | Command   |             |  |
| CONF  | Configuration   |             |  |
| CP  | Control Panel   |             |  |
| CPC   | Cabin Pressure Controller                                     |             |  |
| CPCS  | Cabin Pressure Control System                                 |             |  |
| CPDLC   | Controller-Pilot Datalink Communication                       |             |  |
| CPIOM   | Core Processing Input/Output Module                           |             |  |
| CRC   | Crew Rest Compartment   |             |  |
| CRDC  | Common Remote Data Concentrator                               |             |  |
| CRFL  | Cruise Flight Level   |             |  |
| CSAS  | Conditioned Service Air System                                |             |  |
| CTL   | Control   |             |  |
| CTR   | Center  |             |  |
| CTS   | Cabin/Compartment Zone Temperature Sensor                     |             |  |
| CVMS  | Cabin Video Monitoring System                                 |             |  |
| CVR   | Cockpit Voice Recorder  |             |  |
| D   |   |             |  |
| D-ATIS  | Digital Automatic Terminal Information System                 |             |  |

| U.S. DEPARTMENT OF TRANSPORTATION |
|-----------------------------------|
| FEDERAL AVIATION ADMINISTRATION   |

MASTER MINIMUM EQUIPMENT LIST

#### REVISION NO. 32 DATE: XX/XX/XXXX

PAGE NO. XVI

### AIRCRAFT:

Airbus A320

### LIST OF ACRONYMS

| DEFINITION<br>Door Bypass Valve<br>Direct Current | Change<br>Bar  |
|---|--|
|   |  |
| Direct Current                                    | +  |
|   |  |
| Departure Clearance                               |  |
| Decelerate  |  |
| Decoder/Encoder Unit                              |  |
| Digital Flight Data Recorder                      |  |
| Differential Flap Setting                         |  |
| Decision Height                                   |  |
| Data Loading Configuration System                 |  |
| Data Loading Routing Box                          |  |
| Data Loading Selector Unit                        |  |
| Distance Measuring Equipment                      |  |
| Data Management Unit                              |  |
| Dome Emergency LED Light                          |  |
| Differential Pressure Indicator                   |  |
| Door and Slides Control System                    |  |
| Duct Temperature Sensor                           |  |
| Display Unit                                      |  |
|   |  |
| European Aviation Safety Agency                   |  |
| Engine Bleed Air System                           |  |
| Electrical Backup Hydraulic Actuator              |  |
| European Commission                               |  |
| Electronic Centralized Aircraft Monitoring        |  |
| Emergency Cockpit Alerting System                 |  |
| ECAM Control Panel                                |  |
| Electronic Data Loading Routing Box               |  |
| Electrical Distribution Management Unit           |  |
| Engine Driven Pump                                |  |
| Engine Electronic Controller                      |  |
| Emergency Electrical Network Management Unit      |  |
| ETOPS Entry Point                                 |  |
| Electronic Flight Bag                             |  |
| Electronic Flight Control System                  |  |
| Electronic Flight Instrument System               |  |
| Exhaust Gas Temperature                           |  |
| Electrical Ground Door Opening                    | Ì  |
|   |  |
|   | 1  |
| Engine Interface Function                         | 1  |
|   | 1  |
|   | 1  |
|   |  |
|   | 1  |
|   | 1  |
|   | 1  |
|   | Decoder/Encoder Unit Digital Flight Data Recorder Differential Flap Setting Decision Height Data Loading Configuration System Data Loading Routing Box Data Loading Routing Box Data Loading Selector Unit Distance Measuring Equipment Data Management Unit Dome Emergency LED Light Differential Pressure Indicator Door and Slides Control System Duct Temperature Sensor Display Unit European Aviation Safety Agency Engine Bleed Air System Electronic Centralized Aircraft Monitoring Emergency Cockpit Alerting System Electrical Distribution Management Unit Engine Driven Pump Engine Electoric Controller Emergency Electrical Network Management Unit ETOPS Entry Point Electronic Flight Bag Electronic Flight Bag Electronic Flight Control System Electronic Flight Bag Electronic Flight Instrument System Electronic Flight Instrume |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  | MASTER MINIMUM EQUIPMENT LIST |  |
|--|--|-------------------------------|--|
| REVISION NO. 32  |  |                               |  |
| DATE: XX/XX/XXXX   |  | PAGE NO. XVII                 |  |
| DATE: XX/XX/XX   | XX                                     |                               |  |
| AIRCRAFT:  |  |                               |  |
| Airbus A320 LIST OF ACRONYMS   |  |                               |  |
| ACRONYM  | DEFINITION                             | Change<br>Bar                 |  |
| EMA  | Electro-Mechanical Actuator            | 541                           |  |
| EMCU   | Electrical Motor Control Unit          |                               |  |
| EMER   | Emergency                              |                               |  |
| EMIL   | ELAC Master in Law                     |                               |  |
| EMK  | Emergency Medical Kit                  |                               |  |
| EMP  | Electric Motor Pump                    |                               |  |
| ENG  | Engine                                 |                               |  |
| ENG SD   | Engine System Display                  |                               |  |
| EPR  | Engine Pressure Ratio                  |                               |  |
| EPCU   | External Power Control Unit            |                               |  |
| EPDC   | Electrical Power Distribution Center   |                               |  |
| EPSU   | Emergency Power Supply Unit            |                               |  |
| EQPT   | Equipment                              |                               |  |
| ERAI   | Emergency Ram Air Inlet                |                               |  |
| ESBF   | Electrical System BITE Function        |                               |  |
| ESS  | Essential                              |                               |  |
| EWD  | Engine/Warning Display                 |                               |  |
| ETOC   | Enhanced TakeOff Configuration         |                               |  |
| ETOPS  | Extended Operations                    |                               |  |
| EU   | European Union                         |                               |  |
| EXP  | ETOPS eXit Point                       |                               |  |
| F  |  |                               |  |
| F/CTL  | Flight/Control                         |                               |  |
| F/O  | First Officer                          |                               |  |
| FAC  | Flight Augmentation Computer           |                               |  |
| FADEC  | Full Authority Digital Engine Control  |                               |  |
| FANS   | Future Air Navigation System           |                               |  |
| FAP  | Flight/Forward Attendant Panel         |                               |  |
| FAK  | First Aid Kit                          |                               |  |
| FC   | Failure Condition                      |                               |  |
| FCDC   | Flight Control Data Concentrator       |                               |  |
| FCGS   | Flight Control and Guidance System     |                               |  |
| FCOM   | Flightcrew Operating Manual            |                               |  |
| FCRC   | Flightcrew Rest Compartment            |                               |  |
| FCRM   | Flight Control Remote Module           |                               |  |
| FCTM   | Flightcrew Technique Manual            |                               |  |
| FCU  | Flight Control Unit                    |                               |  |
| FCV  | Flow Control Valve                     |                               |  |
| FD   | Flight Director                        |                               |  |
| FDIU   | Flight Data Interface Unit             |                               |  |
| FDU  | Fire Detection Unit                    |                               |  |
| FDR  | Flight Data Recorder                   |                               |  |
| FE   | Flight Envelope                        |                               |  |
| FEDC   | Fire Extinguisher Data Converter       |                               |  |
| FES  | Fire Extinguishing System              |                               |  |
| FESRA  | Fire, Explosion, and Smoke Risk Analys | sie                           |  |
|  | TITE, EXPLOSION, AND SHOKE RISK ANALYS | อเอ                           |  |

MASTER MINIMUM EQUIPMENT LIST

## **REVISION NO. 32**

PAGE NO. XVIII

## DATE: XX/XX/XXXX

| AIRCRAFT:   |
|-------------|
| Airbus A320 |

| ACRONYM | DEFINITION   | Change<br>Bar |
|---------|--|---------------|
| FG      | Flight Guidance  |               |
| FIDS    | Fault Isolation and Detection System                   |               |
| FL      | Flight Level   |               |
| FLS     | FMS Landing System                                     |               |
| FM      | Flight Management                                      |               |
| FMA     | Flight Mode Annunciator                                |               |
| FMB     | Flow Metered Bottle                                    |               |
| FMC     | Flight Management Computer                             |               |
| FME     | Flow Metering Equipment                                |               |
| FMGC    | Flight Management and Guidance Computer                |               |
| FMGC E  | Flight Management and Guidance Computer for eRudder    |               |
| FMS     | Flight Management System                               |               |
| FO      | First Officer  |               |
| FOB     | Fuel on Board  |               |
| FOD     | Foreign Object Damage                                  |               |
| FOHE    | Fuel/Oil Heat Exchanger                                |               |
| FOMAX   | Flight Operations and Maintenance Exchanger            |               |
| FPEEPMS | Floor-Proximity Emergency-Escape Path-Marking System   |               |
| F-PLN   | Flight Plan  |               |
| FPMS    | Floor Path Marking System                              |               |
| FQ      | Fuel Quantity  |               |
| FQI     | Fuel Quantity Indication                               |               |
| FQMS    | Fuel Quantity and Management System                    |               |
| FSN     | Fleet Serial Number                                    |               |
| FSOV    | Fire Shutoff Valve                                     |               |
| FTIS    | Fuel Tank Inerting System                              |               |
| FWS     | Flight Warning System                                  |               |
| FWD     | Forward  |               |
| FWD ACT | Forward Additional Center Tank                         |               |
| FZFG    | Freezing Fog   |               |
| G       |  |               |
| G/S     | Glide Slope  |               |
| GBAS    | Ground Based Augmentation System                       |               |
| GBCT    | Ground Brake Cooling Time                              |               |
| GCU     | Generator Control Unit                                 |               |
| GDO     | Ground Door Opening                                    |               |
| GDOP    | Ground Door Opening Panel                              |               |
| GEN     | Generator  |               |
| GFLI    | Ground Fuel Level Indicator                            |               |
| GLA     | Gust Load Alleviation                                  |               |
| GLS     | Ground Based Augmentation System (GBAS) Landing System |               |
| GNSS    | Global Navigation Satellite System                     |               |
| GPU     | Ground Power Unit                                      |               |
| GPS     | Global Positioning System                              |               |
| GPWS    | Ground Proximity Warning System                        |               |
| GW      | Gross Weight   |               |

#### MASTER MINIMUM EQUIPMENT LIST

### **REVISION NO. 32**

PAGE NO. XIX

#### DATE: XX/XX/XXXX

| AIRCRAFT:   |
|-------------|
| Airbus A320 |

### LIST OF ACRONYMS

| ACRONYM | DEFINITION                                   | Change<br>Bar |
|---------|--|---------------|
| GWCG    | Gross Weight Center of Gravity               |               |
| Н       |  |               |
| HCF     | Heading Control Function                     |               |
| HCU     | Head-Up Combiner Unit                        |               |
| HERTO   | High Energy Rejected Takeoff                 |               |
| HF      | High Frequency                               |               |
| HI      | High   |               |
| HID     | High Intensity Discharge                     |               |
| HLS     | High Lift System                             |               |
| HMCA    | Hydraulic Monitoring and Control Application |               |
| HP      | High Pressure                                |               |
| HPTCC   | High Pressure Turbine Case Cooling           |               |
| HRB     | High Rated Bottle                            |               |
| HSMU    | Hydraulic System Monitoring Unit             |               |
| HUD     | Head-Up Display                              |               |
|         |  |               |
| I/O     | Input/Output                                 |               |
| IAS     | Indicated Airspeed                           |               |
| ICP     | Integrated Control Panel                     |               |
| ICV     | Isolation Control Valve                      |               |
| IFE     | In-Flight Entertainment                      |               |
| IFEC    | In-Flight Entertainment Center               |               |
| IFR     | Instrument Flight Rules                      |               |
| IGGS    | Inert Gas Generation System                  |               |
| ILS     | Instrument Landing System                    |               |
| IMA     | Integrated Modular Avionics                  |               |
| INTMT   | Intermittent                                 |               |
| IP      | Intermediate Pressure                        |               |
| IPTCC   | Intermediate Pressure Turbine Case Cooling   |               |
| IR      | Inertial Reference                           |               |
| IRS     | Inertial Reference System                    |               |
| ISA     | International Standard Atmosphere            |               |
| ISDU    | Inertial Sensor Display Unit                 |               |
| ISIS    | Integrated Standby Instrument System         |               |
| J       |  |               |
| JFGW    | Jettison Final Gross Weight                  |               |
| К       |  |               |
| KCCU    | Keyboard and Cursor Control Unit             |               |
| L       |  |               |
| L/G     | Landing Gear                                 |               |
| LAF     | Load Alleviation Function                    |               |
| LATC    | Live Animal Transportation Calculation Tool  |               |
| LDCC    | Lower Deck Cargo Compartment                 |               |
| LED     | Light Emitting Diode                         |               |
| LEDU    | List of Effective Documentary Units          |               |
| LG      | Landing Gear                                 |               |

#### MASTER MINIMUM EQUIPMENT LIST

### **REVISION NO. 32**

PAGE NO. XX

DATE: XX/XX/XXXX

#### AIRCRAFT:

Airbus A320

#### LIST OF ACRONYMS

| ACRONYM | DEFINITION                                   | Change<br>Bar |
|---------|--|---------------|
| LF-ULB  | Low Frequency-Underwater Locator Beacon      |               |
| LGCIS   | Landing Gear Control Interface System        |               |
| LGCIU   | Landing Gear Control and Interface Unit      |               |
| LGERS   | Landing Gear Extension and Retraction System |               |
| LGMS    | Landing Gear Monitoring System               |               |
| LIE     | Lightening Indirect Effect                   |               |
| LOC     | Localizer                                    |               |
| LOM     | List of Modifications                        |               |
| LP      | Low Pressure                                 |               |
| LPGC    | Low Pressure Ground Cart                     |               |
| LRU     | Line Replacement Unit                        |               |
| LS      | Landing System                               |               |
| LVDT    | Linear Variable Differential Transducer      |               |
| LW      | Landing Weight                               |               |
| M       |  |               |
| (M)     | Maintenance Procedure designator             |               |
| MAC     | Mean Aerodynamic Chord                       |               |
| MAINT   | Maintenance                                  |               |
| MCA     | Maintenance Central Access                   |               |
| MCCP    | Major Change Certification Program           |               |
| MAN     | Manual                                       |               |
| MDDU    | Multipurpose Disk Drive Unit                 |               |
| MEA     | Minimum Enroute Altitude                     |               |
| MECH    | Mechanics                                    |               |
| MEL     | Minimum Equipment List                       |               |
| MES     | Main Engine Start                            |               |
| MFD     | Multipurpose Flight Display                  |               |
| MFP     | Multifunction Probe                          |               |
| MLA     | Maneuver Load Alleviation                    |               |
| MLG     | Main Landing Gear                            |               |
| MLS     | Microwave Landing System                     |               |
| MLW     | Maximum Landing Weight                       |               |
| MM      | Maintenance Message                          |               |
| MMEL    | Master Minimum Equipment List                |               |
| ММО     | Maximum Operating Mach                       |               |
| MMR     | Multi-Mode Receiver                          |               |
| MNPS    | Minimum Navigation Performance Specification |               |
| Mod     | Modification                                 |               |
| MON     | Monitoring                                   |               |
| MORA    | Minimum On-Route Altitude                    |               |
| MP      | Modification Proposal                        |               |
| MPC     | Maximum Passenger Capacity                   |               |
| MPZC    | Maximum Permitted Zone Capacity              |               |
| MSA     | Minimum Safe Altitude                        |               |
| MTOW    | Maximum Takeoff Weight                       |               |
| MTS     | Mixer Temperature Sensor                     |               |

| -              | IENT OF TRANSPORTATION MASTER MINIMUM EQUIF            | PMENT LIST    |
|----------------|--|---------------|
| REVISION NO.   |  | GE NO. XXI    |
| DATE: XX/XX/   |  |               |
| AIRCRAFT:      |  |               |
| Airbus A320    | LIST OF ACRONYMS                                       |               |
| ACRONYM        | DEFINITION   | Change<br>Bar |
| N              |  | Bai           |
| N <sub>1</sub> | Engine Low Pressure Rotor Speed                        |               |
| N <sub>2</sub> | Engine Intermediate Pressure Rotor Speed               |               |
| N <sub>3</sub> | Engine High Pressure Rotor Speed                       |               |
| N/A            | Not Applicable   |               |
| NAA            | National Aviation Authority                            |               |
| NAV            | Navigation   |               |
| NAVAIDS        | Navigation Aids  |               |
| NBSELV         | Normal Brake Selector Valve                            |               |
| NEF            | Nonessential Equipment and Furnishings                 | 1             |
| ND             | Navigation Display                                     | 1             |
| NDU            | Navigation Display Unit                                | 1             |
| NLG            | Nose Landing Gear                                      | 1             |
| NRV            | Negative Relief Valve                                  |               |
| NSV            | Normal Servo Valve                                     |               |
| NWS            | Nose Wheel Steering                                    |               |
| 0              |  |               |
| (0)            | Operations Procedure designator                        |               |
| ÓÁT            | Outside Air Temperature                                |               |
| OCL            | Oceanic Clearance                                      |               |
| OCU            | Outflow Valve Control Unit                             |               |
| ODMS           | Oil Debris Monitoring System                           |               |
| OEI            | One Engine Inoperative                                 |               |
| OFV            | Outflow Valve  |               |
| OHDC           | Over Heat Detection Card                               |               |
| OIS            | Onboard Information System                             |               |
| OMT            | Onboard Maintenance Terminal                           |               |
| OPS            | Operations   |               |
| ORV            | Overpressure Relief Valve                              |               |
| OSFC           | Open-World Server Function Cabinet                     |               |
| OVRD           | Override   |               |
| Р              |  |               |
| P/N            | Part Number  |               |
| PA             | Passenger Address                                      | 1             |
| PAX            | Passenger  | 1             |
| pb             | Push Button  |               |
| pb-sw          | Push Button Switch                                     |               |
| PBE            | Portable Breathing Equipment                           | 1             |
| PBSELV         | Park Brake Selector Valve                              | 1             |
| PCU            | Power Control Unit                                     |               |
| PDF            | Portable Document Format                               |               |
| PDMMF          | Power Distribution Monitoring and Maintenance Function |               |
| PDS            | Pack Discharge Temperature Sensor                      | <u> </u>      |
| PED            | Portable Electronic Device                             |               |
| PERF           | Performance  |               |
| PF             | Pilot Flying   |               |

|               | ENT OF TRANSPORTATION                          | MASTER MINIMUM EQUIPMENT LIST |  |  |  |
|---------------|--|-------------------------------|--|--|--|
| REVISION NO.  | 32   | PAGE NO. XXII                 |  |  |  |
| DATE: XX/XX/X | XXX  |                               |  |  |  |
| AIRCRAFT:     |  |                               |  |  |  |
| Airbus A320   |  | LIST OF ACRONYMS              |  |  |  |
| ACRONYM       | DEFINITION                                     | Change<br>Bar                 |  |  |  |
| PFCS          | Primary Flight Control System                  |                               |  |  |  |
| PFD           | Primary Flight Display                         |                               |  |  |  |
| PFDU          | Primary Flight Display Unit                    |                               |  |  |  |
| PFR           | Post-Flight Report                             |                               |  |  |  |
| PFS           | Pack Flow Sensor                               |                               |  |  |  |
| PFTU          | Pedal Feel Trim Unit                           |                               |  |  |  |
| PHC           | Probes Heat Computer                           |                               |  |  |  |
| PLD           | Partial Lift Dumping                           |                               |  |  |  |
| PLT           | Pre-Land Test                                  |                               |  |  |  |
| PLV           | Pressure Limiting Valve                        |                               |  |  |  |
| PM            | Pilot Monitoring                               |                               |  |  |  |
| PRA           | Particular Risk Analysis                       |                               |  |  |  |
| PRAM          | Prerecorded Announcement and Mus               |                               |  |  |  |
| PRSOV         | Pressure Regulation and Shutoff Valv           | Ve                            |  |  |  |
| PRV           | Pressure Regulation Valve                      |                               |  |  |  |
| PSU           | Power Supply Unit                              |                               |  |  |  |
| Q<br>QNH      | Sea Level Atmospheric Pressure                 |                               |  |  |  |
| QRH           | Quick Reference Handbook                       |                               |  |  |  |
| R             |  |                               |  |  |  |
| RA            | Radio Altitude                                 |                               |  |  |  |
| RAT           | Ram Air Turbine                                |                               |  |  |  |
| RBCU          | Remote Braking Control Unit                    |                               |  |  |  |
| RBPU          | Rudder Braking Pedal Unit                      |                               |  |  |  |
| RCCB          | Remote Control Circuit Breaker                 |                               |  |  |  |
| RCT           | Rear Center Tank                               |                               |  |  |  |
| RGAU          | Rate Gyro-Accelerometer Unit                   |                               |  |  |  |
| RH            | Right Hand                                     |                               |  |  |  |
| RMP           | Radio Management Panel                         |                               |  |  |  |
| RNAV          | Area Navigation                                |                               |  |  |  |
| RNP           | Required Navigation Performance                |                               |  |  |  |
| RNP-AR        | Required Navigation Performance wi             | th Authorization Required     |  |  |  |
| ROP           | Runway Overrun Protection                      |                               |  |  |  |
| ROW           | Runway Overrun Warning                         |                               |  |  |  |
| RSVR          | Reservoir                                      |                               |  |  |  |
| RTO           | Rejected Takeoff                               |                               |  |  |  |
| RTOW          | Rejected Takeoff Weight                        |                               |  |  |  |
| RVSM          | Reduced Vertical Separation Minimu             | m                             |  |  |  |
| SA SA         | Single Aicle                                   |                               |  |  |  |
| SAT           | Single Aisle                                   |                               |  |  |  |
| SATCOM        | Static Air Temperature Satellite Communication |                               |  |  |  |
| SATCOM        | Satellite Communication                        |                               |  |  |  |
| SBAS          | Satellite-Based Augmentation System            | ne                            |  |  |  |
| SCI           | Secure Communication Interface                 |                               |  |  |  |
| SD            | System Display                                 |                               |  |  |  |
| 55            | - Stotom Biopidy                               |                               |  |  |  |

| -                                | ENT OF TRANSPORTATION MASTER MINIMUM EQUIPMEN | IT LIST       |
|----------------------------------|---|---------------|
| REVISION NO. 3<br>DATE: XX/XX/XX |   | D. XXIII      |
| AIRCRAFT:                        | LIST OF ACRONYMS                              |               |
| Airbus A320                      |   |               |
| ACRONYM                          | DEFINITION                                    | Change<br>Bar |
| SDF                              | Smoke Detection Function                      |               |
| SDU                              | System Display Unit                           |               |
| SEC                              | Spoiler Elevator Computer                     |               |
| SELCAL                           | Selective Call                                |               |
| SFCC                             | Slat/Flap Control Computer                    |               |
| SFCS                             | Slat/Flap Control System                      |               |
| SFD                              | Standby Flight Display                        |               |
| SID                              | Standard Instrument Departure                 |               |
| SLS                              | Satellite Landing System                      |               |
| SND                              | Standby Navigation Display                    |               |
| SOH                              | Summary of Highlights                         |               |
| SOP                              | Standard Operating Procedure                  |               |
| SPD                              | Speed   |               |
| SPDB                             | Secondary Power Distribution Box              |               |
| SPP                              | Software Pin Programing                       |               |
| SPU                              | Starter Power Unit                            |               |
| SSA                              | System Safety Assessment                      |               |
| SSPC                             | Solid State Power Contactor                   |               |
| STAR                             | Standard Terminal Arrival Route               |               |
| STBY                             | Standby                                       |               |
| SURV                             | Surveillance                                  |               |
| SYS                              | System  |               |
| T                                | System  |               |
| TAC                              | Tavijng Aid Camera                            |               |
|                                  | Taxiing Aid Camera                            |               |
| TACKV                            | Trim Air Non-Return Check Valve               |               |
| TACS                             | Taxiing Aid Camera System                     |               |
| TAPRV                            | Trim Air Pressure Regulating Valve            |               |
| TAPS                             | Trim Air Pressure Sensor                      |               |
| TAS                              | True Airspeed                                 |               |
| TASOV                            | Trim Air Shutoff Valve                        |               |
|                                  | Total Air Temperature                         | _             |
| TAV                              | Trim Air Valve                                | _             |
| TAWS                             | Terrain Awareness and Warning System          |               |
| TCAS/T2CAS                       | Traffic Alert and Collision Avoidance System  |               |
| TCV                              | Temperature Control Valve                     | _             |
| THR                              | Thrust  | _             |
| THS                              | Trimmable Horizontal Stabilizer               |               |
| TOC                              | Table of Contents                             |               |
| TOGA                             | Takeoff/Go-Around                             |               |
| TOS                              | Takeoff Securing                              |               |
| TOW                              | Takeoff Weight                                |               |
| TPIC                             | Tire Pressure Indicating Computer             |               |
| TPIS                             | Tire Pressure Indicating System               |               |
| TR                               | Thrust Reverser                               |               |
| TR                               | Transformer Rectifier                         |               |

| U.S. DEPARTI                     |   |               |
|----------------------------------|---|---------------|
| FEDERAL AVI                      | ATION ADMINISTRATION MASTER MINIMUM EQUIPM    | ENT LIST      |
| <b>REVISION NO.</b>              | . 32 PAGE                                     | NO. XXIV      |
| DATE: XX/XX/>                    | XXXX  |               |
| AIRCRAFT:                        |   |               |
| Airbus A320                      | LIST OF ACRONYMS                              |               |
| ACRONYM                          | DEFINITION                                    | Change<br>Bar |
| TSM                              | Trouble Shooting Manual                       | Bai           |
| TTL                              | Taxi, Takeoff, and Landing                    |               |
| TWDC                             | Tank Wall Data Concentrator                   |               |
| U                                |   |               |
| UCV                              | Unpressurized Compartment Ventilation         |               |
| UERF                             | Uncontained Engine Rotor Failure              |               |
| ULD                              | Unit Load Device                              |               |
| UTC                              | Universal Coordinated Time                    |               |
| V                                |   |               |
| V <sub>1</sub>                   | Critical Engine Failure Speed                 |               |
| V <sub>1</sub><br>V <sub>2</sub> | Takeoff Safety Speed                          |               |
| V/S                              | Vertical Speed                                |               |
| VAC                              | Voltage Alternating Current                   |               |
| VAC                              | Approach Speed                                |               |
| VAPP                             | Variable Camber                               |               |
|                                  |   |               |
| VCC                              | Video Control Center                          |               |
| VCRU                             | Vapor Cycle Refrigeration Unit                |               |
| VCS                              | Ventilation Control System                    |               |
| VD                               | Vertical Display                              |               |
| VENT                             | Ventilation                                   |               |
| VFE                              | Maximum Speed for each Flap Configuration     |               |
| VFG                              | Variable Frequency Generator                  |               |
| VFR                              | Visual Flight Rules                           |               |
| VHF                              | Very High Frequency                           |               |
| VIGV                             | Variable Inlet Guide Vane                     |               |
| VLE                              | Max Landing Gear Extended Speed               |               |
| VMC                              | Visual Meteorological Conditions              |               |
| VMCA                             | Minimum Control Speed in Flight               |               |
| VMCG                             | Minimum Control Speed on Ground               |               |
| VMO                              | Maximum Operating Speed                       |               |
| VMU                              | Minimum Unstick Speed                         |               |
| VOZC                             | Volatile Organic Compound and Ozone Converter |               |
| VOR                              | VHF Omnidirectional Range                     |               |
| VQAR                             | Virtual Quick Access Recorder                 |               |
| VR                               | Rotation Speed                                |               |
| VS                               | Reference Stalling Speed                      |               |
| VTP                              | Vertical Tail Plane                           |               |
| Ŵ                                |   |               |
| W&ES                             | Wing and Engine Scan (lights)                 |               |
| Wald                             | Weight  |               |
| WBBC                             | Weight and Balance Backup Computation         |               |
| WBS                              | Weight and Balance System                     |               |
| WDS WD                           |   | <u> </u>      |
|                                  | Warning Display                               |               |
| WDU                              | Warning Display Unit                          |               |
| WETS                             | Water Extractor Temperature Sensor            |               |
| WIPS                             | Wing Ice Protection System                    |               |

| -                             | IENT OF TRANSPORTATION         | MASTER MINIMUM EQUIPMENT LIS |
|-------------------------------|--------------------------------|------------------------------|
| REVISION NO.<br>DATE: XX/XX/X |                                | PAGE NO. XXV                 |
| AIRCRAFT:<br>Airbus A320      |                                | LIST OF ACRONYMS             |
| ACRONYM                       | DEFINITION                     | Chang<br>Bar                 |
| WRDC                          | Wheel Remote Data Concentrator |                              |
| WTB                           | Wing Tip Brake                 |                              |
| WV                            | Weight Variant                 |                              |
| WX                            | Weather                        |                              |
| X                             |                                |                              |
| XML                           | Extensible Markup Language     |                              |
| Z                             |                                |                              |
| ZFW                           | Zero Fuel Weight               |                              |

| -                            | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|---|--|
| REVISION NO<br>DATE: 03/03/2 |  |    |   |   | PAGE NO. 21-1  |
| AIRCRAFT:<br>Airbus A320     | г:   |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                    |
| 21. Air Conditi              | oning  |    |   |   |  |
| Sequence No.                 | Item   | 1  | 2 | 3 | 4 Change<br>Bar  |
| 21-00-00                     | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY   |    |   |   |  |
| 1)                           | Fault(s) Indicated by<br>PACK 1(2)<br>(Without Mod. 30626/<br>MP K6443)                                | С  | - | - | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 2)                           | Fault(s) Indicated by<br>ZONE CONT<br>(Without Mod. 30626/<br>MP K6443)                                | С  | - | - | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 3)<br>***                    | Fault(s) Indicated by<br>AFT CRG HEAT  | С  | - | - | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 4)                           | Fault(s) Indicated by<br>TEMP CTL 1(2)<br>(With Mod. 30626/<br>MP K6443)                               | С  | - | - | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 5)                           | Fault(s) Indicated by<br>CPC 1(2)<br>(With Mod. 162159/<br>MP P20466 and<br>Mod. 152530/<br>MP K15280) | С  | - | - | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |        |    |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|---|--------|----|---|--|--|--|--|--|
| REVISION NO<br>DATE: 03/03/2   |   |        |    | PAGE NO. 21-2   |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |        | Т  | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |  |
| 21. Air Condit   | ioning                                  |        | 1  | 1   |  |  |  |  |  |
| Sequence No.<br>21-21-01   | Item<br>Cabin Fans                      | 1<br>C | 22 | 3<br>1  | 4 Change<br>Bar<br>(M) One may be inoperative provided<br>affected cabin fan is deactivated.   |  |  |  |  |
| 21-21-02   | CAB FAN pb Switch                       |        |    |   |  |  |  |  |  |
| 1)   | OFF Light                               | С      | 1  | 0   | May be inoperative.  |  |  |  |  |
| 21-23-01   | Lavatory and Galley<br>Extraction Fan   |        |    |   |  |  |  |  |  |
| 1)   | Aircraft without<br>Mod. 22561/MP K2335 | С      | 1  | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Lavatory and galley extraction<br/>fan is deactivated,</li> <li>b) Cabin duct temperatures are<br/>available on ECAM,</li> <li>c) Restrictions for an inoperative<br/>lavatory smoke detector<br/>system are applied, and</li> <li>d) GSM ON BOARD system<br/>(Mod. 36790/MP K10889) is<br/>deactivated.</li> </ul> |  |  |  |  |
| 2)   | Aircraft with Mod. 22561/<br>MP K2335   | С      | 1  | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Lavatory and galley extraction<br/>fan is deactivated,</li> <li>b) Cabin duct temperatures are<br/>available on ECAM, and</li> <li>c) GSM ON BOARD system<br/>(Mod. 36790/MP K10889) is<br/>deactivated.</li> </ul>   |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 30<br>DATE: 03/03/2023 |            |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|---|------------|---|---|-------------------------------|--|--|--|--|
|   |            |   |   |                               | PAGE NO. 21-3  |  |  |  |
| AIRCRAFT:<br>Airbus A320  |            |   |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 21. Air Conditi   | oning      | - |   |                               |  |  |  |  |
| Sequence No.  | Item       | 1 | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 21-26-01  | Blower Fan | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> <li>b) BLOWER pb switch is set to OVRD,</li> <li>c) Both packs are operative,</li> <li>d) VENT AVNCS SYS FAULT ECAM caution is not present, and</li> <li>e) FL 270 is not exceeded on airplanes with Mod. 20056.</li> </ul> </li> <li>(M)(O) May be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> </ul> </li> </ul> |  |  |  |
|   |            |   |   |                               | <ul> <li>b) BLOWER pb switch is set to OVRD,</li> <li>c) Both packs are operative,</li> <li>d) Air conditioning inlet valve is verified open prior to each flight, and</li> <li>e) FL 270 is not exceeded on airplanes with Mod. 20056.</li> </ul>   |  |  |  |
|   |            | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> <li>b) BLOWER pb switch is set to OVRD,</li> <li>c) Both packs are operative,</li> <li>d) Air conditioning inlet valve is secured open,</li> <li>e) FL 270 is not exceeded on airplanes with Mod. 20056, and</li> <li>f) AEVC test is performed before each flight.</li> </ul> </li> </ul>  |  |  |  |

| FEDERAL AVIATION ADMINISTRATION |             |   |   | MASTER MINIMUM EQUIPMENT LIST |   |        |  |  |
|---------------------------------|-------------|---|---|-------------------------------|---|--------|--|--|
| REVISION NO<br>DATE: 03/03/2    |             |   |   |                               | PAGE NO.  | . 21-4 |  |  |
| DATE. 03/03/2                   | 023         |   |   |                               |   |        |  |  |
| AIRCRAFT:<br>Airbus A320        |             |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |  |  |
| 21. Air Conditi                 | onina       |   |   |                               |   |        |  |  |
| Sequence No.                    | ltem        | 1 | 2 | 3                             | 4   | Change |  |  |
| 21-26-02                        | Extract Fan | C | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Blower fan operates normally,</li> <li>b) EXTRACT pb-sw is set at OVRD,</li> <li>c) Both packs are operative,</li> <li>d) VENT AVNCS SYS FAULT ECAM caution is not present, and</li> <li>e) Outside air temperature (OAT) and time on ground with electrical power on are limited as follows:</li> <li>OAT</li> <li>OAT</li> <li>39-45°C – 3 hours OAT 46-50°C – 2 hours OAT 46-50°C – 2 hours OAT 51-54°C – 35 minutes.</li> </ul> </li> <li>(M)(O) May be inoperative provided: <ul> <li>a) Blower fan operates normally,</li> <li>b) EXTRACT pb-sw is set at OVRD,</li> <li>c) Both packs are operative,</li> <li>d) Air conditioning inlet valve is verified open prior to each flight, and</li> <li>e) Outside air temperature (OAT) and time on ground with electrical power on are limited as follow:</li> <li>OAT</li> <li>OAT</li> <li>OAT</li> </ul></li></ul> | Bar    |  |  |
|                                 |             |   |   |                               | (Continued)   |        |  |  |

| -                        | MENT OF TRANSPORTAT                  | - |   |   | MASTER MINIMUM EQUIPMENT LIS  |  |  |  |
|--------------------------|--------------------------------------|---|---|---|---|--|--|--|
| REVISION NC              |                                      | N |   | PAGE NO. 21-5   |   |  |  |  |
| DATE: 03/03/2            |                                      |   |   |   |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 | AIRCRAFT:                            |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
| 21. Air Condit           | ioning                               |   | 1 | T   | 01  |  |  |  |
| Sequence No.             | Item                                 | 1 | 2 | 3   | 4 Chang<br>Bar  |  |  |  |
| 21-26-02                 | Extract Fan<br>(Cont'd)              |   |   |   |   |  |  |  |
|                          |                                      | C | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Blower fan operates normally,</li> <li>b) EXTRACT pb-sw is set at OVRD,</li> <li>c) Both packs are operative,</li> <li>d) Air conditioning inlet valve is secured open,</li> <li>e) Outside air temperature (OAT) and time on ground with electrical power on are limited as follows:<br/>OAT&lt;38°C – No limit OAT 39-45°C – 3 hours OAT 46-50°C – 2 hours OAT 51-54°C – 35 minutes, and</li> <li>f) AEVC test is performed before each flight.</li> </ul></li></ul> |  |  |  |
| 21-26-03                 | Skin Exchanger Inlet<br>Bypass Valve | С | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed, and</li> <li>b) AEVC test is performed</li> <li>before each flight.</li> </ul>  |  |  |  |
| 21-26-04                 | Skin Air Outlet Valve                | С | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Internal flap is manually secured to open position,</li> <li>b) Extract valve (skin air outlet valve) is displayed in partially open position (amber or green) on ECAM CAB PRESS page,</li> <li>c) Both packs are operative,</li> <li>d) Skin exchanger isolation valve is secured open, and</li> <li>e) AEVC test is performed before each flight.</li> </ul> </li> </ul>   |  |  |  |

| -                            | MENT OF TRANSPORTATION                | NC |    |          | MASTER MINIMUM EQUIPMENT  | LIST   |
|------------------------------|---------------------------------------|----|----|----------|---|--------|
| REVISION NO<br>DATE: 03/03/2 |                                       |    |    |          | PAGE NO   | . 21-6 |
| DATE. 03/03/2                | 023                                   |    |    |          |   |        |
| AIRCRAFT:<br>Airbus A320     |                                       |    | T. | 1.<br>2. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |        |
|                              |                                       |    |    |          | REMARKS OR EXCEPTIONS   |        |
| 21. Air Conditi              | oning                                 |    |    |          |   |        |
| Sequence No.                 | ltem                                  | 1  | 2  | 3        | 4   | Change |
| 21-26-05                     | Skin Air Inlet Valve                  | C  | 1  | 0        | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed,</li> <li>b) Air conditioning inlet valve is verified open before each flight,</li> <li>c) Both packs are operative, and</li> <li>d) AEVC test is performed before each flight.</li> </ul> | Bar    |
|                              |                                       | С  | 1  | 0        | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed,</li> <li>b) Air conditioning inlet valve is secured open,</li> <li>c) Both packs are operative, and</li> <li>d) AEVC test is performed before each flight.</li> </ul>                     |        |
| 21-26-06                     | Skin Exchanger Isolation<br>Valve     | С  | 1  | 0        | (M)(O) May be inoperative in open<br>position provided AEVC test is<br>performed before each flight.  |        |
|                              |                                       | С  | 1  | 0        | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured open, and</li> <li>b) AEVC test is performed<br/>before each flight.</li> </ul>   |        |
| 21-26-07                     | Skin Exchanger Outlet<br>Bypass Valve | С  | 1  | 0        | May be inoperative.   |        |
| 21-26-08                     | Air Conditioning Inlet<br>Valve       | С  | 1  | 0        | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured open,</li> <li>b) Both packs are operative, and</li> <li>c) AEVC test is performed<br/>before each flight.</li> </ul>   |        |

| -                            | MENT OF TRANSPORTAT                                  | - |          |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|------------------------------|--|---|----------|---|--|--|--|--|
| REVISION NC<br>DATE: 03/03/2 |  |   |          | PAGE NO. 21-  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |  |   | T        | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |
| 21. Air Condit               | ioning   |   | <u>I</u> |   |  |  |  |  |
| Sequence No.                 | Item   | 1 | 2        | 3   | 4 Change<br>Bar  |  |  |  |
| 21-26-09                     | Ventilation Filters                                  | С | 1        | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) Blower and extract fans<br/>operate normally,</li> <li>b) EXTRACT pb switch is set at<br/>OVRD,</li> <li>c) Both packs are operative, and</li> <li>d) VENT AVNCS SYS FAULT<br/>ECAM caution is not present.</li> </ul>   |  |  |  |
|                              |  | C | 1        | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Blower and extract fans<br/>operate normally,</li> <li>b) EXTRACT pb switch is set at<br/>OVRD,</li> <li>c) Both packs are operative, and</li> <li>d) Air conditioning inlet valve is<br/>verified open prior to each<br/>flight.</li> </ul>  |  |  |  |
|                              |  | С | 1        | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Blower and extract fans<br/>operate normally,</li> <li>b) EXTRACT pb switch is set at<br/>OVRD,</li> <li>c) Both packs are operative,</li> <li>d) Air conditioning inlet valve is<br/>secured open, and</li> <li>e) AEVC test is performed<br/>before each flight.</li> </ul>   |  |  |  |
| 21-26-10                     | Avionics Equipment<br>Ventilation Computer<br>(AEVC) | C | 1        | 0   | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Extract fan is verified to operate normally prior to each flight,</li> <li>b) BLOWER and EXTRACT pb switches are set to OVRD,</li> <li>c) Air conditioning inlet valve and extract valve (skin air outlet valve) are verified in the proper position prior to each flight,</li> <li>d) Both packs are operative, and</li> <li>e) Skin air inlet valve is secured closed.</li> </ul> </li> </ul> |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|----------------------------------|---|---|----------------|---|--|--|--|
| REVISION NO<br>DATE: 03/03/2   |                                  |   |   | PAGE NO. 21-8  |   |  |  |  |
| AIRCRAFT:<br>Airbus A320   |                                  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 21. Air Conditi  | onina                            |   |   |                |   |  |  |  |
| Sequence No.   | Item                             | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |
| 21-26-11   | BLOWER FAULT<br>Caution on ECAM  | C | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Blower fan is verified<br/>operative prior to each flight,</li> <li>b) VENT AVNCS SYS FAULT<br/>caution is available on ECAM,<br/>and</li> <li>c) EXTRACT FAULT caution is<br/>not present on ECAM.</li> </ul>             |  |  |  |
|  |                                  | С | 1 | 0              | May be inoperative provided blower fan is considered inoperative.   |  |  |  |
| 21-26-12   | EXTRACT FAULT<br>Caution on ECAM | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Extract fan is verified to<br/>operate normally before each<br/>flight,</li> <li>b) VENT AVNCS SYS FAULT<br/>caution is available on ECAM,<br/>and</li> <li>c) BLOWER FAULT caution is<br/>not present on ECAM.</li> </ul> |  |  |  |
|  |                                  | С | 1 | 0              | May be inoperative provided extract fan is considered inoperative.  |  |  |  |
| 21-26-13   | BLOWER pb Switch                 |   |   |                |   |  |  |  |
| 1)   | FAULT Light                      | С | 1 | 0              | May be inoperative.   |  |  |  |
| 21-26-14   | EXTRACT pb Switch                |   |   |                |   |  |  |  |
| 1)   | FAULT Light                      | С | 1 | 0              | May be inoperative.   |  |  |  |
| 21-26-15   | ECAM CAB PRESS<br>Indications    | С | 2 | 0              | INLET and EXTRACT indications may be inoperative.   |  |  |  |

|                 | ATION ADMINISTRATION  |   |    | MASTER MINIMUM EQUIPMENT LIST |  |  |
|-----------------|---|---|----|-------------------------------|--|--|
| REVISION NO     |   |   |    |                               | PAGE NO. 21-9  |  |
| DATE: 03/03/2   | 023   |   |    |                               |  |  |
|                 |   |   | T. |                               | EKEY   |  |
| AIRCRAFT:       |   |   |    |                               | REPAIR CATEGORY<br>NO. INSTALLED   |  |
| Airbus A320     |   |   |    | 3. NO. REQUIRED FOR DISPATCH  |  |  |
|                 |   |   |    | 4. REMARKS OR EXCEPTIONS      |  |  |
| 21. Air Conditi | oning   |   |    |                               |  |  |
| Sequence No.    | Item  | 1 | 2  | 3                             | 4 Change<br>Bar  |  |
| 21-26-16<br>*** | Avionics Extract/Blower<br>Vibration Monitor Unit<br>(VMU)<br>STC No. ST02356LA | D | 2  | 0                             | (O) May be inoperative provided<br>AVNCS VENT System operates<br>normally.   |  |
| 21-27-01<br>*** | Avionics Equipment<br>Ground Cooling System                                     | D | 1  | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) GND COOL pb-sw is set at<br/>OFF, and</li> <li>b) Both associated skin valves<br/>are checked closed on <u>CAB</u><br/><u>PR</u> SD page.</li> </ul> |  |
|                 |   | D | 1  | 0                             | (M)(O) May be inoperative provided<br>both associated skin valves are<br>secured closed.   |  |
| 21-28-01<br>*** | Forward Cargo<br>Extraction Fan   | D | 1  | 0                             | (O) May be inoperative provided<br>FWD ISOL VALVE pb-sw is set at<br>OFF.  |  |
| 21-28-02<br>*** | Forward Cargo Isolation<br>Valves   | D | 2  | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both valves are closed, and</li> <li>b) FWD ISOL VALVE FAULT<br/>Light operates normally.</li> </ul>   |  |
|                 |   | D | 2  | 0                             | (M) May be inoperative provided both valves are secured closed.  |  |
| 21-28-03<br>*** | FWD ISOL VALVE Fault<br>Light   | D | 1  | 0                             | May be inoperative.  |  |
| 21-28-04<br>*** | Aft Cargo Extraction Fan  | D | 1  | 0                             | (O) May be inoperative provided AFT<br>ISOL VALVE pb-sw is set at OFF.   |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |                |    |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|---|----------------|----|---|---|--|--|--|--|
| REVISION NO<br>DATE: 03/03/2   |   | PAGE NO. 21-10 |    |   |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |                | T. | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |  |
| 21. Air Conditioning   |   |                |    |   |   |  |  |  |  |
| Sequence No.   | Item  | 1              | 2  | 3   | 4 Change<br>Bar   |  |  |  |  |
| 21-28-05<br>***  | Aft Cargo Isolation<br>Valves   | D              | 2  | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both valves are closed, and</li> <li>b) AFT ISOL VALVE FAULT</li> <li>Light operates normally.</li> </ul>   |  |  |  |  |
|  |   | D              | 2  | 0   | (M) May be inoperative provided both valves are secured closed.   |  |  |  |  |
| 21-28-06<br>***  | Aft Cargo AFT ISOL<br>VALVE Fault Light   | D              | 1  | 0   | May be inoperative.   |  |  |  |  |
| 21-31-01   | Automatic Cabin<br>Pressure Control<br>Systems<br>(CPC, Outflow Valve<br>AUTO Channels) | С              | 2  | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) Flight is conducted in an<br/>unpressurized configuration,<br/>and</li> <li>b) Extended overwater flight is<br/>prohibited.</li> </ul>  |  |  |  |  |
| 1)   | System 1  | A              | 1  | 0   | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) CPC 1 is deactivated,</li> <li>b) Manual Mode is verified to operate normally,</li> <li>c) Cabin pressure indications are available on ECAM CAB PRESS Page in manual Mode,</li> <li>d) Both FCU channels operate normally,</li> <li>e) System 2 operates normally, and</li> <li>f) Repairs are made within 3 flight-days.</li> </ul> </li> </ul> |  |  |  |  |
| 2)   | System 2  | С              | 1  | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) CPC 2 is deactivated,</li> <li>b) Manual Mode is verified to operate normally,</li> <li>c) Cabin pressure indications are available on ECAM CAB PRESS Page in manual Mode,</li> <li>d) Both FCU channels operate normally, and</li> <li>e) System 1 operates normally.</li> </ul>  |  |  |  |  |

| -                               | MENT OF TRANSPORTATION   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|---------------------------------|--|---|---|----------------|---|
| REVISION NO                     |  |   |   |                | PAGE NO. 21-11  |
| DATE: 03/03/2                   | 023  |   |   |                |   |
| AIRCRAFT:<br>Airbus A320        |  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 21. Air Conditi                 |  |   |   |                | Change  |
| <u>Sequence No.</u><br>21-31-02 | Item<br>Manual Cabin Pressure<br>Control Systems<br>(Outflow Valve MAN<br>Channel, MAN V/S CTL<br>Sel) | C | 2 | 3<br>0         | 4 Change Bar<br>(M) May be inoperative provided both<br>auto cabin pressure control systems<br>are verified to operate normally<br>before each flight.  |
|                                 |  | С | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Flight is conducted in an<br/>unpressurized configuration,</li> <li>b) Extended overwater flight is<br/>prohibited, and</li> <li>c) Avionics equipment ventilation<br/>system operates normally.</li> </ul> |
| 21-31-04                        | Safety Valves  | С | 2 | 1              | <ul> <li>(M) May be inoperative closed provided:</li> <li>a) Both automatic cabin pressure control systems operate normally, and</li> <li>b) The three outflow valve motors operate normally.</li> </ul>  |
| 21-31-05                        | Landing Elevation<br>Selection System  |   |   |                |   |
| 1)                              | AUTO Function  | С | 1 | 0              | (O) May be inoperative provided LDG<br>ELEV is set to destination field<br>elevation altitude.  |
| 21-31-06                        | MODE SEL FAULT Light   | С | 1 | 0              | (O) May be inoperative provided<br>SYS 1 and SYS 2 indications on<br>ECAM CAB PRESS page are<br>available.  |
| 21-31-07                        | Safety Valves Position<br>Indication on ECAM CAB<br>PRESS Page   | С | 1 | 0              | (M) May be inoperative provided both safety valves are visually verified closed.  |
| 21-31-08                        | SAFETY VALVE OPEN<br>Caution on ECAM   | С | 1 | 0              | (M) May be inoperative provided both safety valves are visually verified closed.  |

|                                | IENT OF TRANSPORTATI<br>ATION ADMINISTRATION | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------------|--|----|---|----------------|---|
| REVISION NO.<br>DATE: 03/03/20 |  |    |   |                | PAGE NO. 21-12  |
| AIRCRAFT:<br>Airbus A320       |  |    | T | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 21. Air Conditio               | oning  |    |   |                |   |
| Sequence No.                   | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 21-43-01                       | Fwd Cargo<br>Compartment Heating<br>System   | C  | 1 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) HOT AIR pb-sw is set to OFF,</li> <li>and</li> </ul> </li> <li>b) Hot air pressure regulating valve is checked closed on <u>COND</u> SD page.</li> </ul> <li>NOTE: With hot air pressure regulating valve closed, unequal passenger distribution may cause high temperature in rear cabin.</li> |
|                                |  | D  | 1 | 0              | (M)(O) May be inoperative provided associated trim air valve is secured closed.   |
|                                |  | С  | 1 | 0              | (M)(O) May be inoperative provided<br>hot air pressure regulating valve is<br>secured closed.   |
|                                |  | D  | 1 | 0              | <ul> <li>NOTE: With hot air pressure<br/>regulating valve closed,<br/>unequal passenger<br/>distribution may cause high<br/>temperature in rear cabin.</li> <li>(O) May be inoperative provided:</li> <li>a) FWD ISOL VALVE pb-sw is<br/>set to OFF, and</li> <li>b) EWD care compartment trim</li> </ul>   |
|                                |  |    |   |                | <ul> <li>b) FWD cargo compartment trim<br/>air valve is checked closed on<br/><u>COND</u> SD page.</li> </ul>   |

| -                              | AENT OF TRANSPORTATION   | 0.11 |   |   | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------------|--|------|---|---|---|
| REVISION NO.<br>DATE: 03/03/20 |  |      |   |   | PAGE NO. 21-13  |
| AIRCRAFT:<br>Airbus A320       | FT:  |      |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 21. Air Conditie               | oning  |      |   |   |   |
| Sequence No.                   | ltem   | 1    | 2 | 3 | 4 Change<br>Bar   |
| 21-43-02<br>***                | Aft Cargo Compartment<br>Heating Systems   | D    | 1 | 0 | <ul> <li>(O) Associated hot air pressure<br/>regulating valve or trim air valve may<br/>be inoperative provided: <ul> <li>a) Heating system is switched</li> <li>OFF, and</li> <li>b) Operative valve is verified</li> <li>closed on ECAM.</li> </ul> </li> </ul>   |
|                                |  | D    | 1 | 0 | (M)(O) Associated hot air pressure<br>regulating valve and trim air valve<br>may be inoperative provided one of<br>these valves is secured closed.  |
| 21-51-01                       | Pack Flow Control<br>Valves<br>(Without Mod. 30626/<br>MP K6443<br>(Enhanced ECS)) | С    | 2 | 1 | <ul> <li>(M) Except for ETOPS, one may be inoperative provided:</li> <li>a) Valve is secured closed, and</li> <li>b) Associated air conditioning pack is considered inoperative.</li> </ul>   |
|                                |  | С    | 2 | 0 | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) Flight is conducted in an unpressurized configuration,</li> <li>b) Avionics equipment ventilation system operates normally,</li> <li>c) Outside air temperature (OAT) is less than 38 °C,</li> <li>d) Both packs are switched OFF,</li> <li>e) Both pack flow control valves are secured closed, and</li> <li>f) Flight is conducted with no passengers on board.</li> </ul> </li> </ul> |

| FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|---------------------------------|---|---|---|----------------|---|--|--|--|--|
| REVISION NO                     |   |   |   |                | PAGE NO. 21-14  |  |  |  |  |
| DATE: 03/03/2                   | 2023  |   |   |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 21. Air Condit                  |   |   |   |                | Change  |  |  |  |  |
| Sequence No.<br>21-51-02        | Item<br>Pack Flow Selections                        | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 1)                              | A319/A320 or A321 with<br>Mod. 157080/<br>MP K17996 | С | 3 | 1              | LO and/or NORM may be inoperative.  |  |  |  |  |
| 2)                              | A321 without<br>Mod. 157080/<br>MP K17996           | С | 2 | 1              | ECON FLOW may be inoperative.   |  |  |  |  |
| 3)                              | A318  | С | 2 | 1              | HI may be inoperative.  |  |  |  |  |
| 21-51-03                        | PACK pb Switch                                      |   |   |                |   |  |  |  |  |
| 1)                              | FAULT Lights  | С | 2 | 0              | One or both may be inoperative.   |  |  |  |  |
| 2)                              | OFF Lights  | С | 2 | 0              | One or both may be inoperative.   |  |  |  |  |
| 21-51-06                        | Pack Flow Sensor<br>(Aircraft with<br>Mod. 30626)   | С | 2 | 1              | (O) One may be inoperative provided<br>the HOT AIR pb switch is selected<br>OFF.  |  |  |  |  |
|                                 |   |   |   |                | NOTE: For aircraft equipped with<br>forward cargo compartment<br>heating (Mod. 20082), refer to<br>Livestock Transportation<br>Manual.  |  |  |  |  |
| 21-52-01                        | Packs   | С | 2 | 0              | <ul> <li>(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) Flight is conducted in an unpressurized configuration,</li> <li>b) Avionics equipment ventilation system operates normally,</li> <li>c) Outside air temperature (OAT) is less than 38 °C, and</li> <li>d) Flight is conducted with no passengers on board.</li> </ul> </li> </ul> |  |  |  |  |
|                                 |   |   |   |                | (Continued)   |  |  |  |  |

|                                     | MENT OF TRANSPORTATI                                      | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|-------------------------------------|---|----|---|----------------|--|--|--|--|--|
| REVISION NO. 30<br>DATE: 03/03/2023 |   |    |   |                | PAGE NO. 21-15   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 21. Air Condit                      | ioning  |    |   |                |  |  |  |  |  |
| Sequence No.                        | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 21-52-01                            | Packs<br>(Cont'd)   |    |   |                |  |  |  |  |  |
| 1)                                  | A319 without<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS) | С  | 2 | 1              | <ul> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) Airplane remains at or below FL 310,</li> <li>b) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to OFF,</li> <li>d) Pack flow control valve is verified closed on ECAM BLEED page,</li> <li>e) PACK FLOW selector is set to HI, and</li> <li>f) Avionics equipment ventilation system operates normally.</li> </ul> </li> <li>NOTE: Proviso d) does not apply if pack valve has been secured closed as per item 21-51-01.</li> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) Airplane remains at or below FL 370,</li> <li>b) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to OFF,</li> </ul> </li> </ul> |  |  |  |  |
|                                     |   |    |   |                | <ul> <li>d) Pack flow control valve is<br/>verified closed on ECAM<br/>BLEED page,</li> </ul>  |  |  |  |  |
|                                     |   |    |   |                | <ul> <li>e) PACK FLOW selector is set to<br/>HI,</li> <li>f) Avionics equipment ventilation<br/>system operates normally, and</li> </ul>   |  |  |  |  |
|                                     |   |    |   |                | <ul> <li>g) Speedbrakes operate normally.</li> <li>NOTE: Proviso d) does not apply if<br/>pack valve has been secured<br/>closed as per item 21-51-01.</li> </ul>  |  |  |  |  |
|                                     |   |    |   |                | (Continued)  |  |  |  |  |

| _                                   | TMENT OF TRANSPORTAT                                      | ION |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------------|---|-----|----|----------------|--|
| REVISION NO. 30<br>DATE: 03/03/2023 |   |     |    |                | PAGE NO. 21-16   |
| AIRCRAFT:<br>Airbus A320            |   |     | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 21. Air Cond                        | itioning  |     |    |                |  |
| Sequence No.                        | Item  | 1   | 2  | 3              | 4 Change<br>Bar  |
| 21-52-01                            | Packs<br>(Cont'd)   |     |    |                |  |
| 2)                                  | A320 without<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS) | C   | 2  | 1              | <ul> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) Airplane remains at or below FL 310,</li> <li>b) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to OFF,</li> <li>d) Pack flow control valve is verified closed on ECAM BLEED page,</li> <li>e) PACK FLOW selector is set to HI, and</li> <li>f) Avionics equipment ventilation system operates normally.</li> </ul> </li> <li>NOTE: Proviso d) does not apply if pack valve has been secured closed as per item 21-51-01.</li> </ul> |
|                                     |   | C   | 2  | 1              | <ul> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>b) Affected pack pb-sw is set to OFF,</li> <li>c) Pack flow control valve is verified closed on ECAM BLEED page,</li> <li>d) PACK FLOW selector is set to HI,</li> <li>e) Avionics equipment ventilation system operates normally, and</li> <li>f) Speedbrakes operate normally.</li> </ul> </li> <li>NOTE: Proviso c) does not apply if pack valve has been secured closed as per item 21-51-01.</li> </ul>        |
|                                     |   |     |    |                | (Continued)  |

| U.S. DEPARTM                   | IENT OF TRANSPORTATIO                                     | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------------|---|----|---|----------------|--|
| FEDERAL AVIA                   | ATION ADMINISTRATION                                      |    |   |                |  |
| REVISION NO.<br>DATE: 03/03/20 |   |    |   |                | PAGE NO. 21-17   |
| AIRCRAFT:<br>Airbus A320       |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 21. Air Conditio               | oning   |    |   |                |  |
| Sequence No.                   | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 21-52-01                       | Packs<br>(Cont'd)   |    |   |                |  |
| 3)                             | A321 without<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS) | С  | 2 | 1              | <ul> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) Airplane remains at or below FL 310,</li> <li>b) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to OFF,</li> <li>d) Pack flow control valve is verified closed on ECAM BLEED page,</li> <li>e) ECON FLOW pb-sw is selected OFF, and</li> <li>f) Avionics equipment ventilation system operates normally.</li> </ul> </li> <li>NOTE: Proviso d) does not apply if pack valve has been secured closed as per item 21-51-01.</li> </ul>               |
|                                |   | C  | 2 | 1              | <ul> <li>(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) COND ZONE REGUL FAULT caution is not displayed on ECAM,</li> <li>b) Affected pack pb-sw is set to OFF,</li> <li>c) Pack flow control valve is verified closed on ECAM BLEED page,</li> <li>d) ECON FLOW pb-sw is selected OFF,</li> <li>e) Avionics equipment ventilation system operates normally, and</li> <li>f) Speedbrakes operate normally.</li> </ul> </li> <li>NOTE: Proviso c) does not apply if pack valve has been secured closed as per item 21-51-01.</li> <li>(Continued)</li> </ul> |

| FEDERAL AVIATION ADMINISTRATION         REVISION NO. 30         DATE: 03/03/2023         AIRCRAFT:         Airbus A320             TABLE KEY         1. REPAIR CAT         2. NO. INSTALL         3. NO. REQUIF  | LED<br>RED FOR DISPATCH<br>OR EXCEPTIONS           |
|--|--|
| DATE: 03/03/2023          AIRCRAFT:       1. REPAIR CAT         Airbus A320       2. NO. INSTAL         3. NO. REQUIF       4. REMARKS C         21. Air Conditioning       1       2       3         Sequence No.       Item       1       2       3         21-52-01       Packs       1       2       3       4 | TEGORY<br>LED<br>RED FOR DISPATCH<br>DR EXCEPTIONS |
| AIRCRAFT:<br>Airbus A3201. REPAIR CAT<br>2. NO. INSTALL<br>3. NO. REQUIR<br>4. REMARKS C21. Air ConditioningSequence No.Item123421-52-01Packs </td <td>LED<br/>RED FOR DISPATCH<br/>OR EXCEPTIONS</td>   | LED<br>RED FOR DISPATCH<br>OR EXCEPTIONS           |
| Sequence No.Item123421-52-01Packs  |  |
| 21-52-01 Packs   |  |
|  | Bar  |
|  |  |
| be inoperative<br>a) Airplar<br>FL 310<br>b) AIR P/<br>FAUL<br>1(2)-A<br>COND<br>caution<br>operat<br>display<br>c) Affecte<br>OFF,<br>d) HI FL0<br>e) Avioni<br>system<br>f) Pack f   | ne remains at or below                             |
| be inoperative<br>a) Airplar<br>FL 350<br>b) AIR P<br>FAUL<br>1(2)-A<br>CONE<br>caution<br>operat<br>display<br>c) Affecte<br>OFF,<br>d) HI FLO<br>e) Avioni<br>system<br>f) Speed<br>and<br>g) Pack f   | ne remains at or below                             |

|   | ON  |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|---|---|---|---|--|
|   |   |   |   |  |
| 30<br>)23   |   |   |   | PAGE NO. 21-19   |
|   |   | Т   | 1.<br>2.<br>3.  | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| oning   |   |   |   |  |
| Item  | 1   | 2   | 3   | 4 Change<br>Bar  |
| Packs<br>(Cont'd)                                   |   |   |   |  |
| A319 with Mod. 30626/<br>MP K6443<br>(Enhanced ECS) | С   | 2   | 1   | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) Airplane remains at or below FL 310,</li> <li>b) AIR PACK 1(2) REGUL FAULT, AIR COND CTL 1(2)-A FAULT, and AIR COND CTL 1(2)-B FAULT cautions associated with operative side are not displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to OFF,</li> <li>d) PACK FLOW selector is set to HI,</li> <li>e) Avionics equipment ventilation system operates normally, and</li> <li>f) Pack flow control valve is secured closed.</li> </ul></li></ul>  |
|   | C   | 2   |   | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Airplane remains at or below<br/>FL 370,</li> <li>b) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL<br/>1(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to<br/>OFF,</li> <li>d) PACK FLOW selector is set to<br/>HI,</li> <li>e) Avionics equipment ventilation<br/>system operates normally,</li> <li>f) Speedbrakes operate normally<br/>and</li> <li>g) Pack flow control valve is<br/>secured closed.</li> </ul> </li> </ul> |
|   | ATION ADMINISTRATION<br>30<br>023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023<br>0023 | 30         D23         Description         Item       1         Packs       1         (Cont'd)       1         A319 with Mod. 30626/       C         MP K6443       C | ATION ADMINISTRATION<br>30<br>023<br>T<br>T<br>T<br>Dning<br>1 2<br>Packs<br>(Cont'd)<br>A319 with Mod. 30626/<br>MP K6443<br>(Enhanced ECS)<br>C 2<br>MP K6443<br>(Enhanced ECS) | ATION ADMINISTRATION<br>30<br>223<br>TABL<br>1.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>4.<br>2.<br>3.<br>Packs<br>(Cont'd)<br>A319 with Mod. 30626/<br>MP K6443<br>(Enhanced ECS)<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.<br>4.  |

| FEDERAL AVIATION ADMINISTRATION  | U.S. DEPARTM     | IENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|------------------|--|----|---|----------------|--|
| DATE: 03/03/2023          AIRCRAFT:       Airbus A320       I. REPAIR CATEGORY         2. NO. INSTALLED       3. NO. REQUIRED FOR DISPATCH         4. REMARKS OR EXCEPTIONS         21.4ir Conditioning       Image: Condition of the model of the mod   | FEDERAL AVIA     | ATION ADMINISTRATION   |    |   |                |  |
| AIRCRAFT:       Airbus A320       1. REPAIR CATEGORY         Airbus A320       2. NO. INSTALLED         21. Air Conditioning       8         Sequence No.       1       2       3       4         Contidio       1       2       3       4         6)       A320 with Mod. 30626/<br>MP K6443<br>(Enhanced ECS) or<br>A321 with Mod. 157080/<br>MP K1996 (PACK<br>FLOW selector) and with<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:         a)       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT (2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>C       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative side are not<br>displayed on ECAM,<br>C         6)       AVAID, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>C       C       2       1         6)       AVAID, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative provided:       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL<br>1(2)-A FAULT<br>cautions associated with<br>operative provided:         a)       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT<br>cautions associated with<br>operative provided:         a)       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT<br>cautions associated with<br>operative provided:         a)       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT<br>cautions associated  |                  |  |    |   |                | PAGE NO. 21-20   |
| Sequence No.       Item       1       2       3       4       Change<br>Back         21-52-01       Packs<br>(Cont'd)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided: <ul> <li>a) Airplane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS) or<br/>A321 with Mod. 157080/<br/>MP K6443</li> <li>(Enhanced ECS)</li> </ul> <ul> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> </ul> <ul> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> <li>Alignane remains at or below<br/>FL 310,<br/>OFF,</li> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> </ul> <ul> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> <li>Alignane remains at or below<br/>FL 310,<br/>MP K6443</li> <li>(Enhanced ECS)</li> <li>(C) A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative provided:</li></ul>   |                  |  |    | T | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |
| sequence No.       term       1       2       3       4       But       But         21-52-01       Packs<br>(Cont'd)       (Cont'd)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:       a) Airplane remains at or below<br>FL 310,       b) Airplane remains at or below<br>FL 310,         6)       A320 with Mod. 157080/<br>MP K17996 (PACK<br>FLOW selector) and with<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:       a) Airplane remains at or below<br>FL 310,       b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,       c) Affected pack pb-sw is set to<br>OFF,       d) PACK FLOW selector is set to<br>HI,       e) Avionics equipment ventilation<br>system operates normally, and       f) Pack flow control value is<br>secured closed.         C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:       a) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,       b) Affected pack pb-sw is set to<br>OFF,       c) PACK FLOW selector is set to<br>HI,         d) Avionics equipment ventilation<br>system operates normally,<br>e) Speedbrakes operate normally,       e) Speedbrakes operate normally  | 21. Air Conditio | oning  |    |   |                |  |
| <ul> <li>(Cont'd)</li> <li>A320 with Mod. 30626/<br/>MP K6443<br/>(Enhanced ECS) or<br/>A321 with Mod. 157080/<br/>MP K17996 (PACK<br/>FLOW selector) and with<br/>Mod. 30626/<br/>MP K6443<br/>(Enhanced ECS)</li> <li>C 2 1 (M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Airplane remains at or below<br/>FL 310,</li> <li>b) AIR PACK 1(2) REGUL<br/>FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to<br/>OFF,</li> <li>d) PACK FLOW selector is set to<br/>HI,</li> <li>e) Avionics equipment ventilation<br/>system operates normally, and</li> <li>f) Pack flow control valve is<br/>secured closed.</li> </ul> </li> <li>C 2 1 (M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL</li> <li>c) AIR PACK 1(2) REGUL<br/>FAULT, and AIR<br/>COND CTL 1(2)-B FAULT</li> <li>c) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL</li> <li>f(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT</li> <li>c) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL</li> <li>f(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT</li> <li>c) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL</li> <li>f(2)-A FAULT, and AIR<br/>COND CTL</li> <li>f(3)-A FAULT, and AIR<br/>COND CTL</li> <li>f(4)-A FAULT, and AIR<br/>COND CTL</li> <li>f(4)-A Vionics equipment ventilation<br/>system operates normally.</li> <li>f(2)-A FAULT and AIR<br/>COND CTL</li> <li>f(3)-A FAULT and AIR<br/>COND CTL</li> <li>f(4)-A FAUL</li></ul></li></ul> | Sequence No.     | Item   | 1  | 2 | 3              |  |
| <ul> <li>MP K6443 <ul> <li>(Enhanced ECS) or</li> <li>A321 with Mod. 157080/</li> <li>MP K17996 (PACK</li> <li>FLOW selector) and with</li> <li>Mod. 30626/</li> <li>MP K6443 <ul> <li>(Enhanced ECS)</li> </ul> </li> <li>(Enhanced ECS)</li> </ul> </li> <li>C 2 1 (M)(O) Except for ETOPS, one may be inoperative side are not displayed on ECAM, and f) Pack flow control valve is secured closed.</li> <li>C 2 1 (M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) AIR PACK 1(2) REGUL</li> <li>FAULT, AIR COND CTL</li> <li>f(2)-A FAULT, and AIR</li> <li>COND CTL 1(2)-B FAULT</li> <li>cautions associated with operates normally, and f) Pack flow control valve is secured closed.</li> </ul> </li> <li>C 2 1 (M)(O) Except for ETOPS, one may be inoperative side are not displayed on ECAM, b) AIR PACK 1(2) REGUL</li> <li>FAULT, AIR COND CTL 1(2)-B FAULT cautions associated with operative side are not displayed on ECAM, b) AIR PACK 1(2) REGUL</li> <li>FAULT, AIR COND CTL 1(2)-B FAULT cautions associated with operative side are not displayed on ECAM, b) Affected pack pb-sw is set to OFF, c) PACK FLOW selector is set to HI, d) Avionics equipment ventilation system operates normally, and f) Pack flow control valve is secured closed.</li> </ul>  | 21-52-01         |  |    |   |                |  |
| <ul> <li>be inoperative provided:</li> <li>a) AIR PACK 1(2) REGUL</li> <li>FAULT, AIR COND CTL</li> <li>1(2)-A FAULT, and AIR</li> <li>COND CTL 1(2)-B FAULT</li> <li>cautions associated with</li> <li>operative side are not</li> <li>displayed on ECAM,</li> <li>b) Affected pack pb-sw is set to</li> <li>OFF,</li> <li>c) PACK FLOW selector is set to</li> <li>HI,</li> <li>d) Avionics equipment ventilation</li> <li>system operates normally,</li> <li>e) Speedbrakes operate normally</li> <li>and</li> </ul>  | 6)               | MP K6443<br>(Enhanced ECS) or<br>A321 with Mod. 157080/<br>MP K17996 (PACK<br>FLOW selector) and with<br>Mod. 30626/<br>MP K6443 | С  | 2 | 1              | <ul> <li>be inoperative provided:</li> <li>a) Airplane remains at or below<br/>FL 310,</li> <li>b) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL<br/>1(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to<br/>OFF,</li> <li>d) PACK FLOW selector is set to<br/>HI,</li> <li>e) Avionics equipment ventilation<br/>system operates normally, and</li> <li>f) Pack flow control valve is</li> </ul> |
| secured closed.  |                  |  | С  | 2 | 1              | <ul> <li>be inoperative provided:</li> <li>a) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL<br/>1(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>b) Affected pack pb-sw is set to<br/>OFF,</li> <li>c) PACK FLOW selector is set to<br/>HI,</li> <li>d) Avionics equipment ventilation<br/>system operates normally,</li> <li>e) Speedbrakes operate normally<br/>and</li> <li>f) Pack flow control valve is</li> </ul>         |

| FEDERAL AVIATION ADMINISTRATION       Image: Construction and the constrely and the construction and the construction and the constructio | U.S. DEPARTI    | MENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|-----------------|---|----|---|----------------|--|
| DATE: 03/03/2023  AIRCRAFT: Airbus A320  AIRCRAFT: Sequence No Ison REQUIRED FOR DISPATCH REPAR CATEGORY NO. REQUIRED FOR DISPATCH REPARARS OR EXCEPTIONS  21. Air Conditioning  Sequence No Ison Ison I I Z 3 I (M)(O) Except for ETOPS, one may be inoperative provided: a) Airplane remains at or below FLOW selector) and with Mod. 30626/ MP K6443 (Enhanced ECS)  C Z I I (M)(O) Except for ETOPS, one may be inoperative provided: b) AIR PACK 1(2) REGUL FAULT, and CND CTL 1(2)-A FAULT, and AIR COND CTL 1(2)-B FAULT cautions associated with operative side are not displayed on ECAM, C I ECN FLOW b-sw is set to OFF, C I ECON FLOW b-sw is set to OFF, C I ECON FLOW b-sw is set to OFF, C I ECON FLOW b-sw is set to OFF, C I AIR PACK 1(2) REGUL FAULT, AIR COND CTL 1(2)-B FAULT Cautions associated with operative side are not displayed on ECAM, D I AIR PACK 1(2) REGUL FAULT, AIR COND CTL 1(2)-B FAULT CAUCH CAUCH CON CTL 1(2)-A FAULT, AIR COND CTL 1(2)-B FAULT CAUCH COND CTL 1(2)-B FAULT CAUCH COND CTL 1(2)-B FAULT CAUCH CAUCH C C C C C C C C C C C C C C C C C C   |                 |   |    |   |                |  |
| AIRCRAFT:       Airbus A320       1       Repair CATEGORY         2. NO. INSTALLED       3. NO. REQUIRED FOR DISPATCH         4. REMARKS OR EXCEPTIONS         21.4ir Conditioning         21.52-01       Packs<br>(Cont'd)         7)       A321 without<br>Mod. 157080/<br>MP K17996 (PACK<br>FLOW selector) and with<br>Mod. 3026/<br>MP K6443<br>(Enhanced ECS)       C       2       1         6       COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative growided:       a) Airplane remains at or below<br>FL 310,         7       A321 without<br>Mod. 157080/<br>MP K6443<br>(Enhanced ECS)       C       2       1         6       COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,       b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,         6       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:         8       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,       1         9       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,         9       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,         9       AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-B FAULT<br>cautions associated with<br>operative side are not  |                 |   |    |   |                | PAGE NO. 21-21   |
| Sequence No.       Item       1       2       3       4       Construction         21-52-01       Packs<br>(Cont'd)       A321 without<br>Mod. 157080/<br>MP K17996 (PACK<br>FLOW selector) and with<br>Mod. 30626/<br>MP K6443<br>(Enhanced ECS)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) Airplane remains at or below<br>FL 310,<br>b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>c) Affected pack pb-sw is set to<br>OFF,<br>e) Avionics equipment ventilation<br>system operates normally, and<br>f) Pack flow control valve is<br>secured closed.         C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative side are not<br>displayed on ECAM,<br>c) Affected pack pb-sw is set to<br>OFF,<br>e) Avionics equipment ventilation<br>system operates normally, and<br>f) Pack flow control valve is<br>secured closed.         C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) AIR PACK 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2) B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>b) Affected pack pb-sw is set to<br>OFF,<br>c) ECON FLOW pb-sw is set to<br>OFF,<br>d) Avionics equipment ventilation<br>system operates normally,<br>e) Speedbrakes operate normally,<br>e) Speedbrakes operate normally   |                 |   |    | T | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |
| Sequence No.       term       1       2       3       4       term       term         21-52-01       Packs<br>(Cont'd)       Packs       (Cont'd)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) Airplane remains at or below<br>FL 310,<br>MP K6443<br>(Enhanced ECS)         7)       A321 without<br>MP K6443<br>(Enhanced ECS)       C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) Airplane remains at or below<br>FL 310,<br>b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>c) Affected pack ps-wi is set to<br>OFF,<br>e) Avionics equipment ventilation<br>system operates normally, and<br>f) Pack flow control valve is<br>secured closed.         C       2       1       (M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) AIR PACK 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>acutions associated with<br>operative provided:<br>a) AIR PACK 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>b) Affected pack pb-sw is set to<br>OFF,<br>c) ECON FLOW pb-sw is set to<br>OFF,<br>d) Avionics equipment ventilation<br>system operates normally,<br>and<br>f) Pack flow control valve is   | 21. Air Conditi | oning   |    |   |                |  |
| (Cont'd)C21(M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) Airplane remains at or below<br>FL310,<br>b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>c) Affected pack pb-sw is set to<br>OFF,<br>e) Avionics equipment ventilation<br>system operates normally, and<br>f) Pack flow control value is<br>displayed on ECAM,<br>b) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>c) Affected pack pb-sw is set to<br>OFF,<br>e) Avionics equipment ventilation<br>system operates normally, and<br>f) Pack flow control value is<br>secured closed.C21(M)(O) Except for ETOPS, one may<br>be inoperative provided:<br>a) AIR PACK 1(2) REGUL<br>FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>b) Affected pack pb-sw is set to<br>OFF,<br>c) ECON FLOW pb-sw is set to<br>ooFF,<br>c) ECON FLOW pb-sw is set to<br>ooFF,<  | Sequence No.    | Item  | 1  | 2 | 3              |  |
| <ul> <li>Mod. 157080/<br/>MP K17996 (PACK<br/>FLOW selector) and with<br/>Mod. 30626/<br/>MP K6443<br/>(Enhanced ECS)</li> <li>C 2 1</li> <li>C 2 1</li> <li>C 2 1</li> <li>C 2 1</li> <li>C (M)(O) Except for ETOPS, one may<br/>be inoperative provided:<br/>a) Airplane remains at or below<br/>FL 310,<br/>b) AiR PACK 1(2) REGUL<br/>FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,<br/>c) Affected pack pb-sw is set to<br/>OFF,<br/>d) ECON FLOW pb-sw is set to<br/>OFF,<br/>e) Avionics equipment ventilation<br/>system operates normally, and<br/>f) Pack flow control valve is<br/>secured closed:<br/>a) AiR PACK 1(2) REGUL<br/>FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative give are not<br/>displayed on ECAM,<br/>b) Affected pack pb-sw is set to<br/>OFF,<br/>c) ECON FLOW pb-sw is set to<br/>OFF,<br/>d) Avionics equipment ventilation<br/>system operates normally,<br/>e) Speedbrakes operate normally<br/>and<br/>f) Pack flow control valve is</li> </ul>  | 21-52-01        |   |    |   |                |  |
| be inoperative provided:<br>a) AIR PACK 1(2) REGUL<br>FAULT, AIR COND CTL<br>1(2)-A FAULT, and AIR<br>COND CTL 1(2)-B FAULT<br>cautions associated with<br>operative side are not<br>displayed on ECAM,<br>b) Affected pack pb-sw is set to<br>OFF,<br>c) ECON FLOW pb-sw is set to<br>OFF,<br>d) Avionics equipment ventilation<br>system operates normally,<br>e) Speedbrakes operate normally<br>and<br>f) Pack flow control valve is   | 7)              | Mod. 157080/<br>MP K17996 (PACK<br>FLOW selector) and with<br>Mod. 30626/<br>MP K6443 | С  | 2 | 1              | <ul> <li>be inoperative provided:</li> <li>a) Airplane remains at or below<br/>FL 310,</li> <li>b) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL<br/>1(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>c) Affected pack pb-sw is set to<br/>OFF,</li> <li>d) ECON FLOW pb-sw is set to<br/>OFF,</li> <li>e) Avionics equipment ventilation<br/>system operates normally, and</li> <li>f) Pack flow control valve is</li> </ul>             |
| (Continued)  |                 |   | С  | 2 | 1              | <ul> <li>be inoperative provided:</li> <li>a) AIR PACK 1(2) REGUL<br/>FAULT, AIR COND CTL<br/>1(2)-A FAULT, and AIR<br/>COND CTL 1(2)-B FAULT<br/>cautions associated with<br/>operative side are not<br/>displayed on ECAM,</li> <li>b) Affected pack pb-sw is set to<br/>OFF,</li> <li>c) ECON FLOW pb-sw is set to<br/>OFF,</li> <li>d) Avionics equipment ventilation<br/>system operates normally,</li> <li>e) Speedbrakes operate normally<br/>and</li> <li>f) Pack flow control valve is<br/>secured closed.</li> </ul> |

| FEDERAL AVIATION ADMINISTRATION |   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|---------------------------------|---|---|---|-------------------------------|--|--|--|--|
| REVISION NO<br>DATE: 03/03/2    |   |   |   |                               | PAGE NO. 21-22   |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 21. Air Conditi                 | onina   |   |   |                               |  |  |  |  |
| Sequence No.                    | ltem  | 1 | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 21-52-01                        | Packs<br>(Cont'd)   |   |   |                               |  |  |  |  |
| 8)                              | Air Cycle Machine<br>(ACM)  | С | 2 | 0                             | <ul> <li>(O) Except for ETOPS, may be<br/>inoperative provided: <ul> <li>a) Flight is conducted in an<br/>unpressurized configuration,</li> <li>b) Avionics equipment ventilation<br/>system operates normally,</li> <li>c) Outside air temperature<br/>(OAT) is less than 38 °C, and</li> <li>d) Flight is conducted with no<br/>passengers on board.</li> </ul> </li> </ul>  |  |  |  |
| a)                              | A319, A320, A321<br>without Mod. 30626/<br>MP K6443<br>(Enhanced ECS) | C | 2 | 1                             | <ul> <li>(O) One pack may be operated on heat exchanger cooling only provided: <ul> <li>a) Affected pack's compressor outlet temperature indication is available on ECAM BLEED page,</li> <li>b) TAT indication is available,</li> <li>c) Corresponding pack controller operates normally,</li> <li>d) Affected pack is not used until airborne,</li> <li>e) TAT is at or below 12 °C, and</li> <li>f) Avionics equipment ventilation system operates normally.</li> </ul> </li> <li>NOTE: FL 310 or below must be maintained if normal operating pack fails.</li> </ul> |  |  |  |

| U.S. DEPART                         | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|-------------------------------------|---|----|---|----------------|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION     |   |    |   |                | MASTER MINIMOM EQUIPMENT LIST  |  |  |  |
| REVISION NO. 30<br>DATE: 03/03/2023 |   |    |   |                | PAGE NO. 21-23   |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 21. Air Condit                      | tioning   |    |   |                |  |  |  |  |
| Sequence No.                        | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |
| 21-52-01                            | Packs<br>(Cont'd)   |    |   |                |  |  |  |  |
| 8)                                  | Air Cycle Machine<br>(ACM)<br>(Cont'd)                                |    |   |                |  |  |  |  |
| b)                                  | A318/A319/<br>A320/A321 with<br>Mod. 30626/MP K6443<br>(Enhanced ECS) | C  | 2 | 1              | <ul> <li>(O) One pack may be operated on heat exchanger cooling only provided: <ul> <li>a) Affected pack's compressor outlet temperature indication is available on ECAM BLEED page,</li> <li>b) TAT indication is available,</li> <li>c) AIR COND CTL 1(2)-A FAULT and AIR COND CTL 1(2)-B FAULT cautions associated with operative side are not displayed on ECAM,</li> <li>d) Affected pack is not used until airborne,</li> <li>e) TAT is at or below 12 °C, and</li> <li>f) Avionics equipment ventilation system operates normally.</li> </ul> </li> <li>NOTE: FL 310 or below must be maintained if normal operating pack fails.</li> </ul> |  |  |  |
| 21-52-02                            | Air Cond Pack Ram Air<br>Inlet Flaps                                  |    |   |                |  |  |  |  |
| 1)                                  | Without Mod. 24371  | С  | 2 | 0              | (M) May be inoperative in the open position provided backlash is verified within limits.   |  |  |  |
|                                     |   | С  | 2 | 0              | (O) May be inoperative in the closed position provided the associated pack(s) is (are) not used.   |  |  |  |
|                                     |   |    |   |                | (Continued)  |  |  |  |

| FEDERAL AVI                  | ATION ADMINISTRATION  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|------------------------------|---|---|---|-------------------------------|--|--|--|--|
| REVISION NC<br>DATE: 03/03/2 |   |   |   | PAGE NO. 21-24                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |   |   |                               | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS  |  |  |  |
| 21. Air Condit               | ioning  |   |   | n                             |  |  |  |  |
| Sequence No.<br>21-52-02     | Item<br>Air Cond Pack Ram Air<br>Inlet Flaps<br>(Cont'd)                | 1 | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 2)                           | With Mod. 24371   | С | 2 | 0                             | (M) May be inoperative in the open position.   |  |  |  |
|                              |   | С | 2 | 0                             | (O) May be inoperative in the closed position provided the associated pack(s) is (are) not used.   |  |  |  |
| 21-52-03                     | Air Cond Pack Ram Air<br>Outlet Flaps<br>(Without Mod. 26249)           | С | 2 | 0                             | (M) May be inoperative in the open position provided backlash is verified within limits.   |  |  |  |
|                              |   | С | 2 | 0                             | (O) May be inoperative in the closed position provided the associated pack(s) is (are) not used.   |  |  |  |
| 21-55-01                     | Emergency Ram Air Inlet   | С | 1 | 0                             | (O) Except for ETOPS and extended<br>overwater flight, may be inoperative<br>in the open position for unpressurized<br>flight.   |  |  |  |
| 21-55-02                     | ECAM Emergency RAM<br>Air Inlet Indication<br>(BLEED SD Page)           | С | 1 | 0                             | (M) May be inoperative provided Ram<br>Air Inlet system is verified to operate<br>normally.  |  |  |  |
| 21-61-01                     | Pack Temperature<br>Control Primary<br>Channels<br>(Without Mod. 30626) | С | 2 | 1                             | NOTE: If the primary channel is<br>failed, pack flow is fixed at the<br>value reached at the time of<br>failure. If primary and<br>secondary channels are<br>failed, the pack outlet<br>temperature is controlled by<br>the anti-ice valve to a nominal<br>value of 15 °C. |  |  |  |

|                              | ATION ADMINISTRATION   |   |   | PAGE NO. 21-25  |  |  |  |
|------------------------------|--|---|---|---|--|--|--|
| REVISION NO<br>DATE: 03/03/2 |  |   |   |   | PAGE NO. 21-23   |  |  |
| AIRCRAFT:<br>Airbus A320     | IRCRAFT:   |   |   | CABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |
| 21. Air Conditi              | oning  |   |   |   |  |  |  |
| Sequence No.                 | Item   | 1 | 2 | 3   | 4 Change<br>Bar  |  |  |
| 21-61-02                     | Turbine Bypass Valves  | С | 2 | 1   | One may be inoperative   |  |  |
| 21-63-01                     | Zone Controller System<br>(A319, A320, A321)<br>(Without Mod. 30626) |   |   |   |  |  |  |
| 1)                           | Primary Channel  | С | 1 | 0   | <ul> <li>May be inoperative provided:</li> <li>a) HOT AIR pb switch is selected OFF, and</li> <li>b) Hot air pressure regulating valve is verified closed on ECAM COND page.</li> </ul>                          |  |  |
|                              |  |   |   |   | NOTE: For aircraft equipped with<br>forward cargo compartment<br>heating (Mod. 20082), refer to<br>Livestock Transportation<br>Manual.   |  |  |
| 2)                           | Secondary Channel  | С | 1 | 0   | May be inoperative provided the minimum idle on ground function is considered inoperative.   |  |  |
| 3)                           | Primary and Secondary<br>Channels                                    | С | 2 | 0   | <ul> <li>(M) May be inoperative provided:</li> <li>a) Hot air pressure regulating<br/>valve is secured closed, and</li> <li>b) The minimum idle on ground<br/>function is considered<br/>inoperative.</li> </ul> |  |  |
|                              |  |   |   |   | NOTE: For aircraft equipped with<br>forward cargo compartment<br>heating (Mod. 20082), refer to<br>Livestock Transportation<br>Manual.   |  |  |

| -                                   | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION |   |   | MASTER MINIMUM EQUIPMENT LIST  |   |  |  |
|-------------------------------------|--|---|---|--|---|--|--|
| REVISION NO. 30<br>DATE: 03/03/2023 |  |   |   |  | PAGE NO. 21-26  |  |  |
| AIRCRAFT:<br>Airbus A320            |  |   |   | 1.<br>2.<br>3.   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 21. Air Conditi                     | oning  | - | - | -  | -   |  |  |
| Sequence No.                        | Item   | 1 | 2 | 3  | 4 Change<br>Bar   |  |  |
| 21-63-02                            | Cockpit/Cabin Trim Air<br>Valves             |   |   |  |   |  |  |
| 1)                                  | Without Mod. 30626                           | С | 3 | 0  | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Affected valve(s) is secured closed, and</li> <li>b) Both pack controllers operate normally.</li> </ul>  |  |  |
|                                     |  | С | 3 | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) HOT AIR pb switch is<br/>selected OFF,</li> <li>b) Hot air pressure regulating<br/>valve is verified closed on<br/>ECAM COND page, and</li> <li>c) Both pack controllers operate<br/>normally.</li> </ul> |  |  |
| 2)                                  | With Mod. 30626                              | С | 3 | 0  | (O) May be inoperative provided<br>associated valve(s) is confirmed<br>closed on ECAM COND page before<br>each flight.  |  |  |
|                                     |  | С | 3 | 0  | (O) May be inoperative provided hot<br>air pressure regulating valve is<br>confirmed operative on ECAM COND<br>page before each flight.   |  |  |
|                                     | С  | 3 | 0 | May be inoperative provided the hot<br>air pressure regulating valve is<br>considered inoperative. |   |  |  |
|                                     |  |   |   |  | NOTE: For aircraft equipped with<br>forward cargo compartment<br>heating (Mod. 20082), refer to<br>Livestock Transportation<br>Manual.  |  |  |

|                              | MENT OF TRANSPORTATIO                | ON |                |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|------------------------------|--------------------------------------|----|----------------|---|---|--|--|--|
|                              | IATION ADMINISTRATION                |    |                |   |   |  |  |  |
| REVISION NO<br>DATE: 03/03/2 |                                      |    | PAGE NO. 21-27 |   |   |  |  |  |
| AIRCRAFT:<br>Airbus A320     |                                      |    |                | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
| 21. Air Condit               | tioning                              |    |                | T   |   |  |  |  |
| Sequence No.                 | Item                                 | 1  | 2              | 3   | 4 Change<br>Bar   |  |  |  |
| 21-63-03                     | Hot Air Pressure<br>Regulating Valve |    |                |   |   |  |  |  |
| 1)                           | Without Mod. 30626                   | С  | 1              | 0   | <ul> <li>(O) May be inoperative in the closed position provided:</li> <li>a) HOT AIR pb switch is selected OFF, and</li> <li>b) Hot air pressure regulating valve is verified closed on ECAM COND page.</li> </ul>  |  |  |  |
|                              |                                      | С  | 1              | 0   | <ul> <li>(M)(O) May be inoperative provided valve is secured closed.</li> <li>NOTE: For aircraft equipped with forward cargo compartment heating (Mod. 20082), refer to Livestock Transportation Manual.</li> </ul> |  |  |  |
| 2)                           | With Mod. 30626                      | С  | 1              | 0   | <ul> <li>(O) May be inoperative in the closed position provided:</li> <li>a) HOT AIR pb switch is selected OFF, and</li> <li>b) Hot air pressure regulating valve is verified closed on ECAM COND page.</li> </ul>  |  |  |  |
|                              |                                      | С  | 1              | 0   | <ul> <li>(O) May be inoperative in the open position provided:</li> <li>a) HOT AIR pb switch is selected OFF, and</li> <li>b) All trim air valves are verified closed on ECAM COND page.</li> </ul>                 |  |  |  |
|                              |                                      | С  | 1              | 0   | <ul> <li>(M)(O) May be inoperative provided valve is secured closed.</li> <li>NOTE: For aircraft equipped with forward cargo compartment heating (Mod. 20082), refer to Livestock Transportation Manual.</li> </ul> |  |  |  |

| -                            | MENT OF TRANSPORTATION                | NC |   | MASTER MINIMUM EQUIPMENT LIST   |   |  |  |  |
|------------------------------|---------------------------------------|----|---|---|---|--|--|--|
| REVISION NC<br>DATE: 03/03/2 |                                       |    |   |   | PAGE NO. 21-28  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |                                       |    | T | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH |   |  |  |  |
|                              |                                       |    |   | 4.  | REMARKS OR EXCEPTIONS   |  |  |  |
| 21. Air Condit               |                                       |    |   | 1   | Change  |  |  |  |
| Sequence No.                 | Item                                  | 1  | 2 | 3   | 4 Change<br>Bar   |  |  |  |
| 21-63-04<br>1)               | HOT AIR pb Switch<br>Fault Light      | С  | 1 | 0   | May be inoperative provided zone<br>duct temperatures are available on<br>ECAM. |  |  |  |
| 2)                           | OFF Light                             | С  | 1 | 0   | May be inoperative.   |  |  |  |
| 21-63-05                     | ECAM Indication                       |    |   |   |   |  |  |  |
| 1)                           | On COND Page                          | С  | - | 0   | All indications may be inoperative.   |  |  |  |
| 2)                           | On CRUISE page                        | С  | - | -   | Cabin and cockpit zone indication may be inoperative.                           |  |  |  |
| 3)                           | On Bleed Page                         |    |   |   |   |  |  |  |
| a)                           | Pack Outlet Temperature               | С  | 2 | 0   | One or both may be inoperative.   |  |  |  |
| b)                           | Pack Turbine Bypass<br>Valve Position | С  | 2 | 0   | One or both may be inoperative.   |  |  |  |
| c)                           | Pack Compressor Outlet<br>Temperature | С  | 2 | 0   | One or both may be inoperative.   |  |  |  |
| d)                           | Pack Flow                             | С  | 2 | 0   | One or both may be inoperative.   |  |  |  |
| e)                           | Pack Flow Control Valve<br>Position   | С  | 2 | 0   | One or both may be inoperative.   |  |  |  |
| 4)                           | On CAB PRESS Page                     | С  | - | -   | Pack 1 and 2 indications may be inoperative.                                    |  |  |  |

| U.S. DEPART              | MENT OF TRANSPORTATION  | ON |   |                               |   |
|--------------------------|---|----|---|-------------------------------|---|
| FEDERAL AV               | /IATION ADMINISTRATION  |    |   | MASTER MINIMUM EQUIPMENT LIST |   |
| <b>REVISION NO</b>       | O. 30   |    |   |                               | PAGE NO. 21-29  |
| DATE: 03/03/             | 2023  |    |   |                               |   |
| AIRCRAFT:<br>Airbus A320 |   |    |   | 1.<br>2.                      | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH                           |
|                          |   |    |   |                               | REMARKS OR EXCEPTIONS   |
| 21. Air Condi            | tioning   |    | • |                               |   |
| Sequence No.             | Item  | 1  | 2 | 3                             | 4 Change<br>Bar   |
| 21-63-06                 | Air Conditioning System<br>Controller (ACSC)<br>(With Mod. 30626)               |    |   |                               |   |
| 1)                       | Channels COND CTL<br>1(2)-A(B)  | С  | 4 | 2                             | Except for ETOPS, one on each side may be inoperative.  |
|                          |   | С  | 4 | 2                             | One on each side may be inoperative<br>provided AIR COND CTL 1-B FAULT<br>is not displayed on ECAM EWD. |
| 21-63-07                 | Cockpit Heater<br>(With Mod. 35861/<br>MP P9801 or<br>Mod. 38212/<br>MP P10187) | D  | 2 | 0                             | (O) May be inoperative.   |

| FEDERAL AVI                 | ATION ADMINISTRATION    |   |   | MASTER MINIMUM EQUIPMENT LIST<br>PAGE NO. 22-1 |  |  |  |  |  |
|-----------------------------|-------------------------|---|---|--|--|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/ |                         |   |   |  |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320    |                         |   | Т | 1.<br>2.<br>3.                                 | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 22. Autoflight              |                         | - |   |  |  |  |  |  |  |
| Sequence No.                | Item                    | 1 | 2 | 3  | 4 Change<br>Bar  |  |  |  |  |
| 22-10-01                    | Autopilot Systems       | С | 2 | 1  | (O) One may be inoperative provided approach minimums do not require its use.  |  |  |  |  |
|                             |                         | В | 2 | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) Approach minimums do not<br/>require their use,</li> <li>b) Enroute operations do not<br/>require their use, and</li> <li>c) Number of flight segments<br/>and segment duration is<br/>acceptable to flightcrew.</li> </ul>  |  |  |  |  |
|                             |                         |   |   |  | NOTE: Any Mode which operates<br>normally may be used.   |  |  |  |  |
| 22-10-02                    | Flight Director Systems | С | 2 | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) Approach minimums do not<br/>require their use, and</li> <li>b) Alternate takeoff procedures<br/>are established and used.</li> </ul>  |  |  |  |  |
| 22-10-03                    | Take Over pb Switch     |   |   |  |  |  |  |  |  |
| 1)                          | AP Disconnect Function  | С | 2 | 1  | <ul> <li>(O) One may be inoperative provided:</li> <li>a) Autopilot is not utilized below<br/>1,500 ft. AGL,</li> <li>b) Priority function is verified to<br/>operate normally before each<br/>departure, and</li> <li>c) Approach minimums do not<br/>require the use of autopilot(s).</li> </ul>   |  |  |  |  |
|                             |                         | В | 2 | 0  | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Autopilots are not engaged,</li> <li>b) Enroute operations do not require their use,</li> <li>c) Priority function is verified to operate normally before each departure,</li> <li>d) Approach minimums do not require the use of autopilots, and</li> <li>e) Number of flight segments and segment duration is acceptable to flightcrew.</li> </ul> </li> </ul> |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |        |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|--|--------|---|---|--|--|--|--|
| REVISION NC<br>DATE: XX/XX/  | -  |        |   |   | PAGE NO. 22-2  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |        | T | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |
| 22. Autoflight   |  |        |   |   | Change   |  |  |  |
| Sequence No.<br>22-10-04   | Item<br>Autoland Lights  | 1<br>C | 2 | 3<br>0  | 4 Change Bar<br>May be inoperative provided<br>approach minimums do not require<br>use of autoland.  |  |  |  |
| 22-10-05   | AP Disengagement<br>Warning System   | В      | 1 | 0   | (O) May be inoperative provided both autopilots are not used.  |  |  |  |
| 22-10-06   | Side Sticks and Rudder<br>Locking Solenoids in<br>AP Mode                                    | С      | 3 | 1   | <ul> <li>May be inoperative unlocked provided:</li> <li>a) Autopilot Disconnect Warning operates normally, and</li> <li>b) Autoland is not used.</li> <li>NOTE: If one of the locking solenoids is inoperative in the unlocked position, the affected side stick or pedals will move freely and the "hard point" will not be felt any longer by the pilots. This may result in an unintentional AP disconnection.</li> </ul> |  |  |  |
| 22-10-08<br>***  | AP/FD TCAS mode<br>(With Mod. 152037/<br>MP P11363 and without<br>Mod. 159900/<br>MP P20212) | D      | 1 | 0   | (O) May be inoperative.  |  |  |  |
| 22-10-09   | Soft Go-Around Function<br>(With Mod. 161254/<br>MP P13922)                                  | С      | 1 | 0   | (O) May be inoperative.  |  |  |  |

| FEDERAL AVIATION ADMINISTRATION     |   |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|-------------------------------------|---|---|---|---|---|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |   |   |   | PAGE NO. 22-3   |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
| 22. Autoflight<br>Sequence No.      | ltom  | 1 | 2 | 3   | 4 Change  |  |  |  |
| 22-30-01                            | Item<br>Autothrust Function                                     | 1 | 2 | 3   | 4 Bar   |  |  |  |
| 1)                                  | Without Soft Go-around<br>Function<br>Mod. 161254/<br>MP P13922 | С | 1 | 0   | <ul> <li>(M) May be inoperative provided: <ul> <li>a) All thrust lever sensors are verified to operate normally, and</li> <li>b) Approach minimums do not require its use.</li> </ul> </li> <li>NOTE: Alpha floor is not available with autothrust function inoperative.</li> </ul> |  |  |  |
| 2)                                  | With Soft Go-around<br>Function<br>Mod. 161254/<br>MP P13922    | С | 1 | 0   | <ul> <li>(M) May be inoperative provided:</li> <li>a) All thrust lever sensors are<br/>verified to operate normally,</li> <li>b) Approach minimums do not<br/>require its use, and</li> <li>c) Soft Go-Around function is<br/>considered inoperative.</li> </ul>                    |  |  |  |
|                                     |   |   |   |   | NOTE: Alpha floor is not available<br>with autothrust function<br>inoperative.  |  |  |  |
| 22-30-02                            | Autothrust Instinctive<br>Disconnect Switches                   | С | 2 | 1   | (O) One may be inoperative provided<br>ability to disconnect A/THR by means<br>of the remaining Instinctive<br>Disconnect pb and by the FCU<br>A/THR pb is verified prior to each<br>departure.   |  |  |  |
| 22-30-03                            | Autothrust<br>Disengagement Warning<br>System                   | С | 1 | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) Autothrust is disconnected<br/>and is considered inoperative,<br/>and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul>  |  |  |  |
|                                     |   |   |   |   | NOTE: Alpha floor is not available.   |  |  |  |

|                                     | MENT OF TRANSPORTATI<br>IATION ADMINISTRATION                            | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|-------------------------------------|--|----|---|-------------------------------|---|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |    |   |                               | PAGE NO. 22-4   |  |  |  |
| AIRCRAFT:<br>Airbus A320            |  |    |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 22. Autoflight                      |  |    |   | <b>I</b> .                    | La Change   |  |  |  |
| Sequence No.<br>22-63-01            | Item<br>Yaw Dampers  | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 1)                                  | System 1   | С  | 1 | 0                             | May be inoperative provided:<br>a) System 2 is operative, and<br>b) Approach minimums do not<br>require its use.  |  |  |  |
| 2)                                  | System 2   | С  | 1 | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) System 2 is deactivated in case of actuator leakage,</li> <li>b) System 1 is operative, and</li> <li>c) Approach minimums do not require its use.</li> </ul>                            |  |  |  |
| 22-66-01                            | Flight Augmentation<br>Computers (FAC)                                   |    |   |                               |   |  |  |  |
| 1)                                  | FAC 2<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder))        | С  | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Both FCU channels operate normally,</li> <li>b) ELAC, SEC, ADIRS, SFCC, RA, and LGCIU systems operate normally, and</li> <li>c) Approach minimums do not require its use.</li> </ul> |  |  |  |
|                                     |  |    |   |                               | Direct Law Mode at landing gear down.   |  |  |  |
| 22-66-02                            | FAC pb Switch  |    |   |                               |   |  |  |  |
| 1)                                  | FAULT Lights<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)) | С  | 2 | 1                             | One may be inoperative.   |  |  |  |
| 2)                                  | OFF Lights<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder))   | С  | 2 | 0                             | One or both may be inoperative.   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|---|---|---|---|--|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |   |   |   |   | PAGE NO. 22-5  |  |  |  |
|  |   |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 22. Autoflight   |   |   |   |   | Change   |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3 | 4 Change<br>Bar  |  |  |  |
| 22-66-03   | Windshear<br>Detection/Guidance and<br>Avoidance Systems      |   |   |   |  |  |  |  |
| 1)   | Windshear Warning and<br>Flight Guidance System<br>(Reactive) | В | - | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |  |  |  |
|  |   |   |   |   | NOTE: Operator's alternate<br>procedures should include<br>reviewing windshear<br>avoidance and windshear<br>recovery procedures.  |  |  |  |
|  |   | С | - | 0 | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) Windshear Detection and<br/>Avoidance System<br/>(Predictive) operates<br/>normally.</li> </ul> |  |  |  |
| 22-72-01   | Flight Management<br>System (FMS)                             |   |   |   |  |  |  |  |
| 1)   | FMS 1   | С | 1 | 0 | <ul> <li>(O) Except for ETOPS, may be inoperative provided:</li> <li>a) FMS 2 is operative, and</li> <li>b) Operations/procedures do not require its use.</li> </ul>   |  |  |  |
|  |   |   |   |   | NOTE: Without Mod. 34825/<br>MP P8799, GPWS Terrain<br>system (installed by<br>Mod. 26526/MP P4885 or<br>Mod. 34637/MP P8454) is<br>considered inoperative.  |  |  |  |
|  |   |   |   |   | (Continued)  |  |  |  |

| -                              | IENT OF TRANSPORTATIO   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------------|---|----|---|---|--|
| REVISION NO.<br>DATE: XX/XX/X  | -   |    |   |   | PAGE NO. 22-6  |
| AIRCRAFT:<br>Airbus A320       |   |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight<br>Sequence No. | ltem  | 1  | 2 | 3 | 4 Change   |
| 22-72-01                       | Flight Management<br>System (FMS)<br>(Cont'd)                   | 1  | 2 | 3 | 4 Bar  |
| 2)                             | FMS 2   | С  | 1 | 0 | <ul> <li>(O) May be inoperative provided:</li> <li>a) FMS 1 is operative, and</li> <li>b) Operations/procedures do not require its use.</li> </ul> |
| 3)                             | Performance Information   | С  | 2 | 0 | (O) May be inoperative provided<br>operations/procedures do not require<br>their use.  |
| 4)                             | Fuel/Time Predictions   | С  | 2 | 0 | (O) May be inoperative provided<br>operations/procedures do not require<br>their use.  |
| 22-75-01<br>***                | RNP pb switch ON Light  | D  | 1 | 0 | May be inoperative.  |
| 22-75-02<br>***                | RNP pb switch   | D  | 1 | 0 | May be inoperative provided operations/procedures do not require its use.  |
| 22-76-01                       | T.O SURV pb-sw<br>(With Mod. 162728/<br>MP P20485)              | С  | 1 | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
| 22-76-02                       | T.O SURV pb-sw OFF<br>Light<br>(With Mod. 162728/<br>MP P20485) | D  | 1 | 0 | May be inoperative.  |

| -                                   | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                         | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------------|--|----|---|----------------|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |    |   |                | PAGE NO. 22-7  |
| AIRCRAFT:<br>Airbus A320            |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight                      |  |    |   |                |  |
| Sequence No.                        | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 22-81-01                            | FCU  |    |   |                |  |
| 1)                                  | Channels<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)) | В  | 2 | 1              | (O) Except for ETOPS, one may be<br>inoperative provided 2 RMPs, all<br>DUs, both RAs, both LGCIUs, both<br>FACs, both cabin pressure<br>controllers, the three ADIRS, and<br>standby altimeter (or ISIS<br>Baro-altimeter function) operate<br>normally.  |
|                                     |  | A  | 2 | 1              | (O) One may be inoperative for<br>1 flight-leg provided 2 RMPs, all DUs,<br>both RAs, both LGCIUs, both FACs,<br>both cabin pressure controllers, the<br>three ADIRS, and standby altimeter<br>(or ISIS Baro-altimeter function)<br>operate normally.      |
| 2)                                  | Channels<br>(Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder))    | В  | 2 | 1              | (O) Except for ETOPS, one may be<br>inoperative provided 2 RMPs, all<br>DUs, both RAs, both LGCIUs, both<br>FMGCs, both cabin pressure<br>controllers, the three ADIRS, and<br>standby altimeter (or ISIS<br>Baro-altimeter function) operate<br>normally. |
|                                     |  | A  | 2 | 1              | (O) One may be inoperative for<br>1 flight-leg provided 2 RMPs, all DUs,<br>both RAs, both LGCIUs, both<br>FMGCs, both cabin pressure<br>controllers, the three ADIRS, and<br>standby altimeter (or ISIS<br>Baro-altimeter function) operate<br>normally.  |

| -                        | MENT OF TRANSPORTATION                           | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|---|----------------|--|
| REVISION NO              | . 32   |    |   |                | PAGE NO. 22-8  |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight           |  |    |   |                |  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 22-81-02                 | FMA Indications on PFD                           |    |   |                |  |
| 1)                       | Autopilot/Flight Director<br>Related Indications | С  | 2 | 1              | (O) Indications may be inoperative on PNF FMA.   |
|                          |  | В  | 2 | 0              | <ul> <li>(O) Except for ETOPS, indications<br/>may be inoperative on both FMAs<br/>provided: <ul> <li>a) Autopilots/Flight Directors are<br/>not engaged,</li> <li>b) Enroute operations do not<br/>require their use, and</li> <li>c) Approach minimums do not<br/>require use of autopilot.</li> </ul> </li> </ul> |
| 2)                       | Autothrust Related<br>Indications                | A  | 2 | 1              | Indications may be inoperative on<br>PNF FMA provided repairs are made<br>within 3 flight-days.  |
|                          |  | С  | 2 | 0              | <ul> <li>(O) Indications may be inoperative on<br/>both FMAs provided: <ul> <li>a) Autothrust is disconnected<br/>and considered inoperative,<br/>and</li> <li>b) Approach minimums do not<br/>require their use.</li> </ul> </li> </ul>   |
| 3)                       | Approach and Landing<br>Capabilities             | С  | - | -              | (O) One or more may be inoperative<br>on one FMA provided approach<br>minimums do not require their use.   |
|                          |  | С  | - | 0              | (O) One or more may be inoperative<br>on both FMAs provided approach<br>minimums do not require use.   |
| 22-81-03                 | Autoflight Control Panel                         |    |   |                |  |
|                          | -  |    |   |                |  |
| 1)                       | Mode Engagement pb                               |    |   |                |  |
| a)                       | LOC  | С  | 1 | 0              | May be inoperative provided<br>approach minimums do not require its<br>use.  |
|                          |  |    |   |                | (Continued)  |

| -                           | MENT OF TRANSPORTATIO  | NC |   |               | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|--|----|---|---------------|--|
| REVISION NO<br>DATE: XX/XX/ |  |    |   | PAGE NO. 22-9 |  |
| AIRCRAFT:<br>Airbus A320    |  |    |   |               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight              |  |    |   |               | Change   |
| Sequence No.<br>22-81-03    | Item<br>Autoflight Control Panel<br>(Cont'd)                         | 1  | 2 | 3             | 4 Change<br>Bar  |
| 1)                          | Mode Engagement pb<br>(Cont'd)                                       |    |   |               |  |
| b)                          | EXPED<br>(Without Mod. 24414/<br>MP P3401)                           | С  | 1 | 0             | May be inoperative provided crew procedures do not require its use.  |
| c)                          | APPR   | С  | 1 | 0             | (O) May be inoperative provided procedures do not require its use.   |
| 2)                          | Selection Windows<br>(Without Mod. 24035,<br>24160, 23963, or 24211) | С  | 4 | 2             | <ul> <li>SPD MACH and HDG TRK windows may be inoperative provided:</li> <li>a) Associated indications are operative on both PFDs and both NDs, and</li> <li>b) Procedures are not dependent of their use.</li> </ul>           |
| 3)                          | Selection Windows<br>(With Mod. 24035,<br>24160, 23963, or 24211)    | С  | 4 | 1             | <ul> <li>SPD MACH, HDG TRK, and V/S FPA windows may be inoperative provided:</li> <li>a) Associated indications are operative on both PFDs and both NDs, and</li> <li>b) Procedures are not dependent of their use.</li> </ul> |
| 4)                          | HDG-V/S TRK-FPA<br>Changeover pb                                     | С  | 1 | 0             | <ul> <li>May be inoperative provided:</li> <li>a) HDG-V/S selection is operative, and</li> <li>b) Crew procedures do not require use of pb.</li> </ul>   |
| 5)                          | SPD/MACH<br>Changeover pb  | С  | 1 | 0             | May be inoperative provided SPD selection is operative.  |
|                             |  |    |   |               | (Continued)  |

| -                            | MENT OF TRANSPORTATION                       | NC |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/2 |  |    |   | PAGE NO. 22-10 |  |
| AIRCRAFT:<br>Airbus A320     |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight               |  |    |   |                | Change   |
| Sequence No.<br>22-81-03     | Item<br>Autoflight Control Panel<br>(Cont'd) | 1  | 2 | 3              | 4 Change<br>Bar  |
| 6)                           | Metric ALT pb                                | С  | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
|                              |  | D  | 1 | 0              | May be inoperative provided operations do not require its use.   |
| 7)                           | Engagement pb Light<br>Bars                  | D  | - | 0              | May be inoperative provided<br>associated indication is available on<br>both PFDs.   |
| 8)                           | V/S-FPA Selection Knob                       | С  | 1 | 0              | May be inoperative provided procedures do not require its use.   |
| 9)<br>***                    | V/S-FPA Push-to Level<br>Off Function        | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) V/S-FPA selection knob<br/>operates normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>            |
| 22-81-04                     | EFIS Control Panel                           |    |   |                |  |
| 1)                           | Baro Reference Display<br>Windows            | С  | 2 | 1              | One may be inoperative.  |
| 2)                           | Baro Reference Sel<br>Outer Ring<br>(Hg/hPa) |    |   |                |  |
| a)                           | Hg   | С  | 2 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Route of flight does not<br/>require its use, and</li> <li>b) Both hPa indications are<br/>available on EFIS control<br/>panel.</li> </ul> |
|                              |  |    |   |                | (Continued)  |

| -                            |  | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|----|----------------|--|
|                              | ATION ADMINISTRATION                                     |    |    |                |  |
| REVISION NO.<br>DATE: XX/XX/ | -  |    |    |                | PAGE NO. 22-11   |
| AIRCRAFT:<br>Airbus A320     |  |    | T  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 22. Autoflight               |  | 1  |    | 1              |  |
| Sequence No.                 | Item   | 1  | 2  | 3              | 4 Change<br>Bar  |
| 22-81-04                     | EFIS Control Panel<br>(Cont'd)                           |    |    |                |  |
| 2)                           | Baro Reference Sel<br>Outer Ring<br>(Hg/hPa)<br>(Cont'd) |    |    |                |  |
| b)                           | hPa  | С  | 2  | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Route of flight does not require its use, and</li> <li>b) Both Hg indications are available on EFIS control panel.</li> </ul>                    |
| 3)                           | ILS/LS pb  | С  | 2  | 0              | One or both may be inoperative<br>provided the associated ILS, FLS,<br>GLS are considered inoperative.   |
| 4)                           | Optional Data Display pb                                 | С  | 10 | 0              | May be inoperative provided<br>operations/procedures do not require<br>their use.  |
| 5)                           | ND Range   | С  | 2  | 1              | (O) One may be inoperative provided<br>the ND unit associated with the<br>operative ND range selector is<br>operative.   |
| 6)                           | ND Mode Select   | С  | 2  | 1              | <ul> <li>(O) One may be inoperative provided:</li> <li>a) ND unit associated with the operative ND selector is operative, and</li> <li>b) Operations/procedures do not require its use.</li> </ul> |
| 7)                           | ADF/VOR Sel  | С  | 4  | -              | As required by 14 CFR.   |
| 8)                           | Display pb Light Bars                                    | D  | 14 | 0              | May be inoperative provided<br>associated indication is available on<br>associated PFD or ND.  |

|                          | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|----|---|----------------|---|
| <b>REVISION NO</b>       | . 32   |    |   |                | PAGE NO. 22-12  |
| DATE: XX/XX/             | XXXX   |    |   |                |   |
| AIRCRAFT:<br>Airbus A320 |  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 22. Autoflight           |  | -  | 1 |                | Change  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 22-81-06                 | Automatic Landing<br>System (AUTOLAND)                             | С  | 1 | 0              | May be inoperative provided<br>approach minimums do not require its<br>use.   |
| 22-82-01                 | Multipurpose Control<br>Display Units (MCDU)                       |    |   |                |   |
| 1)                       | Flightcrew Positions   | С  | 2 | 1              | One may be inoperative provided navigation procedures do not require its use.   |
| 2)<br>***                | Maintenance MCDU   | С  | 1 | 0              | May be inoperative provided first officer's MCDU operates normally.   |
| 3)<br>***                | MCDU Annunciator<br>Lights   | С  | - | 0              | One or more may be inoperative.   |
| 22-83-01                 | Flight Management<br>Guidance Computer<br>(FMGC)                   |    |   |                |   |
| 1)                       | FMGC 1<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)) | А  | 1 | 0              | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) FMGC 1 is deactivated,</li> <li>b) FMGC 2 is operative,</li> <li>c) Alternate procedures are established and used,</li> <li>d) Associated Autopilot and Flight Director are considered inoperative,</li> <li>e) Associated ILS DME displayed on PFD is considered inoperative. (With Mod. 150603/MP P11675), and</li> <li>f) Repairs are made within 3 flight-legs.</li> </ul> </li> </ul> |
|                          |  |    |   |                | (Continued)   |

| FEDERAL AVIATION ADMINISTRATION     |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|-------------------------------------|--|---|---|----------------|---|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |   |   |                | PAGE NO. 22-13  |  |  |  |
|                                     |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 22. Autoflight                      |  |   |   |                |   |  |  |  |
| Sequence No.                        | ltem   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |
| 22-83-01                            | Flight Management<br>Guidance Computer<br>(FMGC)<br>(Cont'd)                   |   |   |                |   |  |  |  |
| 1)                                  | FMGC 1<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder))<br>(Cont'd) |   |   |                | NOTE 1: (Without Mod. 34825/<br>MP P8799) If FMGC 1 is<br>inoperative, the GPWS<br>Terrain system (installed by<br>Mod. 26526/MP P4885<br>or Mod. 34637/MP P8454)<br>is considered inoperative.<br>NOTE 2: When FMGC 1 is<br>deactivated, the F/CTL<br>MAINTENANCE message is<br>displayed on the ECAM  |  |  |  |
| 2)                                  | FMGC 2   | A | 1 | 0              | <ul> <li>STATUS page.</li> <li>(M)(O) May be inoperative provided: <ul> <li>a) FMGC 2 is deactivated,</li> <li>b) FMGC 1 must be operative,</li> <li>c) Alternate procedures are established and used,</li> <li>d) Associated Autopilot and Flight Director are considered inoperative,</li> <li>e) Associated ILS DME displayed on PFD is considered inoperative (With Mod. 150603/MP P11675), and</li> <li>f) Repairs are made within 3 flight-legs.</li> </ul> </li> </ul> |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|----|----------------|---|
| REVISION NO. 32  |  |   |    |                | PAGE NO. 23-1   |
| DATE: XX/XX/   | XXXX   |   |    |                |   |
| AIRCRAFT:<br>Airbus A320   |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communic   | ations   |   |    |                |   |
| Sequence No.   | Item   | 1 | 2  | 3              | 4 Change<br>Bar   |
| 23-00-00   | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |   |    |                |   |
| 1)   | Fault(s) Indicated by CIDS 1(2)  | С | -  | -              | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |
| 23-11-01   | High Frequency (HF)<br>Communication System  |   |    |                |   |
| 1)   | LRCS   | D | -  | -              | Any in excess of those required by 14 CFR may be inoperative.   |
|  |  | С | -  | 1              | <ul> <li>(O) May be inoperative while<br/>conducting operations that require<br/>two LRCS provided: <ul> <li>a) Aircraft SATVOICE system<br/>operates normally,</li> <li>b) SATVOICE services are<br/>available as an LRCS over<br/>the intended route of flight,</li> <li>c) The ICAO Flight Plan is<br/>updated (as required) to notify<br/>ATC of the communications<br/>equipment status of the<br/>aircraft, and</li> <li>d) Alternate procedures are<br/>established and used.</li> </ul> </li> </ul> |
|  |  |   |    |                | (Continued)   |

| U.S. DEPART                | MENT OF TRANSPORTATI                                    | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------|---|----|---|----------------|--|
| FEDERAL AV                 | IATION ADMINISTRATION                                   |    |   |                |  |
| REVISION NO<br>DATE: XX/XX |   |    |   |                | PAGE NO. 23-2  |
| AIRCRAFT:<br>Airbus A320   |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 23. Communio               | cations   |    |   |                |  |
| Sequence No.               | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 23-11-01                   | High Frequency (HF)<br>Communication System<br>(Cont'd) |    |   |                |  |
| 2)<br>***                  | GND HF DATALINK<br>pb-sw                                | D  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) All HFs are set to VOICE<br/>mode on ground, and</li> <li>b) No HF is used during refuel,<br/>defuel or ground fuel transfer.</li> </ul>                                 |
| 3)<br>***                  | GND HF DATALINK<br>pb-sw OVRD Light                     | D  | 1 | 0              | May be inoperative.  |
| 4)<br>***                  | COM HF 1(2) EMITTING<br>Caution on ECAM EWD             | С  | 2 | -              | <ul> <li>(M) May be displayed on the EWD provided:</li> <li>a) The caution COM HF 1(2) EMITTING is confirmed to be false by troubleshooting, and</li> <li>b) Affected HF is deactivated and considered inoperative.</li> </ul> |
| 23-12-01                   | VHF Communications<br>System                            |    |   |                |  |
| 1)                         | Voice   | D  | - | -              | Any in excess of those required by<br>14 CFR may be inoperative provided<br>it is not powered by an Essential Bus<br>and not required for emergency<br>procedures.   |
| 2)<br>***                  | Datalink  |    |   |                |  |
| a)                         | With ACARS  | D  | 1 | 0              | May be inoperative provided ACARS is considered inoperative.   |
| b)                         | With ATSU   | С  | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
|                            |   | D  | 1 | 0              | (O) May be inoperative provided operations or procedures do not require its use.   |
|                            |   |    |   |                | (Continued)  |

| U.S. DEPART              | MENT OF TRANSPORTATI  | ON |          |                |  | о <b>т</b> |
|--------------------------|---|----|----------|----------------|--|------------|
| FEDERAL AV               | IATION ADMINISTRATION   |    |          |                | MASTER MINIMUM EQUIPMENT LIS   | ST         |
| <b>REVISION NC</b>       | ). 32   |    |          |                | PAGE NO. 23  | 3-3        |
| DATE: XX/XX/             | /XXXX   |    |          |                |  |            |
| AIRCRAFT:<br>Airbus A320 |   |    | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |            |
| 23. Communic             | cations   |    | <u> </u> |                |  |            |
| Sequence No.             | ltem  | 1  | 2        | 3              | 4 Char<br>Ba   |            |
| 23-12-01                 | VHF Communications<br>System<br>(Cont'd)                        |    |          |                |  |            |
| 3)<br>***                | COM VHF 1(2)(3)<br>EMITTING Caution on<br>ECAM EWD              | С  | 3        | -              | <ul> <li>(M) COM VHF 1(2(3) EMITTING caution may be displayed on EWD provided:</li> <li>a) COM VHF 1(2(3) EMITTING caution is confirmed to be false by troubleshooting, and</li> <li>b) Affected VHF is deactivated and considered inoperative.</li> </ul>                         |            |
| 23-13-01                 | Radio Management<br>Panels (RMP)                                |    |          |                |  |            |
| 1)                       | RMP 1<br>(Without Mod. 162344/<br>MP P20240 for Digital<br>RMP) |    |          |                |  |            |
| a)                       | VHF Comm Select Keys  | С  | 3        | 2              | VHF 2 or VHF 3 may be inoperative.   |            |
| b)                       | HF Comm Select Keys   | С  | 2        | -              | As required by 14 CFR.   |            |
|                          |   |    |          |                | NOTE: If HF is required for flight,<br>HF 1 select key must be<br>operative.   |            |
| 2)                       | RMP 1<br>(With Mod. 162344/<br>MP P20240 for Digital<br>RMP)    |    |          |                |  |            |
| a)                       | RMP 1 Keys  | С  | -        | -              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) VHF 1 communication is checked operative on one RMP,</li> <li>b) If HF is required, HF 1 communication is checked operative on one RMP, and</li> <li>c) XPDR selection is checked operative on RMP 1.</li> </ul> </li> </ul> |            |
|                          |   |    |          |                | (Continued)  |            |

| U.S. DEPART                | MENT OF TRANSPORTATION   | ON |   |     | MASTER MINIMUM EQUIPMENT  | тет           |
|----------------------------|--|----|---|-----|---|---------------|
| FEDERAL AV                 | IATION ADMINISTRATION  |    |   |     |   | LIGT          |
| REVISION NO<br>DATE: XX/XX |  |    |   |     | PAGE NO   | . 23-4        |
|                            |  |    | Т | ABL | EKEY  |               |
| AIRCRAFT:<br>Airbus A320   |  |    |   |     | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 23. Communi                | cations  |    | l |     |   |               |
| Sequence No.               | ltem   | 1  | 2 | 3   | 4   | Change<br>Bar |
| 23-13-01                   | Radio Management<br>Panels (RMP)<br>(Cont'd)                             |    |   |     |   |               |
| 2)                         | RMP 1<br>(With Mod. 162344/<br>MP P20240 for Digital<br>RMP)<br>(Cont'd) |    |   |     |   | <br>          |
| b)                         | RMP 1 Reception Knob   | С  | - | 0   | <ul> <li>May be inoperative provided:</li> <li>a) VHF1 reception knob is operative on one RMP, and</li> <li>b) If HF is required, HF 1 reception knob is operative on one RMP.</li> </ul>                                   | I             |
| 3)                         | RMP 2<br>(Without Mod 162344/<br>MP P20240 for Digital<br>RMP)           | С  | 1 | 0   | May be inoperative provided RMP 3 operates normally.  | <br>          |
| a)                         | VHF Comm Select Keys   | с  | 3 | 2   | One may be inoperative.   |               |
| b)                         | HF Comm Select Keys  | С  | 2 | -   | As required by 14 CFR.  |               |
| 4)                         | RMP 2<br>(With Mod 162344/<br>MP P20240 for Digital<br>RMP)              | С  | 1 | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) RMP 2 is set to OFF, and</li> <li>b) F/O wears a boomset for<br/>entire flight, and</li> <li>c) RMP 3 operates normally.</li> </ul>                                   |               |
| a)                         | RMP 2 Keys   | С  | - | 0   | <ul> <li>(O) May be inoperative provided:</li> <li>a) VHF 1 communication is<br/>checked operative on one<br/>RMP, and</li> <li>b) If HF is required, HF1<br/>communication is checked<br/>operative on one RMP.</li> </ul> |               |
|                            |  |    |   |     | Deleted, Revision 32.   |               |
|                            |  |    |   |     | (Continued)   |               |

|  |   | ON |   |                | MASTER MINIMUM EQUIPMEN  | LIST          |  |  |  |
|--|---|----|---|----------------|--|---------------|--|--|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 32 |   |    |   |                | PAGE NO. 23-5  |               |  |  |  |
| DATE: XX/XX/                                       |   |    |   |                | PAGE NO  | 0. 23-5       |  |  |  |
|  |   |    |   |                |  |               |  |  |  |
| AIRCRAFT:<br>Airbus A320                           |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |  |
| 23. Communic                                       | ations  |    |   |                |  |               |  |  |  |
| Sequence No.                                       | Item  | 1  | 2 | 3              | 4  | Change<br>Bar |  |  |  |
| 23-13-01   | Radio Management<br>Panels (RMP)<br>(Cont'd)                            |    |   |                |  |               |  |  |  |
| 4)   | RMP 2<br>(With Mod 162344/<br>MP P20240 for Digital<br>RMP)<br>(Cont'd) |    |   |                |  | <br>          |  |  |  |
| b)   | RMP 2 Reception Knob  | С  | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) VHF 1 reception knob is operative on one RMP, and</li> <li>b) If HF is required, HF 1 reception knob is operative on one RMP.</li> </ul>   | Ι             |  |  |  |
|  |   |    |   |                | Deleted, Revision 32.  | Ι             |  |  |  |
| 5)<br>***  | RMP 3<br>(Without Mod 162344/<br>MP P20240 for Digital<br>RMP)          | С  | 1 | 0              | May be inoperative provided RMP 2 operates normally.   |               |  |  |  |
| a)   | VHF Comm Select Keys  | С  | 3 | 2              | One may be inoperative.  |               |  |  |  |
| b)   | HF Comm Select Keys   | С  | 2 | -              | As required by 14 CFR.   |               |  |  |  |
| 6)   | RMP 3<br>(With Mod 162344/<br>MP P20240 for Digital<br>RMP)             | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) RMP 3 is set to OFF,</li> <li>b) Alternate procedure is<br/>established and used for<br/>cockpit to ground<br/>communication, and</li> <li>c) No crewmember on duty<br/>occupies observer seat.</li> </ul> |               |  |  |  |
|  |   |    |   |                | (Continued)  |               |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LI  | ST          |
|--|---|---|---|----------------|--|-------------|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |   |   |   |                | PAGE NO. 23  | 3-6         |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |             |
| 23. Communica  | ations  |   |   |                |  |             |
| Sequence No.   | Item  | 1 | 2 | 3              |  | ange<br>Bar |
| 23-13-01   | Radio Management<br>Panels (RMP)<br>(Cont'd)  |   |   |                | B  | sar         |
| 6)   | RMP 3<br>(With Mod 162344/<br>MP P20240 for Digital<br>RMP)<br>(Cont'd)                     |   |   |                |  |             |
| a)   | RMP 3 Keys  | С | - | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) VHF 1 communication is<br/>checked operative on one<br/>RMP, and</li> <li>b) If HF is required, HF 1<br/>communication is checked<br/>operative on one RMP.</li> </ul> | <br> <br>   |
|  |   |   |   |                | Deleted, Revision 32.  |             |
| b)   | RMP 3 Reception Knob  | С | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) VHF 1 reception knob is operative on one RMP, and</li> <li>b) If HF is required, HF 1 reception knob is operative on one RMP.</li> </ul>                                   |             |
|  |   |   |   |                | Deleted, Revision 32.  | I           |
| 23-14-01   | Audio Management Unit<br>(AMU) Side<br>(With Mod 162344/<br>MP P20240 for 3 Digital<br>RMP) | С | 2 | 1              | <ul> <li>(O) AMU side 2 may be inoperative provided:</li> <li>a) RMP 1 is operative, and</li> <li>b) RMP1 XPDR1/TCAS backup control mode is checked operative.</li> </ul>  | <br>        |

|                          | MENT OF TRANSPORTATION                  | ON |   | MASTER MINIMUM EQUIPMENT LIST   |  |               |  |  |
|--------------------------|---|----|---|---|--|---------------|--|--|
| REVISION NO. 32          |   |    |   |   | PAGE NC  | . 23-7        |  |  |
| DATE: XX/XX/             | XXXX                                    |    |   |   |  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |               |  |  |
| 23. Communic             | ations                                  | •  |   |   |  |               |  |  |
| Sequence No.             | Item                                    | 1  | 2 | 3   | 4  | Change<br>Bar |  |  |
| 23-24-01                 | ACARS System                            | С  | 1 | 0   | (O) May be inoperative provided<br>alternate procedures are established<br>and used. |               |  |  |
|                          |   |    |   |   | NOTE: Any ACARS function or Mode<br>that operates normally may be<br>used.           |               |  |  |
|                          |   | D  | 1 | 0   | May be inoperative provided procedures do not require its use.                       |               |  |  |
|                          |   |    |   |   | NOTE: Any ACARS function or Mode<br>that operates normally may<br>be used.           |               |  |  |
| 23-28-01<br>***          | Satellite Communication (SATCOM) System | С  | 1 | 0   | (O) May be inoperative provided alternate procedures are established and used.       |               |  |  |
|                          |   | D  | 1 | 0   | May be inoperative provided operations or procedures do not require its use.         |               |  |  |
| 1)                       | Voice Channels                          | С  | - | 0   | (O) May be inoperative provided alternate procedures are established and used.       |               |  |  |
|                          |   | D  | - | 0   | May be inoperative provided operations or procedures do not require its use.         |               |  |  |
| 2)                       | Data Channel                            | С  | 1 | 0   | (O) May be inoperative provided<br>alternate procedures are established<br>and used. |               |  |  |
|                          |   | D  | 1 | 0   | (O) May be inoperative provided operations or procedures do not require its use.     |               |  |  |

|                              | IENT OF TRANSPORTATION      |   |               | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|------------------------------|-----------------------------|---|---------------|-------------------------------|---|--|--|
| REVISION NO.<br>DATE: XX/XX/ | . 32                        |   | PAGE NO. 23-8 |                               |   |  |  |
|                              |                             |   |               | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 23. Communic                 | ations                      |   |               |                               |   |  |  |
| Sequence No.                 | Item                        | 1 | 2             | 3                             | 4 Change<br>Bar   |  |  |
| 23-31-01                     | Passenger Address<br>System |   |               |                               |   |  |  |
| 1)                           | Passenger Configuration     | В | 1             | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate, normal, and<br/>emergency procedures and/or<br/>operating restrictions are<br/>established and used, and</li> <li>b) Flight attendant alerting<br/>system (audio and visual)<br/>operates normally.</li> </ul> |  |  |
|                              |                             |   |               |                               | NOTE: Any station function(s) that<br>operates normally may be<br>used.   |  |  |
|                              |                             | С | 1             | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) PA not required by 14 CFR,<br/>and</li> <li>b) Alternate, normal, and<br/>emergency procedures and/or<br/>operating restrictions are<br/>established and used.</li> </ul>   |  |  |
|                              |                             |   |               |                               | NOTE: Any station function(s) that<br>operates normally may be<br>used.   |  |  |
| a)                           | Lavatory Speakers           | С | -             | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |
| b)                           | Cabin Speakers              | С | -             | -                             | May be inoperative provided<br>inoperative speakers are not adjacent<br>to each other.  |  |  |
| 23-31-02<br>***              | PA IN USE LIGHT             | D | 1             | 0                             | May be inoperative.   |  |  |
| 23-42-01                     | Ground External Horn        | С | 1             | 0                             | (O) May be inoperative provided<br>avionics equipment ventilation is<br>monitored in the cockpit while aircraft<br>is on the ground and aircraft electrical<br>network is supplied.   |  |  |

|                          | MENT OF TRANSPORTATI   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--------------------------|--|----|---|----------------|---|--|--|--|--|
| REVISION NO. 32          |  |    |   |                | PAGE NO. 23-9   |  |  |  |  |
| DATE: XX/XX/             |  |    |   |                |   |  |  |  |  |
|                          |  |    | т | ABL            | E KEY   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    |   | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 23. Communic             | cations  | 1  |   | 1              | 0.  |  |  |  |  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 23-42-02                 | Alerting System<br>(Chime/Light)                               |    |   |                |   |  |  |  |  |
| 1)<br>2)                 | Flight Attendant Call<br>Lights<br>(EMER/FWD/<br>MID EXIT/AFT) | В  | - | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) PA System is operative,</li> <li>b) Affected light is not used for Lavatory Smoke Detector Alerting, and</li> <li>c) Alternate procedures for contacting flight attendants are established and used.</li> </ul> </li> <li>NOTE 1: Passenger to Attendant Call System is considered an NEF item.</li> <li>NOTE 2: Any visual alerting system function(s) that operates normally may be used.</li> <li>(O) May be inoperative provided: <ul> <li>a) PA system operates normally,</li> <li>b) Affected Chime is not used for Lavatory Smoke Detector Alerting, and</li> <li>c) Alternate procedures for contacting flight attendants are established and used.</li> </ul> </li> <li>(O) May be inoperative provided: <ul> <li>a) PA system operates normally,</li> <li>b) Affected Chime is not used for Lavatory Smoke Detector Alerting, and</li> <li>c) Alternate procedures for contacting flight attendants are established and used.</li> </ul> </li> <li>NOTE 1: Passenger to Attendant Call System is considered an NEF item.</li> <li>NOTE 1: Passenger to Attendant Call System is considered an NEF item.</li> <li>NOTE 2: Any audio alerting system function(s) that operates normally may be used.</li> </ul> |  |  |  |  |
| 3)                       | ALL ATTND CALL   | D  | - | 0              | One or more may be inoperative.   |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|---|----------------|---|--|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |                | PAGE NO. 23-10  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 23. Communic   | ations   |   |   |                |   |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 23-43-01   | Flight Deck to Ground<br>Interphone System                 | В | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |  |
| 1)   | External Power Panel<br>Call Light                         | С | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |  |
| 2)   | External Power Panel<br>Call Switch                        | С | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |  |
| 23-43-02   | Crewmember Interphone<br>System                            |   |   |                |   |  |  |  |  |
| 1)   | Passenger Configuration                                    |   |   |                |   |  |  |  |  |
| a)   | Flight Deck to Cabin,<br>Cabin to Flight Deck<br>Functions | В | _ | -              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Flight deck to cabin and cabin<br/>to flight deck interphone<br/>functions operate normally on<br/>at least 50% of the cabin<br/>handsets, and</li> <li>b) Alternate communications<br/>procedures between the<br/>affected Flight Attendants<br/>station(s) are established and<br/>used.</li> </ul> |  |  |  |  |
|  |  |   |   |                | NOTE: Any station function(s) that<br>operates normally may be<br>used.   |  |  |  |  |
|  |  | С | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Crewmember interphone<br/>system not required by<br/>14 CFR, and</li> <li>b) Alternate, normal, and<br/>emergency procedures and/or<br/>operating restrictions are<br/>established and used.</li> </ul>   |  |  |  |  |
|  |  |   |   |                | NOTE: Any station function(s) that<br>operates normally may be<br>used.   |  |  |  |  |
|  |  |   |   |                | (Continued)   |  |  |  |  |

|                                     | IENT OF TRANSPORTATIO                               |   |   | MASTER MINIMUM EQUIPMENT LIST |   |
|-------------------------------------|---|---|---|-------------------------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |   |   |                               | PAGE NO. 23-11  |
| AIRCRAFT:<br>Airbus A320            |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communica                       |   |   |   |                               | Change  |
| Sequence No.<br>23-43-02            | Item<br>Crewmember Interphone<br>System<br>(Cont'd) | 1 | 2 | 3                             | 4 Change<br>Bar   |
| 1)                                  | Passenger Configuration (Cont'd)                    |   |   |                               |   |
| b)                                  | Cabin to Cabin Function                             | В | 2 | 0                             | <ul> <li>(O) May be inoperative provided<br/>alternate communications procedures<br/>between the affected flight attendants<br/>stations are established and used.</li> <li>NOTE: Any station function(s) that<br/>operates normally may be<br/>used.</li> </ul>  |
|                                     |   | В | - | _                             | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Cabin to cabin interphone functions operate normally on at least 50% of the cabin handsets, and</li> <li>b) Alternate communications procedures between the affected Flight Attendants station(s) are established and used.</li> </ul> </li> <li>NOTE: Any station function(s) that operates normally may be used.</li> </ul> |

|                             | MENT OF TRANSPORTATION             | ON |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|-----------------------------|------------------------------------|----|---|-------------------------------|--|--|--|--|
| REVISION NC<br>DATE: XX/XX/ |                                    |    |   | PAGE NO. 23-12                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320    |                                    |    | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 23. Communic                | cations                            |    | l |                               |  |  |  |  |
| Sequence No.                | Item                               | 1  | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 23-43-04                    | Handsets                           |    |   |                               |  |  |  |  |
| 1)                          | Passenger Configuration            |    |   |                               |  |  |  |  |
| a)                          | Flight Deck Handset                | С  | 1 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Flight Deck to cabin<br/>communication operates<br/>normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>  |  |  |  |
|                             |                                    | D  | 1 | 0                             | May be inoperative provided procedures do not require its use.   |  |  |  |
| b)                          | Cabin Attendant<br>Handsets        | В  | - | -                             | <ul> <li>(O) May be inoperative provided: <ul> <li>a) 50% of cabin handsets</li> <li>operate normally,</li> </ul> </li> <li>b) Operative handset(s) is <ul> <li>located at an operative flight</li> <li>attendant seat, and</li> </ul> </li> <li>c) Alternate procedures between <ul> <li>the affected Flight Attendants</li> <li>station(s) are established and</li> <li>used.</li> </ul> </li> </ul> |  |  |  |
|                             |                                    |    |   |                               | NOTE 1: Any operative handset at an<br>inoperative flight attendant<br>seat shall not be counted to<br>satisfy the 50%<br>requirement.   |  |  |  |
|                             |                                    |    |   |                               | NOTE 2: Any handset(s) function(s)<br>that operates normally may<br>be used.   |  |  |  |
| 23-44-01                    | Service Interphone Jack<br>Systems | С  | - | 0                             | One or more may be inoperative.  |  |  |  |
| 23-51-01<br>***             | Selcal (AMU)                       | С  | - | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |  |  |  |
|                             |                                    | D  | - | 0                             | May be inoperative provided procedures do not require its use.   |  |  |  |

| -                        | MENT OF TRANSPORTATI  | ION |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--------------------------|---|-----|---|---|---|--|--|--|
|                          | IATION ADMINISTRATION   |     |   |   |   |  |  |  |
| REVISION NO              |   |     |   |   | PAGE NO. 23-13  |  |  |  |
| DATE: XX/XX              | /XXXX   |     |   |   |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |     | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
| 23. Communi              | cations   |     |   |   |   |  |  |  |
| Sequence No.             | Item  | 1   | 2 | 3   | 4 Change<br>Bar   |  |  |  |
| 23-51-02                 | Audio Control Panel<br>(ACP)  |     |   |   |   |  |  |  |
| 1)                       | CAPT and F/O  | С   | 2 | 1   | <ul> <li>(O) One may be inoperative provided:</li> <li>a) ACP 3 operates normally, and</li> <li>b) AUDIO SWITCHING selector operates normally.</li> </ul>   |  |  |  |
| 2)                       | ACP 3   |     |   |   | See Primary Observer Seat for relief.   |  |  |  |
| 3)<br>***                | Fourth Occupant   | D   | 1 | 0   | One may be inoperative.   |  |  |  |
| 4)<br>***                | Avionics Compartment  | D   | 1 | 0   | One may be inoperative.   |  |  |  |
| 5)                       | ATT Call Lights<br>(Flight Deck Call<br>Lights/CAPT and<br>F/O ACP) | В   | 2 | 0   | May be inoperative provided the flight<br>deck buzzer is operative.<br>NOTE: The flight deck buzzer must<br>always be operative.  |  |  |  |
| 6)                       | Transmission Key(s)   | С   | - | -   | <ul> <li>One may be inoperative on each ACP provided:</li> <li>a) VHF 1 transmission key operates normally on either CAPT ACP or F/O ACP, and</li> <li>b) HF 1 transmission key (if HF 1 is required) operates normally on either CAPT ACP or F/O ACP.</li> </ul>   |  |  |  |
| 7)                       | Reception Knob(s)   | С   | - | -   | <ul> <li>One may be inoperative on each</li> <li>ACP provided: <ul> <li>a) VHF 1 reception knob</li> <li>operates normally on either</li> <li>CAPT ACP or F/O ACP, and</li> </ul> </li> <li>b) HF 1 reception knob (If HF 1 <ul> <li>is required) operates normally</li> <li>on either CAPT ACP or F/O</li> <li>ACP.</li> </ul> </li> </ul> |  |  |  |
| 8)                       | Reception Knob Light(s)   | С   | - | 0   | One or more may be inoperative.   |  |  |  |

| FEDERAL AV               | IATION ADMINISTRATION  |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |               |  |  |
|--------------------------|--|---|----------------|---|--|---------------|--|--|
| REVISION NO              |  |   | PAGE NO. 23-14 |   |  |               |  |  |
| DATE: XX/XX              | /XXXX  |   |                |   |  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |  |   | T              | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |               |  |  |
| 23. Communi              | cations  |   | 1              | 1   |  | Ohamma        |  |  |
| Sequence No.             | Item   | 1 | 2              | 3   | 4  | Change<br>Bar |  |  |
| 23-51-03                 | Switching Panel  |   |                |   |  |               |  |  |
| 1)                       | Audio Selector   | С | 1              | 0   | Must operate in NORM Position.   |               |  |  |
| 23-51-04                 | Flight Deck Headsets/<br>Headphones  | D | -              | -   | Any in excess of those required by 14 CFR may be inoperative.  |               |  |  |
| 1)                       | Headset Boom<br>Microphones  | A | -              | 0   | <ul> <li>May be inoperative provided:</li> <li>a) Associated hand microphone<br/>is installed and operates<br/>normally,</li> <li>b) Flight Data Recorder (FDR)<br/>operates normally, and</li> <li>c) Repairs are made within<br/>3 flight-days.</li> </ul> |               |  |  |
| 2)                       | Headset Earphones/<br>Headphones   | С | -              | 1   | Either Captain's or First Officer's<br>earphones/headphones may be<br>inoperative provided associated flight<br>deck speaker operates normally.  |               |  |  |
| 23-51-05                 | Hand Mic System  |   |                |   |  |               |  |  |
| 1)                       | CAPT/F/O   | С | 2              | 0   | May be inoperative provided associated boom microphones operate normally.  |               |  |  |
| 2)                       | Observers Seat(s)/<br>Avionics Compartment   | D | -              | 0   | May be inoperative or missing provided procedures do not require their use.  |               |  |  |
| 23-51-06                 | Cockpit Loudspeakers   |   |                |   |  |               |  |  |
| 1)                       | Without Digital RMP<br>(Without Mod. 162344/<br>MP P20240 (2 Digital<br>RMP) and without<br>Mod.162367/<br>MP P20323 (3 Digital<br>RMP)) | С | 2              | 1   | Only F/O's loudspeaker may be<br>inoperative provided at least one<br>crewmember on flight deck duty<br>wears a headset.   |               |  |  |
|                          |  |   |                |   | (Continued)  |               |  |  |

| FEDERAL AVIATION ADMINISTRATION |   |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|---------------------------------|---|---|----|----------------|---|--|--|--|--|
| REVISION NO. 32                 |   |   |    |                | PAGE NO. 23-15  |  |  |  |  |
| DATE: XX/XX/                    | XXXX  |   |    |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 23. Communic                    | ations  |   | •  |                |   |  |  |  |  |
| Sequence No.                    | ltem  | 1 | 2  | 3              | 4 Change<br>Bar   |  |  |  |  |
| 23-51-06                        | Cockpit Loudspeakers<br>(Cont'd)  |   |    |                |   |  |  |  |  |
| 2)                              | With Digital RMP<br>(With Mod. 162344/<br>MP P20240 (2 Digital<br>RMP),or with<br>Mod. 162367/<br>MP P20323 (3 Digital<br>RMP))           | С | 2  | 1              | One may be inoperative provided<br>crewmember on affected side<br>wears a headset for entire flight.  |  |  |  |  |
|                                 |   | С | 2  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both crewmembers wear a headset for entire flight, and</li> <li>b) Observer headset is checked operative.</li> </ul>  |  |  |  |  |
| 23-51-08                        | Side Stick Radio<br>Selector (PTT)  |   |    |                |   |  |  |  |  |
| 1)                              | Without Digital RMP<br>(Without Mod. 162344/<br>MP P20240 (2 Digital<br>RMP) and without<br>Mod. 162367/<br>MP P20323 (3 Digital<br>RMP)) | С | 2  | 0              | May be inoperative in open/neutral<br>position (non-transmitting position)<br>provided INT/RAD switches on CAPT<br>ACP, F/O ACP, and ACP3 operate<br>normally.  |  |  |  |  |
|                                 |   | С | 2  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) INT/RAD switches on CAPT<br/>ACP, F/O ACP, and ACP3<br/>operate normally, and</li> <li>b) Affected switch is deactivated<br/>in open/neutral position<br/>(non-transmitting position).</li> </ul> |  |  |  |  |
|                                 |   |   |    |                | (Continued)   |  |  |  |  |

|  | TMENT OF TRANSPORTATION                          | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|----|---|----------------|---|
| REVISION NO<br>DATE: XX/XX                     |  |    |   |                | PAGE NO. 23-16  |
| AIRCRAFT:<br>Airbus A320<br>23. Communications |  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| Sequence No.                                   | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 23-51-08                                       | Side Stick Radio Selector<br>(PTT)<br>(Cont'd)   |    |   |                | Bar   |
| 2)   | With 2 Digital RMP<br>(Mod 162344/<br>MP P20240) | С  | 2 | 0              | May be inoperative in open/neutral<br>position (non-transmitting position)<br>provided INT/RAD switches on<br>RMP1, on RMP2 and on ACP 3 are<br>operative.  |
|  |  | С  | 2 | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) INT/RAD switches on RMP 1,<br/>RMP 2, and ACP3 operate<br/>normally, and</li> <li>b) Affected switch is deactivated<br/>in open/neutral position (non-<br/>transmitting position).</li> </ul> |
| 3)   | With 3 Digital RMP<br>(Mod 162367/<br>MP P20323) | С  | 2 | 0              | May be inoperative in open/neutral<br>position (non-transmitting position)<br>provided INT/RAD switches on<br>RMP1, on RMP 2, and on RMP 3 are<br>operative.  |
|  |  | С  | 2 | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) INT/RAD switches on RMP 1,<br/>RMP 2, and RMP 3 operate<br/>normally, and</li> <li>b) Affected switch is deactivated<br/>in open/neutral position<br/>(non-transmitting position).</li> </ul> |

| REVISION NC                     | IATION ADMINISTRATION                                    |        | PAGE NO. 23-17 |                |   |
|---------------------------------|--|--------|----------------|----------------|---|
| DATE: XX/XX                     |  |        |                | FAGE NO. 23-17 |   |
|                                 |  |        |                |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communio                    | cations  | 1      |                |                | <u>.</u>  |
| Sequence No.<br>23-51-09<br>*** | Item<br>Passenger Audio<br>System<br>(Observer Position) | 1<br>D | 2              | 3<br>0         | 4 Change<br>Bar<br>May be inoperative.  |
| 23-71-01                        | Cockpit Voice Recorder<br>System (CVR)                   | A      | 1              | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Flight Data Recorder (FDR) operates normally, and</li> <li>b) Repairs are made within 3 flight-days.</li> </ul> |
| 23-71-02                        | RCDR Control Panel                                       |        |                |                |   |
| 1)                              | RCDR/GND CTL pb-sw                                       | А      | 1              | 0              | (O) May be inoperative in AUTO<br>position provided repairs are made<br>within 3 flight-days.   |
|                                 |  | С      | 1              | 0              | (O) May be inoperative in ON position.  |
|                                 |  | A      | 1              | 0              | <ul> <li>May be inoperative provided:</li> <li>a) CVR is considered<br/>inoperative, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul>        |
| 2)                              | RCDR/GND CTL pb-sw<br>ON Light                           | С      | 1              | 0              | May be inoperative.   |
| 3)                              | CVR Erase pb<br>(Without Mod. 168885/<br>MP K33628)      | D      | 1              | 0              | May be inoperative.   |
| 4)                              | CVR TEST pb  | A      | 1              | 0              | <ul> <li>May be inoperative provided:</li> <li>a) CVR is considered<br/>inoperative, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul>        |

|                          | MENT OF TRANSPORTATION  | ON |          |  | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|---|----|----------|--|---|
| REVISION NO              | 0. 32   |    |          |  | PAGE NO. 23-18  |
|                          |   |    | Т        |  |   |
| AIRCRAFT:<br>Airbus A320 |   |    | 2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |   |
| 23. Communic             | ations  |    |          |  |   |
| Sequence No.             | Item  | 1  | 2        | 3  | 4 Change<br>Bar   |
| 23-72-01                 | Flight Deck Door Visual<br>Surveillance Systems   |    |          |  |   |
| 1)<br>***                | Electric System (CDSS)<br>(With Mod. 36414/<br>MP K11047 or<br>Mod. 38111/MP K11684<br>or<br>Mod. 32087/MP K7778) | A  | 1        | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul>  |
|                          |   | С  | 1        | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) A flight deck door viewing port<br/>is installed and operates<br/>normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>                               |
|                          |   | D  | 1        | 0  | May be inoperative provided procedures do not require its use.  |
| a)                       | Cargo Configuration   | С  | 1        | 0  | May be inoperative provided the<br>aircraft aft of the flight deck door is<br>occupied only by those personnel<br>authorized by 14 CFR.   |
|                          |   | D  | 1        | 0  | May be inoperative provided procedures do not require its use.  |
| 2)<br>***                | Viewing Ports   | A  | 1        | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul>  |
|                          |   | С  | 1        | 0  | <ul> <li>(O) May be inoperative provided:</li> <li>a) An electronic flight deck door<br/>visual surveillance system is<br/>installed and operates<br/>normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul> |
|                          |   |    |          |  | (Continued)   |

|                          | MENT OF TRANSPORTATION                                      | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--------------------------|---|----|---|----------------|---|--|--|--|
| <b>REVISION NC</b>       | -   |    |   | PAGE NO. 23-19 |   |  |  |  |
| DATE: XX/XX/             | XXXX  |    |   |                |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   |                | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS   |  |  |  |
| 23. Communic             | cations   |    | - | -              |   |  |  |  |
| Sequence No.             | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |  |  |  |
| 23-72-01                 | Flight Deck Door Visual<br>Surveillance Systems<br>(Cont'd) |    |   |                |   |  |  |  |
| 2)<br>***                | Viewing Ports<br>(Cont'd)                                   |    |   |                |   |  |  |  |
|                          |   | D  | 1 | 0              | May be inoperative provided procedures do not require its use.  |  |  |  |
| a)                       | Cargo Configuration   | С  | 1 | 0              | May be inoperative provided the<br>aircraft aft of the flight deck door is<br>occupied only by those personnel<br>authorized by 14 CFR.   |  |  |  |
|                          |   | D  | 1 | 0              | May be inoperative provided procedures do not require its use.  |  |  |  |
| 23-73-01                 | Cabin<br>Intercommunication Data                            | С  | 2 | 1              | (M) One may be inoperative.   |  |  |  |
|                          | System (CIDS) CIDS<br>Director                              |    |   |                | NOTE 1: Failure of a single CIDS<br>director is indicated by a<br>MAINTENANCE message<br>on the STATUS SD page.<br>Refer to Item 23-00-00, 1)<br>Fault(s) Indicated by<br>CIDS 1(2).  |  |  |  |
|                          |   |    |   |                | NOTE 2: In the case of disturbance of<br>the CIDS function, the<br>deactivation/removal of the<br>affected CIDS director may<br>recover normal operation of<br>the CIDS function. Refer to<br>AMM TASK<br>23-73-00-040-001. |  |  |  |
|                          |   |    |   |                | (Continued)   |  |  |  |

| U.S. DEPART                 | MENT OF TRANSPORTATIO   | ON |   |                |   |
|-----------------------------|---|----|---|----------------|---|
| FEDERAL AV                  | IATION ADMINISTRATION   |    |   |                | MASTER MINIMUM EQUIPMENT LIST   |
| REVISION NC<br>DATE: XX/XX/ |   |    |   |                | PAGE NO. 23-20  |
| AIRCRAFT:<br>Airbus A320    |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communic                | cations   |    |   |                |   |
| Sequence No.                | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 23-73-01                    | Cabin<br>Intercommunication Data<br>System (CIDS) CIDS<br>Director<br>(Cont'd)                |    |   |                |   |
| 1)                          | Smoke Detection<br>Function Channels<br>(CIDS-SDF)<br>(With Mod. 30354 or with<br>Mod. 33100) | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Restrictions concerning<br/>inoperative lavatory smoke<br/>detection system are applied,<br/>and</li> <li>b) Procedures are established<br/>and used to ensure all cargo<br/>compartments remain empty<br/>or are verified to contain only<br/>empty cargo handling<br/>equipment, ballast (ballast<br/>may be loaded in ULDs),<br/>and/or Fly Away Kits.</li> </ul> </li> <li>NOTE 1: Failure of a single SDF<br/>channel is indicated by a<br/>MAINTENANCE message<br/>on ECAM STATUS page.</li> <li>NOTE 2: Operator MELs must define<br/>which items are approved<br/>for inclusion in the Fly Away<br/>Kits and which materials<br/>can be used as ballast.</li> <li>NOTE 3: Class E cargo<br/>compartments require only<br/>the installation of smoke or<br/>fire detection systems<br/>(not suppression).</li> </ul> |
| 2)<br>***                   | Emergency Cockpit<br>Alerting System (ECAS)   | С  | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |
|                             |   | D  | - | 0              | May be inoperative provided<br>operations or procedures do not<br>require its use.  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |        |   |   | MASTER MINIMUM EQUIPMENT LIS   | ST |
|--|---|--------|---|---|--|----|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |   |        |   |   | PAGE NO. 23-2  | 21 |
|  |   |        |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |    |
| 23. Communica  | ations  |        | 1 | 1 | م Char   |    |
| Sequence No.<br>23-73-02   | Item<br>Cabin<br>Intercommunication Data<br>System (CIDS) CIDS<br>DEU A | C<br>C | - | - | <ul> <li>4 Char Ba</li> <li>(M) May be inoperative provided:         <ul> <li>a) No two consecutive or adjacent DEUs are verified to be inoperative, and</li> <li>b) Lavatory speaker is verified to operate normally or return to seat sign is verified to operate normally for an associated inoperative DEU.</li> <li>(M) May be inoperative provided:</li> </ul> </li> </ul>   | ar |
|  |   |        |   |   | <ul> <li>a) No two consecutive or<br/>adjacent DEUs are verified to<br/>be inoperative, and</li> <li>b) Lavatory door is locked closed<br/>and placarded "INOPERATIVE<br/>– DO NOT ENTER" for an<br/>associated inoperative DEU.</li> <li>NOTE 1: These provisos are not<br/>intended to prohibit lavatory<br/>use or inspections by<br/>crewmembers.</li> <li>NOTE 2: The following items may be<br/>affected: Loudspeakers;<br/>No Smoking/Fasten Seat<br/>Belt Sign general<br/>illumination and Passenger<br/>Call.</li> </ul> |    |

| -  | MENT OF TRANSPORTATION                            | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|----|---|----------------|---|
| REVISION NO                              |   |    |   |                | PAGE NO. 23-22  |
| DATE: XX/XX/<br>AIRCRAFT:<br>Airbus A320 | XXXX  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communic                             | ations  |    |   |                |   |
| Sequence No.                             | ltem  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 23-73-03                                 | Cabin<br>Intercommunication Data<br>System (CIDS) |    |   |                |   |
| 1)                                       | CIDS DEU B  | С  | _ | -              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) DEU B and the associated handset are operative at each pair of floor level exit doors, and</li> <li>b) Alternate procedures are established and used.</li> </ul> </li> <li>NOTE: The following items may be affected: Cabin attendant station intercommunications; slide bottle pressure indications on PTP/FAP; lavatory smoke detection system; and door bottle pressure indication on PTP/FAP.</li> </ul> |
| 2)                                       | Attendant Indication<br>Panels (AIP)              | С  | - | 0              | May be inoperative at a non-required cabin attendant station.   |
|  |   | С  | - | 0              | <ul> <li>(O) May be inoperative at a required cabin attendant station provided: <ul> <li>a) Corresponding area call panel operates normally,</li> <li>b) Passenger address and cabin interphone at affected station operate normally, and</li> <li>c) Alternate procedures are established and used.</li> </ul> </li> </ul>   |
|  |   |    |   |                | (Continued)   |

| -                        | MENT OF TRANSPORTATION  | NC |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|---|----------------|--|
| REVISION NO              | D. 32   |    |   |                | PAGE NO. 23-23   |
| DATE: XX/XX              | /XXXX   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 23. Communi              | cations   |    |   |                |  |
| Sequence No.             | ltem  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 23-73-03                 | Cabin<br>Intercommunication Data<br>System (CIDS)<br>(Cont'd) |    |   |                |  |
| 3)                       | Area Call Panel   | С  | - | 0              | May be inoperative at non-required cabin attendant station.  |
|                          |   | С  | - | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Corresponding Attendant<br/>Indication Panel operates<br/>normally,</li> <li>b) Passenger address and cabin<br/>interphone at affected station<br/>operate normally, and</li> <li>c) Alternate procedures are<br/>established and used.</li> </ul> |
| 4)<br>***                | Additional Attendant<br>Panel (AAP)                           | D  | - | 0              | One or more may be inoperative.  |

| -                        | MENT OF TRANSPORTATION  | ON |   |   | MASTER MINIMUM EQUIPMENT  | LIST          |  |  |  |
|--------------------------|---|----|---|---|---|---------------|--|--|--|
| <b>REVISION NO</b>       | . 32  |    |   |   | PAGE NO. 2  | 23-24         |  |  |  |
| DATE: XX/XX/             | XXXX  |    |   |   |   |               |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS   |               |  |  |  |
| 23. Communic             | ations  |    |   |   |   |               |  |  |  |
| Sequence No.             | Item  | 1  | 2 | 3 | 4   | Change<br>Bar |  |  |  |
| 23-73-04                 | Forward Attendant Panel<br>(FAP)<br>(Without Mod. 30354 or<br>without Mod. 33100) | С  | - | 0 | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated FAP functions are considered inoperative, and</li> <li>b) Alternate procedures are established and used.</li> </ul> |               |  |  |  |
|                          |   |    |   |   | NOTE: LIGHT EMER pb must always be operative.   |               |  |  |  |
| 1)                       | Cabin Lighting Control<br>Functions on FAP  | С  | - | 0 | (O) May be inoperative provided<br>lighting is sufficient for cabin<br>attendants to perform their duties.  |               |  |  |  |
| 2)<br>***                | Prerecorded<br>Announcement and<br>Music Reproducer<br>Control on FAP             | D  | 1 | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |               |  |  |  |
| 3)<br>***                | CABIN READY on FAP  | D  | 1 | 0 | (O) May be inoperative provided alternate procedures are established and used.  |               |  |  |  |
| 4)<br>***                | EVAC Light/CMD pb   | D  | 1 | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |               |  |  |  |
| 5)<br>***                | SYSTEM INOP Light on<br>WATER WASTE Panel<br>on FAP                               | D  | 1 | 0 | (M) May be inoperative provided alternate procedures are established and used.  |               |  |  |  |
| 6)                       | Other Functions on FAP  | D  | - | 0 | (O) May be inoperative provided alternate procedures are established and used.  |               |  |  |  |
|                          |   |    |   |   | NOTE: LIGHT EMER pb must always be operative.   |               |  |  |  |
| 7)                       | CIDS Caution Light on<br>the Forward Attendant<br>Panel                           | С  | 1 | 0 | (M) May be inoperative provided that<br>PTP messages are checked before<br>each flight.   |               |  |  |  |

| FEDERAL AVI              | ATION ADMINISTRATION   |   |          |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|---|----------|----------------|---|
| <b>REVISION NO</b>       | -  |   |          | PAGE NO. 23-25 |   |
| DATE: XX/XX/             | XXXX   |   | <u> </u> |                |   |
| AIRCRAFT:<br>Airbus A320 |  |   | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communic             | ations   |   |          |                |   |
| Sequence No.             | ltem   | 1 | 2        | 3              | 4 Change<br>Bar   |
| 23-73-06                 | Programmed Cabin<br>Assignment Module<br>(CAM)                                       | С | 1        | 0              | May be inoperative.   |
| 23-73-07                 | Programming and Test<br>Panel (PTP)<br>(Without Mod. 30354 or<br>without Mod. 33100) | В | 1        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated PTP functions are considered inoperative, and</li> <li>b) Alternate procedures are established and used.</li> </ul> |
| 1)                       | SYS EMER LIGHT<br>TEST   | В | 1        | 0              | (M) May be inoperative provided<br>emergency lights are verified to<br>operate normally prior to each<br>departure.   |
|                          |  | В | 1        | 0              | May be inoperative provided operational procedures do not require its use.  |
| 2)                       | Slide Bottle Pressure<br>Indication<br>(On PTP)                                      |   |          |                |   |
| a)<br>***                | Passenger Doors  | С | -        | 0              | (O) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day.   |
| b)                       | Overwing Emergency<br>Exits<br>(A319/A320)   | С | 2        | 0              | (O) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day.   |
| C)<br>***                | Cabin Emergency Exit<br>(A321)   | С | 4        | 0              | (O) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day.   |
|                          |  |   |          |                | (Continued)   |

|                          | MENT OF TRANSPORTATION   | NC |   |   | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|----|---|---|---|
| REVISION NC              | 0. 32  |    |   |   | PAGE NO. 23-26  |
| DATE: XX/XX/             | XXXX   |    |   |   |   |
| AIRCRAFT:<br>Airbus A320 |  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 23. Communic             | ations   |    |   |   |   |
| Sequence No.             | Item   | 1  | 2 | 3 | 4 Change<br>Bar   |
| 23-73-07                 | Programming and Test<br>Panel (PTP)<br>(Without Mod. 30354 or<br>without Mod. 33100)<br>(Cont'd) |    |   |   |   |
| 3)<br>***                | Door Bottle Pressure<br>Indication (on PTP)  | С  | - | 0 | (O) May be inoperative provided<br>associated door bottle pressure is<br>verified before first flight of each day.  |
| 4)                       | Drain Masts<br>(Indication on PTP)   | С  | 1 | 0 | May be inoperative.   |
| 5)                       | Lavatory Smoke<br>Detection System<br>(Indication on PTP)  |    |   |   |   |
| a)                       | Without Mod. 21195   | С  | 1 | 0 | May be inoperative.   |
| b)                       | With Mod. 21195  | С  | 1 | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |
| 6)                       | Other Functions<br>(On PTP)  | D  | - | 0 | (M) May be inoperative provided alternate procedures are established and used.  |
| 23-73-08                 | Flight Attendant Panel<br>(FAP)<br>(With Mod. 30354 or with<br>Mod. 33100)                       | С  | 1 | 0 | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated FAP functions are considered inoperative, and</li> <li>b) Alternate procedures are established and used.</li> </ul> |
|                          |  |    |   |   | NOTE: EMER pb must always be operative.   |
| 1)                       | Cabin Lighting Control<br>Functions on FAP   | С  | - | 0 | (O) May be inoperative provided<br>lighting is sufficient for cabin<br>attendants to perform their duties.  |
|                          |  |    |   |   | (Continued)   |

| US DEPARTI               | MENT OF TRANSPORTATIO  | <u> N</u> |   |                               |   |  |  |
|--------------------------|--|-----------|---|-------------------------------|---|--|--|
|                          | ATION ADMINISTRATION   | 011       |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
| REVISION NO              | . 32   |           |   | PAGE NO. 23-27                |   |  |  |
| DATE: XX/XX/             | XXXX   |           |   |                               |   |  |  |
| AIRCRAFT:<br>Airbus A320 |  |           |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                     |  |  |
| 23. Communic             |  |           |   | r                             | Change  |  |  |
| Sequence No.<br>23-73-08 | Item<br>Flight Attendant Panel<br>(FAP)<br>(With Mod. 30354 or with<br>Mod. 33100)<br>(Cont'd) | 1         | 2 | 3                             | 4 Change<br>Bar   |  |  |
| 2)<br>***                | Prerecorded<br>Announcement and<br>Music Reproducer<br>Control on FAP                          | D         | 1 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                                |  |  |
| 3)<br>***                | CABIN READY on FAP   | D         | 1 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                                |  |  |
| 4)<br>***                | EVAC Light/CMD pb<br>(On FAP)  | D         | 1 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                                |  |  |
| 5)<br>***                | SYSTEM INOP Light on<br>WATER WASTE Panel<br>on FAP  | D         | 1 | 0                             | (M) May be inoperative provided<br>alternate procedures are established<br>and used.                                |  |  |
| 6)                       | Slide Bottle Pressure<br>Indication<br>(On FAP)  |           |   |                               |   |  |  |
| a)                       | Passenger Doors  | С         | - | 0                             | (O) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day. |  |  |
| b)<br>***                | Overwing Emergency<br>Exits  | С         | 2 | 0                             | (M) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day. |  |  |
| c)<br>***                | Cabin Emergency Exit<br>(A321)   | С         | - | 0                             | (O) May be inoperative provided<br>associated slide bottle pressure is<br>verified before first flight of each day. |  |  |
|                          |  |           |   |                               | (Continued)   |  |  |

|                          | MENT OF TRANSPORTATION   | JN |   |          | MASTER MINIMUM EQUIPMENT   | LIST          |
|--------------------------|--|----|---|----------|--|---------------|
| REVISION NO              |  |    |   |          | PAGE NO. 2   | 23-28         |
| DATE: XX/XX/             | XXXX   |    |   |          |  |               |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | 1.<br>2. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED  |               |
| 71100371020              |  |    |   |          | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |
| 23. Communic             | ations   |    |   |          |  |               |
| Sequence No.             | Item   | 1  | 2 | 3        | 4  | Change<br>Bar |
| 23-73-08                 | Flight Attendant Panel<br>(FAP)<br>(With Mod. 30354 or with<br>Mod. 33100)<br>(Cont'd) |    |   |          |  |               |
| 7)<br>***                | Door Bottle Pressure<br>Indication<br>(On FAP)   | С  | - | 0        | (O) May be inoperative provided<br>associated door bottle pressure is<br>verified before first flight of each day.   |               |
| 8)                       | Drain Masts Indication<br>(On FAP)   | С  | 1 | 0        | May be inoperative.  |               |
| 9)                       | Lavatory Smoke<br>Detection System<br>(Indication on FAP)                              | С  | 1 | 0        | May be inoperative.  |               |
| 10)                      | Other Functions<br>(On FAP)  | D  | - | 0        | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |               |
|                          |  |    |   |          | NOTE: EMER pb must always be operative.  |               |
| 23-75-01                 | E-Direct View System<br>(With Mod. 166696/<br>MP K21857)                               | В  | 1 | 0        | <ul> <li>(O) May be inoperative provided:</li> <li>a) Direct view of passengers by cabin attendants is not impaired,</li> <li>b) Alternate procedures are established and used.</li> </ul> |               |
|                          |  | D  | 1 | 0        | May be inoperative provided operations do not require its use.   |               |

|                          | MENT OF TRANSPORTATION  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|--------------------------|---|---|---|-------------------------------|--|
| REVISION NO              |   |   |   |                               | PAGE NO. 23-29   |
| DATE: XX/XX              | /^^^  |   |   |                               |  |
| AIRCRAFT:<br>Airbus A320 |   |   | T |                               | NO. REQUIRED FOR DISPATCH  |
| 23. Communio             | cations   |   | 1 |                               |  |
| Sequence No.             | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 23-90-01<br>***          | Cabin Surveillance<br>System (CSS)<br>STC No.ST02483AT            | D | 1 | 0                             | (M) May be inoperative provided system is deactivated off.             |
| 1)<br>***                | Video Display Units<br>(VDU)                                      | D | 2 | 0                             | (M) May be inoperative provided associated VDU(s) is deactivated off.  |
| 2)<br>***                | Cabin Display Cameras   | D | 4 | 0                             | (M) May be inoperative provided associated camera(s) is deactivated.   |
| 3)<br>***                | Digital Passenger<br>Control Units (DPCU)                         | D | 2 | 0                             | (M) May be inoperative provided associated unit(s) is deactivated off. |
| 23-90-03<br>***          | Wireless Aircraft Data<br>Link System (WADL)<br>STC No. ST01447NY | D | 1 | 0                             | (M) May be inoperative provided system is deactivated off.             |

| U.S. DEPART        | MENT OF TRANSPORTATI   | ON |   |     | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------|--|----|---|-----|--|
| FEDERAL AV         | IATION ADMINISTRATION  |    |   |     |  |
| <b>REVISION NO</b> | ). 31  |    |   |     | PAGE NO. 24-1  |
| DATE: 08/13/2      | 2024   |    |   |     |  |
|                    |  |    | T | ABL | EKEY   |
| AIRCRAFT:          |  |    |   |     | REPAIR CATEGORY  |
| Airbus A320        |  |    |   | 2.  |  |
|                    |  |    |   | -   | NO. REQUIRED FOR DISPATCH  |
|                    |  |    |   | 4.  | REMARKS OR EXCEPTIONS  |
| 24. Electrical     | Power  |    | 1 |     |  |
| Sequence No.       | Item   | 1  | 2 | 3   | 4 Change<br>Bar  |
| 24-00-00           | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |   |     |  |
| 1)                 | Fault(s) Indicated by DC BUS TIE   | С  | - | -   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 2)                 | Fault(s) Indicated by GPCU or AC GEN   | С  | - | -   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |

| -                                | VENT OF TRANSPORTATION   | ON |   |   | MASTER MINIMUM EQUIPMENT  | LIST   |
|----------------------------------|--|----|---|---|---|--------|
| REVISION NO. 31                  |  |    |   |   | PAGE NO.  | 24-2   |
| DATE: 08/13/20                   | 024  |    |   |   |   |        |
| AIRCRAFT:<br>Airbus A320         |  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |
| 24. Electrical P<br>Sequence No. | ltem   | 1  | 2 | 3 | 4   | Change |
| 24-20-01                         | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)  |    | 2 | 3 |   | Bar    |
| 1)                               | CFM 56-5 Engines<br>Aircraft with<br>Mods:31296/MP P6319<br>(Digital AMU) and<br>32875/MP P7945<br>(GCU 5.1), or Aircraft<br>with Mods:31107/<br>MP P7009<br>(Digital SATCOM AMU)<br>and 32875/MP P7945<br>(GCU 5.1) | B  | 2 | 1 | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) APU generator operates normally and is used throughout the flight,</li> <li>b) Operator ensures that the APU oil quantity is adequate for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings associated with the remaining engine and APU driven generator channels operate normally,</li> <li>e) Galley automatic shedding is verified to operate normally,</li> <li>f) Aircraft remains at or below FL 330,</li> <li>g) Approach minimums do not require its use, and</li> <li>h) When the Engine Driven Generator Channel 1 is inoperative, the AC ESS FEED manual transfer must be checked to operate normally.</li> </ul> NOTE: Relief is not applicable to aircraft with Mods: 39670/MP P10300 (GCU 5.2), or 37782/MP P10402 (Digital AMU Power Supply Upgrade), or 37317/MP P10098 (AC ESS FEED automatic switching).</li></ul> |        |
|                                  |  |    |   |   | (Continued)   |        |

| -                        | MENT OF TRANSPORTATION  | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|--------------------------|---|----|---|-------------------------------|---|--|--|--|
| REVISION NO. 31          |   |    |   |                               | PAGE NO. 24-3   |  |  |  |
| DATE: 08/13/2            |   |    |   |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.                      | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |  |  |  |
|                          |   |    |   |                               | REMARKS OR EXCEPTIONS   |  |  |  |
| 24. Electrical F         | Power   |    |   |                               |   |  |  |  |
| Sequence No.             | Item  | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 24-20-01                 | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)   |    |   |                               |   |  |  |  |
| 2)                       | CFM 56-5 Engines<br>(Aircraft with an analog<br>AMU or with any of the<br>Following Mods:)<br>37782/MP P10402<br>(Digital AMU Power<br>Supply Upgrade), or<br>37317/MP P10098<br>(AC ESS FEED<br>Automatic Switching), or<br>Aircraft with Mods:<br>31107/MP P7009<br>(Digital SATCOM AMU),<br>and 39670/MP P10300<br>(GCU 5.2)<br>and CFM LEAP-1A<br>Engines | В  | 2 | 1                             | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330, and</li> <li>g) Approach minimums do not<br/>require its use.</li> </ul> </li> </ul> |  |  |  |
|                          |   |    |   |                               | (Continued)   |  |  |  |

| -  | MENT OF TRANSPORTATION  | NC |        |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|----|--------|----------------|--|
| REVISION NO. 31<br>DATE: 08/13/2024                          |   |    |        |                | PAGE NO. 24-4  |
| AIRCRAFT:<br>Airbus A320<br>24. Electrical P<br>Sequence No. | Item  | 1  | 2<br>T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 3)   | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)<br>IAE Engines<br>(With IDGs which<br>Incorporate Mod. 26929/<br>MP P5059/P/N 766219<br>or<br>Mod. 30375/MP P6557/<br>P/N 772292), and<br>Aircraft with either<br>Mod: 31296/MP P6319<br>(Digital AMU)<br>and 32875/MP P7945<br>(GCU 5.1), or 31107/<br>MP P7009<br>(Digital SATCOM AMU)<br>and 32875/MP P7945<br>(GCU 5.1) | В  | 2      | 1              | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330,</li> <li>g) Fuel recirculation system<br/>associated with the operative<br/>IDG is operative,</li> <li>h) Approach minimums do not<br/>require its use,</li> <li>i) When the Engine Driven</li> </ul></li></ul> |
|  |   |    |        |                | Generator Channel 1 is<br>inoperative, the AC ESS<br>FEED manual transfer must<br>be checked to operate<br>normally,<br>(Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |      | MASTER MINIMUM EQUIPMENT LIST  |               |  |  |  |
|--|---|---|---|------|--|---------------|--|--|--|
| REVISION NO  | 0. 31   |   |   |      | PAGE NO.   | 24-5          |  |  |  |
| DATE: 08/13/2  |   |   |   |      |  |               |  |  |  |
|  |   |   | Т | ABLI | EKEY   |               |  |  |  |
| AIRCRAFT:  |   |   |   |      | REPAIR CATEGORY  |               |  |  |  |
| Airbus A320  |   |   |   | 3.   | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |  |
| 24. Electrical F   | Power   |   |   |      |  |               |  |  |  |
| Sequence No.   | ltem  | 1 | 2 | 3    | 4  | Change<br>Bar |  |  |  |
| 3)   | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)<br>IAE Engines  |   |   |      | j) If the associated IDG is  |               |  |  |  |
|  | (With IDGs which<br>Incorporate Mod. 26929/<br>MP P5059/P/N 766219<br>or<br>Mod. 30375/MP P6557/<br>P/N 772292), and<br>Aircraft with either<br>Mod: 31296/MP P6319<br>(Digital AMU)<br>and 32875/MP P7945<br>(GCU 5.1), or 31107/<br>MP P7009<br>(Digital SATCOM AMU)<br>and 32875/MP P7945<br>(GCU 5.1)<br>(Cont'd) |   |   |      | <ul> <li>disconnected, the inner/wing tank fuel temperature on the affected side is checked to be above -30 °C before takeoff, and</li> <li>k) If the associated IDG is disconnected, the inner/wing tank fuel temperature on the affected side is monitored in flight and checked to be above -43 °C.</li> <li>NOTE: Relief is not applicable to aircraft with Mods: 39670/MP P10300 (GCU 5.2), or 37782/MP P10402 (Digital AMU Power Supply Upgrade), or 37317/MP P10098 (AC ESS FEED automatic switching).</li> </ul> |               |  |  |  |
|  |   |   |   |      | (Continued)  |               |  |  |  |

|                          | MENT OF TRANSPORTATION  | NC |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--------------------------|---|----|----|----------------|--|--|--|--|
| REVISION NC              | D. 31   |    |    | PAGE NO. 24-6  |  |  |  |  |
| DATE: 08/13/2            | 2024  |    |    |                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 24. Electrical           | Power   |    |    |                |  |  |  |  |
| Sequence No.             | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |  |  |  |
| 24-20-01                 | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)   |    |    |                |  |  |  |  |
| 4)                       | IAE Engines<br>(Aircraft with an Analog<br>AMU or with any of the<br>Following Mods:)<br>37782/MP P10402<br>(Digital AMU Power<br>Supply Upgrade), or<br>37317/MP P10098<br>(AC ESS FEED<br>Automatic Switching), or<br>Aircraft with Mods:<br>31107/MP P7009<br>(Digital SATCOM AMU)<br>and 39670/MP P10300<br>(GCU 5.2) | В  | 2  | 1              | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330,</li> <li>g) Fuel recirculation system<br/>associated with the operative<br/>IDG is operative,</li> <li>h) Approach minimums do not<br/>require its use,</li> <li>i) If the associated IDG is<br/>disconnected, the inner/wing<br/>tank fuel temperature on the<br/>affected side is checked to be<br/>above -30 °C before takeoff,<br/>and</li> <li>j) If the associated IDG is<br/>disconnected, the inner/wing<br/>tank fuel temperature on the<br/>affected side is monitored in<br/>flight and checked to be<br/>above -43 °C.</li> </ul></li></ul> |  |  |  |

| ATION ADMINISTRATION  |   |   | MASTER MINIMUM EQUIPMENT LIST   |   |
|---|---|---|---|---|
| 31<br>)24   |   |   |   | PAGE NO. 24-7   |
| ower  |   | T   | 1.<br>2.<br>3.  | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| Item  | 1   | 2   | 3   | 4 Change<br>Bar   |
| Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd) |   |   |   | Dar   |
| PW 6000 Engines   | В   | 2   | 1   | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330,</li> <li>g) IDG cooler bypass valve is<br/>checked operative on the<br/>remaining generator before<br/>each flight,</li> <li>h) Approach minimums do not<br/>require its use, and</li> <li>i) If the associated IDG is<br/>disconnected, the inner tank<br/>fuel temperature on the<br/>affected side is checked to be<br/>above -39 °C before takeoff.</li> </ul> </li> </ul> |
|   | ower<br>Item<br>Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd) | ower       Item     1       Engine Driven Generator     1       Channel     (IDG, GCU, Line       Contactor)     (Cont'd) | D24     T       ower     1       Item     1       Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)     I | D24     TABLI       1.     1.       2.     3.       4.     4.       ower     1     2       Item     1     2     3       Engine Driven Generator     Channel     1       (IDG, GCU, Line     1     2     3       Contactor)     1     1     1  |

| -                                |   | NC |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------------|---|----|---|----------------|--|
| FEDERAL AVIATION ADMINISTRATION  |   |    |   |                | 5105110  |
| REVISION NO.                     | -   |    |   |                | PAGE NO. 24-8  |
| DATE: 08/13/20                   | J24   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320         |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 24. Electrical P<br>Sequence No. | ower<br>Item  | 1  | 2 | 3              | 4 Chang  |
| 24-20-01                         | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd) |    |   |                | Dar  |
| 6)                               | A319/A320 with PW<br>1100G Engines  | В  | 2 | 1              | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) APU generator operates normally and is used throughout the flight,</li> <li>b) Operator ensures that the APU oil quantity is adequate for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings associated with the remaining engine and APU driven generator channels operate normally,</li> <li>e) Galley automatic shedding is verified to operate normally,</li> <li>f) Aircraft remains at or below FL 330,</li> <li>g) Both IDG heat exchangers bypass valves of the remaining AC main generation are checked operative before each flight,</li> <li>h) Approach minimums do not require its use, and</li> <li>i) If the associated IDG is disconnected, the inner tank fuel temperature on the affected side is checked to be above -39 °C before takeoff.</li> </ul> </li> </ul> |

| FEDERAL AVIA                        |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|-------------------------------------|---|---|---|----------------|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION     |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
| REVISION NO. 31<br>DATE: 08/13/2024 |   |   |   |                | PAGE NO. 24-9  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 24. Electrical Po                   | ower  |   |   |                |  |  |  |  |  |
| Sequence No.                        | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 24-20-01                            | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd) |   |   |                |  |  |  |  |  |
| 7)                                  | A321 with PW 1100G<br>Engines and without<br>Mod. 163213/<br>MP J4530           | В | 2 | 1              | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) APU generator operates normally and is used throughout the flight,</li> <li>b) Operator ensures that the APU oil quantity is adequate for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings associated with the remaining engine and APU driven generator channels operate normally,</li> <li>e) Galley automatic shedding is verified to operate normally,</li> <li>f) Aircraft remains at or below FL 330,</li> <li>g) Both IDG heat exchangers bypass valves of the remaining AC main generation are checked operative before each flight,</li> <li>h) Approach minimums do not require its use,</li> <li>i) If the associated IDG is disconnected, the wing tank fuel temperature on the affected side is checked to be above -30 °C before takeoff, and</li> <li>j) If the associated IDG is disconnected, the wing tank fuel temperature is monitored in flight and checked to be at or above -38 °C.</li> </ul> </li> </ul> |  |  |  |  |

| U.S. DEPARTM                        | IENT OF TRANSPORTATIO  | ON |   |                               |   |  |  |  |
|-------------------------------------|--|----|---|-------------------------------|---|--|--|--|
| FEDERAL AVIA                        | TION ADMINISTRATION  |    |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
| REVISION NO. 31<br>DATE: 08/13/2024 |  |    |   |                               | PAGE NO. 24-10  |  |  |  |
| AIRCRAFT:<br>Airbus A320            |  |    |   |                               | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 24. Electrical P                    | ower   |    |   |                               |   |  |  |  |
| Sequence No.                        | Item   | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 24-20-01                            | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)                  |    |   |                               |   |  |  |  |
| 8)                                  | A321 with PW 1100G<br>Engines and<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335 | B  | 2 | 1                             | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) APU generator operates normally and is used throughout the flight,</li> <li>b) Operator ensures that the APU oil quantity is adequate for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings associated with the remaining engine and APU driven generator channels operate normally,</li> <li>e) Galley automatic shedding is verified to operate normally,</li> <li>f) Aircraft remains at or below FL 330,</li> <li>g) Both IDG heat exchangers bypass valves of the remaining AC main generation are checked operative before each flight,</li> <li>h) Approach minimums do not require its use,</li> <li>i) If the associated IDG is disconnected, the wing tank fuel temperature on the affected side is checked to be above -30 °C before takeoff,</li> <li>j) If the associated IDG is disconnected, the wing tank fuel temperature is monitored in flight and checked to be at or above -38 °C, and</li> <li>k) FWD ACT is empty or not installed.</li> </ul></li></ul> |  |  |  |

| -                            | IENT OF TRANSPORTATIO   | ON |                |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|------------------------------|---|----|----------------|----------------|--|--|--|--|
| FEDERAL AVIA<br>REVISION NO. | ATION ADMINISTRATION  |    | PAGE NO. 24-11 |                |  |  |  |  |
| DATE: 08/13/20               | -   |    |                |                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |    | T              | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 24. Electrical P             | ower  |    |                |                |  |  |  |  |
| Sequence No.                 | Item  | 1  | 2              | 3              | 4 Change<br>Bar  |  |  |  |
| 24-20-01                     | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)<br>A321 with PW 1100G | В  | 2              | 1              |  |  |  |  |
| 9)                           | AS21 WITPW Troog<br>Engines and<br>Mod. 163213/MP J4530<br>and<br>Mod. 162739/MP J4335                | D  |                | 1              | <ul> <li>(M)(O) Except for ETOPS, one may be inoperative provided: <ul> <li>a) APU generator operates normally and is used throughout the flight,</li> <li>b) Operator ensures that the APU oil quantity is adequate for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings associated with the remaining engine and APU driven generator channels operate normally,</li> <li>e) Galley automatic shedding is verified to operate normally,</li> <li>f) Aircraft remains at or below FL 330,</li> <li>g) Both IDG heat exchangers bypass valves of the remaining AC main generation are checked operative before each flight,</li> <li>h) Approach minimums do not require its use,</li> <li>i) If the associated IDG is disconnected, the wing tank fuel temperature on the affected side is checked to be above -30 °C before takeoff,</li> <li>j) If the associated IDG is disconnected, the wing tank fuel temperature is monitored in flight and checked to be at or above -38 °C, and</li> <li>k) AFT2 ACT is empty or not installed.</li> </ul></li></ul> |  |  |  |

| -                                   | MENT OF TRANSPORTATION  | NC |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |
|-------------------------------------|---|----|---|-------------------------------|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |    |   |                               | PAGE NO. 24-12   |  |  |
|                                     |   |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 24. Electrical F<br>Sequence No.    | Item  | 1  | 2 | 3                             | 4 Change   |  |  |
| 24-20-01                            | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)                     |    |   |                               | Bar  |  |  |
| 10)                                 | A321 with CFM<br>LEAP-1A Engines and<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335 | В  | 2 | 1                             | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330,</li> <li>g) Approach minimums do not<br/>require its use, and</li> <li>h) FWD ACT is empty or not<br/>installed.</li> </ul> </li> </ul> |  |  |
|                                     |   |    |   |                               | (Continued)  |  |  |

| U.S. DEPARTI                    | IENT OF TRANSPORTATIO   | ON |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|---------------------------------|---|----|----|----------------|---|
| FEDERAL AVIATION ADMINISTRATION |   |    |    |                | MASTER MINIMOM EQUIPMENT LIST   |
| REVISION NO. 31                 |   |    |    |                | PAGE NO. 24-13  |
| DATE: 08/13/20                  | 024   |    |    |                |   |
| AIRCRAFT:<br>Airbus A320        |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 24. Electrical P                | lowor   |    |    |                |   |
| Sequence No.                    | Item  | 1  | 2  | 3              | 4 Change<br>Bar   |
| 24-20-01                        | Engine Driven Generator<br>Channel<br>(IDG, GCU, Line<br>Contactor)<br>(Cont'd)             |    |    |                |   |
| 11)                             | A321 with CFM<br>LEAP-1A Engines and<br>Mod. 163213/MP J4530<br>and<br>Mod. 162739/MP J4335 | В  | 2  | 1              | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) APU generator operates<br/>normally and is used<br/>throughout the flight,</li> <li>b) Operator ensures that the<br/>APU oil quantity is adequate<br/>for the intended flight,</li> <li>c) All busses can be powered,</li> <li>d) All indications and warnings<br/>associated with the remaining<br/>engine and APU driven<br/>generator channels operate<br/>normally,</li> <li>e) Galley automatic shedding is<br/>verified to operate normally,</li> <li>f) Aircraft remains at or below<br/>FL 330,</li> <li>g) Approach minimums do not<br/>require its use, and</li> <li>h) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> </ul> |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|----|----------------|--|
| REVISION NO. 31  |   |   |    |                | PAGE NO. 24-14   |
| DATE: 08/13/2  | 024   |   |    |                |  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 24. Electrical F<br>Sequence No.                                     | ltem  | 1 | 2  | 3              | 4 Change<br>Bar  |
| 24-20-02   | APU Generator Channel   | • | -  | •              | Press Bar  |
| 1)   | Aircraft without<br>Mod. 24642/MP P3524<br>or AES APU without<br>Mod. 24498/MP K3680<br>or without<br>Mod. 25568/MP K4157 | A | 1  | 0              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) APU GEN pb-sw is set to OFF,</li> <li>b) It is verified that both APU oil filters are not clogged, and</li> <li>c) Repairs are made within 4 flight-legs.</li> </ul> </li> </ul> |
|  |   |   |    |                | NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.  |
|  |   | С | 1  | 0              | <ul> <li>(M) Except for ETOPS, may be inoperative provided:</li> <li>a) APU GEN pb-sw is set to OFF, and</li> <li>b) It is verified that both APU oil filters are not clogged.</li> </ul>  |
|  |   |   |    |                | NOTE: When GPCU/GAPCU Ground<br>Power Control Function and<br>APU generator are both<br>inoperative, engines cannot<br>be started.   |
|  |   | С | 1  | 0              | Except for ETOPS, may be inoperative provided APU is not used.   |
|  |   |   |    |                | NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.  |
|  |   |   |    |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT L  | IST          |
|--|---|---|---|----------------|---|--------------|
| REVISION NO. 31  |   |   |   |                | PAGE NO. 24   | -15          |
| DATE: 08/13/2  | 024   |   |   |                |   |              |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |              |
| 24. Electrical F   | Power   |   |   |                | -   |              |
| Sequence No.   | Item  | 1 | 2 | 3              |   | nange<br>Bar |
| 24-20-02   | APU Generator Channel<br>(Cont'd)   |   |   |                |   |              |
| 1)   | Aircraft without<br>Mod. 24642/MP P3524<br>or AES APU without<br>Mod. 24498/MP K3680<br>or without<br>Mod. 25568/MP K4157<br>(Cont'd)                   | С | 1 | 0              | <ul> <li>(M) Except for ETOPS, may be<br/>inoperative provided APU generator<br/>is deactivated or removed.</li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> </ul> |              |
| 2)   | Aircraft with<br>Mod. 24642/MP P3524<br>or AES APU with<br>Mod. 24498/MP K3680<br>or with<br>Mod. 25568/MP K4157<br>or APIC APU or<br>APU GTCP 131-9(A) | A | 1 | 0              | Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:<br>a) APU GEN pb-sw is set to<br>OFF, and<br>b) Repairs are made within<br>4 flight-legs.<br>NOTE: When GPCU/Ground Power   |              |
|  |   |   |   |                | Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.   |              |
|  |   | С | 1 | 0              | Except for ETOPS, may be<br>inoperative provided APU GEN pb-sw<br>is set to OFF.  |              |
|  |   |   |   |                | NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.   |              |
|  |   |   |   |                | (Continued)   |              |

| -                        | MENT OF TRANSPORTATIN   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|---|----------------|--|
| REVISION NO. 31          |   |    |   |                | PAGE NO. 24-16   |
| DATE: 08/13/2            | 024   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 24. Electrical F         | Power   | 1  |   | 1              | Change   |
| Sequence No.<br>24-20-02 | Item<br>APU Generator Channel   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 24-20-02                 | (Cont'd)  |    |   |                |  |
| 2)                       | Aircraft with<br>Mod. 24642/MP P3524<br>or AES APU with<br>Mod. 24498/MP K3680<br>or with<br>Mod. 25568/MP K4157<br>or APIC APU or<br>APU GTCP 131-9(A)<br>(Cont'd) | С  | 1 | 0              | Except for ETOPS, may be<br>inoperative provided APU is<br>considered inoperative.<br>NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.  |
|                          |   | С  | 1 | 0              | <ul> <li>(M) Except for ETOPS, may be<br/>inoperative provided APU generator<br/>is deactivated or removed.</li> <li>NOTE: When GPCU/GAPCU Ground<br/>Power Control Function and<br/>APU generator are both<br/>inoperative, engines cannot<br/>be started.</li> </ul>   |
| 3)                       | Aircraft with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335  | A  | 1 | 0              | <ul> <li>Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) APU GEN pb-sw is set to OFF,</li> <li>b) Repairs are made within 4 flight-legs, and</li> <li>c) FWD ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines cannot be started.</li> </ul> |
|                          |   |    |   |                | (Continued)  |

|                                     | MENT OF TRANSPORTATION   | NC |   |                | MASTER MINIMUM EQUIPMENT   | LIST          |  |  |  |
|-------------------------------------|--|----|---|----------------|--|---------------|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |  |    |   |                | PAGE NO. 24-17   |               |  |  |  |
| AIRCRAFT:<br>Airbus A320            |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |  |
| 24. Electrical F                    | ower   | -  |   |                |  |               |  |  |  |
| Sequence No.                        | Item   | 1  | 2 | 3              | 4  | Change<br>Bar |  |  |  |
| 24-20-02                            | APU Generator Channel<br>(Cont'd)  |    |   |                |  |               |  |  |  |
| 3)                                  | Aircraft with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335<br>(Cont'd) | С  | 1 | 0              | <ul> <li>Except for ETOPS, may be inoperative provided: <ul> <li>a) APU GEN pb-sw is set to OFF, and</li> <li>b) FWD ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines cannot be started.</li> </ul>          |               |  |  |  |
|                                     |  | С  | 1 | 0              | Except for ETOPS, may be<br>inoperative provided:<br>a) APU is not used, and<br>b) FWD ACT is empty or not<br>installed.   |               |  |  |  |
|                                     |  |    |   |                | NOTE: When GPCU/GAPCU Ground<br>Power Control Function and<br>APU generator are both<br>inoperative, engines cannot<br>be started.   |               |  |  |  |
|                                     |  | С  | 1 | 0              | <ul> <li>(M) Except for ETOPS, may be inoperative provided: <ul> <li>a) APU generator is deactivated or removed, and</li> <li>b) FWD ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/GAPCU Ground Power Control Function and APU generator are both inoperative, engines cannot be started.</li> </ul> |               |  |  |  |
|                                     |  |    |   |                | (Continued)  |               |  |  |  |

| DATE: 08/13/2024         AIRCRAFT:<br>Airbus A320         Airbus A320         24. Electrical Power         Sequence No.         Hem       1         24-20-02       APU Generator Channel<br>(Cont'd)         4)       Aircraft with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335       C       1       0         Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:       a) APU GEN pb-sw is set to<br>OFF,<br>b) Repairs are made within<br>4 flight-legs, and<br>c) AFT2 ACT is empty or not<br>installed.       a) APU GEN pb-sw is set to<br>OFF,<br>b) Repairs are made within<br>4 flight-legs, and<br>c) AFT2 ACT is empty or not<br>installed.         C       1       0       Except for ETOPS, may be<br>inoperative, engines<br>cannot be started.         C       1       0       Except for ETOPS, may be<br>inoperative provided:<br>a) APU GEN pb-sw is set to<br>OFF, and<br>b) AFT2 ACT is empty or not<br>installed.         C       1       0       Except for ETOPS, may be<br>inoperative provided:<br>a) APU generator<br>are both inoperative, engines<br>cannot be started.         C       1       0       (M) Except for ETOPS, may be<br>inoperative provided:<br>a) APU generator is deactivated<br>or removed, and<br>b) AFT2 ACT is empty or not<br>installed.         NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.         C       1       0       (M) Except for ETOPS, may be<br>inoperative provided:<br>a) APU generator is deactivated<br>or removed, | U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                  |   |   | MASTER MINIMUM EQUIPME |   |  |  |  |  |  |
|---|--|----------------------------------|---|---|------------------------|---|--|--|--|--|--|
| AIRCRAFT:       Airbus A320       1       2       3       4       8         24. Electrical Power       1       2       3       4       6         24. 20-02       APU Generator Channel<br>(Cont'd)       1       2       3       4       6         4)       Aircraft with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335       C       1       0       Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:       a) APU GEN pb-sw is set to<br>OFF,       b) Repairs are made within<br>4 flight-legs, and       c) GFT.       b) Repairs are made within<br>4 flight-legs, and       c) AFT2 ACT is empty or not<br>installed.         VOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.       c)       1       0       Except for ETOPS, may be<br>inoperative provided:<br>a) APU GEN pb-sw is set to<br>OFF, and       b) AFT2 ACT is empty or not<br>installed.         VOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.       c)       1       0       Except for ETOPS, may be<br>inoperative provided:<br>a) APU generator is deactivated<br>or removed, and<br>b) AFT2 ACT is empty or not<br>installed.       NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative provided:<br>a) APU generator is deactivated<br>or removed, and<br>b) AFT2 ACT is empty or not<br>installed.   |  |                                  |   |   |                        | PAGE NO. 24-18  |  |  |  |  |  |
| Sequence No.       Item       1       2       3       4       6         24-20-02       APU Generator Channel<br>(Cont'd)       C       1       0       Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:       a)       APU GEN pb-sw is set to<br>OFF,         4)       Mod. 163213/MP J4335       C       1       0       Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:       a) APU GEN pb-sw is set to<br>OFF,         b)       Repairs are made within<br>4 flight-legs, and<br>0       AFT2 ACT is empty or not<br>installed.       NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.         C       1       0       Except for ETOPS, may be<br>inoperative provided:       a)       APU GEN pb-sw is set to<br>OFF, and         0       AFT2 ACT is empty or not<br>installed.       a)       APU GEN pb-sw is set to<br>OFF, and       AFT2 ACT is empty or not<br>installed.         0       C       1       0       Except for ETOPS, may be<br>inoperative, engines<br>cannot be started.         C       1       0       (M) Except for ETOPS, may be<br>inoperative, engines<br>cannot be started.         1       0       (M) Except for ETOPS, may be<br>inoperative provided:       a)         1       0       (M) Except for ETOPS, may be<br>inoperative provided:       b)         1       0       (M) Exce  | -  |                                  |   | T | 1.<br>2.<br>3.         | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |  |  |
| Sequence No.       usin       1       2       3       4         24-20-02       APU Generator Channel<br>(Cont'd)       C       1       0       Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:         4)       Aircraft with<br>Mod. 163213/MP J4335       C       1       0       Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:         a)       APU GEN pb-sw is set to<br>OFF,       b)       Repairs are made within<br>4 flight-legs, and       c)         AFT2 ACT is empty or not<br>installed.       NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.         C       1       0       Except for ETOPS, may be<br>inoperative provided:         a)       APU GEN pb-sw is set to<br>OFF, and       b)       AFT2 ACT is empty or not<br>installed.         NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.       NOTE: When GPCU/Ground Power<br>Control Function of the<br>GAPCU and APU generator<br>are both inoperative, engines<br>cannot be started.         C       1       0       (M) Except for ETOPS, may be<br>inoperative provided:         a)       APU generator are doth       a)       APU generator are<br>both inoperative, engines<br>cannot be started.  | 24. Electrical F   | ower                             |   |   |                        |   |  |  |  |  |  |
| <ul> <li>24-20-02 APU Generator Channel (Cont d)</li> <li>4) Micraft with Mod. 163213/MP J4530 and with Mod. 162739/MP J4335</li> <li>C 1 0 Except for ETOPS beyond 120 minutes, may be inoperative provided: <ul> <li>a) APU GEN pb-sw is set to OFF,</li> <li>b) Repairs are made within 4 flight-legs, and</li> <li>c) AFT2 ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>C 1 0 Except for ETOPS, may be inoperative, engines cannot be started.</li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines cannot be started.</li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines cannot be started.</li> </ul>   | Sequence No.   | Item                             | 1 | 2 | 3                      | 4 Change<br>Bar   |  |  |  |  |  |
| <ul> <li>Mod. 163213/MP J4530<br/>and with<br/>Mod. 162739/MP J4335</li> <li>I 20 minutes, may be inoperative<br/>provided: <ul> <li>a) APU GEN pb-sw is set to<br/>OFF,</li> <li>b) Repairs are made within<br/>4 flight-legs, and</li> <li>c) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> <li>C 1 0 Except for ETOPS, may be<br/>inoperative provided: <ul> <li>a) APU GEN pb-sw is set to<br/>OFF, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> <li>C 1 0 Except for ETOPS, may be<br/>inoperative provided: <ul> <li>a) APU GEN pb-sw is set to<br/>OFF, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> <li>C 1 0 (M) Except for ETOPS, may be<br/>inoperative, engines<br/>cannot be started.</li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> <li>NOTE: When GPCU/Ground Power<br/>Control Function and<br/>APU generator are both</li> </ul>  |  |                                  |   |   |                        |   |  |  |  |  |  |
| <ul> <li>inoperative provided:         <ul> <li>a) APU GEN pb-sw is set to<br/>OFF, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines<br/>cannot be started.</li> <li>C 1 0 (M) Except for ETOPS, may be<br/>inoperative provided:         <ul> <li>a) APU generator is deactivated<br/>or removed, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> </ul> </li> <li>NOTE: When GPCU/GAPCU Ground<br/>Power Control Function and<br/>APU generator are both</li> </ul>  | 4)   | Mod. 163213/MP J4530<br>and with | С | 1 | 0                      | <ul> <li>120 minutes, may be inoperative provided: <ul> <li>a) APU GEN pb-sw is set to OFF,</li> <li>b) Repairs are made within 4 flight-legs, and</li> <li>c) AFT2 ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/Ground Power Control Function of the GAPCU and APU generator are both inoperative, engines</li> </ul> |  |  |  |  |  |
| inoperative provided:<br>a) APU generator is deactivated<br>or removed, and<br>b) AFT2 ACT is empty or not<br>installed.<br>NOTE: When GPCU/GAPCU Ground<br>Power Control Function and<br>APU generator are both  |  |                                  | С | 1 | 0                      | <ul> <li>inoperative provided:</li> <li>a) APU GEN pb-sw is set to<br/>OFF, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> <li>NOTE: When GPCU/Ground Power<br/>Control Function of the<br/>GAPCU and APU generator<br/>are both inoperative, engines</li> </ul>  |  |  |  |  |  |
| inoperative, engines cannot<br>be started.<br>(Continued)   |  |                                  | С | 1 | 0                      | <ul> <li>inoperative provided:</li> <li>a) APU generator is deactivated<br/>or removed, and</li> <li>b) AFT2 ACT is empty or not<br/>installed.</li> <li>NOTE: When GPCU/GAPCU Ground<br/>Power Control Function and<br/>APU generator are both<br/>inoperative, engines cannot<br/>be started.</li> </ul>                                    |  |  |  |  |  |

| -  |   | NC |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|----|---|----------------|---|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 31 |   |    |   |                | PAGE NO. 24-19  |
| DATE: 08/13/2                                      |   |    |   |                | 1 AOL NO. 24-19   |
| AIRCRAFT:<br>Airbus A320                           |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 24. Electrical F                                   |   |    |   |                | A Change  |
| Sequence No.<br>24-20-02                           | Item<br>APU Generator Channel<br>(Cont'd)   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 4)   | Aircraft with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335<br>(Cont'd) | С  | 1 | 0              | <ul> <li>(M) Except for ETOPS, may be inoperative provided: <ul> <li>a) APU generator is deactivated or removed, and</li> <li>b) AFT2 ACT is empty or not installed.</li> </ul> </li> <li>NOTE: When GPCU/GAPCU Ground Power Control Function and APU generator are both inoperative, engines cannot be started.</li> </ul> |
| 24-20-07   | AC ESS Feed Control   |    |   |                |   |
| 1)   | Manual Transfer to the<br>AC BUS 2<br>(ALTN Function)                                 | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) AC ESS FEED pb switch is<br/>set at NORM position,</li> <li>b) It is checked on the ELEC SD<br/>page that the AC BUS 1<br/>supplies the AC ESS BUS,<br/>and</li> <li>c) TR 2 operates normally.</li> </ul>  |
| 2)   | Automatic Transfer to<br>the AC BUS 2<br>(For aircraft with<br>Mod 37317/MP P10098)   | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) AC ESS FEED pb switch is<br/>set at NORM position,</li> <li>b) It is checked on the ELEC SD<br/>page that the AC BUS 1<br/>supplies the AC ESS BUS,<br/>and</li> <li>c) TR 2 operates normally.</li> </ul>  |
| 24-27-01   | IDG FAULT Lights  | С  | 2 | 1              | One may be inoperative provided<br>frequency and temperature<br>indications are available on ECAM<br>ELEC page and are monitored.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                  |   |          |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|----------------------------------|---|----------|----------------|--|
| REVISION NO<br>DATE: 08/13/2   |                                  |   |          | PAGE NO. 24-20 |  |
| AIRCRAFT:<br>Airbus A320   |                                  |   | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 24. Electrical F   | Power                            |   | <b>L</b> |                |  |
| Sequence No.   | Item                             | 1 | 2        | 3              | 4 Change<br>Bar  |
| 24-27-02   | GEN pb Switch                    |   |          |                |  |
| 1)   | FAULT Lights                     | С | 3        | 1              | One GEN and/or the APU FAULT<br>Light may be inoperative provided the<br>associated indications are available<br>on ECAM ELEC page.  |
| 2)   | OFF Lights                       | С | 3        | 0              | One or more may be inoperative.  |
| 24-27-03   | AC ESS FEED<br>FAULT/ALTN Light  | С | 1        | 0              | May be inoperative provided AC ESS<br>bus indication is available on ECAM<br>ELEC page.  |
| 24-27-04   | GALLEY/GALY and CAB pb Switch    |   |          |                |  |
| 1)   | FAULT Light                      | С | 1        | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) AC load indication for each<br/>generator channel is available<br/>on ECAM ELEC page, and</li> <li>b) Automatic shedding operates<br/>normally.</li> </ul>   |
| 2)   | OFF Light                        | С | 1        | 0              | May be inoperative.  |
| 24-27-05   | RAT and EMER GEN<br>FAULT Light  | С | 1        | 0              | (O) May be inoperative provided<br>indications are available on<br>associated ECAM ELEC page.  |
| 24-27-06   | Indications on ECAM<br>ELEC Page | С | _        | -              | <ul> <li>(O) Indications related to AC generation may be inoperative provided: <ul> <li>a) Load, voltage, and frequency indications of at least one engine driven generator operate normally,</li> <li>b) Associated GEN FAULT caution on ECAM operates normally, and</li> <li>c) Automatic shedding operates normally.</li> </ul> </li> </ul> |
| 1)   | APU GEN Parameters               | С | -        | 0              | Except for ETOPS, may be<br>inoperative provided both Engine<br>Driven Generators are operative.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                     |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|-------------------------------------|---|---|----------------|---|
| REVISION NO. 31<br>DATE: 08/13/2024                                  |                                     |   |   |                | PAGE NO. 24-21  |
| AIRCRAFT:<br>Airbus A320   |                                     |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 24. Electrical P   | Power                               |   |   |                | -   |
| Sequence No.   | Item                                | 1 | 2 | 3              | 4 Change<br>Bar   |
| 24-27-09<br>***  | COMMERCIAL<br>pb Switch             |   |   |                |   |
| 1)   | OFF Light                           | С | 1 | 0              | May be inoperative.   |
| 24-30-01   | Transformer/Rectifier<br>Units (TR) | A | 3 | 2              | <ul> <li>(M)(O) Except for ETOPS, TR1 may<br/>be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> <li>b) Battery voltage indicator<br/>operates normally,</li> <li>c) Both packs operate normally,</li> <li>d) Repairs are made within<br/>2 flight-days, and</li> <li>e) Approach minimums do not<br/>require its use.</li> </ul> </li> </ul>   |
| 1)   | Without Mod. 27620                  | A | 3 | 2              | <ul> <li>(M)(O) Except for ETOPS, TR2 may<br/>be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> <li>b) Battery voltage indicator<br/>operates normally,</li> <li>c) Both packs operate normally,</li> <li>d) Repairs are made within<br/>2 flight-days,</li> <li>e) AC ESS FEED control is<br/>checked operative once each<br/>day,</li> <li>f) Standby Horizon operates<br/>normally,</li> <li>g) Standby Compass operates<br/>normally, and</li> <li>h) Approach minimums do not<br/>require its use.</li> </ul> </li> </ul> |

| U.S. DEPART                  | MENT OF TRANSPORTATI                               | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|----------------|--|
| FEDERAL AVI                  | ATION ADMINISTRATION                               |    |   |                |  |
| REVISION NO<br>DATE: 08/13/2 | -  |    |   | PAGE NO. 24-22 |  |
| AIRCRAFT:<br>Airbus A320     |  |    | Т | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 24. Electrical F             | Power  |    |   |                |  |
| Sequence No.                 | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 24-27-09<br>***              | COMMERCIAL<br>pb Switch<br>(Cont'd)                |    |   |                |  |
| 2)                           | With Mod. 27620                                    | A  | 3 | 2              | <ul> <li>(M)(O) Except for ETOPS, TR2 may<br/>be inoperative provided: <ul> <li>a) Extract fan operates normally,</li> <li>b) Battery voltage indicator<br/>operates normally,</li> <li>c) Both packs operate normally,</li> <li>d) Repairs are made within<br/>2 flight-days,</li> <li>e) AC ESS FEED control is<br/>checked operative once each<br/>day,</li> <li>f) ISIS Horizon operates<br/>normally,</li> <li>g) Standby Compass operates<br/>normally, and</li> <li>h) Approach minimums do not<br/>require its use.</li> </ul></li></ul> |
| 24-30-04                     | Battery Voltmeters                                 | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Battery indications are<br/>available on ECAM, and</li> <li>b) Battery voltage is confirmed<br/>adequate before APU start.</li> </ul>  |
| 24-30-05                     | BAT pb Switches                                    |    |   |                |  |
| 1)                           | FAULT Lights                                       | С  | 2 | 0              | One or both may be inoperative.  |
| 2)                           | OFF Lights   | С  | 2 | 0              | One or both may be inoperative.  |
| 24-30-06                     | DC BUS TIE SYSTEM                                  |    |   |                |  |
| 1)                           | DC TIE Contactor 1<br>(DC BUS 1-DC BAT<br>BUS)     | С  | 1 | 0              | May be inoperative open provided<br>DC TIE contactor ESS operates<br>normally.   |
| 2)                           | DC TIE Contactor ESS<br>(DC BAT BUS-DC ESS<br>BUS) | С  | 1 | 0              | May be inoperative open provided<br>DC TIE contactor 1 operates<br>normally.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|----|----------------|---|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   |  |   |    |                | PAGE NO. 24-23  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 24. Electrical F   | Power  |   |    |                |   |  |  |  |  |
| Sequence No.   | ltem   | 1 | 2  | 3              | 4 Change<br>Bar   |  |  |  |  |
| 24-30-07   | BUS TIE pb Switch  |   |    |                |   |  |  |  |  |
| 1)   | OFF Light  | С | 1  | 0              | May be inoperative.   |  |  |  |  |
| 24-30-08   | ECAM ELEC Page<br>(DC)   | С | -  | 0              | Indications related to DC generation may be inoperative.  |  |  |  |  |
| 24-30-09   | External Power Panel<br>ADIRU/AVNCS Vent<br>Caution Light                              | С | 1  | 0              | (M) May be inoperative provided<br>avionics ventilation system warning<br>horn is verified to operate normally.   |  |  |  |  |
|  |  | С | 1  | 0              | May be inoperative provided ground external horn is considered inoperative.   |  |  |  |  |
| 24-41-01   | AC External Power<br>Control   |   |    |                |   |  |  |  |  |
| 1)   | Ground Power Control<br>Unit (GPCU)/Ground   | С | 1  | 0              | May be inoperative provided external power is not used.   |  |  |  |  |
|  | Power Control Function<br>of the Ground and<br>Auxiliary Power Control<br>Unit (GAPCU) |   |    |                | NOTE: When GPCU/Ground Power<br>Control Function of GAPCU<br>and APU generator are both<br>inoperative, engines cannot<br>be started.   |  |  |  |  |
| 2)   | Receptacle   | С | 1  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Receptacle is visually<br/>inspected,</li> <li>b) External power is not used,<br/>and</li> <li>c) EXT PWR pb is placarded<br/>inoperative.</li> </ul> |  |  |  |  |
|  |  |   |    |                | NOTE: When GPCU/Ground Power<br>Control Function of GAPCU<br>and APU generator are both<br>inoperative, engines cannot<br>be started.   |  |  |  |  |
| 24-41-02   | External Power NOT IN<br>USE and AVAIL Panel<br>Lights                                 | С | 2  | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |  |

|                              | MENT OF TRANSPORTATIN  | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |               |  |  |  |
|------------------------------|--|----|---|-------------------------------|---|---------------|--|--|--|
| REVISION NO<br>DATE: 08/13/2 | -  |    |   |                               | PAGE NO.  | 24-24         |  |  |  |
| AIRCRAFT:<br>Airbus A320     |  |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |  |
| 24. Electrical               | Power  |    |   |                               |   |               |  |  |  |
| Sequence No.                 | Item   | 1  | 2 | 3                             | 4   | Change<br>Bar |  |  |  |
| 24-41-03                     | EXT PWR pb   |    |   |                               |   |               |  |  |  |
| 1)                           | AVAIL Light  | С  | 1 | 0                             | (O) May be inoperative provided alternate procedures are established and used.  |               |  |  |  |
| 2)                           | ON Light   | С  | 1 | 0                             | May be inoperative.   |               |  |  |  |
| 24-50-01                     | Warning and Caution on ECAM EWD  |    |   |                               |   |               |  |  |  |
| 1)                           | C/B TRIPPED  | С  | 1 | 0                             | (M) May be inoperative provided<br>alternate procedures are used to<br>verify that no circuit breaker is tripped<br>on associated C/B panel.  |               |  |  |  |
| 2)                           | ELEC IDG 1(2) OIL LO<br>LVL Alert<br>(A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines)  | С  | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Sight glass of the affected IDG shows a correct oil level, and</li> <li>b) Differential Pressure Indicator (DPI) of the oil filter is not extended on the affected IDG.</li> </ul>                      |               |  |  |  |
|                              |  | В  | 2 | 1                             | <ul> <li>(O) One may be inoperative provided</li> <li>a) Associated generator is set to OFF, and</li> <li>b) Associated AC Main Generation is considered inoperative.</li> </ul>  |               |  |  |  |
|                              |  | A  | 2 | 1                             | One may be inoperative for<br>15 flight-hours or 1 flight-day,<br>whichever occurs first.   |               |  |  |  |
| 3)                           | ELEC IDG 1(2) FILTER<br>CLOG Alert<br>(A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines) | С  | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Sight glass of the affected IDG shows a correct oil level, and</li> <li>b) Differential Pressure Indicator (DPI) of the oil filter is not extended on the affected IDG.</li> <li>(Continued)</li> </ul> |               |  |  |  |

|                          | MENT OF TRANSPORTATION   | NC |   |                | MASTER MINIMUM EQUIPMENT LIS   |
|--------------------------|--|----|---|----------------|--|
| REVISION NO. 31          |  |    |   |                | PAGE NO. 24-2  |
| DATE: 08/13/2            |  |    |   |                | FAGE NO. 24-2  |
| AIRCRAFT:<br>Airbus A320 |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 24. Electrical F         | Power  |    | 1 |                |  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Chang<br>Bar   |
| 24-50-01                 | Warning and Caution on<br>ECAM EWD<br>(Cont'd)   |    |   |                |  |
| 3)                       | ELEC IDG 1(2) FILTER<br>CLOG Alert<br>(A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines)<br>(Cont'd) | В  | 2 | 1              | <ul> <li>(O) One may be inoperative provided</li> <li>a) Associated generator is set to<br/>OFF, and</li> <li>b) Associated AC Main<br/>Generation is considered<br/>inoperative.</li> </ul> |
|                          |  | A  | 2 | 1              | One may be inoperative for<br>15 flight-hours or 1 flight-day,<br>whichever occurs first.  |
| 24-56-01                 | GALLEY/GALY and CAB<br>and COMMERCIAL<br>Supply Systems  |    |   |                |  |
| 1)                       | Automatic Load<br>Shedding System  | С  | 1 | 0              | May be inoperative provided<br>GALLEY/GALY and CAB pb switch<br>and GALLEY/GALY and CAB FAULT<br>Light in the cockpit operate normally.  |
| 2)                       | Automatic and Manual<br>Load Shedding Systems  | С  | 2 | 0              | (M) May be inoperative provided all GALLEY/GALY and CAB loads are disconnected.  |
| a)                       | With<br>Mod 20343/MP P0473 or<br>with<br>Mod 31276/MP P7175  | С  | 2 | 0              | (M)(O) May be inoperative provided<br>that the COMMERCIAL supply<br>system is checked operative.   |
| 3)                       | COMMERCIAL Supply<br>System<br>(With<br>Mod 20343/MP P0473 or<br>with<br>Mod 31276/MP P7175)             | С  | 1 | 0              | (O) May be inoperative.  |

| -                             | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/2  |  |    |   |                | PAGE NO. 25-1  |
| AIRCRAFT:<br>Airbus A320      |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment<br>Sequence No. | /Furnishings<br>Item   | 1  | 2 | 3              | 4 Change   |
| 25-00-00                      | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DESPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |   |                | *         Bar  |
| 1)                            | Fault(s) indicated by ELT<br>(With Mod 166219/<br>MP K32599)   | D  | _ | _              | NOTE 1: Dispatch with maintenance<br>status message displayed<br>on ECAM is permitted<br>without CFDS interrogation.NOTE 2: ELT maintenance status<br>message may be spuriously<br>displayed. In this case, flight<br>crew and/or maintenance<br>personnel should disregard<br>ELT maintenance status<br>message provided that it<br>was confirmed to be false<br>by troubleshooting within<br>last 28 days. To confirm that<br>ELT maintenance status<br>message is spurious, apply<br>TSM task 31-39-00-810-<br>813. |

| -   | MENT OF TRANSPORTATI                        | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|---|---|----|---|----------------|---|
| REVISION NO<br>DATE: XX/XX                      |   |    |   |                | PAGE NO. 25-2   |
| AIRCRAFT:<br>Airbus A320<br><b>25. Equipmen</b> | t/Furnishings                               |    | T | 5.<br>6.<br>7. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| Sequence No.                                    | Item  | 1  | 2 | 3              | 4 Change  |
| 25-11-01  | Pilot Seat Adjustments                      |    | - |                | ↔ Bar   |
| 1)  | Electrical Adjustment                       | D  | 2 | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Horizontal and vertical<br/>mechanical adjustments<br/>operate normally, and</li> <li>b) Associated electrical control is<br/>deactivated.</li> </ul> |
| 2)  | Primary Horizontal<br>Mechanical Adjustment | В  | 2 | 0              | May be inoperative provided backup<br>horizontal mechanical adjustment is<br>installed and operates normally.   |
| 3)<br>***                                       | Backup Horizontal<br>Mechanical Adjustment  | D  | 2 | 0              | May be inoperative provided primary horizontal mechanical adjustment operates normally.   |
| 4)  | Vertical Mechanical<br>Adjustment           | С  | 2 | 0              | May be inoperative provided vertical electrical adjustment operates normally.   |
| 5)  | Lumbar                                      | С  | 2 | 0              | May be inoperative provided seat<br>contour is satisfactory to<br>individual/crewmember requirements.   |
| 6)  | Recline Systems                             | A  | 2 | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Seat is secured in an upright position acceptable to the affected crewmember, and</li> <li>b) Repairs are made within 2 flight-days.</li> </ul>       |

| -                           | MENT OF TRANSPORTATION  | ON     |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|---|--------|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/ |   |        |   |                | PAGE NO. 25-3   |
| AIRCRAFT:<br>Airbus A320    |   |        | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipment               |   |        |   | -              | Change  |
| Sequence No.<br>25-11-02    | Item<br>Crewmember Shoulder<br>Harness<br>(Flight Deck)         | 1<br>D | - | -              | Any in excess of those required for<br>flightcrew members (including official<br>observer in forward observer's seat)<br>may be inoperative.  |
| 1)                          | Manual Shoulder<br>Harness Locking Device                       | A      | - | -              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Inertial reel auto locking<br/>mechanism is verified to<br/>operate normally, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul> |
| 25-11-03                    | CAPT and F/O Outboard<br>Armrest Controls                       |        |   |                |   |
| 1)                          | Height Control  | С      | 2 | 0              | May be inoperative provided setting is acceptable to crewmember(s).   |
| 2)                          | Pitch Control<br>(Tilt)   | С      | 2 | 0              | May be inoperative provided setting is acceptable to crewmember(s).   |
| 3)                          | Armrest Memory<br>Position Display                              | С      | 2 | 0              | One or both may be inoperative.   |
| 25-11-04                    | CAPT and F/O Inboard<br>Armrest Vertical<br>Adjustment Controls | С      | 2 | 0              | One or both may be inoperative.   |
| 25-11-05<br>***             | Pilot Seat Headrests  | D      | 2 | 0              | One or both may be inoperative.   |

|                             | MENT OF TRANSPORTAT   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|---|---|---|----------------|--|
|                             | IATION ADMINISTRATION   |   |   |                |  |
| REVISION NC<br>DATE: XX/XX/ | -   |   |   |                | PAGE NO. 25-4  |
| AIRCRAFT:<br>Airbus A320    |   |   | Т | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipmen                | t/Furnishings   |   |   |                |  |
| Sequence No.                | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 25-11-06                    | Primary Observer's<br>Sliding Seat<br>(Including Associated<br>Equipment) | A | 1 | 0              | May be inoperative provided:<br>a) A passenger seat in the<br>passenger cabin is made<br>available to an FAA inspector<br>for the performance of official<br>duties, and<br>b) Repairs are made within<br>2 flight-days.   |
|                             |   | A | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Secondary observer's seat is available to the FAA inspector for the performance of official duties, and</li> <li>b) Repairs are made within 2 flight-days.</li> </ul>  |
|                             |   | A | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Required minimum safety<br/>equipment (oxygen and<br/>safety belt) is available,</li> <li>b) Seat is acceptable to the<br/>FAA Inspector for the<br/>performance of official duties,<br/>and</li> <li>c) Repairs are made within<br/>2 flight-days.</li> </ul> |
|                             |   |   |   |                | NOTE 1: These provisos are<br>intended to provide for<br>occupancy of the above<br>seats by an FAA inspector<br>when the minimum safety<br>equipment (oxygen and<br>safety belt) is functional and<br>the inspector determines the<br>conditions to be acceptable.   |
|                             |   |   |   |                | NOTE 2: The pilot in command will<br>determine if the minimum<br>safety equipment is<br>functional for other persons<br>authorized to occupy any<br>observer seat(s).  |

| _                               | MENT OF TRANSPORTAT  | - |   |                | MASTER MINIMUM EQUIPMENT LIS   |
|---------------------------------|--|---|---|----------------|--|
| REVISION NO<br>DATE: XX/XX      | -  |   |   |                | PAGE NO. 25-   |
| AIRCRAFT:<br>Airbus A320        |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipmen                    |  |   |   |                | Chang  |
| Sequence No.<br>25-11-07<br>*** | Additional Observer's<br>Fixed Seat<br>(Including Associated<br>Equipment) | D | 2 | <u>3</u><br>0  | <ul> <li>(M) May be inoperative or removed.</li> <li>NOTE: The pilot in command will<br/>determine if the minimum<br/>safety equipment is functional<br/>for other persons authorized<br/>to occupy any observer<br/>seat(s).</li> </ul> |
| 25-13-01<br>***                 | CAPT and F/O Sliding<br>Tables   |   |   |                |  |
| 1)                              | Sliding Tables   | D | 2 | 0              | (M) May be inoperative in the stowed position or removed.  |
| 2)                              | Table Tilt Function  | D | 2 | 0              | May be inoperative provided associated table can be stowed.  |
| 25-13-02<br>***                 | CAPT and F/O<br>Retractable Footrests                                      | D | - | 0              | (M) May be inoperative secured in the retracted position or removed.   |
| 25-15-01<br>***                 | Crew Foot Warmers  | D | 2 | 0              | (M)(O) May be inoperative provided<br>affected crew foot warmer is<br>deactivated.   |

| REVISION NO. 32       PAGE NO. 25-6         DATE: XXXX/XXXX       Image: Construct of the second secon | -            | MENT OF TRANSPORTATI                                      | ON |   |                | MASTER MINIMUM EQUIPMENT   | LIST   |
|---|--------------|---|----|---|----------------|--|--------|
| AIRCRAFT:       1. REPAR CATEGORY         Airbus A320       1. NO. INSTALLED         3. NO. REQUIRED FOR DISPATCH       4. REMARKS OR EXCEPTIONS         25. Equipment/Furnishings       5. No. REQUIRED FOR DISPATCH         3. No. REQUIRED FOR DISPATCH       4. REMARKS OR EXCEPTIONS         25.21-01       Passenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -         1)       Passenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -         2)       Positioning Controls for<br>Taxi, Takeoff, and<br>Landing (TTL)<br>(Mechanical and/or<br>Electrical)       D       -         2)       Positioning Controls for<br>Taxi, Takeoff, and<br>Landing (TTL)       D       -       -         3)       Underseat Baggage<br>Restraining Bars       C       -       -       May be inoperative and seat<br>occupied provided seat to set is placed<br>and/or adjacent outboard<br>seats.         3)       Underseat Baggage<br>Restraining Bars       C       -       -       -         3)       Underseat Baggage<br>Restraining Bars       C       -       -       -  | REVISION NO  | D. 32   |    |   |                | PAGE NO  | . 25-6 |
| Sequence No.       Item       1       2       3       4       Peasenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -       -       May be inoperative provided:<br>a) Seat does not restrict access<br>to any emergency exit,<br>egress route, or main aisle,<br>and         1)       Passenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -       -       May be inoperative provided:<br>a) Seat does not restrict access<br>to any emergency exit,<br>egress route, or main aisle,<br>and         b)       Affected seat(s) are blocked<br>and placarded<br>"DO NOT OCCUPY".       NOTE 1: A seat with an inoperative<br>seat belt is considered<br>inoperative.         0)       OTE 2: Inoperative seats do not<br>affect the required number<br>of flight attendants.       NOTE 3: Affected seat(s) may<br>include the seat(s) behind<br>and/or adjacent outboard<br>seats.         2)       Positioning Controls for<br>Taxi, Takeoff, and<br>Landing (TTL)<br>(Mechanical and/or<br>Electrical)       D       -       -         D       -       -       May be inoperative and seat<br>occupied provided seat is secured in<br>the taxi, takeoff, and landing (TTL)<br>position.         3)       Underseat Baggage<br>Restraining Bars       C       -       -         3)       Underseat Baggage<br>Restraining Bars       C       -       -         4)       Associated seat is placarded<br>"DO NOT STOW BAGGAGE<br>UNDER THIS SEAT, and<br>ol alert cabin crew of inoperative<br>restraining bar.   |              |   |    | Т | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |        |
| Sequence No.       Item       1       2       3       4       Peasenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -       -       May be inoperative provided:<br>a) Seat does not restrict access<br>to any emergency exit,<br>egress route, or main aisle,<br>and         1)       Passenger Seats<br>(Includes All<br>Configurations and<br>Locations)       D       -       -       May be inoperative provided:<br>a) Seat does not restrict access<br>to any emergency exit,<br>egress route, or main aisle,<br>and         b)       Affected seat(s) are blocked<br>and placarded<br>"DO NOT OCCUPY".       NOTE 1: A seat with an inoperative<br>seat belt is considered<br>inoperative.         0)       OTE 2: Inoperative seats do not<br>affect the required number<br>of flight attendants.       NOTE 3: Affected seat(s) may<br>include the seat(s) behind<br>and/or adjacent outboard<br>seats.         2)       Positioning Controls for<br>Taxi, Takeoff, and<br>Landing (TTL)<br>(Mechanical and/or<br>Electrical)       D       -       -         D       -       -       May be inoperative and seat<br>occupied provided seat is secured in<br>the taxi, takeoff, and landing (TTL)<br>position.         3)       Underseat Baggage<br>Restraining Bars       C       -       -         3)       Underseat Baggage<br>Restraining Bars       C       -       -         4)       Associated seat is placarded<br>"DO NOT STOW BAGGAGE<br>UNDER THIS SEAT, and<br>ol alert cabin crew of inoperative<br>restraining bar.   | 25. Fauipmen | t/Furnishings   |    | 1 |                |  |        |
| <ul> <li>25-21-01 Passenger Seats<br/>(Includes All<br/>Configurations and<br/>Locations)</li> <li>1) Passenger Seats<br/>(Includes All<br/>Configurations and<br/>Locations)</li> <li>1) Passenger Seats<br/>(Includes All<br/>Configurations and<br/>Locations)</li> <li>1) Affected seat(s) are blocked<br/>and placarded<br/>"DO NOT OCUPY".</li> <li>NOTE 1: A seat with an inoperative<br/>seat betil is considered<br/>inoperative.</li> <li>NOTE 2: Inoperative seats do not<br/>affect the required number<br/>of flight attendants.</li> <li>NOTE 3: Affected seat(s) may<br/>include the seat(s) behind<br/>and/or adjacent outboard<br/>seats.</li> <li>2) Positioning Controls for<br/>Taxi, Takeoff, and<br/>Landing (TTL)<br/>(Mechanical and/or<br/>Electrical)</li> <li>D - (M) May be inoperative and seat<br/>occupied provided seat is secured in<br/>the taxi, takeoff, and<br/>landing (TTL) position.</li> <li>3) Underseat Baggage<br/>Restraining Bars</li> <li>C - (O) May be inoperative provided:<br/>a) Baggage is not stowed under<br/>seat with inoperative<br/>restraining bar.</li> </ul>  |              |   | 1  | 2 | 3              | 4  |        |
| <ul> <li>(Includes All<br/>Configurations and<br/>Locations)</li> <li>a) Seat does not restrict access<br/>to any emergency exit,<br/>egress route, or main aisle,<br/>and</li> <li>b) Affected seat(s) are blocked<br/>and placarded<br/>"DO NOT OCCUPY".</li> <li>NOTE 1: A seat with an inoperative<br/>seat belt is considered<br/>inoperative.</li> <li>NOTE 2: Inoperative seats do not<br/>affect the required number<br/>of flight attheatats.</li> <li>NOTE 3: Affected seat(s) behind<br/>and/or adjacent outboard<br/>seats.</li> <li>Positioning Controls for<br/>Taxi, Takeoff, and<br/>Landing (TTL)<br/>(Mechanical and/or<br/>Electrical)</li> <li>D -</li> <li>(M) May be inoperative and seat<br/>occupied provided seat is secured in<br/>the taxi, takeoff, and landing (TTL)<br/>position.</li> <li>D -</li> <li>May be inoperative provided:<br/>a) Baggage is not stowed under<br/>seat with inoperative<br/>restraining bar,</li> <li>And Placarded<br/>"DO NOT Store<br/>immovable in the taxi, takeoff, and<br/>landing (TTL) position.</li> <li>And be inoperative provided:<br/>a) Baggage is not stowed under<br/>seat with inoperative<br/>restraining bar,</li> <li>Associated seat is placarded<br/>"DO NOT STOW BAGGAGE<br/>UNDER THIS SEAT", and</li> <li>Procedures are established to<br/>alert cabin crew of inoperative<br/>restraining bar.</li> </ul>   | 25-21-01     |   |    | - | 5              | *  | Bar    |
| <ul> <li>Positioning Controls for<br/>Taxi, Takeoff, and<br/>Landing (TTL)<br/>(Mechanical and/or<br/>Electrical)</li> <li>D - (M) May be inoperative and seat<br/>occupied provided seat is secured in<br/>the taxi, takeoff, and landing (TTL)<br/>position.</li> <li>D - (May be inoperative and seat<br/>occupied provided seat back is<br/>immovable in the taxi, takeoff, and<br/>landing (TTL) position.</li> <li>Underseat Baggage<br/>Restraining Bars</li> <li>C - (O) May be inoperative provided:         <ul> <li>a) Baggage is not stowed under<br/>seat with inoperative<br/>restraining bar,</li> <li>Associated seat is placarded<br/>"DO NOT STOW BAGGAGE<br/>UNDER THIS SEAT", and</li> <li>Procedures are established to<br/>alert cabin crew of inoperative<br/>restraining bar.</li> </ul> </li> </ul>  | 1)           | (Includes All<br>Configurations and                       | D  | - | -              | <ul> <li>a) Seat does not restrict access to any emergency exit, egress route, or main aisle, and</li> <li>b) Affected seat(s) are blocked and placarded "DO NOT OCCUPY".</li> <li>NOTE 1: A seat with an inoperative seat belt is considered inoperative.</li> <li>NOTE 2: Inoperative seats do not affect the required number</li> </ul> |        |
| <ul> <li>Taxi, Takeoff, and<br/>Landing (TTL)<br/>(Mechanical and/or<br/>Electrical)</li> <li>D May be inoperative and seat<br/>occupied provided seat back is<br/>immovable in the taxi, takeoff, and<br/>landing (TTL) position.</li> <li>Underseat Baggage<br/>Restraining Bars</li> <li>C (O) May be inoperative provided:         <ul> <li>a) Baggage is not stowed under<br/>seat with inoperative<br/>restraining bar,</li> <li>b) Associated seat is placarded<br/>"DO NOT STOW BAGGAGE<br/>UNDER THIS SEAT", and</li> <li>c) Procedures are established to<br/>alert cabin crew of inoperative<br/>restraining bar.</li> </ul> </li> </ul>   |              |   |    |   |                | NOTE 3: Affected seat(s) may<br>include the seat(s) behind<br>and/or adjacent outboard   |        |
| <ul> <li>3) Underseat Baggage Restraining Bars</li> <li>C - (O) May be inoperative provided:         <ul> <li>a) Baggage is not stowed under seat with inoperative restraining bar,</li> <li>b) Associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT", and</li> <li>c) Procedures are established to alert cabin crew of inoperative restraining bar.</li> </ul> </li> </ul>   | 2)           | Taxi, Takeoff, and<br>Landing (TTL)<br>(Mechanical and/or | D  | - | -              | occupied provided seat is secured in<br>the taxi, takeoff, and landing (TTL)   |        |
| <ul> <li>Restraining Bars</li> <li>a) Baggage is not stowed under seat with inoperative restraining bar,</li> <li>b) Associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT", and</li> <li>c) Procedures are established to alert cabin crew of inoperative restraining bar.</li> </ul>  |              |   | D  | - | -              | occupied provided seat back is<br>immovable in the taxi, takeoff, and  |        |
| (Continued)   | 3)           |   | С  | _ | -              | <ul> <li>a) Baggage is not stowed under seat with inoperative restraining bar,</li> <li>b) Associated seat is placarded "DO NOT STOW BAGGAGE UNDER THIS SEAT", and</li> <li>c) Procedures are established to alert cabin crew of inoperative restraining bar.</li> </ul>   |        |

| -                            | MENT OF TRANSPORTATION  | ON |     | MASTER MINIMUM EQUIPMENT LIST |  |  |
|------------------------------|---|----|-----|-------------------------------|--|--|
| REVISION NO<br>DATE: XX/XX/2 |   |    |     |                               | PAGE NO. 25-7  |  |
| AIRCRAFT:<br>Airbus A320     |   |    | Т   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |
| 25. Equipment                |   |    | L . | Γ.                            | Change   |  |
| Sequence No.<br>25-21-01     | Item<br>Passenger Seat(s)<br>(Cont'd)   | 1  | 2   | 3                             | 4 Change<br>Bar  |  |
| 4)<br>a)                     | Armrests<br>With Seat Positioning<br>Controls for Taxi,<br>Takeoff, and Landing<br>(TTL) and/or Other<br>Controls             | D  | -   | -                             | <ul> <li>(M) May be inoperative or missing<br/>and seat occupied provided: <ul> <li>a) Armrest does not restrict<br/>access to any emergency exit,<br/>egress route, or main aisle,<br/>and</li> <li>b) If Armrest with seat control is<br/>missing or removed, seat is<br/>secured in taxi, takeoff, and<br/>landing (TTL) position.</li> </ul> </li> </ul> |  |
| b)<br>5)                     | Without Seat Positioning<br>Controls for Taxi,<br>Takeoff, and Landing<br>(TTL) and/or Other<br>Controls<br>Seat Belt/Air Bag | D  | -   | -                             | May be inoperative or missing and<br>seat occupied provided it does not<br>restrict access to any emergency exit,<br>egress route, or main aisle.  |  |
| a)                           | Restraint Systems<br>Seat Belt/Air Bags<br>Required by 14 CFR   | D  | -   | -                             | May be inoperative provided affected seat is blocked and placarded "DO NOT OCCUPY".  |  |
| b)                           | Seat Belt/Air Bags Not<br>Required by 14 CFR  | D  | -   | -                             | (M) May be inoperative or<br>disconnected provided seat belt<br>operates normally.   |  |

|  |  |   |   |                |  | T LIST        |
|--|--|---|---|----------------|--|---------------|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 32 |  |   |   |                | PAGE NO  | ). 25-8       |
| DATE: XX/XX/X                                      |  |   |   |                |  |               |
| AIRCRAFT:<br>Airbus A320                           |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 25. Equipment/                                     | Furnishings  |   | 1 | 1              |  |               |
| Sequence No.                                       | Item   | 1 | 2 | 3              | 4  | Change<br>Bar |
| 25-22-01   | Flight Attendant Seat<br>Assembly<br>(Single or Dual Position) | С | - | 0              | <ul> <li>(O) May be inoperative or missing provided:</li> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul>  |               |
| 1)   | Required Flight<br>Attendant Seats                             | В |   |                | <ul> <li>(M)(O) One seat position or assembly<br/>(dual position) may be inoperative<br/>provided: <ul> <li>a) Affected seat position or seat<br/>assembly is not occupied,</li> <li>b) Flight attendant(s) displaced<br/>by inoperative seat(s)<br/>occupies either an adjacent<br/>flight attendant seat or the<br/>passenger seat which is most<br/>accessible to the inoperative<br/>seat(s) so as to most<br/>effectively perform assigned<br/>duties,</li> <li>c) Alternate procedures are<br/>established and used as<br/>published in crewmember<br/>manuals,</li> <li>d) Folding type seat stows<br/>automatically or is secured in<br/>the retracted position, and</li> <li>e) Passenger seat assigned to<br/>flight attendant is placarded<br/>"FOR FLIGHT ATTENDANT<br/>USE ONLY".</li> </ul> </li> <li>NOTE 1: An automatic folding seat<br/>that will not stow<br/>automatically is considered<br/>inoperative.</li> </ul> | ,             |

| FEDERAL AVIATION ADMINISTRATION       MASTER MINIMUM EQUIPMENT LIST         REVISION NO. 32       PAGE NO. 25-9         DATE: XXIXXXXXX       FABLE KEY         AIRCRAFT:       I. REPAIR CATEGORY         Airbus A320       I. REPAIR CATEGORY         25. Equipment/Furnishings       I. REMARKS OR EXCEPTIONS         25-22-01       Flight Attendant Seat<br>Assembly<br>(Single or Dual Position)<br>(Cont'd)       I       I       I       I. REMARKS OR EXCEPTIONS         25-22-01       Flight Attendant Seat<br>Assembly<br>(Songle or Dual Position)<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperating with inoperative<br>seats, will consider the<br>locations and combinations<br>of seats to ensure that the<br>proximity to exits and<br>distribution requirements of<br>the applicable 14 CFR are<br>met.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative and<br>a flight attendant is<br>displaced to the adjacent<br>seat, the adjacent seat must<br>operate normally.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         2)  | U.S. DEPARTI  | MENT OF TRANSPORTATION                | ON |   |                |   |
|---|---------------|---------------------------------------|----|---|----------------|---|
| DATE: XX/XXXXX         AIRCRAFT:<br>Airbus A320       Image: Constraint of the second                            | FEDERAL AVI   | ATION ADMINISTRATION                  |    |   |                | MASTER MINIMUM EQUIPMENT LIST   |
| AIRCRAFT:<br>Airbus A320       1       2       1       REPAIR CATEGORY         25. Equipment/Furnishings       3       NO. REQUIRED FOR DISPATCH       4.       REMARKS OR EXCEPTIONS         25.22-01       Flight Attendant Seat<br>Assembly<br>(Single or Dual Position)<br>(Cont'd)       1       2       3       4       Change<br>Considered inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative and<br>a flight attendant is<br>displaced to the adjacent<br>seat, the adjacent seat<br>met.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is socured in<br>the retracted position.   |               |                                       |    |   |                | PAGE NO. 25-9   |
| Sequence No.       Item       1       2       3       4       Comparison         25-22-01       Flight Attendant Seat<br>Assembly<br>(Single or Dual Position)<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative and<br>a flight attendant is<br>displaced to the adjacent<br>seat, the adjacent seat must<br>operate normally.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         2)       Excess Flight Attendant<br>Seats       -       -       (M) May be inoperative provided:<br>a) Affected seat position or sea   | -             |                                       |    | Т | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |
| <ul> <li>2) Excess Flight Attendant Seat Seats</li> <li>2) Excess Flight Attendant Seats</li> <li>2) Excess Flight Attendant Seats</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>2) Excess Flight Attendant Seats</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>2) Excess Flight Attendant Seats</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>3) Contiduation of the applicable 14 CFR are met.</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>4) Contiduation of the applicable 14 CFR are met.</li> <li>5) Contiduation of the applicable 14 CFR are met.</li> <li>5) Contiduation of the applicable 14 CFR are met.</li> <li>6) Contiduation of the applicable 14 CFR are met.</li> <li>6) Contiduation of the applicable 14 CFR are met.</li> <li>6) Contiduation of the applicable 14 CFR are met.</li> <li>7) Contiduation of the applicable 14 CFR are met.</li> <li>7) Contiduation of the applicable 14 CFR are met.</li> <li>8) Contiduation of the applicable 14 CFR are met.</li> <li>8) Contiduation of the applicable 14 CFR are met.</li> <li>9) Folding type seat tows and the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>1) Contiduation of the applicable 14 CFR are met.</li> <li>2) Excess Flight Attendant and the applicable 14 CFR are met.</li> <li>2) Excess Flight Attendant and the applicable 14 CFR are met.</li> <li< td=""><td>25. Equipment</td><td>/Furnishings</td><td></td><td></td><td>1</td><td></td></li<></ul> | 25. Equipment | /Furnishings                          |    |   | 1              |   |
| Assembly<br>(Single or Dual Position)<br>(Cont'd)       B       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         1)       Required Flight<br>Attendant Seats<br>(Cont'd)       B       -       -       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is<br>considered inoperative.         NOTE 3: Individual operators, when<br>operating with inoperative<br>seats, will consider the<br>locations and combinations<br>of seats to ensure that the<br>proximity to exits and<br>distribution requirements of<br>the applicable 14 CFR are<br>met.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a) Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         NOTE 1: An automatic folding seat<br>that will not stow<br>automatically is considered<br>inoperative.       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is  | Sequence No.  |                                       | 1  | 2 | 3              |   |
| Attendant Seats<br>(Cont'd)       inoperative or missing<br>restraint system is<br>considered inoperative.         NOTE 3: Individual operators, when<br>operating with inoperative<br>seats, will consider the<br>locations and combinations<br>of seats to ensure that the<br>proximity to exits and<br>distribution requirements of<br>the applicable 14 CFR are<br>met.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>assembly is inoperative and<br>a flight attendant is<br>displaced to the adjacent<br>seat, the adjacent seat must<br>operate normally.         2)       Excess Flight Attendant<br>Seats       C       -       -       (M) May be inoperative provided:<br>a Affected seat position or seat<br>assembly is not occupied, and<br>b) Folding type seat stows<br>automatically or is secured in<br>the retracted position.         NOTE 1: An automatic folding seat<br>that will not stow<br>automatically is considered<br>inoperative.       NOTE 2: A seat position with an<br>inoperative or missing<br>restraint system is   | 25-22-01      | Assembly<br>(Single or Dual Position) |    |   |                |   |
| <ul> <li>2) Excess Flight Attendant<br/>Seats</li> <li>C - (M) May be inoperative provided:         <ul> <li>a) Affected seat position or seat<br/>assembly is not occupied, and</li> <li>b) Folding type seat stows<br/>automatically or is secured in<br/>the retracted position.</li> </ul> </li> <li>NOTE 1: An automatic folding seat<br/>that will not stow<br/>automatically is considered<br/>inoperative.</li> <li>NOTE 2: A seat position with an<br/>inoperative or missing<br/>restraint system is</li> </ul>   | 1)            | Attendant Seats                       | В  |   | -              | <ul> <li>inoperative or missing<br/>restraint system is<br/>considered inoperative.</li> <li>NOTE 3: Individual operators, when<br/>operating with inoperative<br/>seats, will consider the<br/>locations and combinations<br/>of seats to ensure that the<br/>proximity to exits and<br/>distribution requirements of<br/>the applicable 14 CFR are<br/>met.</li> <li>NOTE 4: If one side of a dual seat<br/>assembly is inoperative and<br/>a flight attendant is<br/>displaced to the adjacent<br/>seat, the adjacent seat must</li> </ul> |
| (Continued)   | 2)            | <b>U</b>                              | С  | _ | _              | <ul> <li>(M) May be inoperative provided: <ul> <li>a) Affected seat position or seat assembly is not occupied, and</li> <li>b) Folding type seat stows automatically or is secured in the retracted position.</li> </ul> </li> <li>NOTE 1: An automatic folding seat that will not stow automatically is considered inoperative.</li> <li>NOTE 2: A seat position with an inoperative or missing restraint system is considered inoperative.</li> </ul>   |

| -                            |  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|----------------|--|
|                              |  |    |   |                |  |
| REVISION NO<br>DATE: XX/XX/X | -  |    |   |                | PAGE NO. 25-10   |
| AIRCRAFT:<br>Airbus A320     |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment                |  | [  |   | 1              | Change   |
| Sequence No.<br>25-22-01     | Item<br>Flight Attendant Seat<br>Assembly<br>(Single or Dual Position)<br>(Cont'd) | 1  | 2 | 3              | 4 Change<br>Bar  |
| 3)                           | All-Cargo Configuration  | D  | - | -              | May be inoperative provided affected seat or seat assembly is not occupied.  |
| 25-22-03                     | Nonessential Equipment<br>and Furnishings (NEF)                                    | -  | - | 0              | May be inoperative, damaged, or<br>missing provided that the item(s) is<br>deferred in accordance with the<br>operator's NEF deferral program. The<br>NEF program, procedures, and<br>processes are outlined in the<br>operator's (insert name) Manual.<br>(M) and (O) procedures, if required,<br>must be available to the flightcrew<br>and included in the operator's<br>appropriate document.<br>NOTE: Exterior lavatory door<br>ashtrays are not considered<br>NEF items. |
| 25-22-04                     | Exterior Lavatory Door<br>Ashtrays   |    |   |                |  |
| 1)                           | Airplanes with More<br>Than One Exterior<br>Lavatory Door Ashtray<br>Installed     | A  | - | -              | Up to and including 50% may be<br>missing or inoperative for<br>10 consecutive calendar-days.  |
|                              |  | A  | - | -              | More than 50% may be missing or inoperative for 3 days.  |
| 2)                           | Airplanes with Only One<br>Exterior Lavatory Door<br>Ashtray Installed             | A  | 1 | 0              | May be missing or inoperative for<br>10 days.  |

| FEDERAL AVIATION ADMINISTRATION |   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |        |  |  |
|---------------------------------|---|---|---|-------------------------------|--|--------|--|--|
| REVISION NO<br>DATE: XX/XX/     |   |   |   |                               | PAGE NO.   | 25-11  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |  |  |
| 25. Equipment                   |   |   |   |                               | 1.   | Change |  |  |
| Sequence No.<br>25-27-01<br>*** | Item<br>Heating Function of<br>Heated Floor Panels<br>(Passenger/Crew Doors,<br>Emergency Exits, and<br>Galley Areas) | D | - | 3<br>0                        | 4<br>(M) May be inoperative provided the<br>heating elements of the affected<br>heated floor panel are deactivated.  | Bar    |  |  |
| 25-28-01                        | Storage Bin(s)/Cabin,<br>Galley, and Lavatory<br>Storage<br>Compartment/Closets                                       | С |   |                               | <ul> <li>(M) May be inoperative provided: <ul> <li>a) Procedures are established to secure affected bin, compartment, or closet in closed position,</li> <li>b) Associated bin, compartment, or closet is prominently placarded "DO NOT USE",</li> <li>c) Any emergency equipment located in affected bin, compartment or closet is considered inoperative, and</li> <li>d) Affected bin, compartment, or closet is not used for storage of any item(s) except for those permanently affixed.</li> </ul> NOTE 1: For overhead bins, if no partitions are installed, the entire overhead bin is considered one compartment. NOTE 2: Proviso is not intended to preclude crewmember inspections.</li></ul> |        |  |  |
|                                 |   |   |   |                               | (Continued)  |        |  |  |

| -                        | MENT OF TRANSPORTAT<br>IATION ADMINISTRATION  |   |   |                | MASTER MINIMUM EQUIPMEN  | T LIST        |
|--------------------------|---|---|---|----------------|--|---------------|
| REVISION NO              | 0. 32   |   |   |                | PAGE NO.   | 25-12         |
| DATE: XX/XX              | XXXX  |   |   |                |  |               |
| AIRCRAFT:<br>Airbus A320 |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 25. Equipmen             | t/Furnishings   |   |   |                |  |               |
| Sequence No.             | Item  | 1 | 2 | 3              | 4  | Change<br>Bar |
| 25-28-01                 | Storage Bin(s)/Cabin,<br>Galley, and Lavatory<br>Storage<br>Compartment/Closets<br>(Cont'd) |   |   |                |  |               |
|                          |   | C |   |                | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) For nonretractable doors, affected door is removed,</li> <li>b) For retractable doors, affected door is removed or secured in the retracted (fully open) position,</li> <li>c) Affected bin, compartment, or closet is prominently placarded "DO NOT USE",</li> <li>d) Affected bin, compartment, or closet is not used for storage of any items except those permanently affixed,</li> <li>e) Procedures are established and used to alert crewmembers and passengers of inoperative bins, compartments, or closets, and</li> <li>f) Passengers are briefed that associated bin, compartment or closet is not used.</li> </ul> NOTE 1: For overhead bins, if no partitions are installed, the entire overhead bin is considered inoperative. NOTE 2: Any emergency equipment located in affected bin, compartment, or closet (permanently affixed) is available for use.</li></ul> |               |
|                          |   |   |   |                | (Continued)  |               |

| -                                   | IMENT OF TRANSPORTAT  | ION |   |                | MASTER MINIMUM EQUIPMEN   | T LIST        |  |  |  |
|-------------------------------------|---|-----|---|----------------|---|---------------|--|--|--|
| FEDERAL AVIATION ADMINISTRATION     |   |     |   |                |   |               |  |  |  |
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |     |   |                | PAGE NO.  | 25-13         |  |  |  |
| DATE: XX/XX                         |   |     |   |                |   |               |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |     | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |  |
| 25. Equipmer                        | nt/Furnishings  |     |   |                |   |               |  |  |  |
| Sequence No.                        | Item  | 1   | 2 | 3              | 4   | Change<br>Bar |  |  |  |
| 25-28-01                            | Storage Bin(s)/Cabin,<br>Galley, and Lavatory<br>Storage<br>Compartment/Closets<br>(Cont'd) | C   | - | -              | <ul> <li>May be inoperative in closed position provided: <ul> <li>a) Affected bin, compartment, or closet is prominently placarded "DO NOT USE",</li> <li>b) Any emergency equipment located in affected bin, compartment, or closet is considered inoperative, and</li> <li>c) Location placarding for any emergency equipment stored in affected bin, compartment, or closet is removed or obscured.</li> </ul> </li> <li>NOTE: Use of this proviso may be dependent upon an operator's aircraft security program, as appropriate.</li> </ul> |               |  |  |  |
| 1)<br>***                           | Storage Compartment<br>Key Locks  | D   | - | 0              | (M) May be inoperative in the<br>unlocked position provided doors can<br>be secured by other means.   |               |  |  |  |
| 2)                                  | Multi-Latch/<br>Quarter-Turn Lug  | С   | - | -              | <ul> <li>One latch per compartment may be inoperative provided:</li> <li>a) Remaining latch(es)/lug(s) on affected compartment(s) operates normally, and</li> <li>b) If affected compartment is used for a galley cart, the cart remains empty.</li> </ul>  |               |  |  |  |
| 3)<br>***                           | Mid-Latch Locking<br>Assembly   | D   | - | 0              | May be inoperative provided galley<br>half-length carts are not used at<br>affected location.<br>NOTE: Galley full-length carts can be<br>used.   |               |  |  |  |

| _                            | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                              | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|----|----------------|--|
| REVISION NO<br>DATE: XX/XX/X | -   |    |    |                | PAGE NO. 25-14   |
| AIRCRAFT:<br>Airbus A320     |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment                | /Furnishings  |    |    |                |  |
| Sequence No.                 | Item  | 1  | 2  | 3              | 4 Change   |
| 25-40-01                     | Lavatory Waste<br>Receptacle Access<br>Doors/Covers/Flapper/<br>Doors     | C  | -  | -              | <ul> <li>(M) May be inoperative provided:         <ul> <li>a) Associated waste container is empty,</li> <li>b) Affected receptacle access doors/covers/flapper door is secured to prevent waste introduction into the receptacle,</li> <li>c) Lavatory is used only by crewmembers, and</li> <li>d) Associated lavatory entrance door is locked closed and placarded "INOPERATIVE - DO NOT ENTER".</li> </ul> </li> <li>NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.</li> </ul> |
| 25-45-01                     | Galley/Cabin Waste<br>Receptacles Access<br>Doors/Covers/Flapper<br>Doors | С  | -  | _              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) The container is empty and<br/>the access is secured to<br/>prevent waste introduction<br/>into the compartment, and</li> <li>b) Procedures are established to<br/>ensure that sufficient<br/>galley/cabin waste<br/>receptacles are available to<br/>accommodate all waste that<br/>may be generated on a flight.</li> </ul>   |
| 25-50-01<br>***              | Cargo Loading System  | D  | -  | 0              | NOTE: Any part of the CLS that<br>operates normally may be<br>used.  |

| -  | MENT OF TRANSPORTATION                                    | ON |   |                | MASTER MINIMUM EQUIPMENT L   | .IST         |
|--|---|----|---|----------------|--|--------------|
| REVISION NO.<br>DATE: XX/XX/X                    |   |    |   |                | PAGE NO. 25  | 5-15         |
| AIRCRAFT:<br>Airbus A320<br><b>25. Equipment</b> | /Furnishings  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |              |
| Sequence No.                                     | Item  | 1  | 2 | 3              | 4  | hange<br>Bar |
| 25-50-02   | Blow In/Out Panels in<br>Lower Deck Cargo<br>Compartments | C  |   | 0              | <ul> <li>(O) May be damaged or missing provided procedures are established and used to ensure associated compartment remains empty or is verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Away Kits.</li> <li>NOTE 1: When Blow In/Out Panels in AFT or BULK cargo compartments are damaged or missing, both cargo compartments remain empty or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and/or Fly Xits.</li> <li>NOTE 2: Operator MELs must define which items are approved for inclusion in Fly Away Kits and which materials can be used as ballast.</li> </ul> | Bar          |

| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 32 |  |   |   |                | PAGE NO. 25-16   |
|--|--|---|---|----------------|--|
| DATE: XX/XX/X                                      |  |   |   |                | PAGE NO. 25-10   |
| AIRCRAFT:<br>Airbus A320                           |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment/F<br>Sequence No.                    | tem  | 1 | 2 | 3              | 4 Change   |
| 25-50-03   | Lining Panels in Lower<br>Deck Cargo<br>Compartments | C | - | 0              | <ul> <li>(O) May be damaged provided<br/>procedures are established and used<br/>to ensure associated compartment<br/>remains empty or is verified to<br/>contain only empty cargo handling<br/>equipment, ballast (ballast may be<br/>loaded in ULDs), and/or Fly Away<br/>Kits.</li> <li>NOTE 1: Lining panels covered by<br/>this MMEL item include<br/>ceiling panels, sidewall<br/>panels, partition panels<br/>(including tarpaulin), cargo<br/>door panels, and actuator<br/>panels.</li> <li>NOTE 2: When lining panels in AFT<br/>or BULK cargo<br/>compartments are<br/>damaged, both cargo<br/>compartments remain<br/>empty or are verified to<br/>contain only empty cargo<br/>handling equipment, ballast<br/>(ballast may be loaded in<br/>ULDs), and/or Fly Away<br/>Kits.</li> <li>NOTE 3: Operator MELs must define<br/>which items are approved<br/>for inclusion in Fly Away<br/>Kits and which materials<br/>can be used as ballast.</li> </ul> |

| -                                   | MENT OF TRANSPORTATI   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|--|----|---|---|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |    |   |   | PAGE NO. 25-17  |
| AIRCRAFT:<br>Airbus A320            | AIRCRAFT:  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipmen                        | nt/Furnishings   |    |   |   |   |
| Sequence No.                        | ltem   | 1  | 2 | 3 | 4 Change<br>Bar   |
| 25-50-03                            | Lining Panels in Lower<br>Deck Cargo<br>Compartments<br>(Cont'd)     |    |   |   |   |
|                                     |  | С  | - | 0 | May be missing provided associated cargo compartment remains empty.   |
|                                     |  |    |   |   | NOTE 1: Lining panels covered by<br>this MMEL item include<br>ceiling panels, sidewall<br>panels, partition panels<br>(including tarpaulin), cargo<br>door panels, and actuator<br>panels.  |
|                                     |  |    |   |   | NOTE 2: When Lining Panels in AFT<br>or BULK cargo<br>compartments are missing,<br>both cargo compartments<br>remain empty.   |
| 25-50-04                            | Cargo Restraint System<br>(Nets, Attach Points,<br>Stanchions, etc.) | A  | - |   | <ul> <li>(M) May be inoperative or missing provided: <ul> <li>a) Approved cargo-loading limits are observed. The only source documents are:</li> <li>Type certificate (TC),</li> <li>Supplemental Type Certificate (STC),</li> <li>Airplane Flight Manual (AFM),</li> <li>Airplane Flight Manual Supplement (AFMS),</li> <li>Pilot's Operating Handbook (POH),</li> <li>TC/STC Weight and Balance Manual (WBM), and</li> </ul> </li> <li>b) Repairs are made within 120 consecutive calendar-days.</li> </ul> |
|                                     |  |    |   |   | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|--|---|---|----------------|---|--|--|--|
| REVISION NC  |  |   |   |                | PAGE NO. 25-18  |  |  |  |
| DATE: XX/XX/   | XXXX   |   |   |                |   |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 25. Equipment  |  |   |   |                | A Change  |  |  |  |
| Sequence No.<br>25-50-04   | Item<br>Cargo Restraint System<br>(Nets, Attach Points,<br>Stanchions, etc.)<br>(Cont'd) | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |
|  |  | A | - | -              | <ul> <li>May be inoperative or missing provided:</li> <li>a) Cargo compartment remains empty, and</li> <li>b) Repairs are made within 120 consecutive calendar-days.</li> </ul>   |  |  |  |
|  |  | A | - | -              | <ul> <li>Individual cargo areas may be inoperative provided:</li> <li>a) Aircraft is operated in accordance with Original Equipment Manufacturer (OEM) W&amp;B source document, and</li> <li>b) Repairs are made within 120 consecutive calendar-days.</li> </ul> |  |  |  |
|  |  | С | - | 0              | (O) May be inoperative, damaged, or<br>missing provided associated cargo<br>compartment remains empty or is<br>checked to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits.                    |  |  |  |

| U.S. DEPART                     | MENT OF TRANSPORTATIO   | ON |   |                |  |  |  |  |  |
|---------------------------------|---|----|---|----------------|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
| REVISION NO. 32                 |   |    |   |                | PAGE NO. 25-19   |  |  |  |  |
| DATE: XX/XX                     | X/XXXX  |    |   |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
|                                 | nt/Furnishings  |    | 1 |                |  |  |  |  |  |
| Sequence No.                    | ltem  | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 25-50-05<br>***                 | Protection Panel of<br>Decompression Panels<br>at the FWD Partition<br>Wall of FWD Cargo<br>Compartment | С  | - | 0              | <ul> <li>(M) One or more may be damaged provided:</li> <li>a) The affected protection panel is removed if the damage prevents correct operation of the decompression panel, and</li> <li>b) Bulk loading is not permitted in the section between the affected protection panel and the closest divider net.</li> </ul> |  |  |  |  |
|                                 |   |    |   |                | NOTE: Tied down cargo is not considered as bulk loading.   |  |  |  |  |
| 25-60-01<br>***                 | Evacuation Alarm<br>Signaling System<br>(EVAC COMMAND)  | С  | 1 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |  |  |  |  |
|                                 |   | D  | 1 | 0              | May be inoperative provided operations do not require its use.   |  |  |  |  |
| 25-60-03                        | SLIDE ARMED Warning<br>Systems  |    |   |                |  |  |  |  |  |
| 1)                              | SLIDE ARMED Indicator<br>Light<br>(Without Mod. 160940/<br>MP P20211                                    | С  | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |  |  |  |  |
| 2)                              | Inadvertent Slide<br>Deployment Prevention<br>System (ISDPS)<br>(With Mod. 160940/<br>MP P20211         | С  | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |  |  |  |  |
| a)                              | Acoustic Buzzer   | С  | - | 0              | May be inoperative provided associated SLIDE ARMED light is operative.   |  |  |  |  |
| b)                              | Light   | С  | - | 0              | One or more may be inoperative.  |  |  |  |  |

| -                            | MENT OF TRANSPORTATION                                   | NC |          |                | MASTER MINIMUM EQUIPMENT LIST   |
|------------------------------|--|----|----------|----------------|---|
| REVISION NO<br>DATE: XX/XX/2 |  |    |          |                | PAGE NO. 25-20  |
| AIRCRAFT:<br>Airbus A320     |  |    | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipment                |  |    | <b>^</b> | <b>^</b>       | A Change  |
| Sequence No.<br>25-60-04     | Item<br>SLIDE Indications on<br>ECAM DOOR/OXY Page       | 1  | 2        | 3              | 4 Change<br>Bar   |
| 1)                           | Passenger Doors  |    |          |                |   |
| a)                           | Armed Indication   | В  | -        | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |
| b)                           | Not Armed Indication                                     | С  | -        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) Aircraft is not operated at<br/>night.</li> </ul> |
| 2)<br>***                    | Overwing Emergency<br>Exit(s)                            |    |          |                |   |
| a)                           | Armed Indication   | В  | -        | 0              | (M) May be inoperative provided a visual check is made to verify that slide(s) is armed.  |
| b)                           | Not Armed Indication                                     | С  | -        | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Visual check is made that<br/>slide(s) is armed, and</li> <li>b) Aircraft is not operated at<br/>night.</li> </ul>      |
| 25-60-07                     | "Fasten Seat Belts While<br>Seated" Signs or<br>Placards | С  | -        | -              | One or more may be illegible or<br>missing provided a legible sign or<br>placard is visible from each occupied<br>passenger seat.   |

|                               | IENT OF TRANSPORTATI                             | ON     |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------|--|--------|---|----------------|---|
| REVISION NO.<br>DATE: XX/XX/> |  |        |   |                | PAGE NO. 25-21  |
| AIRCRAFT:<br>Airbus A320      |  |        | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipment/                | Furnishinas                                      |        |   |                |   |
| Sequence No.                  | Item   | 1      | 2 | 3              | 4 Change  |
| 25-60-08                      | Flashlight and Holders<br>(Flight Deck or Cabin) | D      | - | -              | <ul> <li>May be inoperative or removed provided:         <ul> <li>a) Crewmember assigned to the affected position has an equivalent operative flashlight readily available,</li> <li>b) Inoperative flashlight remains in a certified location or is removed from the aircraft, and</li> <li>c) Location placarding is removed or obscured.</li> </ul> </li> <li>Any in excess of those required by 14 CFR may be inoperative or removed provided:         <ul> <li>a) Inoperative flashlight remains in a certified location until removed from the aircraft at the next suitable maintenance facility, and</li> <li>b) Location placarding is removed or obscured.</li> </ul> </li> </ul> |
| 1)                            | Tamper seals or Tags                             | C<br>C | - | 0              | <ul> <li>(O) May be inoperative or missing provided:</li> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> <li>(O) May be inoperative, damaged, or missing provided proper installation and operation is verified at each</li> </ul>   |

| _                              | MENT OF TRANSPORTATION                        | ON |   | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------------|---|----|---|--|
| REVISION NO<br>DATE: XX/XX/2   |   |    |   | PAGE NO. 25-22   |
| AIRCRAFT:<br>Airbus A320       |   |    | Т | ABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS   |
| 25. Equipment                  | /Furnishings                                  |    | 1 |  |
| Sequence No.<br>25-60-09<br>1) | Item<br>Megaphones<br>Passenger Configuration | D  | - | <ul> <li>3 4 Change Bar</li> <li>0 (O) May be inoperative or missing provided: <ul> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul> </li> <li>2 Any in excess of those required by 14 CFR may be inoperative or removed provided: <ul> <li>a) Inoperative megaphone remains in a certified location until removed from the aircraft at the next suitable maintenance facility,</li> <li>b) Location placarding is removed or obscured, and</li> <li>c) Required distribution is maintained.</li> </ul> </li> </ul> |
| 2)                             | Cargo Configuration                           | D  | - | 0 May be inoperative or missing.   |
| 3)<br>***                      | Tamper seals or Tags                          | С  | - | - (O) May be inoperative, damaged, or missing provided proper installation and operation is verified at each preflight.  |

|                                 | MENT OF TRANSPORTATION   | ON     |   |                | MASTER MINIMUM EQUIPMENT  | LIST   |
|---------------------------------|--|--------|---|----------------|---|--------|
| REVISION NO<br>DATE: XX/XX/2    | -  |        |   |                | PAGE NO.  | 25-23  |
| AIRCRAFT:<br>Airbus A320        |  |        | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |
| 25. Equipment                   |  |        |   |                | 1.  | Change |
| Sequence No.<br>25-60-11<br>*** | Item<br>Slide Raft Lanyards<br>(White and/or Yellow)                     | 1<br>D | 8 | 3              | 4<br>(O) May be missing or damaged<br>beyond serviceable limits provided<br>aircraft is not operated on extended<br>overwater flights.  | Bar    |
| 25-60-13                        | Emergency Medical<br>Equipment   |        |   |                |   |        |
| 1)                              | Automated External<br>Defibrillator (AED) and/or<br>Associated Equipment | A      |   | 0              | <ul> <li>(O) May be incomplete, inoperative, or removed provided: <ul> <li>a) AED is labeled or placarded in a manner that will identify it as a unit that cannot be mistaken for a fully serviceable unit,</li> <li>b) Location placarding is removed or obscured, and</li> <li>c) Repairs or replacements are made within one flight.</li> </ul> </li> <li>NOTE: Medical equipment installed in the aircraft as part of an Emergency Medical Service (EMS) operation is not considered part of the normal complement of equipment. No MMEL relief applies to that equipment and 14 CFR maintenance and inspection requirements do not apply.</li> </ul> |        |
|                                 |  | D      | - | -              | Any in excess of those required by<br>14 CFR may be incomplete,<br>inoperative, or removed.   |        |
| a)<br>***                       | Tamper seals or Tags   | С      | - | -              | (O) May be inoperative, damaged, or<br>missing provided proper servicing is<br>verified at each preflight.  |        |
|                                 |  |        |   |                | (Continued)   |        |

| -                        | MENT OF TRANSPORTATION  |   |                | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------|---|---|----------------|-------------------------------|--|--|--|--|
| <b>REVISION NO</b>       | . 32  |   | PAGE NO. 25-24 |                               |  |  |  |  |
| DATE: XX/XX/             | XXXX  |   |                |                               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   |                |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 25. Equipment            | /Furnishings  |   |                |                               |  |  |  |  |
| Sequence No.             | Item  | 1 | 2              | 3                             | 4 Change<br>Bar  |  |  |  |
| 25-60-13                 | Emergency Medical<br>Equipment<br>(Cont'd)                    |   |                |                               | Bar  |  |  |  |
| 2)                       | Emergency Medical Kit<br>(EMK) and/or Associated<br>Equipment | A | _              | 0                             | <ul> <li>(O) May be incomplete, or removed provided: <ul> <li>a) EMK is labeled or placarded in a manner that will identify it as a unit that cannot be mistaken for a fully serviceable unit, and</li> <li>b) Location placarding is removed or obscured, and</li> <li>c) Repairs or replacements are made within one flight.</li> </ul> </li> <li>NOTE: Medical equipment installed in the aircraft as part of an EMS operation is not considered part of the normal complement of equipment. No MMEL relief applies to that equipment and 14 CFR maintenance and inspection requirements do not apply.</li> </ul> |  |  |  |
|                          |   | D | -              | -                             | Any in excess of those required by<br>14 CFR may be incomplete or<br>removed.  |  |  |  |
| a)<br>***                | Tamper seals or Tags  | С | -              | -                             | (O) May be inoperative, damaged, or<br>missing provided proper installation<br>and operation is verified at each<br>preflight.   |  |  |  |
|                          |   |   |                |                               | (Continued)  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/2   |  |   |   | PAGE NO. 25-25 |   |
| AIRCRAFT:<br>Airbus A320   |  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipment  | /Furnishings   |   |   |                |   |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |
| 25-60-13   | Emergency Medical<br>Equipment<br>(Cont'd)             |   |   |                |   |
| 3)   | First Aid Kits (FAK)<br>and/or Associated<br>Equipment | A | - | -              | <ul> <li>(O) If more than one is required by<br/>14 CFR, only one of the required<br/>FAKs may be incomplete or removed<br/>provided: <ul> <li>a) The FAK is labeled or<br/>placarded in a manner that<br/>will identify it as a unit that<br/>cannot be mistaken for a fully<br/>serviceable unit,</li> <li>b) Location placarding is<br/>removed or obscured, and</li> <li>c) Repairs or replacements are<br/>made within one flight.</li> </ul> </li> <li>NOTE: Medical equipment installed in<br/>the aircraft as part of an EMS<br/>operation is not considered<br/>part of the normal<br/>complement of equipment. No<br/>MMEL relief applies to that<br/>equipment and 14 CFR<br/>maintenance and inspection<br/>requirements do not apply.</li> </ul> |
|  |  | D | - | -              | Any in excess of those required by<br>14 CFR may be incomplete or<br>removed.   |
| a)<br>***  | Tamper seals or Tags                                   | С | - | -              | (O) May be inoperative, damaged, or<br>missing provided proper FAK<br>servicing is verified at each preflight.  |

|                             | MENT OF TRANSPORTATI   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|-----------------------------|--|----|---|---|---|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/ |  |    |   |   | PAGE NO. 25-26  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320    |  |    |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |
| 25. Equipmen                | t/Furnishings  |    |   |   |   |  |  |  |  |
| Sequence No.                | Item   | 1  | 2 | 3 | 4 Change<br>Bar   |  |  |  |  |
| 25-60-14<br>***             | Escape Life Lines  |    |   |   |   |  |  |  |  |
| 1)                          | Overwing   | D  | - | - | May be damaged or missing provided aircraft is not operated on extended overwater flights.      |  |  |  |  |
| 2)                          | Flight Deck Escape Life<br>Line Cover Plates   | С  | 2 | 0 | May be damaged or missing.  |  |  |  |  |
| 25-60-15<br>***             | Emergency Vision<br>Assurance Systems<br>(EVAS)<br>(A319/A320/A321)<br>(Vision Safe<br>STC #SA00892LA) | D  | 2 | 0 | (M) May be inoperative provided system is deactivated.  |  |  |  |  |
| 25-60-16                    | Flotation Equipment (Crew and Passenger)   | D  | - | - | Any in excess of that required by<br>14 CFR may be inoperative or<br>missing.                   |  |  |  |  |
| 25-60-17<br>***             | Survival Kit   | D  | - | - | Any in excess of those required by<br>14 CFR may be incomplete, missing,<br>or inoperative.     |  |  |  |  |
| 25-60-18                    | Crash Axe/Crow Bar   | D  | - | - | Any in excess of those required by<br>14 CFR may be inoperative or<br>missing.                  |  |  |  |  |
| 25-61-01<br>***             | Emergency Locator<br>Transmitter   |    |   |   |   |  |  |  |  |
| 1)                          | Survival Type ELTs   | D  | - | - | Any in excess of those required by<br>14 CFR may be inoperative or<br>missing.                  |  |  |  |  |
|                             |  |    |   |   | (Continued)   |  |  |  |  |

|                             | MENT OF TRANSPORTAT<br>ATION ADMINISTRATION  |   |   |          | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|--|---|---|----------|---|
| REVISION NO<br>DATE: XX/XX/ |  |   |   |          | PAGE NO. 25-27  |
|                             |  |   | т |          | E KEY   |
| AIRCRAFT:                   |  |   | • |          | REPAIR CATEGORY   |
| Airbus A320                 |  |   |   | 2.       | -   |
|                             |  |   |   | 3.<br>4. | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment               | /Furnishings                                 |   |   |          |   |
| Sequence No.                | ltem   | 1 | 2 | 3        | 4 Change<br>Bar   |
| 25-61-01<br>***             | Emergency Locator<br>Transmitter<br>(Cont'd) |   |   |          |   |
| 2)                          | Fixed ELTs                                   | A | - | 0        | <ul> <li>(M) May be inoperative provided:</li> <li>a) System is deactivated, and</li> <li>b) Repairs are made within<br/>90 consecutive calendar-days.</li> </ul>   |
|                             |  | A | - | 0        | <ul> <li>May be missing provided:</li> <li>a) Placard stating</li> <li>"ELT not installed" is placed in view of the pilot, and</li> <li>b) Repairs are made within 90 consecutive calendar-days.</li> </ul> |
|                             |  | D | - | -        | (M) Any in excess of those required<br>by 14 CFR may be inoperative<br>provided system is deactivated.  |
|                             |  | D | - | -        | Any in excess of those required by<br>14 CFR may be missing.  |
| 3)                          | Remote ELT Switch                            | D | _ | 0        | <ul> <li>(M) May be inoperative provided:</li> <li>a) Remote ELT switch is deactivated, and</li> <li>b) ELT switch is placed in the ARMED mode.</li> </ul>  |
| 4)                          | ELT Indicator Light                          | D | - | 0        | One or more may be inoperative.   |
| 5)                          | ELT Aural Alarm                              | D | - | 0        | One or more may be inoperative.   |
|                             |  |   |   |          | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|----|----------------|---|--|--|--|--|
| REVISION NO.<br>DATE: XX/XX/X  |  |   |    |                | PAGE NO. 25-28  |  |  |  |  |
|  |  |   |    |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 25. Equipment/   |  |   |    |                | Change  |  |  |  |  |
| Sequence No.   | Item   | 1 | 2  | 3              | 4 Change<br>Bar   |  |  |  |  |
| 25-61-01<br>***  | Emergency Locator<br>Transmitter<br>(Cont'd)   |   |    |                |   |  |  |  |  |
| 6)   | Low Frequency -<br>Underwater Locator<br>Beacon (LF-ULB)<br>(With Mod. 162066/<br>MP K19334) | D | -  | -              | May be inoperative provided operations do not require its use.  |  |  |  |  |
|  |  | С | -  | 0              | May be inoperative or missing.  |  |  |  |  |
| 7)   | Equipment for Location<br>of an Aircraft in Distress<br>(ELT-DT)                             | A | -  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) System is deactivated, and</li> <li>b) Repairs are made within</li> <li>90 consecutive calendar-days.</li> </ul>                                      |  |  |  |  |
|  |  | A | -  | 0              | <ul> <li>May be missing provided:</li> <li>a) Placard stating</li> <li>"ELT not installed" is placed in view of the pilot, and</li> <li>b) Repairs are made within 90 consecutive calendar-days.</li> </ul> |  |  |  |  |
|  |  | С | -  | 0              | May be inoperative provided that at least one automatic ELT is operative.   |  |  |  |  |
|  |  | D | -  | -              | Any in excess of those required by<br>14 CFR may be inoperative or<br>missing.  |  |  |  |  |

| -  | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                            |   | MASTER MINIMUM EQUIPMENT | LIST           |  |               |
|--|---|---|--------------------------|----------------|--|---------------|
| REVISION NO<br>DATE: XX/XX/2                     |   |   |                          |                | PAGE NO.   | 25-29         |
| AIRCRAFT:<br>Airbus A320<br><b>25. Equipment</b> | /Furnishings  |   | Т                        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| Sequence No.                                     | Item  | 1 | 2                        | 3              | 4  | Change<br>Bar |
| 25-61-02   | Passenger or Overwing<br>Door Slide/Slide Rafts<br>(Without Passengers) | C |                          | 1              | <ul> <li>(M)(O) May be inoperative or missing provided: <ul> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons are carried as authorized by 14 CFR for non-passenger-carrying operations,</li> <li>c) Each person has unobstructed access from their seat to an operative exit, either regular or emergency,</li> <li>d) Inoperative exits are conspicuously identified as inoperative,</li> <li>e) An Emergency Exit sign and floor proximity lights associated only with the inoperative exits are covered to obscure the sign and lights,</li> <li>f) Safety briefing includes the location of the inoperative exit(s) and instructions not to use the inoperative exit(s), and</li> <li>g) Alternate procedures are established and used.</li> </ul> </li> </ul> |               |
| 25-65-01<br>***                                  | Security Kit and<br>Associated Equipment                                | D | -                        | 0              | May be incomplete or missing.  |               |
| 25-65-02<br>***                                  | Fireproof Gloves  | D | -                        | 0              | One or more maybe damaged or missing   |               |

| -               | MENT OF TRANSPORTATION   | ON |   |    | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------|--|----|---|----|---|
| REVISION NO     |  |    |   |    | PAGE NO. 25-30  |
| DATE: XX/XX/    |  |    |   |    |   |
| AIRCRAFT:       |  |    | Т | 1. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED   |
| Airbus A320     |  |    |   | 3. | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 25. Equipment   | /Furnishings   |    |   |    |   |
| Sequence No.    | Item   | 1  | 2 | 3  | 4 Change<br>Bar   |
| 25-75-01<br>*** | Flightcrew Rest Cabin<br>Seat  |    |   |    |   |
| 1)              | Pilot Rest Seat Recline,<br>Leg Rest and Foot Rest<br>(Class 2 and 3 Seats)          | С  | - | 0  | <ul> <li>(M) May be inoperative and seat occupied provided:</li> <li>a) Seat is in full upright position for taxi, takeoff, and landing, and</li> <li>b) Seat can be manually operated to lay flat position.</li> </ul> |
| 2)              | Pilot Rest Seat Recline,<br>Leg Rest and Foot Rest<br>(Class 2 and 3 Seats)          | С  | - | 0  | May be inoperative provided operations do not require their use.  |
| 3)              | Class 2 Pilot Rest Seat<br>Curtain   | С  | - | 0  | (O) May be inoperative and seat<br>occupied provided Pilot Rest Seat is<br>downgraded to a Class 3 facility for<br>flight planning purposes.  |
| 4)              | Class 2 Pilot Rest Seat<br>Curtain Attachments<br>(Grommets/Magnets)                 | С  | - | -  | May be missing or inoperative with no effect on crew facility provided no two attachments in a row are inoperative.   |
| 5)              | Class 2 Pilot Rest Seat<br>Curtain Attachments<br>(Grommets/Magnets)                 | С  | - | -  | (O) May be inoperative and seat<br>occupied provided Pilot Rest Seat is<br>downgraded to a Class 3 facility for<br>flight planning purposes.  |
| 6)              | Class 2 Pilot Rest Seat<br>Window Shade  | С  | - | -  | (O) May be inoperative and seat<br>occupied provided Pilot Rest Seat is<br>downgraded to a Class 3 facility for<br>flight planning purposes.  |
| 25-75-02<br>*** | Flightcrew Rest Facilities<br>and Equipment<br>(14 CFR Part 117,<br>§ 117.3 Class 3) | С  | - | 0  | May be inoperative provided the<br>airplane is not used for augmented<br>flightcrew member operations.  |
|                 |  | С  | - | 0  | May be inoperative provided operations do not require their use.  |

| -                             | IENT OF TRANSPORTAT<br>ATION ADMINISTRATION        | ION |          |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------|--|-----|----------|----------------|---|
| REVISION NO.<br>DATE: XX/XX/X | -  |     |          |                | PAGE NO. 25-31  |
| AIRCRAFT:<br>Airbus A320      |  |     | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 25. Equipment/                |  |     | <b>^</b> |                | Change  |
| Sequence No.<br>25-90-01      | Item<br>Printed Supplemental<br>Safety Information | C C | -        | -              | <ul> <li>4 Charge Bar</li> <li>(O) May be inoperative or missing provided: <ul> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul> </li> <li>(M)(O) May be missing or damaged provided: <ul> <li>a) Safety Information Card is located in convenient locations for use of each passenger,</li> <li>b) Cards cannot be missing from each exit seat, and</li> <li>c) Any seat(s) or row(s) of seats must be blocked where a Safety Information Card is not located in convenient locations for use of each passenger.</li> </ul> </li> </ul> |

| -                        | IMENT OF TRANSPORTATIO   | JN     |                |   | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|--------|----------------|---|---|
| REVISION NO              | D. 31  |        |                | PAGE NO. 26-1   |   |
| DATE: 08/13/             | 2024   |        |                |   |   |
| AIRCRAFT:<br>Airbus A320 |  | Т.<br> | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |   |
| 26. Fire Prote           | ection   |        | 1              |   | Chapta  |
| Sequence No.             | Item   | 1      | 2              | 3   | 4 Change<br>Bar   |
| 26-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |        |                |   |   |
| 1)                       | Fault(s) Indicated by<br>SDCU<br>(Without Mod. 30354 or<br>without Mod. 33100)                       | С      | -              | -   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |
| 2)                       | Fault(s) Indicated by<br>SMOKE<br>(With Mod. 30354 or with<br>Mod. 33100)                            | С      | -              | -   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |
| 26-11-01                 | MLG Bay Fire Detection<br>Loops<br>(A321neo XLR)   |        |                |   |   |
| 1)                       | Loop A   | С      | 1              | 0   | (M) May be inoperative provided<br>MLG bay fire detection loop B is<br>verified operative before each<br>departure.   |
| 2)                       | Loop B   | С      | 1              | 0   | (M) May be inoperative provided<br>MLG bay fire detection loop A is<br>verified operative before each<br>departure.   |
| 3)                       | Loop A and B   | A      | 2              | 0   | <ul> <li>May be inoperative provided:</li> <li>a) MLG bay fire detection<br/>system is considered<br/>inoperative, and</li> <li>b) Repairs are made within<br/>10 consecutive<br/>calendar-days.</li> </ul> |

|                              | MENT OF TRANSPORTATI                              | ON |                |  | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|----------------|--|--|
| FEDERAL AV                   | IATION ADMINISTRATION                             |    |                |  |  |
| REVISION NO<br>DATE: 08/13/2 |   |    |                |  | PAGE NO. 26-2  |
| AIRCRAFT:<br>Airbus A320     |   | Т  | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |
| 26. Fire Prote               | ction   |    |                |  |  |
| Sequence No.                 | ltem  | 1  | 2              | 3  | 4 Change<br>Bar  |
| 26-11-02                     | MLG Bay Fire Detection<br>System<br>(A321neo XLR) | A  | 1              | 0  | <ul> <li>(M) May be inoperative provided:</li> <li>a) MLG bay is visually inspected<br/>before each departure, and</li> <li>b) Repairs are made within<br/>10 consecutive<br/>calendar-days.</li> </ul>  |
| 26-12-01                     | Engine Fire Detection<br>Systems                  |    |                |  |  |
| 1)                           | Loop A  | С  | 2              | 0  | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative<br/>on each engine provided: <ul> <li>a) Associated Loop B is<br/>operative, and</li> <li>b) Engine fire test is performed<br/>before each departure.</li> </ul> </li> </ul>       |
| 2)                           | Loop B  | С  | 2              | 0  | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative</li> <li>on each engine provided: <ul> <li>a) Associated Loop A is</li> <li>operative, and</li> </ul> </li> <li>b) Engine fire test is performed before each departure.</li> </ul> |
| 26-12-02                     | FIRE Lights on ENG<br>Control Panel               | С  | 2              | 0  | One or both may be inoperative.  |
| 26-12-03                     | ENG FIRE pb Lights                                |    |                |  |  |
| 1)                           | Bulbs/LEDs  | С  | 16             | 8  | Four bulbs/LEDs in each pb-sw may be inoperative.  |
| 26-13-01                     | APU Fire Detection<br>System                      |    |                |  |  |
| 1)                           | Loops   | С  | 2              | 1  | Except for ETOPS beyond<br>120 minutes, detection loop (B) may<br>be inoperative provided APU fire test<br>is performed before each APU start.   |
|                              |   |    |                |  | (Continued)  |

|                              | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION | UN |   |     | MASTER MINIMUM EQUIPMENT   | LIST          |
|------------------------------|--|----|---|-----|--|---------------|
| REVISION NO<br>DATE: 08/13/2 |  |    |   |     | PAGE NO.   | . 26-3        |
|                              |  |    | Т | ABL | E KEY  |               |
| AIRCRAFT:                    |  |    |   |     | REPAIR CATEGORY  |               |
| Airbus A320                  |  |    |   | 3.  | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 26. Fire Protec              | tion   |    | L |     |  |               |
| Sequence No.                 | Item   | 1  | 2 | 3   | 4  | Change<br>Bar |
| 26-13-01                     | APU Fire Detection<br>System<br>(Cont'd)     |    |   |     |  |               |
| 1)                           | Loops<br>(Cont'd)                            | С  | 2 | 1   | <ul> <li>Except for ETOPS beyond</li> <li>120 minutes, detection loop (A) may</li> <li>be inoperative provided: <ul> <li>a) APU fire test is performed</li> <li>before each APU start, and</li> </ul> </li> <li>b) During ground operations,<br/>APU condition is monitored in<br/>the cockpit.</li> </ul> |               |
|                              |  | A  | 2 | 0   | Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:<br>a) APU is not used, and<br>b) Repairs are made within<br>4 flights.   |               |
|                              |  | С  | 2 | 0   | Except for ETOPS, may be inoperative provided APU is not used.   |               |
| 26-13-02                     | APU FIRE pb Light                            |    |   |     |  |               |
| 1)                           | Bulbs/LEDs                                   | С  | 8 | 4   | Four bulbs/LEDs in pb may be inoperative.  |               |
|                              |  | С  | 8 | 0   | Except for ETOPS, may be inoperative provided APU is not used.   |               |
| 26-15-01                     | Avionics Smoke<br>Detection System           | A  | 1 | 0   | (O) Except for ETOPS, may be inoperative for 3 flight-legs.  |               |

| FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |               |  |  |  |
|---------------------------------|--|---|----|----------------|---|---------------|--|--|--|
| REVISION NO. 31                 |  |   |    |                | PAGE NC   | ). 26-4       |  |  |  |
| DATE: 08/13/2                   | 024  |   |    |                |   |               |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |  |
| 26. Fire Protec                 | tion   |   |    |                |   |               |  |  |  |
| Sequence No.                    | Item   | 1 | 2  | 3              | 4   | Change<br>Bar |  |  |  |
| 26-16-03                        | Smoke Detectors in<br>FWD Cargo<br>Compartment | С | -  | 0              | <ul> <li>(O) May be inoperative provided<br/>procedures are established and used<br/>to ensure the associated<br/>compartment remains empty or is<br/>verified to contain only empty cargo<br/>handling equipment, ballast (ballast<br/>may be loaded in ULDs), and/or Fly<br/>Away Kits.</li> <li>NOTE: Operator MELs should define</li> </ul> |               |  |  |  |
| 1)                              | Aircraft with AAE, Ltd.                        | С | 4  | 2              | <ul><li>which items are approved for inclusion in the Fly Away Kits and which materials can be used as ballast.</li><li>(M) One detector/channel in each</li></ul>  |               |  |  |  |
| .,                              | STC No. ST01077WI<br>(Four Detector System)    |   |    | -              | detector enclosure may be<br>inoperative provided the remaining<br>detector/channel in the enclosure is<br>verified to operate normally before<br>each departure.   |               |  |  |  |
|                                 |  | C | 4  | 0              | (O) May be inoperative provided<br>procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits.   |               |  |  |  |
|                                 |  |   |    |                | NOTE: Operator MELs should define<br>which items are approved for<br>inclusion in the Fly Away Kits<br>and which materials can be<br>used as ballast.   |               |  |  |  |

|                                     | MENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|---|----|---|----------------|---|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |    |   |                | PAGE NO. 26-5   |
| DATE: 08/13/2                       | 2024  |    |   |                |   |
| AIRCRAFT:<br>Airbus A320            |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 26. Fire Prote                      | ction   |    | 1 | -              |   |
| Sequence No.                        | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 26-16-04                            | Smoke Detectors in AFT<br>and Bulk Cargo<br>Compartments              | С  | - | 0              | (O) May be inoperative provided<br>procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits. |
|                                     |   |    |   |                | NOTE: Operator MELs should define<br>which items are approved for<br>inclusion in the Fly Away Kits<br>and which materials can be<br>used as ballast.   |
| 1)                                  | Aircraft with AAE, Ltd.<br>STC No. ST01077WI<br>(Six Detector System) | С  | 6 | 3              | (M) One detector/channel in each<br>detector enclosure may be<br>inoperative provided the remaining<br>detector/channel in the enclosure is<br>verified to operate normally before<br>each departure.   |
|                                     |   | С  | 6 | 0              | (O) May be inoperative provided<br>procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits. |
|                                     |   |    |   |                | NOTE 1: Operator MELs should<br>define which items are<br>approved for inclusion in the<br>Fly Away Kits and which<br>materials can be used as<br>ballast.  |
|                                     |   |    |   |                | NOTE 2: If the AFT Cargo<br>Compartment Smoke<br>Detectors are inoperative,<br>the bulk cargo compartment<br>must also remain empty.  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |     | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|---|---|---|-----|---|--|--|--|
| <b>REVISION NO</b>   | . 31  |   |   |     | PAGE NO. 26-6   |  |  |  |
| DATE: 08/13/2  | 024   |   |   |     |   |  |  |  |
|  |   |   | 1 | ABL | EKEY  |  |  |  |
| AIRCRAFT:  |   |   |   |     | REPAIR CATEGORY   |  |  |  |
| Airbus A320  |   |   |   |     | NO. INSTALLED   |  |  |  |
|  |   |   |   |     | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 26. Fire Protec  | tion  |   |   | _   |   |  |  |  |
| Sequence No.   | ltem  | 1 | 2 | 3   | 4 Change<br>Bar   |  |  |  |
| 26-16-05   | FWD/AFT Detection<br>Loops/Channels<br>AAE, Ltd.<br>STC No. ST01077WI | С | 4 | 2   | (M) One loop/channel (A or B) in<br>each cargo compartment may be<br>inoperative provided remaining<br>loop/channel in associated cargo<br>compartment is verified to operate<br>normally before each departure.  |  |  |  |
| 26-17-01   | Lavatory Smoke<br>Detection System                                    | С | _ | -   | <ul> <li>(M)(O) For each lavatory, the lavatory smoke detection system may be inoperative provided: <ul> <li>a) Lavatory waste receptacle is empty,</li> <li>b) Lavatory door is locked closed and placarded</li> <li>"INOPERATIVE – DO NOT ENTER", and</li> <li>c) Lavatory is used only by crewmembers.</li> </ul> </li> <li>NOTE: These provisos are not intended to prohibit lavatory use or inspections by crewmembers.</li> </ul> |  |  |  |
|  |   | D | - | 0   | Any in excess of that required by<br>14 CFR may be inoperative.   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |               |  |  |  |
|--|---|---|---|----------------|--|---------------|--|--|--|
| REVISION NO. 31  |   |   |   |                | PAGE NO.   | . 26-7        |  |  |  |
| DATE: 08/13/20   | 24  |   |   |                |  |               |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |  |
| 26. Fire Protect   | ion   |   |   |                |  |               |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4  | Change<br>Bar |  |  |  |
| 26-17-02   | Smoke Detection Control<br>Unit (SDCU)<br>(A319/A320/A321)<br>(Without Mod. 30354 or<br>without Mod. 33100) |   |   |                |  |               |  |  |  |
| 1)   | Channels  | В | 2 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Restrictions concerning</li> <li>inoperative lavatory smoke</li> <li>detection system and cargo</li> <li>smoke detection system are</li> <li>applied, and</li> </ul> </li> <li>b) Procedures are established</li> <li>and used to ensure all cargo</li> <li>compartments remain empty</li> <li>or are verified to contain only</li> <li>empty cargo handling</li> <li>equipment, ballast (ballast</li> <li>may be loaded in ULDs),</li> <li>and/or Fly Away Kits.</li> </ul> NOTE 1: Failure of a single SDCU <ul> <li>channel is indicated by a</li> <li>MAINTENANCE message</li> <li>on ECAM STATUS page.</li> </ul> NOTE 2: Operator MELs must define <ul> <li>which items are approved</li> <li>for inclusion in the Fly Away</li> <li>Kits and which materials</li> <li>can be used as ballast.</li> </ul> NOTE 3: Class E cargo <ul> <li>compartments require only</li> <li>the installation of smoke or</li> <li>fire detection systems</li> <li>(not suppression).</li> </ul> |               |  |  |  |

|                          | MENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|---|----------------|--|
| FEDERAL AVI              | ATION ADMINISTRATION   |    |   |                | PAGE NO. 26-8  |
| DATE: 08/13/2            | -  |    |   | PAGE NU. 20-8  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 26. Fire Protec          | tion   |    |   |                |  |
| Sequence No.             | ltem   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 26-18-01<br>***          | Video Control Center<br>Standalone Smoke<br>Detection System | С  | 1 | 0              | (O) May be inoperative provided a<br>procedure is used to check the<br>absence of smoke in the Video<br>Control Center every 30 minutes.   |
|                          |  | D  | 1 | 0              | (M) May be inoperative provided the Video Control Center is deactivated.   |
| 26-21-01                 | Engine AGENT 1 and 2<br>DISCH Light Systems                  | С  | 4 | 2              | (M) One may be inoperative for each<br>engine provided associated bottle(s)<br>is verified properly charged before<br>the first flight of each day.  |
| 26-21-02                 | Engine AGENT 1 and 2<br>SQUIB Light Systems                  | С  | 4 | 0              | (M) May be inoperative provided it is verified that the failure is in the test circuit only.   |
| 26-21-03                 | ENG FIRE Test Systems  | С  | 2 | 1              | <ul> <li>(M) One test function may be inoperative provided: <ul> <li>a) The fault is in the test system only,</li> <li>b) System is tested once each flight-day, and</li> <li>c) All other functions of fire detect systems operate normally.</li> </ul> </li> </ul> |
| 26-22-00                 | APU Fire Extinguisher<br>System                              | С  | 1 | 0              | May be inoperative provided the APU is not used.   |
| 26-22-01                 | APU Agent DISCH Light  | С  | 1 | 0              | (M) May be inoperative provided<br>bottle is verified properly charged<br>before the first flight of each day.   |
|                          |  | С  | 1 | 0              | May be inoperative provided APU is not used.   |
| 26-22-02                 | APU SQUIB Light  | С  | 1 | 0              | (M) May be inoperative provided APU<br>extinguishing system firing circuit is<br>verified operative before the first flight<br>of the day.   |
|                          |  | С  | 1 | 0              | May be inoperative provided APU is not used.   |

| -                        | MENT OF TRANSPORTATION   | JIN |   | MASTER MINIMUM EQUIPMENT LIST   |  |               |  |  |
|--------------------------|--|-----|---|---|--|---------------|--|--|
| REVISION NO. 31          |  |     |   |   | PAGE NC  | . 26-9        |  |  |
| DATE: 08/13/2            | .024   |     |   |   |  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |  |     | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |               |  |  |
| 26. Fire Protec          | tion   |     |   |   |  |               |  |  |
| Sequence No.             | ltem   | 1   | 2 | 3   | 4  | Change<br>Bar |  |  |
| 26-22-03                 | APU Ground Automatic<br>Fire Extinguisher System               | С   | 1 | 0   | May be inoperative provided APU is<br>continuously monitored in the cockpit<br>during all APU ground operations.   |               |  |  |
|                          |  | С   | 1 | 0   | May be inoperative provided APU is not used.   |               |  |  |
| 26-22-04                 | APU Fire Test System   | С   | 1 | 0   | (M) May be inoperative provided<br>firing circuit and bottle low pressure<br>detection systems are verified<br>operative before the first flight of the<br>day.  |               |  |  |
|                          |  | С   | 1 | 0   | May be inoperative provided APU is not used.   |               |  |  |
| 26-22-05                 | APU Fire Extinguisher<br>Overpressure Indication<br>(Red Disc) | С   | 1 | 0   | <ul> <li>(M) May be missing provided:</li> <li>a) Squib test is used to verify squib integrity, and</li> <li>b) Bottle pressure switch is verified operative before the first flight of each day.</li> </ul> |               |  |  |
|                          |  | С   | 1 | 0   | May be missing provided APU is not used.   |               |  |  |
| 26-22-06                 | APU FIRE PUSH pb   | С   | 1 | 0   | May be inoperative provided the APU is not used.   |               |  |  |
| 26-22-07                 | APU AGENT pb   | С   | 1 | 0   | May be inoperative provided the APU is not used.   |               |  |  |
| 26-22-08                 | APU Fire Extinguisher<br>Bottle                                | С   | 1 | 0   | May be inoperative provided the APU is not used.   |               |  |  |
| 26-22-09                 | APU Fire Bottle Squibs   | С   | 2 | 1   | (M) One may be inoperative provided<br>the remaining squib is verified<br>operative before the first flight of each<br>day.  |               |  |  |
|                          |  | С   | 2 | 0   | May be inoperative provided the APU is not used.   |               |  |  |

|                          | MENT OF TRANSPORTATI                       | ON |   |          | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|---|----------|--|
| REVISION NO              |  |    |   |          | PAGE NO. 26-10   |
| DATE: 08/13/2            |  |    |   |          |  |
|                          |  |    | Т | ABL      | E KEY  |
| AIRCRAFT:<br>Airbus A320 |  |    |   | 2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                     |
| 26. Fire Prote           | ction                                      |    |   |          |  |
| Sequence No.             | ltem                                       | 1  | 2 | 3        | 4 Change<br>Bar  |
| 26-22-10                 | APU AUTO EXTING<br>TEST                    | С  | 1 | 0        | May be inoperative provided the APU<br>Automatic Fire Extinguishing System<br>is considered inoperative.   |
| 26-22-11                 | APU FIRE Light on<br>External Power Panel  | С  | 1 | 0        | (M) May be inoperative provided the<br>APU Automatic Fire Extinguishing<br>System is verified operative.   |
|                          |  | С  | 1 | 0        | May be inoperative provided APU is continuously monitored in the cockpit during all APU ground operations. |
| 26-22-12                 | APU SHUT OFF pb on<br>External Power Panel | С  | 1 | 0        | (M) May be inoperative provided the<br>APU Automatic Fire Extinguishing<br>System is verified operative.   |
|                          |  | С  | 1 | 0        | May be inoperative provided the APU<br>Automatic Fire Extinguishing System<br>is considered inoperative.   |

|                              | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                                | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2 |   |    |   |                | PAGE NO. 26-11   |
| AIRCRAFT:<br>Airbus A320     |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 26. Fire Protec              | tion  |    |   |                |  |
| Sequence No.                 | Item  | 1  | 2 | 3              | 4 Change   |
| 26-23-01                     | FWD/AFT Cargo and<br>BULK Cargo<br>Compartment Fire<br>Extinguishing System |    | _ |                | ₩ Bar  |
| 1)                           | Bottle 1  | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided procedures are established and used to ensure all compartments remain empty or are verified to contain only empty cargo handling equipment, ballast (ballast may be loaded in ULDs), and /or Fly Away Kits.</li> <li>NOTE 1: Operator MELs should define which items are approved for inclusion in the Fly Away Kits and which materials can be used as ballast.</li> <li>NOTE 2: Class E cargo compartments require only the installation of smoke or fire detection systems (not suppression).</li> </ul> |
| 2)<br>***                    | Bottle 2  |    |   |                |  |
| a)                           | Without<br>Mod. 163213/MP J4530   | С  | 1 | 0              | Bottle 2 may be inoperative<br>(and cargo compartments used)<br>provided airplane remains within<br>60 minutes of landing at a suitable<br>airport.  |
|                              |   |    |   |                | (Continued)  |

|                 | IENT OF TRANSPORTATI  |    |   |      |  |              |
|-----------------|---|----|---|------|--|--------------|
|                 | ATION ADMINISTRATION  | UN |   |      | MASTER MINIMUM EQUIPMENT L   | IST          |
| REVISION NO. 31 |   |    |   |      | PAGE NO. 26  | 6-12         |
| DATE: 08/13/20  |   |    |   |      |  |              |
|                 |   |    | Т | ABLI | EKEY   |              |
| AIRCRAFT:       |   |    |   |      | REPAIR CATEGORY  |              |
| Airbus A320     |   |    |   |      | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |              |
|                 |   |    |   |      | REMARKS OR EXCEPTIONS  |              |
| 26. Fire Protec | tion  |    |   |      |  |              |
| Sequence No.    | ltem  | 1  | 2 | 3    |  | hange<br>Bar |
| 26-23-01        | FWD/AFT Cargo and<br>BULK Cargo<br>Compartment Fire<br>Extinguishing System<br>(Cont'd) |    |   |      |  |              |
| 2)<br>***       | Bottle 2<br>(Cont'd)  |    |   |      |  |              |
| b)              | With<br>Mod. 163213/MP J4530  | С  | 1 | 0    | <ul> <li>(O) May be inoperative provided<br/>procedures are established and used<br/>to ensure all compartments remain<br/>empty or are verified to contain only<br/>empty cargo handling equipment,<br/>ballast (ballast may be loaded in<br/>ULDs), and/or Fly Away Kits.</li> <li>NOTE 1: Operator MELs should<br/>define which items are<br/>approved for inclusion in the<br/>Fly Away Kits and which<br/>materials can be used as<br/>ballast</li> </ul> |              |
|                 |   |    |   |      | ballast.<br>NOTE 2: Class E cargo compartments<br>require only the installation<br>of smoke or fire detection<br>systems.  |              |

| U.S. DEPARTN             | MENT OF TRANSPORTATI  | ON |    |                |  |
|--------------------------|---|----|----|----------------|--|
| FEDERAL AVI              | ATION ADMINISTRATION  |    |    |                | MASTER MINIMUM EQUIPMENT LIST  |
| <b>REVISION NO</b>       |   |    |    | PAGE NO. 26-13 |  |
| DATE: 08/13/2            | 024   |    |    |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 26. Fire Protec          |   |    |    |                | A Change   |
| Sequence No.<br>26-23-01 | FWD/AFT Cargo and<br>BULK Cargo<br>Compartment Fire<br>Extinguishing System<br>(Cont'd) | 1  | 2  | 3              | 4 Change<br>Bar  |
| 3)                       | Squib of Cargo Bottle 1   | C  |    | 0              | <ul> <li>(O) May be inoperative provided<br/>procedures are established and used<br/>to ensure associated compartment<br/>remains empty or is verified to<br/>contain only empty cargo handling<br/>equipment, ballast (ballast may be<br/>loaded in ULDs), and/or Fly Away<br/>Kits.</li> <li>NOTE 1: When a squib of cargo<br/>bottle 1 linked to AFT Cargo<br/>Compartment is inoperative,<br/>both AFT and BULK cargo<br/>compartments remain<br/>empty or are verified to<br/>contain only empty cargo<br/>handling equipment, ballast<br/>(ballast may be loaded in<br/>ULDs), and/or Fly Away<br/>Kits.</li> <li>NOTE 2: Operator MELs should<br/>define which items are<br/>approved for inclusion in Fly<br/>Away Kits and which<br/>materials can be used as<br/>ballast.</li> <li>NOTE 3: Class E cargo compartments<br/>require only installation of<br/>smoke or fire detection<br/>systems (not suppression).</li> </ul> |
| 4)<br>***                | Squib of Cargo Bottle 2   | с  | -  | 0              | May be inoperative provided bottle 2 is considered inoperative.  |

| -                            | MENT OF TRANSPORTATION                           | NC |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|---|--|
| REVISION NO<br>DATE: 08/13/2 |  |    |   |   | PAGE NO. 26-14   |
|                              |  |    | т |   | E KEY  |
| AIRCRAFT:                    |  |    | - |   | REPAIR CATEGORY  |
| Airbus A320                  |  |    |   |   | NO. INSTALLED  |
|                              |  |    |   |   | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 26. Fire Protec              | tion   |    |   |   |  |
| Sequence No.                 | ltem   | 1  | 2 | 3 | 4 Change<br>Bar  |
| 26-23-02                     | FWD/AFT Cargo<br>Compartment<br>DISCH/BTL Lights | С  | - | 0 | (M) May be inoperative provided an acceptable test procedure is used once each flight-day to verify that the bottle is properly charged.   |
|                              |  | С  | - | 0 | (O) May be inoperative provided<br>procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs) and/or Fly<br>Away Kits. |
|                              |  |    |   |   | NOTE 1: Operator MELs should<br>define which items are<br>approved for inclusion in the<br>Fly Away Kits and which<br>materials can be used as<br>ballast.   |
|                              |  |    |   |   | NOTE 2: If the AFT Cargo<br>Compartment DISCH light is<br>inoperative, the bulk cargo<br>compartment must also<br>remain empty.  |
| 26-23-03                     | CARGO SMOKE DISCH<br>AGENT 2 Light               | С  | 1 | 0 | May be inoperative provided that the agent bottle 2 is considered inoperative.   |
|                              |  | С  | 1 | 0 | (O) May be inoperative.  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |             |          |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|-------------|----------|----------------|--|
| REVISION NO  | D. 31  |             |          |                | PAGE NO. 26-15   |
| DATE: 08/13/2  | 2024   |             |          |                |  |
| AIRCRAFT:<br>Airbus A320   |  |             | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 26. Fire Prote   |  | <u> </u>    | <u> </u> |                | La Change  |
| Sequence No.<br>26-23-04   | Item<br>"PUSH" DSCH Switch<br>Lights<br>AAE, Ltd.<br>STC No. ST01077WI | 1<br>C<br>C | 2        | 3<br>0<br>0    | May be inoperative provided an<br>acceptable test procedure is used<br>once each flight-day to verify that the<br>affected bottle(s) is properly charged.     (O) May be inoperative provided  |
|  |  | 0           |          | Ū              | procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits. |
|  |  |             |          |                | NOTE: Operator MELs should define<br>which items are approved for<br>inclusion in the Fly Away Kits<br>and which materials can be<br>used as ballast.  |

| _                              | IENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMEN   | T LIST        |
|--------------------------------|--|----|---|----------------|---|---------------|
| REVISION NO.<br>DATE: 08/13/20 | •  |    |   |                | PAGE NO.  | 26-16         |
| AIRCRAFT:<br>Airbus A320       |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |
| 26. Fire Protec                | tion   |    |   |                |   |               |
| Sequence No.                   | ltem   | 1  | 2 | 3              | 4   | Change<br>Bar |
| 26-23-05                       | "AUTO/MAN" DSCH<br>Switch Lights<br>AAE, Ltd.<br>STC No. ST01077WI | С  | 1 | 0              | (O) May be inoperative provided an acceptable test procedure is used once each flight-day to verify that the affected bottle(s) is properly charged.  |               |
|                                |  | С  | 1 | 0              | (O) May be inoperative provided<br>procedures are established and used<br>to ensure the associated<br>compartment remains empty or is<br>verified to contain only empty cargo<br>handling equipment, ballast (ballast<br>may be loaded in ULDs), and/or Fly<br>Away Kits. |               |
|                                |  |    |   |                | NOTE 1: Operator MELs should<br>define which items are<br>approved for inclusion in the<br>Fly Away Kits and which<br>materials can be used as<br>ballast.  |               |
|                                |  |    |   |                | NOTE 2: Class E cargo compartments<br>require only the installation<br>of smoke or fire detection<br>systems (not suppression).   |               |
|                                |  |    |   |                | NOTE 3: If the AUTO/MAN DSCH<br>switch light is inoperative for<br>the AFT Cargo Compartment,<br>the bulk cargo compartment<br>must also remain empty.  |               |
| 26-23-06                       | DET LEDs<br>AAE, Ltd.<br>STC No. ST01077WI                         | С  | 4 | 2              | (O) One LED in each cargo<br>compartment may be inoperative<br>provided the remaining loop in the<br>affected compartment is verified to<br>operate normally before each<br>departure.  |               |

|                              | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                           | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2 | . 31   |    |   |                | PAGE NO. 26-17   |
| AIRCRAFT:<br>Airbus A320     |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 26. Fire Protec              | tion   |    |   |                |  |
| Sequence No.                 | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 26-23-07                     | FAIL LEDs<br>AAE, Ltd.<br>STC No. ST01077WI                            | С  | 4 | 2              | (O) One LED in each cargo<br>compartment may be inoperative<br>provided the remaining loop in the<br>affected compartment is verified to<br>operate normally before each<br>departure.   |
| 26-23-08                     | Fault Panel<br>(E and E Compartment)<br>AAE, Ltd.<br>STC No. ST01077WI | D  | 1 | 0              | May be inoperative.  |
| 26-25-01                     | Lavatory Waste Bin Fire<br>Extinguisher System                         | С  | - | -              | For each lavatory, the fire extinguisher<br>system may be inoperative provided<br>lavatory smoke detection system<br>operates normally.  |
|                              |  | С  | - | -              | <ul> <li>(M)(O) For each lavatory, the fire extinguisher system may be inoperative provided: <ul> <li>a) Lavatory waste receptacle is empty,</li> <li>b) Lavatory door is locked closed and placarded "INOPERATIVE – DO NOT ENTER", and</li> <li>c) Lavatory is used only by crewmembers.</li> </ul> </li> </ul> |
|                              |  |    |   |                | NOTE: These provisos are not<br>intended to prohibit lavatory<br>use or inspection by<br>crewmembers.  |
|                              |  | D  | - | 0              | Any in excess of that required by 14 CFR may be inoperative.   |

| -                            | MENT OF TRANSPORTATI                   | ON |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |
|------------------------------|--|----|---|-------------------------------|--|--|--|
| REVISION NC<br>DATE: 08/13/2 | -                                      |    |   |                               | PAGE NO. 26-18   |  |  |
| AIRCRAFT:<br>Airbus A320     |  |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 26. Fire Protec              | ction                                  |    | 1 | I                             | Change   |  |  |
| Sequence No.<br>26-26-24     | Item<br>Portable Fire<br>Extinguishers | D  | 2 | -                             | <ul> <li>Any in excess of those required by<br/>14 CFR may be inoperative or<br/>removed provided: <ul> <li>a) Inoperative fire extinguisher<br/>remains in a certified location<br/>until removed from the aircraft<br/>at the next suitable<br/>maintenance facility,</li> <li>b) Location placarding is<br/>removed or obscured, and</li> <li>c) Required distribution is<br/>maintained.</li> </ul> </li> <li>NOTE: Inoperative fire extinguishers,</li> </ul> |  |  |
| 1)<br>***                    | Tamper Seals or Tags                   | С  | - | -                             | removed from a certified<br>location or removed from the<br>aircraft, are subject to 49 CFR<br>dangerous goods regulations.<br>(O) May be inoperative, damaged, or<br>missing provided proper installation<br>and servicing is verified at each<br>preflight.  |  |  |

| _                        | TMENT OF TRANSPORTATI<br>/IATION ADMINISTRATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIS  |  |  |  |  |
|--------------------------|--|----|---|----------------|---|--|--|--|--|
| REVISION NO. 32          |  |    |   |                | PAGE NO. 27-1   |  |  |  |  |
| DATE: XX/XX              |  |    |   |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 27. Flight Co            |  |    |   |                | Chang   |  |  |  |  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Chang<br>Bar  |  |  |  |  |
| 27-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |   |                |   |  |  |  |  |
| 1)                       | Fault(s) Indicated by<br>F/CTL   |    |   |                |   |  |  |  |  |
| a)                       | All aircraft except<br>A321neo XLR   | С  | - | -              | F/CTL <u>MAINTENANCE</u> message<br>may be displayed on the STATUS SD<br>page.  |  |  |  |  |
|                          |  |    |   |                | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |  |  |
| b)                       | A321neo XLR  | С  | - | -              | (M) F/CTL <u>MAINTENANCE</u> message<br>may be displayed on the STATUS SD<br>page provided that it is checked,<br>before each flight, that the BITE test<br>of the Electrical Flight Control System<br>(EFCS) does not report a failure of<br>communication BUS between the<br>ELACs and the FCDCs. |  |  |  |  |
| 2)                       | Fault(s) Indicated by SFCC   | С  | - | -              | SFCC <u>MAINTENANCE</u> message  <br>may be displayed on the STATUS SD  <br>page.   |  |  |  |  |
|                          |  |    |   |                | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |  |  |
|                          |  |    |   |                | (Continued)   |  |  |  |  |

|                          | MENT OF TRANSPORTATI  | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |
|--------------------------|---|----|---|-------------------------------|---|--|
|                          |   |    |   |                               |   |  |
| REVISION NO              |   |    |   |                               | PAGE NO. 27-2   |  |
| DATE: XX/XX              | /XXXX   |    |   |                               |   |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |
| 27. Flight Con           | ntrols  | 1  | 1 | -                             |   |  |
| Sequence No.             | Item  | 1  | 2 | 3                             | 4 Change<br>Bar   |  |
| 27-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd)    |    |   |                               |   |  |
| 3)                       | Fault(s) Indicated by<br>SLAT SYNCH 1(2)<br>(Aircraft with<br>Mod 166490/<br>MP P21265<br>(FWC H2-F13<br>Standard)) | С  | - | -                             | SLAT SYNCH 1(2) <u>MAINTENANCE</u><br>message may be displayed on the<br>STATUS SD page.<br>NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.                                |  |
| 4)                       | Fault(s) Indicated by<br>FLAP SYNCH 1(2)<br>(Aircraft with<br>Mod 166490/<br>MP P21265<br>(FWC H2-F13<br>Standard)) | С  | - | -                             | <ul> <li>FLAP SYNCH 1(2) <u>MAINTENANCE</u><br/>message may be displayed on the<br/>STATUS SD page.</li> <li>NOTE: Dispatch with maintenance<br/>status message displayed on<br/>ECAM is permitted without<br/>CFDS interrogation.</li> </ul> |  |

| -                           | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|---|----|---|----------------|---|
|                             | ATION ADMINISTRATION  |    |   |                |   |
| REVISION NO<br>DATE: XX/XX/ |   |    |   |                | PAGE NO. 27-3   |
|                             | ~~~~  |    |   |                | EKEY  |
| AIRCRAFT:<br>Airbus A320    |   |    |   | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 27. Flight Cont             |   |    |   |                | Change  |
| Sequence No.<br>27-14-01    | Item<br>Aileron Servo Controls  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 1)                          | A320-200 without<br>Mod. 26334/<br>MP J1616 or<br>Mod. 26335/<br>MP J1617 | A  | 4 | 2              | <ul> <li>(M)(O) Two associated with ELAC 2</li> <li>(left green and right blue) may be<br/>inoperative provided: <ul> <li>a) Servos remain mechanically<br/>connected and hydraulically<br/>supplied (damping function is<br/>not affected),</li> <li>b) All roll spoilers operate<br/>normally,</li> <li>c) Aileron Servo Controls<br/>associated with ELAC 1<br/>operate normally, and</li> <li>d) Repairs are made within<br/>3 flight-days.</li> </ul> </li> <li>NOTE: LAF is in degraded Mode.</li> </ul>  |
|                             |   | A  | 4 | 2              | <ul> <li>(M)(O) Two associated with ELAC 1</li> <li>(left blue and right green) may be<br/>inoperative provided: <ul> <li>a) Servos remain mechanically<br/>connected and hydraulically<br/>supplied (damping function is<br/>not affected),</li> <li>b) All roll spoilers operate<br/>normally,</li> <li>c) Aileron Servo Controls<br/>associated with ELAC 2<br/>operate normally,</li> <li>d) TR 1 and TR 2 operate<br/>normally,</li> <li>e) DC TIE contactor 1 is verified<br/>closed before takeoff, and</li> <li>f) Repairs are made within<br/>3 flight-days.</li> </ul> </li> <li>NOTE: LAF is in degraded Mode.</li> <li>(Continued)</li> </ul> |

| FEDERAL AVI                                 | ATION ADMINISTRATION  |   |    |                | MASTER MINIMUM EQUIPMEN  |               |
|---|---|---|----|----------------|--|---------------|
| REVISION NO                                 | . 32  |   |    |                | PAGE NC  | . 27-4        |
| DATE: XX/XX/                                | XXXX  |   |    |                |  |               |
| AIRCRAFT:<br>Airbus A320<br>27. Flight Cont | trols   |   | Т. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| Sequence No.                                | Item  | 1 | 2  | 3              | 4  | Change<br>Bar |
| 27-14-01                                    | Aileron Servo Controls<br>(Cont'd)  |   |    |                |  |               |
| 2)  | A318, A319, A320 with<br>Mod. 26334/<br>MP J1616 or<br>Mod. 26335/<br>MP J1617, and<br>A321 | A | 4  | 2              | <ul> <li>(M)(O) Two associated with ELAC 2</li> <li>(left green and right blue) may be<br/>inoperative provided: <ul> <li>a) Servos remain mechanically<br/>connected and hydraulically<br/>supplied (damping function is<br/>not affected),</li> <li>b) All roll spoilers operate<br/>normally,</li> <li>c) Aileron Servo Controls<br/>associated with ELAC 1<br/>operate normally, and</li> <li>d) Repairs are made within<br/>3 flight-days.</li> </ul> </li> </ul>   | I             |
|   |   | A | 4  | 2              | <ul> <li>(M)(O) Two associated with ELAC 1</li> <li>(left blue and right green) may be inoperative provided: <ul> <li>a) Servos remain mechanically connected and hydraulically supplied (damping function is not affected),</li> <li>b) All roll spoilers operate normally,</li> <li>c) Aileron Servo Controls associated with ELAC 2 operate normally,</li> <li>d) TR 1 and TR 2 operate normally,</li> <li>e) DC TIE contactor 1 is verified closed before takeoff, and</li> <li>f) Repairs are made within 3 flight-days.</li> </ul> </li> </ul> |               |
| 3)  | A321neo XLR   |   |    |                | Deleted, Revision 32.  | I             |

|                                | MENT OF TRANSPORTATI<br>IATION ADMINISTRATION                                  | ON |   |                | MASTER MINIMUM EQUIPMENT LIS  |
|--------------------------------|--|----|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/    | -  |    |   |                | PAGE NO. 27-  |
| AIRCRAFT:<br>Airbus A320       | AIRCRAFT:  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 27. Flight Con<br>Sequence No. | trois<br>Item  | 1  | 2 | 3              | 4 Chan  |
| 27-14-02                       | Aileron Indications on<br>ECAM Flight Control<br>Page                          |    | 2 | 3              | Bar   |
| 1)                             | ECAM Aileron Position<br>Indications   | С  | 2 | 0              | (O) May be inoperative provided<br>capability to move affected aileron<br>through each servo control is verified<br>visually before each departure.   |
| 2)                             | ECAM Aileron Actuator<br>Indications   | С  | 4 | 0              | One or more may be inoperative.   |
| 27-20-01                       | ECAM Rudder Position<br>Indication   | В  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) A visual verification of rudder<br/>movement is made before<br/>each departure, and</li> <li>b) RUD TRIM indication is<br/>verified at zero before each<br/>departure.</li> </ul> |
| 27-20-02                       | Rudder Hydraulic<br>System Pressure<br>Indication Symbol on<br>ECAM F/CTL Page | С  | 3 | 0              | One or more may be inoperative.   |

| -                           | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/ | . 32   |    |   |                | PAGE NO. 27-6  |
| AIRCRAFT:<br>Airbus A320    |  |    | Т | 1.<br>2.<br>3. |  |
| 27. Flight Con              | trols  |    |   |                |  |
| Sequence No.                | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 27-21-01                    | Rudder Pedal<br>Adjustment System  | С  | 2 | 0              | <ul> <li>(O) CAPT and/or F/O may be inoperative provided:</li> <li>a) Associated rudder pedals can be adjusted to a position which is acceptable to the affected crewmember, and</li> <li>b) Full and unrestricted movement of rudder pedals and brake pedal deflection is possible at both pilot stations.</li> </ul> |
| 27-22-01                    | Rudder Trim Systems  |    |   |                |  |
| 1)                          | System No. 1   | С  | 1 | 0              | <ul> <li>(O) Except for ETOPS, may be inoperative provided:</li> <li>a) Approach minimums do not require its use, and</li> <li>b) System 2 is operative.</li> </ul>  |
| 2)                          | System No. 2   | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Approach minimums do not require its use, and</li> <li>b) System 1 is operative.</li> </ul>  |
| 27-22-02                    | Rudder Manual Trim<br>Reset Function   | С  | 1 | 0              | May be inoperative provided one rudder position indication is available.   |
| 27-22-03                    | Rudder Trim Position<br>Indications  | С  | 2 | 1              | One indicator on ECAM or pedestal may be inoperative.  |
|                             |  | В  | 2 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Rudder trim is verified to operate normally,</li> <li>b) Rudder position is verified at zero before each departure, and</li> <li>c) Rudder pedals are verified in a neutral position.</li> </ul> </li> </ul>   |
| 27-23-01                    | Rudder Travel Limiter<br>Systems<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)) | С  | 2 | 1              | One may be inoperative.  |

|                          | MENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--------------------------|---|----|---|----------------|---|--|--|--|
|                          | ATION ADMINISTRATION  |    |   |                |   |  |  |  |
| REVISION NO              |   |    |   |                | PAGE NO. 27-7   |  |  |  |
| DATE. XX/XX/             | ^^^^  |    |   |                |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                           |  |  |  |
| 27. Flight Cont          |   |    |   | <u> </u>       | A Change  |  |  |  |
| Sequence No.             |   | 1  | 2 | 3              | 4 Bar   |  |  |  |
| 27-23-02                 | ECAM Rudder Travel<br>Limiter Position<br>Indication<br>(Aircraft with Mod. 31040<br>and Mod 30368 and<br>without Mod 163323/<br>MP P20703 (eRudder)) | С  | 1 | 0              | May be inoperative.   |  |  |  |
| 27-30-01                 | Elevator Indications on<br>ECAM Flight Control<br>Page  |    |   |                |   |  |  |  |
| 1)                       | ECAM Elevator Position<br>Indications   | С  | 2 | 0              | May be inoperative provided a visual<br>verification of affected elevator<br>movement is made before each<br>departure.   |  |  |  |
| 2)                       | ECAM Elevator Actuator<br>Indications   | С  | 4 | 0              | One or more may be inoperative.   |  |  |  |
| 27-34-02                 | Elevator Servo Control<br>Position Transducers  | С  | 8 | 4              | (M) One per servo control must<br>operate normally.   |  |  |  |
| 27-40-01                 | ECAM Pitch Trim<br>Position Indication  | С  | 1 | 0              | (M)(O) May be inoperative provided a<br>check of pitch trim handwheel and<br>stabilizer verifies synchronous<br>movement. |  |  |  |
| 27-44-01                 | Stabilizer Actuator<br>Electrical Motors  | С  | 3 | 2              | Motor 3 may be inoperative.   |  |  |  |
|                          |   | В  | 3 | 2              | (M) Except for ETOPS, motor 2 may<br>be inoperative provided ELAC 1 is<br>considered inoperative.                         |  |  |  |
| 27-44-02                 | Pitch Trim Hydraulic<br>System Pressure<br>Indication Symbol on<br>ECAM F/CTL Page  | С  | 2 | 0              | One or both may be inoperative.   |  |  |  |

| Airbus A320 2. NO. INSTALLED 3. NO. REQUIRED FOR DISPATCH 4. REMARKS OR EXCEPTIONS 7. Flight Controls  |              | MENT OF TRANSPORTATION          | NC |   |   | MASTER MINIMUM EQUIPMEN   | T LIST  |
|--|--------------|---------------------------------|----|---|---|---|---------|
| NIRCRAFT:<br>Nirbus A320       1. REPAIR CATEGORY         2. NO. INSTALLED       NO. REQUIRED FOR DISPATCH         4. REMARKS OR EXCEPTIONS       1         7. Flight Control       1         7.51-01       Slat/Flap Control<br>Computer (SFCC)       1         1)       FLAP Channels       1         a)       A318/A319ceo/A320ceo/<br>A321ceo       B       2       1         M)(O) SFCC 2 flap channel may be  <br>inoperative provided:       1       0. Operation of SFCC 1 WTBs<br>are confirmed by tests before<br>each departure,       0. Operation of SFCC 1 WTBs<br>are confirmed by tests before<br>each departure,         b)       A319neo/A320neo/<br>A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:         a)       Satisend flaps operate<br>normally, and       1       FAC, and RA systems<br>operate normally, and       1         b)       A319neo/A320neo/<br>A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:       1         b)       A319neo/A320neo/<br>A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:       1         b)       Operation of SFCC 1 WTBs<br>are confirmed by tests before<br>each departure,       2       1       <  |              |                                 |    |   |   | PAGE NC   | ). 27-8 |
| equence No.     Item     1     2     3     4       7-51-01     Slat/Flap Control<br>Computer (SFCC)     I     I     I     I       1)     FLAP Channels     I     I     Image: Control (M) (M) (O) SFCC 2 flap channel may be inoperative provided:<br>a) Slats and flaps operate normally on SFCC 1,<br>b) Operation of SFCC 1 WTBs are confirmed by tests before<br>each departure,       i     Image: Control (M)  |              |                                 |    |   |   | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |         |
| b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 c)       Electrical supply to SFCC 2<br>flap channel is inhibited,<br>d)                                 b)       A319neo/A320neo/<br>A321neo       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 a)       Slats and flaps operate<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be<br>inoperative provided:                 a)       Slats and flaps operate<br>normally on SFCC 1.               )       Operate on of SFCC 1 WTBs<br>are confirmed by tests before<br>each departure,                 i)       Operation of SFCC 2 thap channel is inhibited, <td></td> <td>rols</td> <td></td> <td></td> <td>1</td> <td>1</td> <td>01</td>   |              | rols                            |    |   | 1 | 1   | 01      |
| Computer (SFCC)                 1)       FLAP Channels         a)       A318/A319ceo/A320ceo/<br>A321ceo       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:         a)       A318/A319ceo/A320ceo/<br>A321ceo       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:         a)       A319neo/A320neo/<br>A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative, and 4<br>operate normally, and<br>f) The minimum idle on ground<br>function is considered<br>inoperative.         b)       A319neo/A320neo/<br>A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:         a)       Slats and flaps operate<br>(without Mod 163323/<br>MP P20703 (eRudder))       B       2       1       (M)(O) SFCC 2 flap channel may be  <br>inoperative provided:         a)       Slats and flaps operate<br>normally on SFCC 1, WTBs<br>are confirmed by tests before<br>each departure,       I         b)       Operation of SFCC 1 WTBs<br>are confirmed by tests before<br>each departure,       I         c)       Electrical supply to SFCC 2<br>flap channel is inhibited,       I         d)       ELAC, SEC, ADIRS, LGCIU,<br>FAC, and RA systems<br>operate normally,       Spoilers surfaces 2 and 4<br>operate normally,         f)       The minimum idle on ground<br>function i | Sequence No. |                                 | 1  | 2 | 3 | 4   |         |
| <ul> <li>a) A318/A319ceo/A320ceo/<br/>A321ceo</li> <li>b) A319neo/A320neo/<br/>A321neo</li> <li>b) A319neo/A320neo/<br/>A321neo</li> <li>b) A319neo/A320neo/<br/>A321neo</li> <li>c) A319neo/A320neo/<br/>A321neo</li> <li>c) A319neo/A320neo/<br/>A321neo</li> <li>c) Electrical supply to SFCC 2<br/>flap channel is inhibited,<br/>d) ELAC, SEC, ADIRS, LGCIU,<br/>FAC, and RA systems<br/>operate normally, and<br/>f) The minimum idle on ground<br/>function is considered<br/>inoperative.</li> <li>c) M(O) SFCC 2 flap channel may be<br/>operate normally, and<br/>f) The minimum idle on ground<br/>function is considered<br/>inoperative.</li> <li>d) (M)(O) SFCC 2 flap channel may be<br/>inoperative.</li> <li>e) Spoilers surfaces 2 and 4<br/>operate normally, and<br/>f) The minimum idle on ground<br/>function is considered<br/>inoperative.</li> <li>d) (M)(O) SFCC 2 flap channel may be<br/>inoperative provided:</li> <li>a) Slats and flaps operate<br/>normally on SFCC 1,<br/>b) Operation of SFCC 1 WTBs<br/>are confirmed by tests before<br/>each departure,<br/>c) Electrical supply to SFCC 2<br/>flap channel is inhibited,<br/>d) ELAC, SEC, ADIRS, LGCIU,<br/>FAC, and RA systems<br/>operate normally,<br/>e) Spoilers surfaces 2 and 4<br/>operate normally,<br/>f) The minimum idle on ground<br/>function is considered<br/>inoperative, and</li> </ul>   | 27-51-01     |                                 |    |   |   |   | Ι       |
| <ul> <li>A321ceo</li> <li>inoperative provided: <ul> <li>a) Slats and flaps operate normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs are confirmed by tests before each departure,</li> <li>c) Electrical supply to SFCC 2 flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FAC, and RA systems operate normally,</li> <li>e) Spoilers surfaces 2 and 4 operate normally, and</li> <li>f) The minimum idle on ground function is considered inoperative provided: <ul> <li>a) Slats and flaps operate</li> <li>b) A319neo/A320neo/A320neo/A321neo</li> <li>(without Mod 163323/MP P20703 (eRudder))</li> </ul> </li> <li>B 2 1 (M)(O) SFCC 2 flap channel may be   inoperative provided: <ul> <li>a) Slats and flaps operate normally, on SFCC 1,</li> <li>b) Operation of SFCC 1,</li> <li>b) Operation of SFCC 1,</li> <li>c) Electrical supply to SFCC 2,</li> <li>flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FAC, and RA systems operate normally,</li> <li>f) The minimum idle on ground function is considered innoperative,</li> <li>c) Electrical supply to SFCC 2 flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FAC, and RA systems operate normally,</li> <li>f) The minimum idle on ground function is considered inoperative, and</li> </ul> </li> </ul></li></ul>   | 1)           | FLAP Channels                   |    |   |   |   |         |
| A321neo<br>(without Mod 163323/<br>MP P20703 (eRudder))<br>MP P20703 (eRudder))<br>AB C 2 1 WTBs<br>are confirmed by tests before<br>each departure,<br>C) Electrical supply to SFCC 2<br>flap channel is inhibited,<br>d) ELAC, SEC, ADIRS, LGCIU,<br>FAC, and RA systems<br>operate normally,<br>e) Spoilers surfaces 2 and 4<br>operate normally,<br>f) The minimum idle on ground<br>function is considered<br>inoperative, and  | a)           |                                 | В  | 2 | 1 | <ul> <li>inoperative provided:</li> <li>a) Slats and flaps operate<br/>normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs<br/>are confirmed by tests before<br/>each departure,</li> <li>c) Electrical supply to SFCC 2<br/>flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU,<br/>FAC, and RA systems<br/>operate normally,</li> <li>e) Spoilers surfaces 2 and 4<br/>operate normally, and</li> <li>f) The minimum idle on ground<br/>function is considered</li> </ul>                  | Ι       |
|  | b)           | A321neo<br>(without Mod 163323/ | В  | 2 | 1 | <ul> <li>inoperative provided:</li> <li>a) Slats and flaps operate<br/>normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs<br/>are confirmed by tests before<br/>each departure,</li> <li>c) Electrical supply to SFCC 2<br/>flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU,<br/>FAC, and RA systems<br/>operate normally,</li> <li>e) Spoilers surfaces 2 and 4<br/>operate normally,</li> <li>f) The minimum idle on ground<br/>function is considered<br/>inoperative, and</li> </ul> | Ι       |

|                            | MENT OF TRANSPORTATI   | ON |   |                | MASTER MINIMUM EQUIPMENT   | LIST          |
|----------------------------|--|----|---|----------------|--|---------------|
|                            | VIATION ADMINISTRATION                                       |    |   |                |  | <b>a</b>      |
| REVISION NO<br>DATE: XX/XX |  |    |   |                | PAGE NO  | . 27-9        |
| AIRCRAFT:<br>Airbus A320   |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 27. Flight Cor             | ntrols   |    |   |                |  |               |
| Sequence No.               | ltem   | 1  | 2 | 3              | 4  | Change<br>Bar |
| 27-51-01                   | Slat/Flap Control<br>Computer (SFCC)<br>(Cont'd)             |    |   |                |  |               |
| 1)                         | FLAP Channels<br>(Cont'd)                                    |    |   |                |  |               |
| c)                         | A320neo/A321neo<br>(with Mod 163323/<br>MP P20703 (eRudder)) | В  | 2 | 1              | <ul> <li>(M)(O) SFCC 2 flap channel may be inoperative provided: <ul> <li>a) Slats and flaps operate normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs are confirmed by tests before each departure,</li> <li>c) Electrical supply to SFCC 2 flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FMGC, and RA systems operate normally,</li> <li>e) Spoilers surfaces 2 and 4 operate normally,</li> <li>f) The minimum idle on ground function is considered inoperative, and</li> <li>g) The OAT is below ISA+35 °C.</li> </ul> </li> </ul> | I             |
| 2)<br>a)                   | Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)       | В  | 2 | 1              | <ul> <li>(M)(O) SFCC 2 slat channel may be inoperative provided: <ul> <li>a) Slats and flaps operate normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs are confirmed by tests before each departure,</li> <li>c) Electrical supply to SFCC 2 slat channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FAC, and RA systems operate normally, and</li> <li>e) Takeoff in CONF 1+F is prohibited.</li> </ul> </li> <li>(Continued)</li> </ul>   | Ι             |

| -                           | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION             |    |   |                | MASTER MINIMUM EQUIPMEN   | T LIST |
|-----------------------------|--|----|---|----------------|---|--------|
| REVISION NO<br>DATE: XX/XX/ |  |    |   |                | PAGE NO.  | 27-10  |
| AIRCRAFT:<br>Airbus A320    |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |
| 27. Flight Cont             |  | Γ. | - | Γ.             | 1   | Change |
| Sequence No.<br>27-51-01    | Item<br>Slat/Flap Control<br>Computer (SFCC)<br>(Cont'd) | 1  | 2 | 3              | 4   | Bar    |
| 2)                          | SLAT Channel<br>(Cont'd)                                 |    |   |                |   |        |
| b)                          | A321neo XLR  | В  | 2 | 1              | <ul> <li>(M)(O) SFCC 2 slat channel may be inoperative provided: <ul> <li>a) Slats and flaps operate normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs are confirmed by tests before each departure,</li> <li>c) Electrical supply to SFCC 2 slat channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU, FMGC, and RA systems operate normally, and</li> <li>e) Takeoff in CONF 1A+F is prohibited.</li> </ul> </li> </ul> | Ι      |
| 27-51-02                    | Flap Wing Tip Brake<br>Solenoids                         | С  | 4 | 2              | (M)(O) Solenoids associated with<br>SFCC 2 may be inoperative provided<br>operation of SFCC 1 WTBs is<br>confirmed by test before each flight.  |        |
| 27-54-01                    | Flap Hydraulic Motors                                    | С  | 2 | 1              | Green motor may be inoperative.   |        |
|                             |  | С  | 2 | 1              | Yellow motor may be inoperative provided blue slat motor operates normally.   |        |

| -                           | MENT OF TRANSPORTATI  | ION |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|---|-----|----|----------------|---|
| REVISION NC<br>DATE: XX/XX/ |   |     |    |                | PAGE NO. 27-11  |
| AIRCRAFT:<br>Airbus A320    |   |     | Т  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 27. Flight Con              | trols   |     |    |                |   |
| Sequence No.                | Item  | 1   | 2  | 3              | 4 Change<br>Bar   |
| 27-54-02                    | Flap PCU Valve Blocks   | В   | 2  | 1              | <ul> <li>(M)(O) SFCC 2 Flap PCU Valve  </li> <li>Block may be inoperative provided: <ul> <li>a) Slats and flaps operate</li> <li>normally on SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs</li> <li>are confirmed by tests before</li> <li>each departure,</li> <li>c) Electrical supply to SFCC 2</li> <li>flap channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU,</li> <li>FAC, and RA systems</li> <li>operate normally,</li> <li>e) Spoilers surfaces 2 and 4</li> <li>operate normally, and</li> </ul> </li> <li>f) The minimum idle on ground function is considered inoperative.</li> </ul> |
| 27-64-01                    | Spoiler Surfaces  |     |    |                |   |
| 1)                          | A320 without<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617 | С   | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical<br/>surfaces 1 or 3 may be inoperative in<br/>the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally, and</li> <li>b) AFM performance penalties<br/>are applied.</li> </ul> </li> </ul>  |
|                             |   | С   | 10 | 8              | (M)(O) One pair of symmetrical<br>surfaces 5 may be inoperative in the<br>retracted position provided SECs<br>associated with operative spoilers<br>operate normally.   |
|                             |   | С   | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical<br/>surfaces 2 or 4 may be inoperative in<br/>the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally,</li> <li>b) SFCC 2 flap channel operates<br/>normally, and</li> <li>c) AFM performance penalties<br/>are applied.</li> </ul> </li> <li>(Continued)</li> </ul>  |

| -                           | MENT OF TRANSPORTA  | - |    |                | MASTER MINIMUM EQUIPMEN  | T LIST |
|-----------------------------|---|---|----|----------------|--|--------|
| REVISION NC<br>DATE: XX/XX/ |   |   |    |                | PAGE NO.   | 27-12  |
| AIRCRAFT:<br>Airbus A320    |   |   | Т. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |
| 27. Flight Con              |   |   |    |                | 4  | Change |
| Sequence No.<br>27-64-01    | Item<br>Spoiler Surfaces<br>(Cont'd)  | 1 | 2  | 3              | 4  | Bar    |
| 1)                          | A320 without<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617<br>(Cont'd) | С | 10 | 6              | <ul> <li>(M)(O) Two pair of symmetrical<br/>surfaces 1 and 2 may be inoperative<br/>in the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally,</li> <li>b) SFCC 2 flap channel operates<br/>normally, and</li> <li>c) AFM performance penalties<br/>are applied.</li> </ul> </li> </ul>   | I      |
|                             |   | C | 10 | 6              | <ul> <li>(M)(O) Two pair of symmetrical surfaces 3 and 4 may be inoperative in the retracted position provided: <ul> <li>a) SECs associated with operative spoilers operate normally,</li> <li>b) TR 1 and TR 2 operate normally,</li> <li>c) DC Tie Contactor 1 is verified closed before departure,</li> <li>d) SFCC 2 flap channel operates normally, and</li> <li>e) AFM performance penalties are applied.</li> </ul> </li> <li>NOTE: If spoiler 4 or 5 is inoperative, LAF is in degraded Mode. Refer to item 27-64-02.</li> </ul> | I      |
|                             |   |   |    |                | (Continued)  |        |

| U.S. DEPARTI             | MENT OF TRANSPORTATI  | ON |    |                               |  | эт  |  |  |
|--------------------------|---|----|----|-------------------------------|--|-----|--|--|
| FEDERAL AVI              | ATION ADMINISTRATION  |    |    | MASTER MINIMUM EQUIPMENT LIST |  |     |  |  |
| <b>REVISION NO</b>       | -   |    |    |                               | PAGE NO. 27-1  | 13  |  |  |
| DATE: XX/XX/             | XXXX  |    |    |                               |  |     |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |    | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |     |  |  |
| 27. Flight Cont          |   |    |    |                               | Chan   | nae |  |  |
| Sequence No.<br>27-64-01 | Item<br>Spoiler Surfaces<br>(Cont'd)  | 1  | 2  | 3                             | 4 Chan<br>Bar  |     |  |  |
| 2)                       | A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(all without<br>Mod 163323/<br>MP P20703 (eRudder)) | C  | 10 | 8                             | <ul> <li>(M)(O) One pair of symmetrical surfaces 1 or 3 may be inoperative in the retracted position provided:</li> <li>a) SECs associated with operative spoilers operate normally, and</li> <li>b) AFM performance penalties are applied.</li> </ul>   |     |  |  |
|                          |   | С  | 10 | 8                             | (M)(O) One pair of symmetrical<br>surfaces 5 may be inoperative in the<br>retracted position provided SECs<br>associated with operative spoilers<br>operate normally.  |     |  |  |
|                          |   | С  | 10 | 8                             | <ul> <li>(M)(O) One pair of symmetrical surfaces 2 or 4 may be inoperative in the retracted position provided:</li> <li>a) SECs associated with operative spoilers operate normally,</li> <li>b) SFCC 2 flap channel operates normally, and</li> <li>c) AFM performance penalties are applied.</li> </ul>  |     |  |  |
|                          |   | C  | 10 | 6                             | <ul> <li>(M)(O) Two pair of symmetrical surfaces 1 and 2 may be inoperative in the retracted position provided:</li> <li>a) SECs associated with operative spoilers operate normally,</li> <li>b) SFCC 2 flap channel operates normally, and</li> <li>c) AFM performance penalties are applied.</li> </ul> |     |  |  |
|                          |   |    |    |                               | (Continued)  |     |  |  |

| IATION ADMINISTRATION   |   |   |   |   | T LIST  |  |  |  |
|---|---|---|---|---|---|--|--|--|
| D. 32<br>/XXXX  |   |   | PAGE NO. 27-  |   |   |  |  |  |
| CRAFT:<br>ous A320  |   |   |   | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |   |  |  |  |
| itrols  |   |   |   |   |   |  |  |  |
| Item  | 1   | 2   | 3   | 4   | Change<br>Bar   |  |  |  |
| Spoiler Surfaces<br>(Cont'd)  |   |   |   |   |   |  |  |  |
| A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(all without<br>Mod 163323/<br>MP P20703 (eRudder))<br>(Cont'd) | С   | 10  | 6   | <ul> <li>(M)(O) Two pair of symmetrical surfaces 3 and 4 may be inoperative in the retracted position provided: <ul> <li>a) SECs associated with operative spoilers operate normally,</li> <li>b) TR 1 and TR 2 operate normally,</li> <li>c) DC Tie Contactor 1 is verified closed before departure,</li> <li>d) SFCC 2 flap channel operates normally, and</li> <li>e) AFM performance penalties are applied.</li> </ul> </li> </ul>  | Ι   |  |  |  |
| A321neo XLR   | С   | 10  | 8   | <ul> <li>(M)(O) One pair of symmetrical surfaces 1 or 3 may be inoperative in the retracted position provided:</li> <li>a) SECs and ELAC associated with operative spoilers operate normally, and</li> <li>b) AFM performance penalties are applied.</li> </ul>   | I   |  |  |  |
|   | С   | 10  | 6   | <ul> <li>(M)(O) Two pair of symmetrical<br/>surfaces 3 and 4 may be inoperative<br/>in the retracted position provided: <ul> <li>a) SECs and ELAC associated<br/>with operative spoilers<br/>operate normally,</li> <li>b) TR 1 and TR 2 operate<br/>normally,</li> <li>c) DC TIE Contactor 1 is verified<br/>closed before departure,</li> <li>d) SFCC 2 flap channel operates<br/>normally,</li> <li>e) AFM performance penalties<br/>are applied, and</li> <li>f) MTOW is limited to 97,000 kg<br/>(213,840 lbs).</li> </ul> </li> </ul> |   |  |  |  |
|   | 0. 32<br>/XXXX<br>htrols<br>ltem<br>Spoiler Surfaces<br>(Cont'd)<br>A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(all without<br>Mod 163323/<br>MP P20703 (eRudder))<br>(Cont'd) | D. 32         /XXXX         Item       1         Spoiler Surfaces<br>(Cont'd)       1         A319, A320 with       C         Mod 26334/       C         MP J1616 or       Mod 26335/         MP J1617, and A321       (all without         Mod 163323/       MP P20703 (eRudder))         (Cont'd)       A321neo XLR       C | D. 32       /XXXX       Transmitted         Item       1       2         Spoiler Surfaces       (Cont'd)       10         A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(all without<br>Mod 163323/<br>MP P20703 (eRudder))<br>(Cont'd)       C       10         A321neo XLR       C       10 | D. 32<br>/XXXX       TABLI<br>1.<br>2.<br>3.<br>4.         1       2         Item       1       2         Spoiler Surfaces<br>(Cont'd)       1       2         A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(all without<br>Mod 163323/<br>MP P20703 (eRudder))<br>(Cont'd)       C       10       6         A321neo XLR       C       10       8  | 3.32       PAGE NO.         XXXX       TABLE KEY         1       REPAIR CATEGORY         2. NO. INSTALLED         3. NO. REQUIRED FOR DISPATCH         4. REMARKS OR EXCEPTIONS         ttrols         ttem       1       2       3         A319, A320 with<br>Mod 26334/       C       10       6       (M)(O) Two pair of symmetrical<br>surfaces 3 and 4 may be inoperative<br>in the retracted position provided:         A319, A320 with<br>Mod 26335/       C       10       6       (M)(O) Two pair of symmetrical<br>surfaces 3 and 4 may be inoperative<br>in the retracted position provided:         a) SECs associated with<br>operative spoilers operate<br>normally,       b) TR 1 and TR 2 operate<br>normally, and       c) DC Tie Contactor 1 is verified<br>closed before departure,<br>d) SEC2 afla channel operates<br>normally, and         A321neo XLR       C       10       8       (M)(O) One pair of symmetrical<br>surfaces 1 or 3 may be inoperative in<br>the retracted position provided:         a) SECs and ELAC associated<br>with operative spoilers<br>operate normally, and       b) AFM performance penalties<br>are applied.         C       10       6       (M)(O) Two pair of symmetrical<br>surfaces 3 and 4 may be inoperative in<br>the retracted position provided:         a) SECs and ELAC associated<br>with operative spoilers<br>operate normally,       b) AFM performance penalties<br>are applied.         C       10       6       (M)(O) |  |  |  |

|                               | TMENT OF TRANSPORT           |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|-------------------------------|------------------------------|---|----|----------------|---|--|--|--|
| REVISION NO<br>DATE: XX/XX    |                              |   |    | PAGE NO. 27-15 |   |  |  |  |
| AIRCRAFT:<br>Airbus A320      |                              |   | T  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 27. Flight Co<br>Sequence No. |                              | 1 | 2  | <b>_</b>       | Change  |  |  |  |
| 27-64-01                      | Spoiler Surfaces<br>(Cont'd) | 1 | 2  | 3              | 4 Change Bar  |  |  |  |
| 3)                            | A321neo XLR<br>(Conťd)       |   |    |                |   |  |  |  |
|                               |                              | C | 10 | 6              | <ul> <li>(M)(O) Two pair of symmetrical<br/>surfaces 2 and 5 may be inoperative<br/>in the retracted position provided: <ul> <li>a) SECs and ELAC associated<br/>with operative spoilers<br/>operate normally,</li> <li>b) SFCC 2 flap channel operates<br/>normally,</li> <li>c) AFM performance penalties<br/>are applied, and</li> <li>d) MTOW is limited to 97,000 kg<br/>(213,840 lbs).</li> </ul> </li> </ul> |  |  |  |
|                               |                              | С | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical surfaces 5 may be inoperative in the retracted position provided:</li> <li>a) SECs and ELAC associated with operative spoilers operate normally, and</li> <li>b) MTOW is limited to 97,000 kg (213,840 lbs).</li> </ul>   |  |  |  |
|                               |                              | С | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical<br/>surfaces 2 may be inoperative in the<br/>retracted position provided: <ul> <li>a) SECs and ELAC associated</li> <li>with operative spoilers</li> <li>operate normally,</li> </ul> </li> <li>b) SFCC 2 flap channel operates<br/>normally, and</li> <li>c) AFM performance penalties<br/>are applied.</li> </ul>   |  |  |  |
|                               |                              |   |    |                | (Continued)   |  |  |  |

|                          | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                                    |   |    | MASTER MINIMUM EQUIPMENT LIST |   |               |  |  |
|--------------------------|---|---|----|-------------------------------|---|---------------|--|--|
| REVISION NO              | . 32  |   |    |                               | PAGE NO.  | 27-16         |  |  |
| DATE: XX/XX/             | XXXX  |   |    |                               |   |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   | Т  | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |
| 27. Flight Cont          | trols   | - |    |                               |   |               |  |  |
| Sequence No.             | ltem  | 1 | 2  | 3                             | 4   | Change<br>Bar |  |  |
| 27-64-01                 | Spoiler Surfaces<br>(Cont'd)  |   |    |                               |   |               |  |  |
| 3)                       | A321neo XLR<br>(Cont'd)   |   |    |                               |   | <br>          |  |  |
|                          |   | С | 10 | 8                             | <ul> <li>(M)(O) One pair of symmetrical surfaces 4 may be inoperative in the retracted position provided: <ul> <li>a) SECs and ELAC associated with operative spoilers operate normally,</li> <li>b) SFCC 2 flap channel operates normally,</li> <li>c) AFM performance penalties are applied, and</li> <li>d) MTOW is limited to 97,000 kg (213,840 lbs).</li> </ul> </li> </ul> |               |  |  |
| 4)                       | A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705 | С | 10 | 8                             | <ul> <li>(M)(O) One pair of symmetrical surfaces 1 or 3 may be inoperative in the retracted position provided:</li> <li>a) SECs associated with operative spoilers operate normally, and</li> <li>b) AFM performance penalties are applied.</li> </ul>  |               |  |  |
|                          |   |   |    |                               | (Continued)   |               |  |  |

| U.S. DEPART                | IMENT OF TRANSPORTATI   | ON |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|----------------------------|---|----|----|----------------|---|
| FEDERAL AV                 | /IATION ADMINISTRATION  |    |    |                |   |
| REVISION NO<br>DATE: XX/XX |   |    |    |                | PAGE NO. 27-17  |
| AIRCRAFT:<br>Airbus A320   |   |    | Т  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 27. Flight Cor             | ntrols  | 1  | 1  |                |   |
| Sequence No.               | ltem  | 1  | 2  | 3              | 4 Change<br>Bar   |
| 27-64-01                   | Spoiler Surfaces<br>(Cont'd)  |    |    |                |   |
| 4)                         | A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705<br>(Cont'd) |    |    |                |   |
|                            |   | С  | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical surfaces 5 may be inoperative in the retracted position provided:</li> <li>a) SECs associated with operative spoilers operate normally, and</li> <li>b) The MTOW is limited to 76,400 kg (168,430 lbs).</li> </ul>  |
|                            |   | C  | 10 | 8              | <ul> <li>(M)(O) One pair of symmetrical<br/>surfaces 2 or 4 may be inoperative in<br/>the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally,</li> </ul> </li> <li>b) SFCC 2 flap channel operates<br/>normally,</li> <li>c) AFM performance penalties<br/>are applied, and</li> <li>d) If the pair of spoilers 4 is<br/>inoperative, the MTOW is<br/>limited to 76,400 kg<br/>(168,430 lbs).</li> </ul> |
|                            |   | С  | 10 | 6              | <ul> <li>(M)(O) Two pair of symmetrical<br/>surfaces 1 and 2 may be inoperative<br/>in the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally,</li> <li>b) SFCC 2 flap channel operates<br/>normally, and</li> <li>c) AFM performance penalties<br/>are applied.</li> </ul> </li> <li>(Continued)</li> </ul>   |

| -                          | MENT OF TRANSPORTATION  | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------|---|----|----|----------------|--|
| REVISION NO<br>DATE: XX/XX | ). 32   |    |    | PAGE NO. 27-18 |  |
| AIRCRAFT:<br>Airbus A320   |   |    | Т  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 27. Flight Con             | trols   |    |    |                |  |
| Sequence No.               | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |
| 27-64-01                   | Spoiler Surfaces<br>(Cont'd)  |    |    |                |  |
| 4)                         | A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705<br>(Cont'd) | С  | 10 | 6              | <ul> <li>(M)(O) Two pair of symmetrical<br/>surfaces 3 and 4 may be inoperative<br/>in the retracted position provided: <ul> <li>a) SECs associated with<br/>operative spoilers operate<br/>normally,</li> <li>b) TR 1 and TR 2 operate<br/>normally,</li> <li>c) DC Tie Contactor 1 is verified<br/>closed before departure,</li> <li>d) SFCC 2 flap channel operates  <br/>normally,</li> <li>e) AFM performance penalties<br/>are applied, and</li> <li>f) The MTOW is limited to<br/>76,400 kg (168,430 lbs).</li> </ul> </li> </ul> |
| 27-64-02                   | Load Alleviation Function<br>(LAF)<br>(A320-200 without<br>Mod. 26334 or 26335)             | D  | 1  | 0              | May be inoperative.  |
| 27-64-03                   | LAF Accumulators<br>(A320-200 without<br>Mod. 26334 or 26335)                               | D  | 4  | 0              | One or more may be inoperative.  |
| 27-64-04                   | Spoilers Hydraulic<br>System Pressure<br>Indication Symbol on<br>F/CTL Page                 | С  | 3  | 0              | One or more may be inoperative.  |
| 27-64-05                   | LAF DEGRADED<br>Caution on ECAM EWD<br>(A321neo XLR)  | С  | 1  | 0              | May be inoperative.  |
| 27-81-01                   | Slat Wing Tip Brakes<br>Solenoids   | С  | 4  | 2              | <ul> <li>(M)(O) Solenoids associated with<br/>SFCC 2 may be inoperative provided: <ul> <li>a) Approach minimums do not<br/>require its use, and</li> <li>b) SFCC 1 WTBs operate<br/>normally before each flight.</li> </ul> </li> </ul>  |

|                            | /IATION ADMINISTRATION                                |   |   |                |  |               |  |  |
|----------------------------|---|---|---|----------------|--|---------------|--|--|
| REVISION NO<br>DATE: XX/XX |   |   |   | PAGE NO. 2     | 27-19  |               |  |  |
| AIRCRAFT:<br>Airbus A320   | CRAFT:  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |
| 27. Flight Cor             | ntrols  |   |   |                |  |               |  |  |
| Sequence No.               | ltem  | 1 | 2 | 3              | 4  | Change<br>Bar |  |  |
| 27-84-01                   | Slats Hydraulic Motors                                | С | 2 | 1              | One may be inoperative.  |               |  |  |
| 27-84-02                   | Slat PCU Valve Blocks                                 |   |   |                |  |               |  |  |
| 1)                         | A321neo XLR   | В | 2 | 1              | <ul> <li>(M)(O) SFCC 2 Slat PCU Valve Block<br/>may be inoperative provided: <ul> <li>a) Slats, Flaps, and associated<br/>monitoring and protection<br/>systems operate normally on<br/>SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs<br/>are confirmed by tests before<br/>each departure,</li> <li>c) Electrical supply to SFCC 2<br/>slat channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU,<br/>FMGC, and RA systems<br/>operate normally, and</li> <li>e) Takeoff in CONF 1A+F is<br/>prohibited.</li> </ul></li></ul> | I             |  |  |
| 2)                         | A318, A319, A320, and<br>A321<br>(except A321neo XLR) | В | 2 | 1              | <ul> <li>(M)(O) SFCC 2 Slat PCU Valve Block<br/>may be inoperative provided: <ul> <li>a) Slats, Flaps, and associated<br/>monitoring and protection<br/>systems operate normally on<br/>SFCC 1,</li> <li>b) Operation of SFCC 1 WTBs<br/>are confirmed by tests before<br/>each departure,</li> <li>c) Electrical supply to SFCC 2<br/>slat channel is inhibited,</li> <li>d) ELAC, SEC, ADIRS, LGCIU,<br/>FAC, and RA systems<br/>operate normally, and</li> <li>e) Takeoff in CONF 1+F is<br/>prohibited.</li> </ul></li></ul>   | I             |  |  |

|                          | MENT OF TRANSPORTATION   | ЛС |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------|--|----|---|-------------------------------|--|--|--|--|
| <b>REVISION NO</b>       | . 32   |    |   | PAGE NO. 27-20                |  |  |  |  |
| DATE: XX/XX/             | XXXX   |    |   |                               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 27. Flight Cont          | rols   |    | 1 | 1                             |  |  |  |  |
| Sequence No.             | Item   | 1  | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 27-92-01                 | Speedbrake Control<br>System   | С  | 1 | 0                             | (O) May be inoperative provided AFM<br>performance penalties associated<br>with all ground spoilers inoperative<br>are applied.  |  |  |  |
| 1)                       | Speedbrake 2 or 3 and 4  | С  | - | -                             | (O) May be inoperative provided AFM<br>performance penalties associated<br>with one pair or two pairs of ground<br>spoilers inoperative are applied.   |  |  |  |
| 27-92-02                 | Ground Spoiler Control<br>System   | A  | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) A check of the thrust reverser system is performed before each flight to ensure that both thrust reversers operate normally,</li> <li>b) Autobrake function is not used,</li> <li>c) Approach minimums do not require its use,</li> <li>d) AFM takeoff and landing performance penalties are applied, and</li> <li>e) Repairs are made within 3 flight-legs.</li> </ul> </li> </ul> |  |  |  |
| 1)                       | Spoiler 5<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder))                      | С  | 1 | 0                             | The pair of spoilers 5 may be inoperative.   |  |  |  |
| 2)                       | Spoilers 1 and 2 or 3<br>and 4<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder)) | С  | 4 | 2                             | (O) The pairs of spoilers 1 and 2 or<br>the pairs of spoilers 3 and 4 may be<br>inoperative provided AFM<br>performance penalties are applied.   |  |  |  |
|                          |  |    |   |                               | (Continued)  |  |  |  |

|                             | MENT OF TRANSPORTATION  | JIN |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|---|-----|----|----------------|--|
| REVISION NO<br>DATE: XX/XX/ |   |     |    | PAGE NO. 27-21 |  |
| AIRCRAFT:<br>Airbus A320    | IRCRAFT:  |     |    |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 27. Flight Cont             | trols   |     |    |                |  |
| Sequence No.                | ltem  | 1   | 2  | 3              | 4 Change<br>Bar  |
| 27-92-02                    | Ground Spoiler Control<br>System<br>(Cont'd)  |     |    |                |  |
| 3)                          | Spoiler 1<br>(Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder))  | С   | 1  | 0              | The pair of spoilers 1 may be inoperative.   |
| 4)                          | Spoilers 2 and 5 or<br>3 and 4<br>(Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder))                       | С   | 4  | 2              | (O) The pairs of spoilers 2 and 5 or<br>the pairs of spoilers 3 and 4 may be<br>inoperative provided AFM<br>performance penalties are applied. |
| 27-92-05                    | Spoiler/Speedbrake<br>Indications on ECAM<br>F/CTL and Wheel Page   | С   | 10 | -              | May be inoperative for an associated inoperative spoiler.  |
|                             |   | С   | 10 | 0              | (O) May be inoperative provided a<br>visual check of affected surface<br>movement is made before each<br>departure.                            |
| 27-92-06<br>***             | Side Stick Dual Input<br>Warning System   |     |    |                |  |
| 1)                          | Flashing Portion of<br>Sidestick Dual Input<br>Function in Lower Half of<br>Sidestick Priority Green<br>Light | D   | 2  | 0              | May be inoperative provided<br>Sidestick priority function is operative.   |
| 2)                          | Aural Warning   | D   | 1  | 0              | May be inoperative.  |
| 27-92-07                    | STICK SENSOR FAULT<br>Caution on ECAM EWD<br>(A321neo XLR)  | С   | 1  | 0              | May be inoperative.  |
| 27-92-11<br>***             | STEEP APPR pb Switch<br>(With Mod. 35542)   |     |    |                |  |
| 1)                          | ON Light  | С   | 1  | 0              | May be inoperative.  |
| 2)                          | FAULT Light   | С   | 1  | 0              | May be inoperative.  |

| U.S. DEPARTI             | IENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--------------------------|--|----|---|----------------|--|--|--|--|--|
| FEDERAL AVIA             | ATION ADMINISTRATION   |    |   | PAGE NO. 27-22 |  |  |  |  |  |
| DATE: XX/XX/>            |  |    |   |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 27. Flight Cont          | rols   |    | - | -              | -  |  |  |  |  |
| Sequence No.             | ltem   | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 27-93-01                 | Elevator Aileron<br>Computers (ELAC)                                       |    |   |                |  |  |  |  |  |
| 1)                       | A320-200 without<br>Mod 263334/<br>MP J1616, and<br>Mod 26335/<br>MP J1617 | В  | 2 | 1              | <ul> <li>(M)(O) Except for ETOPS, ELAC 1 or<br/>any ELAC 1 function may be<br/>inoperative provided: <ul> <li>a) Both accelerometers</li> <li>associated with ELAC 2</li> <li>operate normally,</li> </ul> </li> <li>b) All Sidestick transducers <ul> <li>associated with ELAC 2 and</li> <li>the three SECs operate</li> <li>normally,</li> </ul> </li> <li>c) ELAC 2, SECs, ADIRs,</li> <li>SFCCs, LGCIUs, FACs, and</li> <li>RAs operate normally,</li> <li>d) TR 1 and TR 2 operate</li> <li>normally,</li> <li>e) DC TIE contactor 1 is verified</li> <li>closed before each departure,</li> <li>f) All roll spoilers operate</li> <li>normally,</li> <li>g) Elevators and roll spoilers</li> <li>control through the SECs is</li> <li>verified operative before each</li> <li>flight,</li> <li>h) Approach minimums do not</li> <li>require its use, and</li> <li>i) Above FL 200, the use of</li> <li>speedbrakes lever is limited to</li> <li>its half position without</li> <li>Mod. 33317.</li> </ul> <li>NOTE 1: With ELAC 1 Roll channel <ul> <li>failed, LAF is in degraded</li> <li>Mode. Refer to</li> <li>item 27-64-02.</li> </ul> </li> <li>NOTE 2: When the ELAC 1 FAULT <ul> <li>alert is displayed (ELAC 1 is</li> <li>not electrically supplied),</li> <li>F/O Take-Over pb cannot</li> <li>disengage AP1.</li> </ul> </li> |  |  |  |  |

| -                                | IENT OF TRANSPORTATION   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------------|--|----|---|---|--|
| REVISION NO.                     | 32   |    |   |   | PAGE NO. 27-23   |
| DATE: XX/XX/X                    | XXX  |    |   |   |  |
| AIRCRAFT:<br>Airbus A320         |  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 27. Flight Conti<br>Sequence No. |  | 1  | 2 | 3 | 4 Change   |
| 27-93-01                         | Item<br>Elevator Aileron<br>Computers (ELAC)<br>(Cont'd)   |    | 2 | 3 | 4 Bar  |
| 2)                               | A318, A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, and A321<br>(except A321neo XLR) | В  | 2 | 1 | <ul> <li>(M)(O) Except for ETOPS, ELAC 1 or<br/>any ELAC 1 function may be<br/>inoperative provided: <ul> <li>a) Both accelerometers<br/>associated with ELAC 2<br/>operate normally,</li> <li>b) All Sidestick transducers<br/>associated with ELAC 2 and<br/>the three SECs operate<br/>normally,</li> <li>c) ELAC 2, SECs, ADIRs,<br/>SFCCs, LGCIUs, FACs, and<br/>RAs operate normally,</li> <li>d) TR 1 and TR 2 operate<br/>normally,</li> <li>e) DC TIE contactor 1 is verified<br/>closed before each departure,</li> <li>f) All roll spoilers operate<br/>normally,</li> <li>g) Elevators and roll spoilers<br/>control through the SECs is<br/>verified operative before each<br/>flight,</li> <li>h) Approach minimums do not<br/>require its use, and</li> <li>i) Above FL 200, the use of<br/>speedbrakes lever is limited to<br/>its half position (A320 without<br/>Mod. 33317).</li> </ul> </li> <li>NOTE: When the ELAC 1 FAULT<br/>alert is displayed (ELAC 1 is<br/>not electrically supplied),<br/>F/O Take-Over pb cannot<br/>disengage AP1.</li> </ul> |

| -                          | MENT OF TRANSPORTATION                                   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX |  |    |   |                | PAGE NO. 27-24   |
| AIRCRAFT:<br>Airbus A320   |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 27. Flight Con             |  |    |   |                | Change   |
| Sequence No.<br>27-93-02   | Item<br>ELAC pb Switch                                   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 1)                         | FAULT Lights   | С  | 2 | 1              | May be inoperative provided:<br>a) Both FWCs operate normally,<br>and<br>b) ELAC indications operate<br>normally.                                    |
| 2)                         | OFF Lights   | С  | 2 | 0              | One or both may be inoperative.  |
| 27-93-03                   | ECAM ELAC Indications                                    | С  | 2 | 1              | One may be inoperative for an inoperative ELAC 1.  |
|                            |  | С  | 2 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Both FWCs operate normally,<br/>and</li> <li>b) ELAC fault light operates<br/>normally.</li> </ul> |
| 27-93-04                   | LAWS REDUND LOST<br>Caution on ECAM EWD<br>(A321neo XLR) | С  | 1 | 0              | May be inoperative.  |

| REVISION NO.             |   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |               |  |  |
|--------------------------|---|---|---|-------------------------------|--|---------------|--|--|
|                          | 32  |   |   |                               | PAGE NO. 2   | 27-25         |  |  |
| DATE: XX/XX/X            | XXX   |   |   |                               |  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |
| 7. Flight Contr          | ols   | • | 1 |                               |  |               |  |  |
| Sequence No.             | Item  | 1 | 2 | 3                             | 4  | Change<br>Bar |  |  |
| 27-94-01                 | Spoiler Elevator<br>Computers (SEC)   |   |   |                               |  |               |  |  |
| 1)                       | SEC 1   |   |   |                               |  |               |  |  |
| a)                       | A320 without<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617,<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705 | C | 1 | 0                             | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) SFCC No. 2 flap channel is operative,</li> <li>f) All aileron servo channels are operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified closed before each flight,</li> <li>i) Elevators control through SEC 2 and ELACs and roll spoilers control through operative before each flight, and</li> <li>j) AFM performance penalties for two pairs of spoilers inoperative are applied.</li> </ul> </li> <li>NOTE: LAF is in degraded Mode. (Refer to item 27-64-02).</li> </ul> |               |  |  |

| -                               | IENT OF TRANSPORTATIO  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |        |  |  |
|---------------------------------|--|---|---|-------------------------------|--|--------|--|--|
| REVISION NO.<br>DATE: XX/XX/    |  |   |   | PAGE NO. 27                   | 7-26   |        |  |  |
| AIRCRAFT:<br>Airbus A320        |  |   |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |  |  |
| 27. Flight Cont<br>Sequence No. | Item   | 1 | 2 | 3                             | 4 c  | Change |  |  |
| 27-94-01                        | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)  | 1 | 2 | 3                             | 4  | Bar    |  |  |
| 1)                              | SEC 1<br>(Conťd)   |   |   |                               |  |        |  |  |
| b)                              | A318, A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, A320 without<br>Mod 160500/<br>MP J3283 and<br>Mod 160080/<br>MP J3705, A321 without<br>Mod 163323/<br>MP P20703 (eRudder) | C | 1 | 0                             | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) SFCC No. 2 flap channel is operative,</li> <li>f) All aileron servo channels are operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified closed before each flight,</li> <li>i) Elevators control through SEC 2 and ELACs and roll spoilers control through operative before each flight, and</li> <li>j) AFM performance penalties for two pairs of spoilers inoperative are applied.</li> </ul> </li> </ul> |        |  |  |

|   |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |
|---|---|---|---|--|
| 32  |   |   |   | PAGE NO. 27-27   |
| XXXX  |   |   |   |  |
|   | Т   | 1.<br>2.<br>3.  | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |
| rols  |   |   | 1   |  |
| Item  | 1   | 2   | 3   | 4 Change<br>Bar  |
| Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                                 |   |   |   |  |
| SEC 1<br>(Conťd)  |   |   |   |  |
| A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705 | C   | 1   | 0   | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided:</li> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) SFCC No. 2 flap channel is operative,</li> <li>f) All aileron servo channels are operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified closed before each flight,</li> <li>i) Elevators control through SEC 2 and ELACs and roll spoilers control through operative before each flight,</li> <li>j) AFM performance penalties for two pairs of spoilers inoperative are applied, and</li> <li>k) MTOW is limited to 76,400 kg (168,430 lbs).</li> </ul> |
|   | ATION ADMINISTRATION<br>32<br>XXX<br>rols<br>Item<br>Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/ | 32<br>(XXX<br>rols<br>Item 1<br>Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/ | ATION ADMINISTRATION<br>32<br>XXX<br>rols<br>Item 1 2<br>Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/ | ATION ADMINISTRATION<br>32<br>XXX<br>TABL<br>1.<br>2.<br>3.<br>4.<br>rols<br>Item 1 2 3<br>Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>SEC 1<br>(Cont'd)<br>A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                 | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|---|---|---|-----------------|---|--|--|--|
|  |   |   |   | 54.05 NO. 07.00 |   |  |  |  |
| REVISION NO.<br>DATE: XX/XX/   |   |   |   |                 | PAGE NO. 27-28  |  |  |  |
|  |   |   |   |                 | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 27. Flight Cont  | rols  |   |   |                 |   |  |  |  |
| Sequence No.   | ltem  | 1 | 2 | 3               | 4 Change<br>Bar   |  |  |  |
| 27-94-01   | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                             |   |   |                 |   |  |  |  |
| 1)   | SEC 1<br>(Conťd)  |   |   |                 |   |  |  |  |
| d)   | A321 with<br>Mod 163213/<br>MP J4530 and without<br>Mod 162739/<br>MP J4335 | С | 1 | 0               | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) SFCC No. 2 flap channel is operative,</li> <li>f) All aileron servo channels are operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified closed before each flight,</li> <li>i) Elevators control through SEC 2 and ELACs and roll spoilers control through operative before each flight,</li> <li>j) AFM performance penalties for two pairs of spoilers inoperative are applied, and</li> <li>k) FWD ACT is empty or not installed.</li> </ul> </li> </ul> |  |  |  |

| -                                   | IENT OF TRANSPORTATIO   | ON |   |                                       | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|-------------------------------------|---|----|---|---------------------------------------|--|--|--|--|
|                                     | ATION ADMINISTRATION  |    |   | · · · · · · · · · · · · · · · · · · · |  |  |  |  |
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |    |   |                                       | PAGE NO. 27-29   |  |  |  |
| DATE: XX/XX/                        | <b>XXXX</b>   |    |   |                                       |  |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |    | T | 1.<br>2.<br>3.                        | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 27. Flight Cont                     | rols  | 1  |   |                                       |  |  |  |  |
| Sequence No.                        | Item  | 1  | 2 | 3                                     | 4 Change<br>Bar  |  |  |  |
| 27-94-01                            | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                     |    |   |                                       |  |  |  |  |
| 1)                                  | SEC 1<br>(Conťd)  |    |   |                                       |  |  |  |  |
| e)                                  | A321 with<br>Mod 163213/<br>MP J4530 and<br>Mod 162739/<br>MP J4335 | С  | 1 | 0                                     | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) SFCC No. 2 flap channel is operative,</li> <li>f) All aileron servo channels are operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified closed before each flight,</li> <li>i) Elevators control through SEC 2 and ELACs and roll spoilers control through operative before each flight,</li> <li>j) AFM performance penalties for two pairs of spoilers inoperative are applied, and</li> <li>k) AFT2 ACT is empty or not installed.</li> </ul> </li> </ul> |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIS   | зт |
|--|--|---|---|----------------|--|----|
| REVISION NO.   | 32   |   |   |                | PAGE NO. 27-3  | 30 |
| DATE: XX/XX/>  | XXXX   |   |   |                |  |    |
| AIRCRAFT:<br>Airbus A320   |  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |    |
| 27. Flight Cont  | rols   | 1 |   | 1              |  |    |
| Sequence No.   | ltem   | 1 | 2 | 3              | 4 Chan<br>Bar  |    |
| 27-94-01   | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)<br>SEC 1 |   |   |                |  |    |
| ,  | (Cont'd)   |   |   |                |  |    |
| f)   | A321neo XLR  | C | 1 | 0              | <ul> <li>(M)(O) Except for ETOPS, may be<br/>inoperative provided: <ul> <li>a) SEC 1 is deactivated,</li> <li>b) SEC 2 is operative,</li> <li>c) Sidestick transducers<br/>associated with ELACs and<br/>SEC 2 are verified operative<br/>before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs,<br/>RAs, FMGCs, and ADIRs are<br/>operative,</li> <li>e) SFCC 2 flap channel is<br/>operative,</li> <li>f) All aileron servo channels are<br/>operative,</li> <li>g) TR 1 and TR 2 are operative,</li> <li>h) DC TIE contactor 1 is verified<br/>closed before each flight,</li> <li>i) Elevators control through<br/>SEC 2 and ELACs and roll<br/>spoilers control through<br/>SEC 2 are verified operative<br/>before each flight,</li> <li>j) AFM performance penalties<br/>for two pairs of spoilers<br/>inoperative are applied, and</li> <li>k) The MTOW is limited to<br/>97,000 kg (213,840 lbs).</li> </ul> </li> </ul> |    |

| -                        | MENT OF TRANSPORTA<br>ATION ADMINISTRATION  | - |   | MASTER MINIMUM EQUIPMENT LIST |  |               |  |  |
|--------------------------|---|---|---|-------------------------------|--|---------------|--|--|
| REVISION NO              | . 32  |   |   |                               | PAGE NO.   | . 27-31       |  |  |
| DATE: XX/XX/             | XXXX  |   |   |                               |  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |
| 27. Flight Con           | trols   |   |   |                               |  |               |  |  |
| Sequence No.             | Item  | 1 | 2 | 3                             | 4  | Change<br>Bar |  |  |
| 27-94-01                 | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)   |   |   |                               |  |               |  |  |
| 2)                       | SEC 2   |   |   |                               |  |               |  |  |
| a)                       | A320 without<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617,<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705 | C | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 2 is deactivated,</li> <li>b) SEC 1 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) All aileron servo channels are operative,</li> <li>f) Elevators control through SEC 1 and ELACs and roll spoilers control through operative SECs are verified operative before each flight.</li> </ul> </li> <li>NOTE: LAF is in degraded Mode. (Refer to item 27-64-02).</li> </ul> |               |  |  |
|                          |   |   |   |                               | (Continued)  |               |  |  |

| -                           | MENT OF TRANSPORTATION  | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|---|----|---|---|--|
| REVISION NO<br>DATE: XX/XX/ |   |    |   |   | PAGE NO. 27-32   |
|                             |   |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.                | Item  | 1  | 2 | 3 | 4 Change<br>Bar  |
| 27-94-01                    | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)   |    |   |   |  |
| 2)                          | SEC 2<br>(Conťd)  |    |   |   |  |
| b)                          | A318, A319, A320 with<br>Mod 26334/<br>MP J1616 or<br>Mod 26335/<br>MP J1617, A320 without<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705, and A321<br>(except A321neo XLR) | С  | 1 | 0 | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 2 is deactivated,</li> <li>b) SEC 1 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) All aileron servo channels are operative, and</li> <li>f) Elevators control through SEC 1 and ELACs and roll spoilers control through operative SECs are verified operative before each flight.</li> </ul> </li> </ul> |
|                             |   |    |   |   | (Continued)  |

| FEDERAL AVI                     | ATION ADMINISTRATION  |   |   |                | MASTER MINIMUM EQUIPMEN  | LIST   |
|---------------------------------|---|---|---|----------------|--|--------|
| REVISION NO<br>DATE: XX/XX/2    |   |   |   |                | PAGE NO.   | 27-33  |
| AIRCRAFT:<br>Airbus A320        |   |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |
| 27. Flight Cont<br>Sequence No. | Item  | 1 | 2 | 3              | 4  | Change |
| 27-94-01                        | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                                 |   | 2 | 3              | 4  | Bar    |
| 2)                              | SEC 2<br>(Conťd)  |   |   |                |  |        |
| c)                              | A320-200 with Sharklet<br>Mod 160500/<br>MP J3283 or<br>Mod 160080/<br>MP J3705 | C | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 2 is deactivated,</li> <li>b) SEC 1 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) All aileron servo channels are operative,</li> <li>f) Elevators control through SEC 1 and ELACs and roll spoilers control through operative SECs are verified operative before each flight, and</li> <li>g) MTOW is limited to 76,400 kg (168,430 lbs).</li> </ul> </li> </ul> |        |
|                                 |   |   |   |                | (Continued)  |        |

| FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |        |  |  |
|---------------------------------|---|---|---|----------------|---|--------|--|--|
| REVISION NO<br>DATE: XX/XX/2    |   |   |   |                | PAGE NO.  | 27-34  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |  |  |
| 27. Flight Cont                 |   | 4 | 2 | 2              | 4   | Change |  |  |
| Sequence No.<br>27-94-01        | Item<br>Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                     | 1 | 2 | 3              | 4   | Bar    |  |  |
| 2)                              | SEC 2<br>(Cont'd)   |   |   |                |   |        |  |  |
| d)                              | A321 with<br>Mod 163213/<br>MP J4530 and without<br>Mod 162739/<br>MP J4335 | C | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 2 is deactivated,</li> <li>b) SEC 1 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) All aileron servo channels are operative,</li> <li>f) Elevators control through SEC 1 and ELACs and roll spoilers control through operative before each flight, and</li> <li>g) FWD ACT is empty or not installed.</li> </ul></li></ul> |        |  |  |
|                                 |   |   |   |                | (Continued)   |        |  |  |

| -                        | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|---|----|---|----------------|---|
| REVISION NO              | D. 32   |    |   | PAGE NO. 27-35 |   |
| AIRCRAFT:<br>Airbus A320 | AIRCRAFT:   |    |   |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 27. Flight Con           |   |    |   |                | Change  |
| Sequence No.<br>27-94-01 | Spoiler Elevator<br>Computers (SEC)<br>(Cont'd)                     | 1  | 2 | 3              | 4 Change<br>Bar   |
| 2)                       | SEC 2<br>(Cont'd)   |    |   |                |   |
| e)                       | A321 with<br>Mod 163213/<br>MP J4530 and<br>Mod 162739/<br>MP J4335 | C  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 2 is deactivated,</li> <li>b) SEC 1 and SEC 3 are operative,</li> <li>c) Sidestick transducers associated with ELACs and operative SECs are verified operative before each flight,</li> <li>d) All ELACs, SFCCs, LGCIUs, RAs, FACs, and ADIRs are operative,</li> <li>e) All aileron servo channels are operative,</li> <li>f) Elevators control through SEC 1 and ELACs and roll spoilers control through operative before each flight, and</li> <li>g) AFT 2 ACT is empty or not installed.</li> </ul> </li> </ul> |
| 3)                       | SEC 3<br>(Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder))   | C  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) SEC 3 is deactivated,</li> <li>b) SEC 1 and SEC 2 are operative,</li> <li>c) SFCC No. 2 flap channel is operative,</li> <li>d) All aileron servo channels are operative,</li> <li>e) All roll spoilers associated with operative SECs are operative, and</li> <li>f) AFM performance penalties for two pairs of spoilers inoperative are applied.</li> </ul> </li> </ul>   |

|                             | ATION ADMINISTRATION                                   |   |   |    |  |
|-----------------------------|--|---|---|----|--|
| REVISION NO<br>DATE: XX/XX/ |  |   |   |    | PAGE NO. 27-36   |
|                             | ^^^^   |   |   |    |  |
|                             |  |   |   |    | E KEY<br>REPAIR CATEGORY   |
| AIRCRAFT:                   |  |   |   |    | NO. INSTALLED  |
| Airbus A320                 |  |   |   |    | NO. REQUIRED FOR DISPATCH  |
|                             |  |   |   | 4. | REMARKS OR EXCEPTIONS  |
| 27. Flight Con              | trols  | 1 |   |    | atawa  |
| Sequence No.                | Item   | 1 | 2 | 3  | 4 Change<br>Bar  |
| 27-94-02                    | SEC pb Switch  |   |   |    |  |
| 1)                          | FAULT Lights   |   |   |    |  |
| a)                          | Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder) | С | 3 | 2  | One may be inoperative provided associated SEC caution operates normally.  |
|                             |  | С | 3 | 0  | One or more may be inoperative<br>provided:<br>a) FWCs operate normally, and<br>a) ECAM SEC indications<br>operate normally. |
| b)                          | Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder)    | С | 2 | 1  | One may be inoperative provided associated SEC caution operates normally.  |
|                             |  | С | 2 | 0  | One or both may be inoperative<br>provided:<br>a) FWCs operate normally, and<br>b) ECAM SEC indications<br>operate normally. |
| 2)                          | OFF Lights   |   |   |    |  |
| a)                          | Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder) | С | 3 | 0  | One or more may be inoperative.  |
| b)                          | Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder)    | С | 2 | 0  | One or both may be inoperative<br>provided:<br>a) FWCs operate normally, and<br>b) ECAM SEC indications<br>operate normally. |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|---|---|
| REVISION NO  | D. 32  |   |   |   | PAGE NO. 27-37  |
| DATE: XX/XX  | /XXXX  |   |   |   |   |
| AIRCRAFT:<br>Airbus A320   |  |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 27. Flight Cor   | ntrols   |   |   | 1 | 2   |
| Sequence No.   | Item   | 1 | 2 | 3 | 4 Change<br>Bar   |
| 27-94-03   | SEC Indication on ECAM<br>F/CTL Page                   |   |   |   |   |
| 1)   | Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder) | С | 3 | 0 | One or more may be inoperative<br>provided SEC pb switch fault light<br>system operates normally. |
| 2)   | Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder)    | С | 2 | 0 | One or both may be inoperative<br>provided SEC pb switch fault light<br>system operates normally. |
| 27-95-01   | Flight Control Data<br>Concentrators                   |   |   |   |   |
| 1)   | Without Mod. 35542                                     | С | 2 | 1 | (M) FCDC 2 may be inoperative.  |
| 2)   | With Mod. 35542  | С | 2 | 1 | (M) FCDC 2 may be inoperative provided steep approach function is not used.                       |

| -                        | MENT OF TRANSPORTATION   | NC |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|---|----------------|--|
| REVISION NC              | ). 32  |    |   |                | PAGE NO. 28-1  |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                 |  |    |   |                |  |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 28-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |   |                |  |
| 1)                       | Fault(s) Indicated by FUEL   | С  | - | -              | NOTE: Dispatch with this MAINT STS<br>message displayed on ECAM<br>is permitted without CFDS<br>interrogation.   |
| 28-12-01                 | Overpressure Protectors  |    |   |                |  |
| 1)                       | A318/A319/A320   |    |   |                |  |
| a)                       | Between Inner and Outer<br>Tank  | С  | 2 | 0              | (O) One or both may be damaged or<br>missing provided the inner tank fuel<br>temperature is monitored.   |
|                          |  | С  | 2 | 0              | <ul> <li>(M)(O) One or both may be damaged<br/>or missing provided: <ul> <li>a) The associated transfer<br/>valves are latched in open<br/>position, and</li> <li>b) The associated transfer<br/>valves are verified in the open<br/>position prior to each flight.</li> </ul> </li> </ul> |
|                          |  |    |   |                | NOTE: After Transfer Valves have<br>been electrically latched<br>open, any refueling,<br>repowering, or opening of the<br>refuel door will cause the<br>Transfer Valves to unlatch<br>and close, requiring that the<br>Transfer Valves be electrically<br>latched open again.              |
| b)                       | In Vent Surge Tank   | С  | 2 | 0              | (M)(O) One or both may be damaged or missing.  |
|                          |  |    |   |                | (Continued)  |

|                          |  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|---|----------------|--|
| REVISION NO              |  |    |   |                | PAGE NO. 28-2  |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                 |  |    |   |                |  |
| Sequence No.             | ltem   | 1  | 2 | 3              | 4 Change   |
| 28-12-01                 | Overpressure Protectors (Cont'd)                 |    |   |                | ₩ Bar  |
| 1)                       | A318/A319/A320<br>(Cont'd)                       |    |   |                |  |
| c)                       | In Additional Center<br>Tank(s)<br>(With ACT(s)) | С  | - | 0              | <ul> <li>(M)(O) May be open provided:</li> <li>a) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>b) ACT(s) fuel quantity indications (both FQI if both ACTs installed) and center tank fuel quantity indications are operative on ECAM FUEL page.</li> </ul>             |
|                          |  | С  | - | 0              | May be open provided there is no fuel in any ACT.  |
|                          |  | С  | - | 0              | <ul> <li>(M)(O) May be open provided:</li> <li>a) Fuel in any ACT is considered<br/>unusable and included in<br/>ZFW and CG calculations,<br/>and</li> <li>b) ACT transfer value is secured<br/>closed.</li> </ul>   |
| 2)                       | A321   |    |   |                |  |
| a)                       | In Vent Surge Tank                               | С  | 2 | 0              | (M)(O) One or both may be damaged or missing.  |
| b)                       | In Additional Center<br>Tank(s)<br>(With ACT(s)) | С  | - | 0              | <ul> <li>(M)(O) May be open provided: <ul> <li>a) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>a) ACT(s) fuel quantity indications (both FQI if both ACTs installed) and center tank fuel quantity indications are operative on ECAM FUEL page.</li> </ul> </li> </ul> |
|                          |  |    |   |                | (Continued)  |

| FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|---------------------------------|--|---|----|----------------|--|--|--|--|--|
| <b>REVISION NO</b>              |  |   |    | PAGE NO. 28-3  |  |  |  |  |  |
| DATE: XX/XX/                    | XXXX   |   |    |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 28. Fuel                        |  |   |    |                |  |  |  |  |  |
| Sequence No.                    | ltem   | 1 | 2  | 3              | 4 Change<br>Bar  |  |  |  |  |
| 28-12-01                        | Overpressure Protectors<br>(Cont'd)                          |   |    |                |  |  |  |  |  |
| 2)                              | A321<br>(Cont'd)   |   |    |                |  |  |  |  |  |
| b)                              | In Additional Center<br>Tank(s)<br>(With ACT(s))<br>(Cont'd) | С | -  | 0              | May be open provided there is no fuel<br>in any ACT.   |  |  |  |  |
|                                 |  | С | -  | 0              | <ul> <li>(M)(O) May be open provided:</li> <li>a) Fuel in any ACT is considered<br/>unusable and included in<br/>ZFW and CG calculations,<br/>and</li> <li>b) ACT transfer valve is secured<br/>closed.</li> </ul> |  |  |  |  |
| 3)                              | A321 with<br>Mod. 163213/MP J4530                            |   |    |                |  |  |  |  |  |
| a)                              | In Vent Surge Tank   | С | 2  | 0              | (M)(O) One or both may be damaged or missing.  |  |  |  |  |
| b)                              | In the Center Tank for<br>ACT Vent Line                      | С | 2  | 0              | One or both may be damaged or<br>missing provided there is no fuel in<br>any ACT(s) and in the center tank.  |  |  |  |  |
| c)                              | In FWD ACT   | С | 1  | 0              | May be damaged or missing provided<br>there is no fuel in any ACT(s) and in<br>the center tank.  |  |  |  |  |
| 4)                              | A321neo XLR  |   |    |                |  |  |  |  |  |
| a)                              | In Vent Surge Tank   | С | 2  | 0              | (M)(O) One or both may be damaged or missing.  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                      |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--------------------------------------|---|---|----------------|--|
| REVISION NC<br>DATE: XX/XX/  |                                      |   |   |                | PAGE NO. 28-4  |
| AIRCRAFT:<br>Airbus A320   |                                      |   | Т | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel   |                                      |   |   |                |  |
| Sequence No.   | Item                                 | 1 | 2 | 3              | 4 Change<br>Bar  |
| 28-15-01   | Outer to Inner TK<br>Transfer Valves |   |   |                |  |
| 1)   | A318/A319/A320                       |   |   |                |  |
| a)   | LH Wing                              | С | 2 | 0              | (O) May be inoperative open.   |
|  |                                      | С | 2 | 0              | <ul> <li>(O) May be inoperative closed provided:</li> <li>a) LH outer tank is full, and</li> <li>b) LH outer tank fuel is considered unusable and included in ZFW and CG calculations.</li> </ul>  |
|  |                                      | C | 2 | 1              | <ul> <li>(M)(O) One may be inoperative closed provided: <ul> <li>a) Operative LH wing outer to inner tank transfer valve is latched in open position, and</li> <li>b) Operative LH wing outer to inner tank transfer valve is checked to be in open position prior to each flight.</li> </ul> </li> <li>NOTE: After Transfer Valves have been electrically latched open, any refueling, repowering, or opening of refuel door will cause Transfer Valves to unlatch and close. This will require Transfer Valves to be electrically latched open again.</li> </ul> |
|  |                                      |   |   |                | (Continued)  |

| IATION ADMINISTRATIO                             | N  |   |   | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|---|
| 0. 32  |  |   |   | PAGE NO. 28-5   |
| /XXXX  |  |   |   |   |
|  |  | Т   | 1.<br>2.<br>3.  | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
|  |  |   |   |   |
| Item   | 1  | 2   | 3   | 4 Change<br>Bar   |
| Outer to Inner TK<br>Transfer Valves<br>(Cont'd) |  |   |   |   |
| A318/A319/A320<br>(Conťd)                        |  |   |   |   |
| RH Wing  | С  | 2   | 0   | (O) May be inoperative open.  |
|  | С  | 2   | 0   | <ul> <li>(O) May be inoperative closed provided:</li> <li>a) RH outer tank is full, and</li> <li>b) RH outer tank fuel is considered unusable and included in ZFW and CG calculations.</li> </ul>   |
|  | С  | 2   | 1   | <ul> <li>(M)(O) One may be inoperative closed provided: <ul> <li>a) Operative RH wing outer to inner tank transfer valve is latched in open position, and</li> <li>b) Operative RH wing outer to inner tank transfer valve is checked to be in open position prior to each flight.</li> </ul> </li> <li>NOTE: After Transfer Valves have been electrically latched open, any refueling, repowering, or opening of refuel door will cause Transfer Valves to unlatch and close. This will</li> </ul>   |
|  | IATION ADMINISTRATIO<br>). 32<br>/XXXX<br>Item<br>Outer to Inner TK<br>Transfer Valves<br>(Cont'd)<br>A318/A319/A320<br>(Cont'd) | IATION ADMINISTRATION<br>0. 32<br>/XXXX<br>Item 1<br>Outer to Inner TK<br>Transfer Valves<br>(Cont'd)<br>A318/A319/A320<br>(Cont'd)<br>RH Wing C<br>C | IATION ADMINISTRATION<br>0. 32<br>/XXXX<br>Item 1 2<br>Outer to Inner TK<br>Transfer Valves<br>(Cont'd)<br>A318/A319/A320<br>(Cont'd)<br>RH Wing C 2<br>C 2 | Item       1       2       3         Item       1       2       3         Outer to Inner TK<br>Transfer Valves<br>(Cont'd)       1       2       3         A318/A319/A320<br>(Cont'd)       1       2       0         RH Wing       C       2       0         Image: Control of the state of the s |

| U.S. DEPARTI                | MENT OF TRANSPORTATI   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|--|----|---|---|--|
| FEDERAL AVI                 | ATION ADMINISTRATION   |    |   |   | MASTER MINIMOM EQUIPMENT LIST  |
| REVISION NO<br>DATE: XX/XX/ |  |    |   |   | PAGE NO. 28-6  |
| AIRCRAFT:<br>Airbus A320    | -T:  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                    |  |    |   |   |  |
| Sequence No.                | Item   | 1  | 2 | 3 | 4 Change<br>Bar  |
| 28-20-01                    | Automatic Fuel Feed<br>System  |    |   |   |  |
| 1)                          | Feed System for<br>A318/A319/A320 without<br>Mod. 154327/MP J3527  |    |   |   |  |
| a)                          | With<br>Mod. 37508/MP J2832  | С  | 1 | 0 | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
| b)                          | Without<br>Mod. 37508/MP J2832   | С  | 1 | 0 | (O) May be inoperative provided the total FOB after refueling is less than or equal to 12,000 kg (26,500 lbs).   |
|                             |  | С  | 1 | 0 | <ul> <li>(O) May be inoperative provided:</li> <li>a) The total FOB after refueling<br/>is more than 12,000 kg<br/>(26,500 lbs), and</li> <li>b) The fuel quantity in the center<br/>tank is between 2,000 kg<br/>(4,400 lbs) and 3,000 kg<br/>(6,600 lbs).</li> </ul>               |
| 28-21-01                    | Wing Tank Pumps<br>(Aircraft Fitted with<br>Mod. 36387/MP J2487<br>or Aircraft Not Specified<br>in Service Bulletin<br>A320-28-1102) |    |   |   |  |
| 1)                          | CFM Engines  | С  | 4 | 3 | (O) One pump may be inoperative provided JP4/Jet B is not used.  |
|                             |  | С  | 4 | 3 | <ul> <li>(M)(O) One pump 2 may be<br/>inoperative when JP4/Jet B is used<br/>provided: <ul> <li>a) Prior to each flight, fuel return<br/>valve is verified to operate<br/>normally, and</li> <li>b) Takeoff ECAM fuel<br/>temperature is less than<br/>30 °C.</li> </ul> </li> </ul> |
|                             |  |    |   |   | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |               | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|---------------|---|
| REVISION NO<br>DATE: XX/XX/  |  |   |   | PAGE NO. 28-7 |   |
|  |  |   | Т |               | E KEY<br>REPAIR CATEGORY  |
| AIRCRAFT:<br>Airbus A320   |  |   |   | 2.<br>3.      | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel   |  | 1 |   |               |   |
| Sequence No.   | ltem   | 1 | 2 | 3             | 4 Change<br>Bar   |
| 28-21-01   | Wing Tank Pumps<br>(Aircraft Fitted with<br>Mod. 36387/MP J2487<br>or Aircraft Not Specified<br>in Service Bulletin<br>A320-28-1102)<br>(Cont'd) |   |   |               |   |
| 2)   | IAE Engines  | С | 4 | 3             | (O) One pump may be inoperative provided JP4/Jet B is not used.   |
|  |  | С | 4 | 3             | (O) One pump 2 may be inoperative<br>when JP4/Jet B is used provided<br>takeoff fuel temperature is less than<br>30 °C.                                       |
| 3)   | PW Engines   | С | 4 | 3             | (O) One pump may be inoperative provided JP4/Jet B is not used.   |
| 28-21-02   | Center Tank Systems  |   |   |               |   |
| 1)   | Pumps  |   |   |               |   |
| a)   | A318/A319/A320 without<br>ACT and without<br>Mod. 154327/MP J3527  | С | 2 | 1             | (O) One may be inoperative provided<br>(when center tank fuel is required) a<br>suitable alternate airport exists within<br>range of wing tanks fuel loading. |
|  |  | С | 2 | 0             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Center tank pumps remain<br/>OFF, and</li> <li>b) Center tank remains empty.</li> </ul>                 |
|  |  | С | 2 | 0             | (O) May be inoperative provided fuel<br>in center tank is considered unusable<br>and is included in ZFW and CG<br>calculations.                               |
|  |  |   |   |               | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |               | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|---|---|---------------|--|--|--|--|--|
| REVISION NC<br>DATE: XX/XX/  |  |   |   | PAGE NO. 28-8 |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   |   |               | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS  |  |  |  |  |
| 28. Fuel   |  | 1 | 1 |               | Change   |  |  |  |  |
| Sequence No.<br>28-21-02   | Item<br>Center Tank Systems<br>(Cont'd)                      | 1 | 2 | 3             | 4 Change<br>Bar  |  |  |  |  |
| 1)   | Pumps<br>(Conťd)   |   |   |               |  |  |  |  |  |
| b)   | A319/A320 with ACT(s)<br>and without<br>Mod. 154327/MP J3527 | С | 2 | 1             | (O) One may be inoperative provided<br>(when center tank fuel is required) a<br>suitable alternate airport exists within<br>range of wing tanks fuel loading.  |  |  |  |  |
|  |  | С | 2 | 0             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Center tank pumps remain<br/>OFF, and</li> <li>b) Center tank and ACT(s)<br/>remain empty.</li> </ul>  |  |  |  |  |
|  |  | С | 2 | 0             | (M)(O) May be inoperative provided<br>fuel in center tank or ACT(s) is<br>considered unusable and included in<br>ZFW and CG calculations and the<br>ACT transfer valve is secured closed.                            |  |  |  |  |
| 2)   | Transfer Valves  |   |   |               |  |  |  |  |  |
| a)   | A321neo XLR  | С | 2 | 1             | (O) One may be inoperative in closed<br>position provided (when center tank<br>fuel is required) a suitable alternate<br>airport exists within range of wing<br>tanks fuel loading.                                  |  |  |  |  |
|  |  | С | 2 | 0             | <ul> <li>(O) One or both may be inoperative<br/>in closed position provided: <ul> <li>a) Center tank and RCT remain<br/>empty, and</li> <li>b) FWD ACT remains empty or<br/>is not installed.</li> </ul> </li> </ul> |  |  |  |  |
|  |  |   |   |               | (Continued)  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |   |   |   |                | PAGE NO. 28-9  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel   |   |   |   |                |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 28-21-02   | Center Tank Systems<br>(Cont'd)   |   |   |                |  |
| 2)   | Transfer Valves<br>(Conťd)  |   |   |                |  |
| a)   | A321neo XLR<br>(Conťd)  | С | 2 | 0              | <ul> <li>(O) One or both may be inoperative<br/>in closed position provided: <ul> <li>a) Fuel in center tank is<br/>considered unusable and is<br/>included in ZFW and CG<br/>calculations,</li> <li>b) RCT remains empty, and</li> <li>c) FWD ACT remains empty or<br/>is not installed.</li> </ul> </li> </ul> |
|  |   | С | 2 | 0              | <ul> <li>(O) One or both may be inoperative<br/>in open position provided: <ul> <li>a) Center tank and RCT remain<br/>empty, and</li> <li>b) FWD ACT remains empty or<br/>is not installed.</li> </ul> </li> </ul>   |
| b)   | A321 without ACT or<br>A319/A320 without ACT<br>and with Mod. 154327/<br>MP J3527 | С | 2 | 1              | (O) One may be inoperative in closed<br>position provided (when center tank<br>fuel is required) a suitable alternate<br>airport exists within range of wing<br>tanks fuel loading.  |
|  |   | С | 2 | 0              | (O) One or both may be inoperative<br>in closed position provided center<br>tank remains empty.  |
|  |   | С | 2 | 0              | (O) One or both may be inoperative<br>in closed position provided fuel in<br>center tank is considered unusable<br>and is included in ZFW and CG<br>calculations.  |
|  |   | С | 2 | 0              | (O) One or both may be inoperative<br>in open position provided center tank<br>remains empty.  |
|  |   |   |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |                | PAGE NO. 28-10   |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel   |   |   |   |                |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 28-21-02   | Center Tank System<br>(Cont'd)  |   |   |                |  |
| 2)   | Transfer Valves<br>(Cont'd)   |   |   |                |  |
| c)   | A321 with ACT(s) or<br>A319/A320 with ACT(s)<br>and with Mod. 154327/<br>MP J3527 | С | 2 | 1              | (O) One may be inoperative in closed<br>position provided (when center tank<br>fuel is required) a suitable alternate<br>airport exists within range of wing<br>tanks fuel loading.  |
|  |   | С | 2 | 0              | One or both may be inoperative in<br>closed position provided center tank<br>and ACTs remain empty.  |
|  |   | С | 2 | 0              | One or both may be inoperative in<br>closed position provided fuel in center<br>tank and ACTs is considered<br>unusable and is included in ZFW and<br>CG calculations.   |
|  |   | С | 2 | 0              | One or both may be inoperative in open position provided center tank and ACTs remain empty.  |
|  |   | C | 2 | 0              | <ul> <li>(M)(O) One or both may be inoperative in open position provided:</li> <li>a) Center tank remains empty,</li> <li>b) Fuel in any ACT is considered unusable and is included in ZFW and CG calculations, and</li> <li>c) ACT transfer valve is secured closed.</li> </ul> |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |                | PAGE NO. 28-11   |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel   |   |   |   |                |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 28-21-03   | Wing Tank Pump<br>Sequence Valves<br>(A318/A319/A320)<br>without Mod. 154327/<br>MP J3527 | С | 4 | 3              | (O) One may be inoperative provided<br>the associated pump is switched off<br>when center tank is feeding.   |
| 28-21-04   | Rear Center Tank<br>System<br>(A321neo XLR)   |   |   |                |  |
| 1)   | Transfer Pumps  | С | 2 | 1              | <ul> <li>(M)(O) One may be inoperative</li> <li>provided:</li> <li>a) Affected pump is deactivated,</li> <li>b) Affected pump is set to OFF,</li> <li>and</li> <li>c) Both RCT transfer isolation</li> <li>valves are operative.</li> </ul>  |
|  |   | C | 2 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Both pumps are deactivated,</li> <li>b) Both pumps are set to OFF,</li> <li>and</li> <li>c) There is no fuel in RCT.</li> </ul>   |
|  |   | C | 2 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Both pumps are deactivated,</li> <li>b) Both pumps are set to OFF,</li> <li>c) Fuel quantity in RCT is at or</li> <li>below 8,000 kg (17,600 lbs),</li> <li>and</li> <li>d) Fuel in RCT is considered</li> <li>unusable and is included in</li> <li>ZFW and CG calculations.</li> </ul> |
|  |   |   |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |                | PAGE NO. 28-12  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel<br>Sequence No.   | ltem  | 1 | 2 | 3              | 4 Change  |
| 28-21-04   | Rear Center Tank<br>System<br>(A321neo XLR)<br>(Cont'd) | 1 | 2 | 3              | 4 Bar  <br> <br> <br> <br>  |
| 2)   | Transfer Valves   | C | 2 | 1              | <ul> <li>(M) One may be inoperative</li> <li>provided:</li> <li>a) Affected valve is deactivated</li> <li>in closed position, and</li> <li>b) Aircraft is refueled using</li> <li>manual procedure.</li> </ul>  |
|  |   | С | 2 | 0              | <ul> <li>(M) Both may be inoperative  </li> <li>provided:  </li> <li>a) Both valves are deactivated in  </li> <li>closed position, and  </li> <li>b) There is no fuel in RCT.  </li> </ul>  |
|  |   | С | 2 | 0              | <ul> <li>(M) Both may be inoperative provided:</li> <li>a) Both valves are deactivated in closed position,</li> <li>b) Fuel Quantity in RCT is at or below 8,000 kg (17,600 lbs), and</li> <li>c) Fuel in RCT is considered unusable and is included in ZFW and CG calculations.</li> </ul> |
|  |   |   |   |                | (Continued)   |

| -                               | MENT OF TRANSPORTATIO                                   | NC |   |                | MASTER MINIMUM EQUIPMENT LI  | IST            |
|---------------------------------|---|----|---|----------------|--|----------------|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |                |  |                |
| REVISION NO<br>DATE: XX/XX/2    |   |    |   |                | PAGE NO. 28  | -13            |
| AIRCRAFT:<br>Airbus A320        |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |                |
| 28. Fuel<br>Sequence No.        | ltem  | 1  | 2 | 3              |  | ange<br>Bar    |
| 28-21-04                        | Rear Center Tank<br>System<br>(A321neo XLR)<br>(Cont'd) |    |   |                |  | <br> <br> <br> |
| 3)                              | Transfer Isolation Valves                               | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Affected valve is deactivated in closed position,</li> <li>b) Both RCT transfer pumps are operative, and</li> <li>c) Aircraft is refueled using manual procedure.</li> </ul>   |                |
|                                 |   | С  | 2 | 0              | <ul> <li>(M) Both may be inoperative provided:</li> <li>a) Both valves are deactivated in closed position, and</li> <li>b) There is no fuel in RCT.</li> </ul>   | <br> <br>      |
|                                 |   | С  | 2 | 0              | <ul> <li>(M)(O) Both may be inoperative provided:</li> <li>a) Both valves are deactivated in closed position,</li> <li>b) Fuel quantity in RCT is at or below 8,000 kg (17,600 lbs), and</li> <li>c) Fuel in RCT is considered unusable and is included in ZFW and CG calculations.</li> </ul> |                |

|                             | MENT OF TRANSPORTATION  | ON |    |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|-----------------------------|---|----|----|---|---|--|--|
| REVISION NO<br>DATE: XX/XX/ |   |    |    |   | PAGE NO. 28-14  |  |  |
| AIRCRAFT:<br>Airbus A320    |   |    | T. | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |
| 28. Fuel                    |   |    |    |   | Change  |  |  |
| Sequence No.                | Item  | 1  | 2  | 3   | 4 Change<br>Bar   |  |  |
| 28-23-02                    | CROSSFEED pb Switch   |    |    |   |   |  |  |
| 1)                          | ON Light  | С  | 1  | 0   | May be inoperative provided X FEED<br>indication on ECAM FUEL page<br>operates normally.  |  |  |
| 2)                          | OPEN Light  | С  | 1  | 0   | May be inoperative provided X FEED<br>indication on ECAM FUEL page<br>operates normally.  |  |  |
| 28-24-01                    | Engine LP Fuel Valve<br>Electrical Motor<br>(With Mod. 25537) | С  | 4  | 2   | <ul> <li>(M) One may be inoperative on each valve provided:</li> <li>a) Affected valve motor is deactivated, and</li> <li>b) Remaining valve motor is checked operative.</li> </ul> |  |  |
| 28-25-01                    | Fuel Quantity<br>Preselector System                           | С  | -  | 0   | One or more may be inoperative.   |  |  |
| 28-25-02                    | Fuel Quantity Indicator<br>(Refueling Panel)                  | С  | 1  | 0   | (M) One or more indications may be<br>inoperative provided alternate means<br>of refueling are used.  |  |  |
| 28-25-03                    | High Level Fuel<br>Detection System                           |    |    |   |   |  |  |
| 1)                          | A318/A319/A320/A321<br>without ACT                            | С  | 1  | 0   | May be inoperative provided an acceptable means of monitoring fuel loading is used.   |  |  |
|                             |   |    |    |   | (Continued)   |  |  |

|                          | MENT OF TRANSPORTA                              |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|--------------------------|---|---|---|----------------|---|--|--|
|                          | ATION ADMINISTRATION                            | l |   |                |   |  |  |
| REVISION NC              |   |   |   |                | PAGE NO. 28-15  |  |  |
| DATE: XX/XX/             | XXXX  |   |   |                |   |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 28. Fuel                 |   |   |   |                |   |  |  |
| Sequence No.             | ltem  | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |
| 28-25-03                 | High Level Fuel<br>Detection System<br>(Cont'd) |   |   |                |   |  |  |
| 2)                       | A319/A320 with ACT                              |   |   |                |   |  |  |
| a)                       | Inner Tank                                      | С | 1 | 0              | May be inoperative provided an<br>acceptable means of monitoring fuel<br>loading is used.   |  |  |
| b)                       | Center Tank                                     | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) An acceptable means of monitoring fuel loading is used,</li> <li>b) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>c) ACT(s) and center fuel indications on ECAM FUEL page are operative.</li> </ul> </li> </ul> |  |  |
|                          |   | С | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) An acceptable means of<br/>monitoring fuel loading is<br/>used, and</li> <li>b) There is no fuel in any ACT.</li> </ul>   |  |  |
|                          |   | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) An acceptable means of<br/>monitoring fuel loading is<br/>used,</li> <li>b) Fuel in any ACT is considered<br/>unusable and included in ZFW<br/>and CG calculations, and</li> <li>c) ACT transfer valve is secured<br/>closed.</li> </ul>                   |  |  |
| c)                       | Additional Center<br>Tank(s)                    | С | - | 0              | May be inoperative provided an acceptable means of monitoring fuel loading is used.   |  |  |
|                          |   |   |   |                | (Continued)   |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |          | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|---|---|---|----------|--|--|--|--|--|
| REVISION NO  |   |   |   |          | PAGE NO. 28-16   |  |  |  |  |
| DATE: XX/XX  |   |   |   |          | TAGE NO. 20-10   |  |  |  |  |
| D/(12:70070  |   |   |   |          | EKEY   |  |  |  |  |
|  |   |   |   |          | REPAIR CATEGORY  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   |   | 2.       | NO. INSTALLED  |  |  |  |  |
| Allbus A320  |   |   |   | 3.<br>4. | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 28. Fuel   |   |   |   |          |  |  |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3        | 4 Change<br>Bar  |  |  |  |  |
| 28-25-03   | High Level Fuel<br>Detection System<br>(Cont'd) |   |   |          |  |  |  |  |  |
| 3)   | A321neo XLR                                     |   |   |          |  |  |  |  |  |
| a)   | Wing Tank                                       | C | 1 | 0        | May be inoperative provided an<br>acceptable means of monitoring fuel<br>loading is used.  |  |  |  |  |
| b)   | Center Tank                                     | С | 1 | 0        | <ul> <li>May be inoperative provided:</li> <li>a) An acceptable means of<br/>monitoring fuel loading is<br/>used,</li> <li>b) RCT remains empty, and</li> <li>c) FWD ACT remains empty or<br/>is not installed.</li> </ul> |  |  |  |  |
| c)   | Rear Center Tank                                | С | 1 | 0        | May be inoperative.  |  |  |  |  |
|  |   |   |   |          | NOTE: With RCT High Level Fuel<br>Detection System inoperative,<br>fuel in RCT (if any) remains<br>usable but RCT can no longer<br>be refueled for next flights.   |  |  |  |  |
|  |   |   |   |          | (Continued)  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/2   |   |   |   |                | PAGE NO. 28-17  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel   |   |   |   |                |   |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar   |
| 28-25-03   | High Level Fuel<br>Detection System<br>(Cont'd) |   |   |                |   |
| 4)   | A321 with ACT(s)                                |   |   |                |   |
| a)   | Wing Tank                                       | С | 1 | 0              | May be inoperative provided an acceptable means of monitoring fuel loading is used.   |
| b)   | Center Tank                                     | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) An acceptable means of monitoring fuel loading is used,</li> <li>b) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>c) ACT(s) and center fuel indications on ECAM FUEL page are operative.</li> </ul> </li> </ul> |
|  |   | С | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) An acceptable means of<br/>monitoring fuel loading is<br/>used, and</li> <li>b) There is no fuel in any ACT.</li> </ul>   |
|  |   | C | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) An acceptable means of monitoring fuel loading is used,</li> <li>b) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>c) ACT transfer valve is secured closed.</li> </ul> </li> </ul>                           |
|  |   |   |   |                | closed.<br>(Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|---|---|---|----------------|---|--|--|--|
| REVISION NO. 32  |   |   |   |                | PAGE NO. 28-18  |  |  |  |
| DATE: XX/XX/   | XXXX  |   |   |                |   |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |  |  |
| 28. Fuel   |   | [ | 1 |                |   |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |
| 28-25-03   | High Level Fuel<br>Detection System<br>(Cont'd)                                     |   |   |                |   |  |  |  |
| 4)   | A321 with ACT(s)<br>(Cont'd)  |   |   |                |   |  |  |  |
| c)   | Additional Center<br>Tank(s)  | С | - | 0              | May be inoperative provided an<br>acceptable means of monitoring fuel<br>loading is used.       |  |  |  |
| 28-25-04   | Refuel Valves   | С | 3 | 0              | (M) May be inoperative provided alternate procedures are developed and used.                    |  |  |  |
| 28-25-05   | Transfer Defuel Valve   | С | 1 | 0              | (M) May be inoperative provided valve is secured in the closed position.                        |  |  |  |
| 28-25-06   | Refuel/Defuel Control<br>Panel  |   |   |                |   |  |  |  |
| 1)   | Exterior Control Panel  |   |   |                |   |  |  |  |
| a)   | Aircraft without<br>Mod 20164/MP J0022<br>or 22760/MP J0835                         | С | 1 | 0              | (M) May be inoperative provided alternate procedures are established and used.                  |  |  |  |
| b)   | Aircraft with<br>Mod 20164/MP J0022<br>or 22760/MP J0835                            | С | 1 | 0              | (O) May be inoperative provided that<br>the cockpit fuel quantity pre-selector<br>is operative. |  |  |  |
|  |   | С | 1 | 0              | (M) May be inoperative provided alternate procedures are established and used.                  |  |  |  |
| 2)<br>***  | Cockpit Control Panel<br>(Aircraft with<br>Mod 20164/MP J0022 or<br>22760/MP J0835) | D | 1 | 0              | May be inoperative.   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION |                  |   |   | MASTER MINIMUM EQUIPMENT LIS |  |               |  |  |
|-----------------------------------|------------------|---|---|------------------------------|--|---------------|--|--|
| FEDERAL AVIATION ADMINISTRATION   |                  |   |   |                              |  |               |  |  |
| <b>REVISION NC</b>                | 0. 32            |   |   |                              | PAGE NO. 2   | 28-19         |  |  |
| DATE: XX/XX/                      | /XXXX            |   |   |                              |  |               |  |  |
|                                   |                  |   | Т | ABL                          | EKEY   |               |  |  |
| AIRCRAFT:                         |                  |   |   |                              | REPAIR CATEGORY  |               |  |  |
| Airbus A320                       |                  |   |   |                              | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |               |  |  |
|                                   |                  |   |   | -                            | REMARKS OR EXCEPTIONS  |               |  |  |
| 28. Fuel                          |                  |   |   |                              |  |               |  |  |
| Sequence No.                      | Item             | 1 | 2 | 3                            | 4  | Change<br>Bar |  |  |
| 28-25-07                          | RCT Inlet Valve  | С | 1 | 0                            | <ul> <li>(M) May be inoperative provided:</li> <li>a) RCT refuel valve is operative,</li> <li>b) RCT is refueled using manual procedure, and</li> <li>c) RCT inlet valve is deactivated in closed position after each RCT refueling.</li> <li>(M) May be inoperative provided RCT</li> </ul> |               |  |  |
|                                   |                  |   | I | U                            | <ul> <li>inlet valve is deactivated in closed position.</li> <li>NOTE: With RCT inlet valve inoperative in closed position, fuel in RCT (if any) remains usable but RCT can no longer be refueled for next flights.</li> </ul>   |               |  |  |
| 28-25-08                          | RCT Refuel Valve | С | 1 | 0                            | May be inoperative in open position provided wing tank refuel valves are operative.  | <br> <br>     |  |  |
|                                   |                  | С | 1 | 0                            | May be inoperative in closed position.<br>NOTE: With RCT refuel valve<br>inoperative in closed position,<br>fuel in RCT (if any) remains<br>usable but RCT can no longer<br>be refueled for next flights.  |               |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 32<br>DATE: XX/XX/XXXX |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|---|--|---|----|----------------|--|--|--|--|--|
|   |  |   |    |                | PAGE NO. 28-20   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320  |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 28. Fuel  |  |   |    |                |  |  |  |  |  |
| Sequence No.  | Item   | 1 | 2  | 3              | 4 Change<br>Bar  |  |  |  |  |
| 28-28-01  | Auto Transfer System<br>Additional Center<br>Tank(s) (ACT)                               |   |    |                |  |  |  |  |  |
| 1)  | A319/A320/A321 with<br>ACT(s) without<br>Mod 163213/<br>MP J4530<br>(except A321neo XLR) | С | 1  | 0              | May be inoperative provided there is no fuel in any ACT.   |  |  |  |  |
|   |  | С | 1  | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel in any ACT is considered<br/>unusable and included in ZFW<br/>and CG calculations, and</li> <li>b) ACT transfer value is secured<br/>closed.</li> </ul>  |  |  |  |  |
|   |  | С | 1  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Manual transfer from ACT(s)<br/>to center tank is checked<br/>before each flight, and</li> <li>b) ACT(s) and center tank fuel<br/>quantity indications on ECAM<br/>FUEL page are operative.</li> </ul> |  |  |  |  |
| 2)  | A321 with Mod 163213/<br>MP J4530  | С | 1  | 0              | May be inoperative provided there is no fuel in any ACT.   |  |  |  |  |
|   |  | С | 1  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Manual transfer from ACT(s)<br/>to center tank is checked<br/>before each flight, and</li> <li>b) ACT(s) and center tank fuel<br/>quantity indications on ECAM<br/>FUEL page are operative.</li> </ul> |  |  |  |  |

|                          | MENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|---|----------------|--|
| REVISION NO. 32          |   |    |   |                | PAGE NO. 28-21   |
| DATE: XX/XX/             | XXXX  |    |   |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                 |   |    |   |                |  |
| Sequence No.             | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 28-28-02                 | Transfer Valve Additional<br>Center Tank(s)   |    |   |                |  |
| 1)                       | A319/A320/A321 with<br>ACT(s) without<br>Mod. 163213/<br>MP J4530<br>(except A321neo XLR) | С  | 1 | 0              | May be inoperative in closed position provided there is no fuel in any ACT.  |
|                          |   | С  | 1 | 0              | <ul> <li>(M)(O) May be inoperative in closed position provided:</li> <li>a) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>b) ACT transfer value is secured closed.</li> </ul> |
|                          |   | С  | 1 | 0              | (M) May be inoperative in open<br>position provided an alternate<br>procedure is used for refueling<br>ACT(s).   |
| 2)                       | A321 with ACT(s) with<br>Mod 163213/MP J4530  | С  | 1 | 0              | May be inoperative in closed position provided there is no fuel in any ACT.  |
|                          |   | С  | 1 | 0              | (M)(O) May be inoperative in open<br>position provided an alternate<br>procedure is used for refueling<br>ACT(s).  |
| 28-28-03                 | Transfer Pump<br>Additional Center<br>Tank(s)   |    |   |                |  |
| 1)                       | A319/A320/A321 with<br>ACT(s)<br>(except A321neo XLR)                                     | С  | 1 | 0              | May be inoperative.  |

| US DEPART                |   | ON |    |                               |   |  |  |  |
|--------------------------|---|----|----|-------------------------------|---|--|--|--|
| -                        | ATION ADMINISTRATION  |    |    | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
| REVISION NO. 32          |   |    |    |                               | PAGE NO. 28-22  |  |  |  |
| DATE: XX/XX/             | XXXX  |    |    |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 28. Fuel                 |   |    | 1  | 1                             |   |  |  |  |
| Sequence No.             | Item  | 1  | 2  | 3                             | 4 Change<br>Bar   |  |  |  |
| 28-28-04                 | Air Shutoff Valve<br>Additional Center<br>Tank(s)   |    |    |                               |   |  |  |  |
| 1)                       | A319/A320/A321 with<br>ACT(s) without<br>Mod. 163213/<br>MP J4530<br>(except A321neo XLR) | С  | 1  | 0                             | May be inoperative closed provided there is no fuel in any ACT.   |  |  |  |
|                          |   | С  | 1  | 0                             | <ul> <li>(M)(O) May be inoperative closed provided:</li> <li>a) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>b) ACT transfer value is secured closed.</li> </ul>                                      |  |  |  |
|                          |   | С  | 1  | 0                             | <ul> <li>(O) May be inoperative closed provided:</li> <li>a) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>b) ACT(s) and center tank fuel quantity indications on ECAM FUEL page are operative.</li> </ul> |  |  |  |
| 2)                       | A321 with ACT(s) with<br>Mod. 163213/MP J4530   | С  | 1  | 0                             | May be inoperative closed provided there is no fuel in any ACT.   |  |  |  |
|                          |   | С  | 1  | 0                             | <ul> <li>(O) May be inoperative closed provided:</li> <li>a) Manual transfer from ACT(s) to center tank is verified to operate normally, and</li> <li>b) ACT(s) and center tank fuel quantity indications on ECAM FUEL page are operative.</li> </ul> |  |  |  |

| -                        | MENT OF TRANSPORTATI  | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|----|----------------|--|
|                          | ATION ADMINISTRATION  |    |    |                |  |
| REVISION NO. 32          |   |    |    |                | PAGE NO. 28-23   |
| DATE: XX/XX/             | ****  |    |    |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                 |   |    | 1  | 1              | <u>.</u>   |
| Sequence No.             | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |
| 28-28-05                 | Inward Pressure Relief<br>Valve Additional Center<br>Tank(s)                              |    |    |                |  |
| 1)                       | A319/A320/A321 with<br>ACT(s)<br>(except A321neo XLR)                                     | С  | -  | 0              | May be inoperative open provided there is no fuel in any ACT.  |
| 28-28-06                 | Vent Valve Additional<br>Center Tank(s)   |    |    |                |  |
| 1)                       | A319/A320/A321 with<br>ACT(s) without<br>Mod. 163213/<br>MP J4530<br>(except A321neo XLR) | С  | -  | 0              | May be inoperative provided there is no fuel in any ACT.   |
|                          |   | С  | -  | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel in any ACT is considered<br/>unusable and included in ZFW<br/>and CG calculations, and</li> <li>b) ACT transfer valve is secured<br/>closed.</li> </ul>  |
|                          |   | С  | -  | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Manual transfer from ACT(s)<br/>to center tank is verified to<br/>operate normally,</li> <li>b) ACT(s) and center tank fuel<br/>quantity indications on ECAM<br/>FUEL page are operative, and</li> <li>c) Associated ACT vent valve is<br/>secured open.</li> </ul> |
| 2)                       | A321 with ACT(s) with<br>Mod. 163213/MP J4530   | С  | 1  | 0              | May be inoperative provided there is no fuel in any ACT.   |
|                          |   | С  | 1  | 0              | (M) May be inoperative in closed<br>position provided an alternate<br>procedure is used for refueling<br>ACT(s).   |

|                             | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION          | ON |   | MASTER MINIMUM EQUIPMENT LIST   |   |  |  |
|-----------------------------|---|----|---|---|---|--|--|
| REVISION NO<br>DATE: XX/XX/ | -   |    |   | PAGE NO. 28-24  |   |  |  |
| AIRCRAFT:<br>Airbus A320    | AIRCRAFT:   |    |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |
| 28. Fuel                    |   |    |   |   |   |  |  |
| Sequence No.                | Item  | 1  | 2 | 3   | 4 Change<br>Bar   |  |  |
| 28-28-07                    | Refuel Valve Additional<br>Center Tank(s)             |    |   |   |   |  |  |
| 1)                          | A319/A320/A321 with<br>ACT(s)<br>(except A321neo XLR) | С  | 1 | 0   | <ul> <li>(M) May be inoperative in the closed position.</li> <li>NOTE: The (M) procedure only needs to be accomplished at each ACT refueling.</li> </ul>  |  |  |
| 28-28-08                    | Inlet Valve Additional<br>Center Tank(s)              | С  | 1 | 0   | May be inoperative in open position.  |  |  |
| 1)                          | ACT 1   | с  | 1 | 0   | May be inoperative in closed position provided there is no fuel in any ACT.   |  |  |
|                             |   | С  | 1 | 0   | <ul> <li>(M)(O) May be inoperative in closed position provided:</li> <li>a) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>b) ACT transfer value is secured closed.</li> </ul>                    |  |  |
|                             |   | С  | 1 | 0   | <ul> <li>(M) May be inoperative in open<br/>position provided: <ul> <li>a) ACT 2 is not installed or is<br/>empty, and</li> <li>b) Transfer valve is verified<br/>operative prior to each flight<br/>when ACT 1 is used.</li> </ul> </li> </ul> |  |  |
|                             |   |    |   |   | (Continued)   |  |  |

| -                        | MENT OF TRANSPORTATION  | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--------------------------|---|----|---|---|--|--|--|--|
| REVISION NO. 32          |   |    |   |   | PAGE NO. 28-25   |  |  |  |
| DATE: XX/XX/X            | -   |    |   |   | 17.02.1.01.20.20   |  |  |  |
| AIRCRAFT:<br>Airbus A320 | AIRCRAFT:   |    |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS  |  |  |  |
| 28. Fuel                 |   | 1  |   |   |  |  |  |  |
| Sequence No.             | Item  | 1  | 2 | 3 | 4 Change<br>Bar  |  |  |  |
| 28-28-08                 | Inlet Valve Additional<br>Center Tank(s)<br>(Cont'd)                                    |    |   |   |  |  |  |  |
| 2)                       | ACT 2   | С  | 1 | 0 | May be inoperative in closed position provided there is no fuel in ACT 2.  |  |  |  |
|                          |   | С  | 1 | 0 | <ul> <li>(M)(O) May be inoperative in closed position provided:</li> <li>a) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>b) ACT transfer value is secured closed.</li> </ul> |  |  |  |
|                          |   | С  | 1 | 0 | May be inoperative in open position provided there is no fuel in any ACT.  |  |  |  |
|                          |   | С  | 1 | 0 | <ul> <li>(M) May be inoperative in open position provided:</li> <li>a) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>b) ACT transfer value is secured closed.</li> </ul>      |  |  |  |
| 3)                       | AFT 1 ACT<br>(A321 with<br>Mod. 163213/MP J4530)  | С  | 1 | 0 | May be inoperative in closed position provided there is no fuel in any ACT.  |  |  |  |
| 4)                       | AFT 2 ACT<br>(A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335) | С  | 1 | 0 | May be inoperative in closed position provided there is no fuel in any ACT.  |  |  |  |
|                          |   | С  | 1 | 0 | May be inoperative in closed position<br>provided there is no fuel in FWD ACT<br>and AFT 2 ACT.  |  |  |  |
|                          |   |    |   |   | (Continued)  |  |  |  |

|                             | MENT OF TRANSPORTATION  | UN |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|-----------------------------|---|----|---|-------------------------------|---|--|--|--|
| REVISION NO<br>DATE: XX/XX/ |   |    |   |                               | PAGE NO. 28-26  |  |  |  |
| AIRCRAFT:<br>Airbus A320    |   |    | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |  |  |
| 28. Fuel                    |   |    |   |                               |   |  |  |  |
| Sequence No.                | ltem  | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 28-28-08                    | Inlet Valve Additional<br>Center Tank(s)<br>(Cont'd)                                  |    |   |                               |   |  |  |  |
| 5)                          | AFT2 ACT<br>(A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335)   | С  | 1 | 0                             | May be inoperative in closed position provided there is no fuel in any ACT.                     |  |  |  |
|                             |   | С  | 1 | 0                             | May be inoperative in closed position provided there is no fuel in AFT 2 ACT.                   |  |  |  |
| 6)                          | FWD ACT<br>(A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335) | С  | 1 | 0                             | May be inoperative in closed position provided there is no fuel in any ACT.                     |  |  |  |
|                             |   | С  | 1 | 0                             | May be inoperative in closed position provided there is no fuel in FWD ACT.                     |  |  |  |
| 7)                          | FWD ACT<br>(A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335)    | С  | 1 | 0                             | May be inoperative in closed position provided there is no fuel in any ACT.                     |  |  |  |
|                             |   | С  | 1 | 0                             | May be inoperative in closed position<br>provided there is no fuel in FWD ACT<br>and AFT 2 ACT. |  |  |  |

| -                           | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                              | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|---|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/ |   |    |   |                | PAGE NO. 28-27   |
| AIRCRAFT:<br>Airbus A320    |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                    |   |    |   |                |  |
| Sequence No.                | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 28-28-09                    | FWD ACT Ventilation<br>Isolation Valve                                    |    |   |                |  |
| 1)                          | A321 with<br>Mod. 163213/ MP J4530<br>and without<br>Mod. 162739/MP J4335 | С  | 1 | 0              | May be inoperative in the closed<br>position provided there is no fuel in<br>FWD ACT.  |
| 2)                          | A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335     | С  | 1 | 0              | May be inoperative in the closed<br>position provided there is no fuel in<br>FWD ACT and AFT 2 ACT.  |
| 28-28-10                    | FWD ACT Isolation<br>Valve  |    |   |                |  |
| 1)                          | A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335  | С  | 1 | 0              | <ul> <li>(M) May be inoperative in the closed position provided:</li> <li>a) There is no fuel in FWD ACT, and</li> <li>b) FWD ACT REFUEL VALVE selector, located on the ACT refueling control panel, is set to SHUT.</li> </ul>  |
| 2)                          | A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335     | С  | 1 | 0              | <ul> <li>(M) May be inoperative in the closed position provided: <ul> <li>a) There is no fuel in FWD ACT and AFT 2 ACT, and</li> <li>b) FWD ACT REFUEL VALVE selector and AFT 2 ACT REFUEL VALVE selector, located on the ACT refueling control panel, are set to SHUT.</li> </ul> </li> </ul> |

|                          |         | IENT OF TRANSPORTATION   | ON |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--------------------------|---------|--|----|----------------|---|--|--|--|
| REVISION NO. 32          |         |  |    |                |   | PAGE NO. 28-28   |  |  |
| DATE:                    | XX/XX/X | XXXX   |    |                |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |         |  | T  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |  |  |
| 28. Fue                  |         |  |    | 1              |   | Change   |  |  |
| Sequenc<br>28-28-7       |         | Item<br>Fuel ACT Overhead<br>Panel (A321 with<br>Mod. 163213/MP J4530) | 1  | 2              | 3   | 4 Change<br>Bar  |  |  |
| 1)                       |         | ACT XFR MODE SEL<br>pb-sw  |    |                |   |  |  |  |
|                          | a)      | FAULT light  | С  | 1              | 0   | (O) May be inoperative provided the<br>fuel quantity indications of the ACTs<br>are operative on the ECAM FUEL<br>page.  |  |  |
|                          | b)      | MAN light  | С  | 1              | 0   | May be inoperative.  |  |  |
| 2)                       |         | ALL ACT pb-sw  |    |                |   |  |  |  |
|                          | a)      | OVFL light   | С  | 1              | 0   | May be inoperative provided the fuel<br>quantity indication of the center tank<br>is operative on the ECAM FUEL<br>page. |  |  |
|                          | b)      | ISOL light   | С  | 1              | 0   | May be inoperative.  |  |  |
| 3)                       |         | FWD ACT pb-sw  |    |                |   |  |  |  |
|                          | a)      | FAULT light  | С  | 1              | 0   | May be inoperative.  |  |  |
|                          | b)      | OVRD light   | С  | 1              | 0   | May be inoperative.  |  |  |
| 4)                       |         | ACT XFR selector   | С  | 1              | 0   | (O) May be inoperative.  |  |  |

|                             | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION  | ON |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |
|-----------------------------|---|----|---|---|---|--|
| REVISION NO<br>DATE: XX/XX/ |   |    |   |   | PAGE NO. 28-29  |  |
| AIRCRAFT:<br>Airbus A320    |   |    | T | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |
| 28. Fuel                    |   |    |   |   | A Change  |  |
| Sequence No.<br>28-40-01    | Item<br>Low Level Detection<br>Systems  | 1  | 2 | 3   | 4 Change<br>Bar   |  |
| 1)                          | Wing  | С  | 2 | 1   | One may be inoperative provided all flight deck fuel quantity indicators are operative.   |  |
| 2)                          | Additional Center Tank  |    |   |   |   |  |
| a)                          | A319/A320/A321 with<br>ACT(s) without<br>Mod. 163213/<br>MP J4530<br>(except A321neo XLR) | C  | - | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Manual transfer from ACT to center tank is verified to operate normally,</li> <li>b) ACT(s) and center tank fuel quantity indications on ECAM FUEL page are operative, and</li> <li>c) There is no fuel in ACT 2.</li> </ul> |  |
|                             |   | С  | - | 0   | May be inoperative provided there is no fuel in any ACT.  |  |
|                             |   | С  | - | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel in any ACT is considered<br/>unusable and included in ZFW<br/>and CG calculations, and</li> <li>b) ACT transfer valve is secured<br/>closed.</li> </ul>   |  |
| b)                          | A321 with ACT(s) with<br>Mod 163213/<br>MP J4530  | С  | - | 0   | May be inoperative provided the ACT<br>auto transfer system is considered<br>inoperative.   |  |
|                             |   |    |   |   | (Continued)   |  |

| -                                    | VENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |   | MASTER MINIMUM EQUIPMENT   | LIST          |  |
|--------------------------------------|--|----|---|---|--|---------------|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX  |  |    |   |   | PAGE NO. 2   | 28-30         |  |
| AIRCRAFT:<br>Airbus A320<br>28. Fuel |  |    | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |               |  |
| Sequence No.                         | ltem   | 1  | 2 | 3   | 4  | Change<br>Bar |  |
| 28-40-01                             | Low Level Detection<br>Systems<br>(Cont'd)   |    |   |   |  | Bai           |  |
| 3)                                   | Rear Center Tank<br>(A321neo XLR)  | С  | 1 | 0   | May be inoperative provided there is no fuel in RCT.   | <br>          |  |
|                                      |  | С  | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Both RCT transfer pumps are deactivated,</li> <li>b) Both RCT transfer pumps are set to OFF,</li> <li>c) Fuel quantity in RCT is at or below 8,000 kg (17,600 lbs), and</li> <li>d) Fuel in RCT is considered unusable and is included in ZFW and CG calculations.</li> </ul> |               |  |
| 28-40-02                             | Fuel Quantity Indicating<br>Computer System  |    |   |   |  |               |  |
| 1)                                   | Channels   |    |   |   |  |               |  |
| a)                                   | A321 without<br>Mod 155635/<br>MP J3702 or<br>A319/A320 without<br>Mod 155636/<br>MP J3703 | A  | 2 | 1   | Except for ETOPS, one may be<br>inoperative provided:<br>a) Low level warning system<br>operates normally, and<br>b) Repairs are made within<br>2 flight-days.   |               |  |
|                                      |  |    |   |   | (Continued)  |               |  |

| -                                   | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|---|----|---|----------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |    |   |                | PAGE NO. 28-31  |
| AIRCRAFT:<br>Airbus A320            |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                            |   |    |   |                |   |
| Sequence No.                        | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 28-40-02                            | Fuel Quantity Indicating<br>Computer System<br>(Cont'd)   |    |   |                |   |
| 1)                                  | Channels<br>(Conťd)   |    |   |                |   |
| b)                                  | A319 with<br>Mod 28238/<br>MP J1993 and without<br>Mod 155636/<br>MP J3703 or<br>A321 with<br>Mod 155635/<br>MP J3702 and with<br>Mod.163213/<br>MP J4530 | A  | 2 | 1              | <ul> <li>Except for ETOPS operations, one may be inoperative provided: <ul> <li>a) Low level warning system operates normally,</li> <li>b) Repairs are made within 2 flight-days, and</li> <li>c) There is no fuel in any ACT.</li> </ul> </li> </ul>                                     |
| c)                                  | A321 with<br>Mod 155635/<br>MP J3702 and without<br>Mod 163213/<br>MP J4530 or<br>A319/A320 with<br>Mod 155636<br>/MP J3703                               | A  | 2 | 1              | <ul> <li>(M) Except for ETOPS operations,<br/>one may be inoperative provided: <ul> <li>a) Low level warning system<br/>operates normally,</li> <li>b) Repairs are made within<br/>2 flight-days, and</li> <li>c) Alternate procedures are<br/>developed and used.</li> </ul> </li> </ul> |
| d)                                  | A321neo XLR   | A  | 2 | 1              | <ul> <li>Except for ETOPS, one may be inoperative provided:</li> <li>a) Low level warning system operates normally,</li> <li>b) Repairs are made within 2 flight-days,</li> <li>c) RCT remains empty, and</li> <li>d) FWD ACT remains empty or is not installed.</li> </ul>               |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|---|---|----------------|--|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/  |  |   |   |                | PAGE NO. 28-32   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 28. Fuel   |  |   | • |                |  |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Chang<br>Bar   |  |  |  |  |
| 28-40-03   | TK PUMP and CTR TK<br>XFR FAULT Lights   |   |   |                |  |  |  |  |  |
| 1)   | TK PUMP FAULT Lights   | С | - | 0              | (O) May be inoperative provided<br>associated pump is switched off<br>when tank is empty.  |  |  |  |  |
| 2)   | CTR TK XFR FAULT<br>Lights<br>(A321 or A319/A320 with<br>Mod. 154327/MP J3527) | С | 2 | 0              | (O) May be inoperative provided<br>associated transfer valve is switched<br>off when tank is empty.  |  |  |  |  |
| 3)   | RCT XFR PUMP FAULT<br>Lights<br>(A321neo XLR)                                  | С | 2 | 0              | May be inoperative provided  <br>associated RCT transfer pump  <br>indications on ECAM Fuel page are  <br>operative.   |  |  |  |  |
| 28-40-04   | TK PUMP and CTR TK<br>XFR OFF Lights   |   |   |                |  |  |  |  |  |
| 1)   | TK PUMP OFF Lights   | С | - | 0              | May be inoperative provided corresponding pump indication is available on ECAM.  |  |  |  |  |
| 2)   | CTR TK XFR OFF Lights<br>(A321 or A319/A320 with<br>Mod. 154327/MP J3527)      | С | 2 | 0              | May be inoperative provided<br>corresponding transfer valve<br>indication is available on ECAM.  |  |  |  |  |
| 3)   | RCT XFR PUMP OFF<br>Lights<br>(A321neo XLR)                                    | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:         <ul> <li>a) Both RCT transfer pump<br/>indications on ECAM FUEL</li> <li>page are operative, and</li> <li>b) Status of RCT transfer pumps<br/>is confirmed using ECAM</li> <li>FUEL page indications.</li> </ul> </li> </ul> |  |  |  |  |

| -                           | MENT OF TRANSPORTATION                                |   |   | MASTER MINIMUM EQUIPMENT | T LIST  |           |
|-----------------------------|---|---|---|--------------------------|---|-----------|
| REVISION NC<br>DATE: XX/XX/ | -   |   |   | PAGE NO.                 | 28-33   |           |
| AIRCRAFT:<br>Airbus A320    |   |   | Т | 1.<br>2.<br>3.           | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                                       |           |
| 28. Fuel                    | Itom  | 1 | 2 | 3                        | 4   | Change    |
| Sequence No.<br>28-40-05    | Item<br>Fuel Transfer Control                         | 1 | 2 | 3                        |   | Bar       |
| 1)                          | CTR TK MODE SEL<br>FAULT Light                        |   |   |                          |   | I         |
| a)                          | A318 or A319/A320<br>without Mod. 154327/<br>MP J3527 | С | 1 | 0                        | (O) May be inoperative provided all<br>tank pump indications on ECAM<br>FUEL page are operative.                                      |           |
| b)                          | A321 or A319/A320 with<br>Mod. 154327/<br>MP J3527    | С | 1 | 0                        | May be inoperative provided all wing<br>tank pumps and center tank transfer<br>valves indications on ECAM FUEL<br>page are operative. |           |
| 2)                          | ACT pb Switch<br>Additional Center Tank               |   |   |                          |   |           |
| a)                          | FAULT Light   | С | 1 | 0                        | (O) May be inoperative provided ACT<br>and center tank fuel quantity<br>indications on ECAM FUEL page are<br>operative.               |           |
| b)                          | FWD Light   | С | 1 | 0                        | May be inoperative.   |           |
| 3)                          | RCT XFR MODE SEL<br>FAULT Light                       | С | 1 | 0                        | May be inoperative provided RCT to<br>Center Tank transfer indication on<br>ECAM FUEL page is operative.                              | <br> <br> |

| FEDERAL AVIATION ADMINISTRATION |   |   |          |                |  |
|---------------------------------|---|---|----------|----------------|--|
| REVISION NO<br>DATE: XX/XX/2    |   |   |          |                | PAGE NO. 28-34   |
| AIRCRAFT:<br>Airbus A320        |   |   | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                        |   |   | <u> </u> |                |  |
| Sequence No.                    | ltem  | 1 | 2        | 3              | 4 Change<br>Bar  |
| 28-40-06                        | ECAM FUEL PAGE<br>Indications   |   |          |                |  |
| 1)                              | A318/A319/A320  |   |          |                |  |
| a)                              | Tank Pumps  |   |          |                |  |
| i)                              | A318 or A319/A320<br>without<br>Mod. 154324/MP J3527  | С | -        | 0              | One or more may be inoperative.  |
| ii)                             | Wing Tank Pumps and<br>Center Tank Transfer<br>Valves<br>(A319/A320 with<br>Mod. 154324/MP J3527) | С | 6        | 0              | One or more may be inoperative.  |
| b)                              | APU LP Valve  | С | 1        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed, and</li> <li>b) APU is considered inoperative.</li> </ul>  |
| c)                              | Cross Feed  | С | 1        | 0              | (M) May be inoperative provided<br>operation of the cross feed valve is<br>verified before first flight of each day,<br>and for ETOPS, is verified before<br>each flight.  |
| d)                              | Transfer Valves   | С | 2        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated inner and outer<br/>cells fuel quantity indicators<br/>are operative, and</li> <li>b) Transfer valve operation is<br/>verified before each departure.</li> </ul> |
| e)                              | Fuel Temperature  | С | 4        | 2              | One in each wing or both in one wing may be inoperative.   |
|                                 |   |   |          |                | (Continued)  |

| -                               |   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|---------------------------------|---|----|---|----------------|---|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |                |   |  |  |  |  |
| REVISION NO<br>DATE: XX/XX/     |   |    |   |                | PAGE NO. 28-35  |  |  |  |  |
|                                 | ^^^^                                      |    |   |                | - //=>/   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 28. Fuel                        |   | -  |   |                |   |  |  |  |  |
| Sequence No.                    | Item                                      | 1  | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 28-40-06                        | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |    |   |                |   |  |  |  |  |
| 1)                              | A318/A319/A320<br>(Cont'd)                |    |   |                |   |  |  |  |  |
| f)                              | Fuel on Board                             | С  | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Associated indication is<br/>available on the MCDU, and</li> <li>b) Fuel Used indications operate<br/>normally.</li> </ul>  |  |  |  |  |
| g)                              | Fuel Quantity Indications<br>(All Tanks)  | D  | - | -              | (O) The last two digits may be<br>displayed dashed (degraded Mode)<br>provided the loss of accuracy is<br>accounted for in fuel planning.   |  |  |  |  |
|                                 |   |    |   |                | NOTE 1: Fuel quantity is considered operative.  |  |  |  |  |
|                                 |   |    |   |                | NOTE 2: Fuel on Board display will<br>also be in degraded<br>(dashed) Mode.   |  |  |  |  |
| h)                              | Fuel Quantity Outer<br>Tank               | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Fuel quantity in associated<br/>tank is verified after each<br/>refueling by manual magnetic<br/>indicators or by corresponding<br/>fuel quantity indicator on<br/>refuel/defuel panel,</li> <li>b) Associated fuel used indicator<br/>operates normally, and</li> <li>c) Associated inner tank<br/>indication is operative.</li> </ul> |  |  |  |  |
|                                 |   |    |   |                | (Continued)   |  |  |  |  |

|                                     | MENT OF TRANSPORTA                        |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|---|---|---|----------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |   |   |                | PAGE NO. 28-36  |
| AIRCRAFT:<br>Airbus A320            |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                            |   |   |   |                |   |
| Sequence No.                        | Item                                      | 1 | 2 | 3              | 4 Change<br>Bar   |
| 28-40-06                            | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |   |   |                |   |
| 1)                                  | A318/A319/A320<br>(Cont'd)                |   |   |                |   |
| h)                                  | Fuel Quantity Outer<br>Tank<br>(Cont'd)   |   |   |                |   |
|                                     |   | C | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) High level fuel detection<br/>system is verified operative<br/>before refueling the aircraft,</li> <li>b) Alternate procedure is used<br/>for refueling the aircraft,</li> <li>c) Associated fuel used indicator<br/>operates normally, and</li> <li>d) Associated inner tank<br/>indication is operative.</li> </ul> |
|                                     |   | В | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Fuel quantity in associated<br/>tank is verified after each<br/>refueling by manual magnetic<br/>indicators or by corresponding<br/>fuel quantity indicator on<br/>refuel/defuel panel, and</li> <li>b) Associated fuel used indicator<br/>operates normally.</li> </ul>  |
|                                     |   | В | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) High level fuel detection<br/>system is verified operative<br/>before refueling the aircraft,</li> <li>b) Alternate procedure is used<br/>for refueling the aircraft, and</li> <li>c) Associated fuel used indicator<br/>operates normally.</li> </ul>  |
|                                     |   |   |   |                | (Continued)   |

|  |   | 0.11 |   |     |  |  |  |  |
|--|---|------|---|-----|--|--|--|--|
| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |      |   |     | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
| REVISION NO.   | 32  |      |   |     | PAGE NO. 28-37   |  |  |  |
| DATE: XX/XX/X  | XXX                                       |      |   |     |  |  |  |  |
|  |   |      | Т | ABL | EKEY   |  |  |  |
| AIRCRAFT:  |   |      |   |     | REPAIR CATEGORY  |  |  |  |
| Airbus A320  |   |      |   |     |  |  |  |  |
|  |   |      |   |     | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 28. Fuel   |   |      |   |     |  |  |  |  |
| Sequence No.   | Item                                      | 1    | 2 | 3   | 4 Change<br>Bar  |  |  |  |
| 28-40-06   | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |      |   |     |  |  |  |  |
| 1)   | A318/A319/A320<br>(Cont'd)                |      |   |     |  |  |  |  |
| i)   | Fuel Quantity Inner Tank                  | С    | 2 | 1   | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Fuel quantity in associated<br/>tank is verified after each<br/>refueling by manual magnetic<br/>indicator or by corresponding<br/>fuel quantity indicator on<br/>refuel/defuel panel,</li> <li>b) Associated fuel used indicator<br/>operates normally, and</li> <li>c) Associated outer tank<br/>indication is operative.</li> </ul> |  |  |  |
|  |   | В    | 2 | 1   | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Fuel quantity in associated<br/>tank is verified after each<br/>refueling by manual magnetic<br/>indicator or by corresponding<br/>fuel quantity indicator on<br/>refuel/defuel panel, and</li> <li>b) Associated fuel used indicator<br/>operates normally.</li> </ul>  |  |  |  |
|  |   |      |   |     | (Continued)  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX   |   |   |   | PAGE NO. 28-38 |   |
| AIRCRAFT:<br>Airbus A320   |   |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel   |   | - |   |                | Change  |
| Sequence No.<br>28-40-06   | Item<br>ECAM FUEL PAGE<br>Indications<br>(Cont'd) | 1 | 2 | 3              | 4 Change<br>Bar   |
| 1)   | A318/A319/A320<br>(Cont'd)                        |   |   |                |   |
| j)   | Fuel Quantity Center<br>Tank                      |   |   |                |   |
| i)   | A318/A319/A320 without<br>ACT                     | С | 1 | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Fuel quantity in associated tank is verified after each refueling,</li> <li>b) All wing tank quantity indicators operate normally, and</li> <li>c) Both fuel used indicators operate normally.</li> </ul> |
|  |   | С | 1 | 0              | May be inoperative provided the tank remains empty.   |
|  |   | С | 1 | 0              | May be inoperative provided fuel is<br>considered unusable and is included<br>in computing ZFW and CG<br>calculations.  |
|  |   |   |   |                | (Continued)   |

| U.S. DEPARTI                  | IENT OF TRANSPORTATI                      | ON |   |                |   |
|-------------------------------|---|----|---|----------------|---|
| FEDERAL AVI                   | ATION ADMINISTRATION                      |    |   |                | MASTER MINIMUM EQUIPMENT LIST   |
| REVISION NO.<br>DATE: XX/XX/> |   |    |   | PAGE NO. 28-39 |   |
| AIRCRAFT:<br>Airbus A320      | AIRCRAFT:                                 |    |   |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                      |   |    |   |                |   |
| Sequence No.                  | Item                                      | 1  | 2 | 3              | 4 Change<br>Bar   |
| 28-40-06                      | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |    |   |                |   |
| 1)                            | A318/A319/A320<br>(Cont'd)                |    |   |                |   |
| j)                            | Fuel Quantity Center<br>Tank<br>(Cont'd)  |    |   |                |   |
| ii)                           | A319/A320 with ACT(s)                     | C  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel quantity in center tank is verified after each refueling,</li> <li>b) All wing tank and ACT quantity indicators are operative,</li> <li>c) Both fuel used indicators operate normally, and</li> <li>d) Forward transfer from ACT(s) to center tank is monitored during flight.</li> </ul> |
|                               |   | С  | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Center tank remains empty or<br/>fuel is considered unusable and<br/>is included in ZFW and CG<br/>calculations, and</li> <li>b) There is no fuel in ACT.</li> </ul>  |
|                               |   | С  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Center tank remains empty or<br/>fuel is considered unusable and<br/>is included in ZFW and CG<br/>calculations, and</li> <li>b) Fuel in any ACT is considered<br/>unusable and included in ZFW<br/>and CG calculations and the<br/>ACT transfer valve is secured<br/>closed.</li> </ul>       |
|                               |   |    |   |                | NOTE: This failure will result in the<br>inhibition or erroneous<br>triggering of ECAM caution<br>FUEL ACT XFR FAULT while<br>automatic transfer is still<br>operative.   |
|                               |   |    |   | l              | (Continued)   |

| -                           | MENT OF TRANSPORTATIO  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|-----------------------------|--|---|---|-------------------------------|--|
|                             | ATION ADMINISTRATION   |   |   |                               |  |
| REVISION NO<br>DATE: XX/XX/ | -  |   |   | PAGE NO. 28-40                |  |
| AIRCRAFT:<br>Airbus A320    |  |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                    |  |   |   |                               |  |
| Sequence No.                | ltem   | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 28-40-06                    | ECAM FUEL PAGE<br>Indications<br>(Cont'd)  |   |   |                               |  |
| 1)                          | A318/A319/A320<br>(Cont'd)   |   |   |                               |  |
| k)                          | Fuel Quantity Additional<br>Center Tank(s)<br>(A319/A320 with ACT(s))                                  | С | - | -                             | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) All wing tanks, center tank, and other ACT fuel quantity indicators are operative,</li> <li>b) Both fuel used indicators operate normally,</li> <li>c) Forward transfer from ACT(s) to center tank is monitored during flight, and</li> <li>d) Tank is serviced with a known quantity.</li> </ul> |
|                             |  | С | - | 0                             | <ul> <li>(M) May be inoperative provided</li> <li>ACT(s) is verified empty after each refueling.</li> <li>NOTE: This failure will result in inhibition or erroneous display of the ECAM caution FUEL ACT XFR FAULT.</li> </ul>   |
| I)                          | ACT to CTR Tank<br>Transfer Indication<br>(Arrow) Additional<br>Center Tank<br>(A319/A320 with ACT(s)) | С | 1 | 0                             | May be inoperative provided ACT(s)<br>and center tank fuel quantity<br>indications on ECAM FUEL page are<br>operative.   |
| m)                          | Engine LP Valve<br>Indication  | С | 2 | 0                             | (M) May be inoperative provided<br>associated LP valve(s) is checked<br>operative before each flight.  |
| n)<br>***                   | FUEL FLOW 1+2<br>(With MP P7092)   | С | 1 | 0                             | May be inoperative.  |
|                             |  |   |   |                               | (Continued)  |

| -                           | MENT OF TRANSPORTATION                                |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|-----------------------------|---|---|---|-------------------------------|--|
|                             |   |   |   |                               | PAGE NO. 28-41   |
| REVISION NC<br>DATE: XX/XX/ |   |   |   | PAGE NO. 28-41                |  |
| AIRCRAFT:<br>Airbus A320    |   |   |   | 1.<br>2.<br>3.                | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                    |   |   |   |                               |  |
| Sequence No.                | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 28-40-06                    | ECAM FUEL PAGE<br>Indications<br>(Cont'd)             |   |   |                               |  |
| 1)                          | A318/A319/A320<br>(Conťd)                             |   |   |                               |  |
| o)                          | FUEL USED   | С | 2 | 0                             | May be inoperative provided<br>associated fuel used indication on<br>ENG SD page is considered<br>inoperative.   |
| p)<br>***                   | FUEL USED 1+2<br>(With Mod 30368/<br>MP P6578)        | С | 1 | 0                             | May be inoperative.  |
| 2)                          | A321<br>(except A321neo XLR)                          |   |   |                               |  |
| a)                          | Wing Tank Pumps and<br>Center Tank Transfer<br>Valves | С | 6 | 0                             | One or more may be inoperative.  |
| b)                          | APU LP Valve  | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed, and</li> <li>b) APU is considered<br/>inoperative.</li> </ul>                              |
| c)                          | Cross Feed  | С | 1 | 0                             | (M) May be inoperative provided<br>operation of the cross feed valve is<br>verified before first flight of each day,<br>and for ETOPS, is verified before<br>each flight.    |
| d)                          | Fuel Temperature                                      | С | 2 | 1                             | One may be inoperative.  |
| e)                          | Fuel on Board   | С | 1 | 0                             | <ul> <li>May be inoperative provided:</li> <li>a) Associated indication is<br/>available on the MCDU, and</li> <li>b) Fuel Used indications operate<br/>normally.</li> </ul> |
|                             |   |   |   |                               | (Continued)  |

| -            |   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------|---|----|---|----------------|---|
| FEDERAL AVI  | ATION ADMINISTRATION                      |    |   |                | PAGE NO. 28-42  |
| DATE: XX/XX/ | -   |    |   | PAGE NO. 28-42 |   |
|              |   |    |   |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel     |   |    |   |                |   |
| Sequence No. | Item                                      | 1  | 2 | 3              | 4 Change<br>Bar   |
| 28-40-06     | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |    |   |                |   |
| 2)           | A321<br>(except A321neo XLR)<br>(Cont'd)  |    |   |                |   |
| f)           | Fuel Quantity Wing Tank                   | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Fuel quantity in associated<br/>tank is verified after each<br/>refueling, and</li> <li>b) Associated fuel used indicator<br/>operates normally.</li> </ul>   |
| g)           | Fuel Quantity Indications (All Tanks)     | D  | - | -              | (O) The last two digits may be<br>displayed dashed (degraded Mode)<br>provided the loss of accuracy is<br>accounted for in fuel planning.   |
|              |   |    |   |                | NOTE 1: Fuel quantity is considered<br>operative.   |
|              |   |    |   |                | NOTE 2: Fuel on Board display will<br>also be in degraded<br>(dashed) Mode.   |
| h)           | Fuel Quantity Center<br>Tank              |    |   |                |   |
| i)           | A321 without ACT                          | С  | 1 | 0              | <ul> <li>(M) May be inoperative provided: <ul> <li>a) Fuel quantity in associated tank is verified after each refueling,</li> <li>b) All wing tank quantity indicators operate normally, and</li> <li>c) Both fuel used indicators operate normally.</li> </ul> </li> </ul> |
|              |   | С  | 1 | 0              | May be inoperative provided the tank remains empty.   |
|              |   | С  | 1 | 0              | May be inoperative provided fuel is<br>considered unusable and is included<br>in computing ZFW and CG<br>calculations.  |
|              |   |    |   |                | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/2   |   |   |   |                | PAGE NO. 28-43  |
| AIRCRAFT:<br>Airbus A320<br><b>28. Fuel</b>                          |   |   | T | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.   | Item                                      | 1 | 2 | 3              | 4 Change<br>Bar   |
| 28-40-06   | ECAM FUEL PAGE<br>Indications<br>(Cont'd) |   |   |                | Bal   |
| 2)   | A321<br>(except A321neo XLR)<br>(Cont'd)  |   |   |                |   |
| h)   | Fuel Quantity Center<br>Tank<br>(Cont'd)  |   |   |                |   |
| ii)  | A321 with ACT(s)                          | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel quantity in center tank is verified after each refueling,</li> <li>b) All wing tank and ACT quantity indicators are operative,</li> <li>c) Both fuel used indicators operate normally, and</li> <li>d) Forward transfer from ACT(s) to center tank is monitored during flight.</li> </ul> |
|  |   | С | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Center tank remains empty or fuel is considered unusable and is included in ZFW and CG calculations, and</li> <li>b) There is no fuel in any ACT.</li> </ul>  |
|  |   |   |   |                | (Continued)   |

| -                             | IENT OF TRANSPORTATI                                  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------|---|----|---|----------------|---|
|                               | TION ADMINISTRATION                                   |    |   |                | · · · · · · · · · · · · · · · · · · ·   |
| REVISION NO.<br>DATE: XX/XX/X |   |    |   |                | PAGE NO. 28-44  |
| AIRCRAFT:<br>Airbus A320      |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                      |   |    |   |                |   |
| Sequence No.                  | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 28-40-06                      | ECAM FUEL PAGE<br>Indications<br>(Cont'd)             |    |   |                |   |
| 2)                            | A321<br>(except A321neo XLR)<br>(Cont'd)              |    |   |                |   |
| h)                            | Fuel Quantity Center<br>Tank<br>(Cont'd)              |    |   |                |   |
| ii)                           | A321 with ACT(s)<br>(Cont'd)                          | С  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Center tank remains empty or fuel is considered unusable and is included in ZFW and CG calculations,</li> <li>b) Fuel in any ACT is considered unusable and included in ZFW and CG calculations, and</li> <li>c) The ACT transfer valve is secured closed.</li> </ul> </li> <li>NOTE: This failure will result in inhibition or erroneous triggering of the ECAM caution FUEL ACT XFR</li> </ul> |
|                               |   |    |   |                | FAULT while automatic transfer is still operative.  |
| iii)                          | A321 with ACT(s) and<br>with Mod. 163213/<br>MP J4530 | C  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Fuel quantity in center tank is verified after each refueling,</li> <li>b) All wing tank and ACT quantity indicators are operative, and</li> <li>c) Both fuel used indicators operate normally.</li> </ul>   |
|                               |   | С  | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Center tank remains empty or<br/>fuel is considered unusable<br/>and is included in ZFW and<br/>CG calculations, and</li> <li>b) There is no fuel in any ACT.</li> </ul>  |

| U.S. DEPARTN                 | MENT OF TRANSPORTATI   | ON |   |                |  |
|------------------------------|--|----|---|----------------|--|
| FEDERAL AVI                  | ATION ADMINISTRATION   |    |   |                | MASTER MINIMUM EQUIPMENT LIST  |
| REVISION NO<br>DATE: XX/XX/2 |  |    |   |                | PAGE NO. 28-45   |
| AIRCRAFT:<br>Airbus A320     |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                     |  |    |   |                |  |
| Sequence No.                 | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 28-40-06                     | ECAM FUEL PAGE<br>Indications<br>(Cont'd)                                |    |   |                |  |
| 2)                           | A321<br>(except A321neo XLR)<br>(Cont'd)                                 |    |   |                |  |
| i)                           | Fuel Quantity Additional<br>Center Tank(s)                               |    |   |                |  |
| i)                           | A321 With ACT(s)   | С  | - | -              | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) All wing tanks, center tank, and other ACT fuel quantity indicators are operative,</li> <li>b) Both fuel used indicators operate normally,</li> <li>c) Forward transfer from ACT(s) to center tank is monitored during flight, and</li> <li>d) Tank is serviced with a known quantity.</li> </ul> |
|                              |  | С  | - | 0              | <ul> <li>(M) May be inoperative provided<br/>ACT(s) is verified empty after each<br/>refueling.</li> <li>NOTE: This failure will result in<br/>inhibition or erroneous display<br/>of the ECAM caution FUEL<br/>ACT XFR FAULT.</li> </ul>  |
| ii)                          | A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335 | С  | - | -              | <ul> <li>(O) One may be inoperative provided:</li> <li>a) All wing tanks, center tank,<br/>and other ACT fuel quantity<br/>indicators are operative,</li> <li>b) Both fuel used indicators<br/>operate normally, and</li> <li>c) The affected ACT(s) and<br/>previous ACT(s) in fuel feed<br/>sequence FWD – AFT 2 –<br/>AFT 1 are empty.</li> </ul>           |
|                              |  |    |   |                | (Continued)  |

|                                 | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|---------------------------------|---|----|---|----------------|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |                |  |
| REVISION NO<br>DATE: XX/XX/     |   |    |   |                | PAGE NO. 28-46   |
|                                 | ^^^^  |    |   |                | EKEY   |
| AIRCRAFT:<br>Airbus A320        |   |    |   | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                        |   |    |   |                |  |
| Sequence No.                    | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 28-40-06                        | ECAM FUEL PAGE<br>Indications<br>(Cont'd)                                   |    |   |                |  |
| 2)                              | A321<br>(except A321neo XLR)<br>(Cont'd)                                    |    |   |                |  |
| i)                              | Fuel Quantity Additional<br>Center Tank(s)<br>(Cont'd)                      |    |   |                |  |
| iii)                            | A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/<br>MP J4335   | C  | - | -              | <ul> <li>(O) One may be inoperative provided:</li> <li>a) All wing tanks, center tank,<br/>and other ACT fuel quantity<br/>indicators are operative,</li> <li>b) Both fuel used indicators<br/>operate normally, and</li> <li>c) The affected ACT(s) and<br/>previous ACT(s) in fuel feed<br/>sequence AFT 2 – FWD –<br/>AFT 1 are empty.</li> </ul> |
| j)                              | ACT to CTR Tank<br>Transfer Indication<br>(Arrow) Additional<br>Center Tank |    |   |                |  |
| i)                              | A321 with ACT(s)  | С  | 1 | 0              | May be inoperative provided ACT(s)<br>and center tank fuel quantity<br>indications on ECAM FUEL page are<br>operative.   |
| k)                              | Engine LP Valve<br>Indication   | С  | 2 | 0              | (M) May be inoperative provided<br>associated LP valve(s) is checked<br>operative before each flight.  |
| l)<br>***                       | FUEL USED 1+2 with<br>Mod 30368/MP P6578                                    | С  | 1 | 0              | May be inoperative.  |
|                                 |   |    |   |                | (Continued)  |

| U.S. DEPART                 | MENT OF TRANSPORTAT                                   | ION |    |   |  |  |  |
|-----------------------------|---|-----|----|---|--|--|--|
| FEDERAL AV                  | IATION ADMINISTRATION                                 | -   |    | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
| REVISION NC<br>DATE: XX/XX/ |   |     |    | PAGE NO. 28-47  |  |  |  |
| AIRCRAFT:<br>Airbus A320    |   |     | T. | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |
| 28. Fuel                    |   |     |    |   |  |  |  |
| Sequence No.                | Item  | 1   | 2  | 3   | 4 Change<br>Bar  |  |  |
| 28-40-06                    | ECAM FUEL PAGE<br>Indications<br>(Cont'd)             |     |    |   |  |  |  |
| 2)                          | A321<br>(except A321neo XLR)<br>(Cont'd)              |     |    |   |  |  |  |
| m)                          | FUEL USED   | С   | 2  | 0   | May be inoperative provided<br>associated fuel used indication on<br>ENG SD page is considered<br>inoperative.   |  |  |
| n)<br>***                   | FUEL FLOW 1+2 with<br>MP P7092                        | С   | 1  | 0   | May be inoperative.  |  |  |
| 3)                          | A321neo XLR   |     |    |   |  |  |  |
| a)                          | Wing Tank Pumps and<br>Center Tank Transfer<br>Valves | С   | 6  | 0   | One or more may be inoperative.  |  |  |
| b)                          | APU LP Valve  | С   | 1  | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Valve is secured closed, and</li> <li>b) APU is considered<br/>inoperative.</li> </ul>                              |  |  |
| c)                          | Cross Feed  | С   | 1  | 0   | (M) May be inoperative provided<br>operation of the cross feed valve is<br>verified before first flight of each day,<br>and for ETOPS, is verified before<br>each flight.    |  |  |
| d)                          | Fuel Temperature                                      | с   | 2  | 1   | One may be inoperative.  |  |  |
| e)                          | Fuel on Board   | С   | 1  | 0   | <ul> <li>May be inoperative provided:</li> <li>a) Associated indication is<br/>available on the MCDU, and</li> <li>b) Fuel Used indications operate<br/>normally.</li> </ul> |  |  |
|                             |   |     |    |   | (Continued)  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMEN   | T LIST        |  |  |  |
|--|--|---|---|----------------|---|---------------|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |                | PAGE NO. 28-48  |               |  |  |  |
|  |  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |  |
| 28. Fuel   |  |   |   |                |   |               |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4   | Change<br>Bar |  |  |  |
| 28-40-06   | ECAM FUEL PAGE<br>Indications<br>(Cont'd)    |   |   |                |   |               |  |  |  |
| 3)   | A321neo XLR<br>(Cont'd)                      |   |   |                |   |               |  |  |  |
| f)   | Fuel Quantity Indications<br>(All Tanks)     | D | - | -              | (O) The last two digits may be<br>displayed dashed (degraded Mode)<br>provided the loss of accuracy is<br>accounted for in fuel planning. | Ι             |  |  |  |
|  |  |   |   |                | NOTE 1: Fuel Quantity Indications<br>are considered operative.  |               |  |  |  |
|  |  |   |   |                | NOTE 2: Fuel on Board display will<br>also be in degraded<br>(dashed) Mode.   |               |  |  |  |
| g)   | Engine LP Valve<br>Indication                | С | 2 | 0              | (M) One or both may be inoperative<br>provided associated LP valve(s) is<br>checked operative before each flight.                         | Ι             |  |  |  |
| h)<br>***  | FUEL USED 1+2 with<br>Mod 30368/<br>MP P6578 | С | 1 | 0              | May be inoperative.   | Ι             |  |  |  |
| i)   | FUEL USED                                    | С | 2 | 0              | One or both may be inoperative<br>provided associated fuel used<br>indication on ENG SD page is<br>considered inoperative.                | Ι             |  |  |  |
| j)<br>***  | FUEL FLOW 1+2 with<br>MP P7092               | С | 1 | 0              | May be inoperative.   | Ι             |  |  |  |
| 28-40-07   | Manual Magnetic<br>Indicators                | С | - | 0              | One or more may be inoperative provided fuel quantity is determined by acceptable means.  |               |  |  |  |
| 28-40-08<br>***  | Fuel Quantity Attitude<br>Monitor            | D | 1 | 0              | May be inoperative provided fueling<br>and defueling procedures do not<br>require its use.  |               |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|---|---|---|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |   | PAGE NO. 28-49   |
| AIRCRAFT:<br>Airbus A320   |  |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel   | 14   |   |   |   | A Change   |
| Sequence No.<br>28-40-09   | Item<br>Cautions on ECAM                               | 1 | 2 | 3 | 4 Change<br>Bar  |
| 1)   | TK HI TEMP<br>(Left, Right, Inner, Outer<br>Wing Tank) |   |   |   |  |
| a)   | A318/319/A320  | С | 4 | 2 | (O) One in each wing or both in one<br>wing may be inoperative provided<br>fuel temperature indications on the<br>ECAM FUEL system page are<br>available for the non-affected tank(s)<br>and fuel temperature is monitored<br>prior to takeoff and during the flight.                              |
|  |  |   |   |   | NOTE: For fuel temperature<br>limitations, refer to AFM.   |
|  |  | С | 4 | 0 | (O) May be inoperative provided fuel<br>temperature indications on the ECAM<br>FUEL system page are available and<br>fuel temperature is monitored prior to<br>takeoff and during flight.  |
|  |  |   |   |   | NOTE: For fuel temperature<br>limitations, refer to AFM.   |
| 2)   | TK HI TEMP<br>(Left, Right Wing Tank)                  |   |   |   |  |
| a)   | A321   | С | 2 | 1 | <ul> <li>(O) One may be inoperative provided fuel temperature indications on the ECAM FUEL system page are available for the non-affected tank and fuel temperature is monitored prior to takeoff and during the flight.</li> <li>NOTE: For fuel temperature limitations, refer to AFM.</li> </ul> |
|  |  |   |   |   | (Continued)  |

| U.S. DEPARTN                        | MENT OF TRANSPORTATIO                                    | ON |   |                |   |
|-------------------------------------|--|----|---|----------------|---|
| FEDERAL AVI                         | ATION ADMINISTRATION                                     |    |   |                | MASTER MINIMUM EQUIPMENT LIST   |
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |    |   |                | PAGE NO. 28-50  |
| AIRCRAFT:<br>Airbus A320            |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 28. Fuel                            |  |    |   |                |   |
| Sequence No.                        | ltem   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 28-40-09                            | Cautions on ECAM<br>(Cont'd)                             |    |   |                |   |
| 2)                                  | TK HI TEMP<br>(Left, Right Wing Tank)                    |    |   |                |   |
| a)                                  | A321<br>(Cont'd)   |    |   |                |   |
|                                     |  | С  | 2 | 0              | (O) May be inoperative provided fuel<br>temperature indications on the ECAM<br>FUEL system page are available and<br>fuel temperature is monitored prior to<br>takeoff and during flight.   |
|                                     |  |    |   |                | NOTE: For fuel temperature<br>limitations, refer to AFM.  |
| 3)                                  | TK LO TEMP<br>(Left, Right, Inner, Outer)<br>(Wing Tank) |    |   |                |   |
| a)                                  | A318/A319/A320   | С  | 4 | 2              | (O) One in each wing or both in one<br>wing may be inoperative provided<br>fuel temperature indications on the<br>ECAM FUEL system page are<br>available for the non-affected tanks<br>and fuel temperature is monitored<br>prior to takeoff and during the flight. |
|                                     |  |    |   |                | NOTE: For fuel temperature indications, refer to AFM.   |
|                                     |  | С  | 4 | 0              | (O) May be inoperative provided fuel<br>temperature indications on the ECAM<br>FUEL system page are available and<br>fuel temperature is monitored prior to<br>takeoff and during flight.   |
|                                     |  |    |   |                | NOTE: For fuel temperature indications, refer to AFM.   |
|                                     |  |    |   |                | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|---|---|---|----------------|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |                | PAGE NO. 28-51   |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 28. Fuel   |   |   |   |                |  |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |
| 28-40-09   | Cautions on ECAM<br>(Cont'd)                          |   |   |                |  |  |  |  |
| 4)   | TK LO TEMP<br>(Left, Right, Wing Tank)                |   |   |                |  |  |  |  |
| a)   | A321  | С | 2 | 1              | (O) One may be inoperative provided<br>fuel temperature indications on the<br>ECAM FUEL system page are<br>available for the non-affected tank<br>and fuel temperature is monitored<br>prior to takeoff and during the flight. |  |  |  |
|  |   |   |   |                | NOTE: For fuel temperature<br>indications, refer to AFM.   |  |  |  |
|  |   | С | 2 | 0              | (O) May be inoperative provided fuel<br>temperature indications on the ECAM<br>FUEL system page are available and<br>fuel temperature is monitored prior to<br>takeoff and during the flight.                                  |  |  |  |
|  |   |   |   |                | NOTE: For fuel temperature<br>indications, refer to AFM.   |  |  |  |
| 5)   | ACT XFR FAULT<br>Additional Center<br>Tank(s)         |   |   |                |  |  |  |  |
| a)   | A319/A320/A321 with<br>ACT(s)<br>(except A321neo XLR) | С | 1 | 0              | (O) May be inoperative provided<br>transfer from ACT(s) to center tank is<br>monitored during flight if ACT(s) is<br>fueled.   |  |  |  |
|  |   |   |   |                | (Continued)  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   | MASTER MINIMUM EQUIPMENT LIST |   |           |  |  |
|--|---|---|---|-------------------------------|---|-----------|--|--|
| REVISION NO<br>DATE: XX/XX/2   |   |   |   |                               | PAGE NO. 28-  | 52        |  |  |
| AIRCRAFT:<br>Airbus A320<br>28. Fuel                                 |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |           |  |  |
| Sequence No.   | Item  | 1 | 2 | 3                             | 4 Char<br>Ba  |           |  |  |
| 28-40-09   | Cautions on ECAM<br>(Cont'd)                            |   |   |                               | ва  | <u>ir</u> |  |  |
| 6)   | ACT PUMP LO PR<br>(A319/A320/A321 with<br>ACT(s))       |   |   |                               |   |           |  |  |
| a)   | A319/A320/A321 with<br>ACT(s)<br>(except A321neo XLR)   | С | 1 | 0                             | May be inoperative.   |           |  |  |
| 7)   | FWD ACT ISOLATED<br>(A321 with Mod 163213/<br>MP J4530) | С | 1 | 0                             | May be inoperative provided there is<br>no fuel in any ACT and in the center<br>tank.   |           |  |  |
| 8)   | ACT SYSTEM FAULT<br>(A321 with Mod 163213/<br>MP J4530) | С | 1 | 0                             | May be inoperative provided there is no fuel in any ACT.  |           |  |  |
| 9)   | RCT AUTO XFR FAULT                                      | С | 1 | 0                             | May be inoperative provided there is  <br>no fuel in RCT.   |           |  |  |
|  |   | С | 1 | 0                             | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Manual transfer from RCT to</li> <li>center tank is checked</li> <li>operative before each flight,</li> <li>b) RCT manual transfer is</li> <li>performed during flight, and</li> <li>c) Fuel quantity indications of</li> <li>RCT and center tank are</li> <li>operative on the ECAM FUEL</li> <li>page.</li> </ul> </li> </ul> |           |  |  |

| -                        | MENT OF TRANSPORTATIO   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|--------------------------|---|---|---|-------------------------------|--|
| <b>REVISION NO</b>       | D. 32   |   |   |                               | PAGE NO. 28-53   |
| DATE: XX/XX              | /XXXX   |   |   |                               |  |
| AIRCRAFT:<br>Airbus A320 |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 28. Fuel                 |   |   |   |                               |  |
| Sequence No.             | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 28-40-10                 | Indication on ECAM<br>EWD   |   |   |                               |  |
| 1)                       | Fuel on Board (FOB)   | С | 1 | 0                             | <ul> <li>May be inoperative provided:</li> <li>a) Associated indication is<br/>available on the MCDU, and</li> <li>b) Fuel Used indications operate<br/>normally.</li> </ul> |
| 28-40-11                 | Auxiliary Fuel<br>Management Computer<br>System Channels<br>(A321 with<br>Mod. 163213/MP J4530) | A | 2 | 1                             | Except for ETOPS, one may be<br>inoperative provided:<br>a) Repairs are made within<br>2 flight-days, and<br>b) There is no fuel in any ACT.                                 |

|                          | ATION ADMINISTRATION   |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|---|----|----------------|---|
| REVISION NO              |  |   |    |                | PAGE NO. 29-1   |
| DATE: 03/03/2            | 023  |   |    |                |   |
| AIRCRAFT:<br>Airbus A320 |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 29. Hydraulic F          | Power  |   |    |                |   |
| Sequence No.             | Item   | 1 | 2  | 3              | 4 Change<br>Bar   |
| 29-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |   |    |                |   |
| 1)                       | Pre Mod. 23119 Fault(s)<br>Indicated by BLUE<br>RSVR   | - | -  | -              | Dispatch not permitted with this<br>MAINT. STATUS message displayed<br>on ECAM.   |
| 29-10-01                 | Engine Driven Pump<br>Depressurization<br>Function   |   |    |                |   |
| 1)                       | A318, A319ceo,<br>A320ceo, A321ceo   | С | 2  | 1              | One may be inoperative.   |
| 2)                       | A319neo, A320neo,<br>A321neo   | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Remaining EDP<br/>depressurization function is<br/>checked operative,</li> <li>b) APU is operative, and</li> <li>c) Start valve of associated side<br/>is operative.</li> </ul> |
| 29-10-02                 | Blue System Electric<br>Pump   |   |    |                |   |
| 1)                       | Automatic Control  | С | 1  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Pump can be manually<br/>operated, and</li> <li>b) Indications of blue hydraulic<br/>system are verified normal.</li> </ul>   |

| US DEPART                       |   | ON |   |   |  |  |  |  |  |
|---------------------------------|---|----|---|---|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
| REVISION NO                     |   |    |   |   | PAGE NO. 29-2  |  |  |  |  |
| DATE: 03/03/2                   | 2023  |    |   |   |  |  |  |  |  |
|                                 |   |    | Т |   |  |  |  |  |  |
| AIRCRAFT:                       |   |    |   |   |  |  |  |  |  |
| Airbus A320                     |   |    |   |   | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |  |
|                                 |   |    |   |   | REMARKS OR EXCEPTIONS  |  |  |  |  |
| 29. Hydraulic                   | Power   |    |   |   |  |  |  |  |  |
| Sequence No.                    | Item  | 1  | 2 | 3 | 4 Change<br>Bar  |  |  |  |  |
| 29-10-03                        | Hydraulic System<br>Accumulators  |    |   |   |  |  |  |  |  |
| 1)                              | Pre Mod. 21414  | С  | 3 | 1 | <ul> <li>(M) One or two may be inoperative provided:</li> <li>a) Blue hydraulic generation accumulator is operative, and</li> <li>b) The affected accumulator is deactivated.</li> </ul> |  |  |  |  |
| 2)                              | Post Mod. 21414   | С  | 3 | 0 | (M) May be inoperative provided the affected accumulator is deactivated.   |  |  |  |  |
| 29-10-07                        | Filters   |    |   |   |  |  |  |  |  |
| 1)                              | System Filters  | С  | 8 | 7 | One LP or one reservoir filling filter may be inoperative.   |  |  |  |  |
| 2)                              | Case Drain Filters  | С  | 3 | 2 | (M) One may be inoperative provided it is removed.   |  |  |  |  |
| 29-10-10                        | Hydraulic Reservoir<br>Drain Valve  | С  | 3 | 0 | (M) May be inoperative provided associated reservoir drain circuit is secured with a cap.  |  |  |  |  |
| 29-20-01                        | Hydraulic Reservoir<br>Quantity Indicator<br>(Green Servicing Panel)      | С  | 1 | 0 | (M) May be inoperative provided<br>hydraulic fluid quantity is monitored<br>during servicing of the hydraulic<br>reservoir using the visual quantity<br>gauge.                           |  |  |  |  |
| 29-20-02                        | Hydraulic Reservoir Four<br>Way Selector Valve on<br>Ground Service Panel | С  | 1 | 0 | (M) May be inoperative provided<br>associated system is serviced using<br>the HP ground connection.  |  |  |  |  |

| -                        | MENT OF TRANSPORTATI             | ION |          |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|----------------------------------|-----|----------|----------------|--|
| REVISION NC              |                                  |     |          |                | PAGE NO. 29-3  |
| DATE: 03/03/2            |                                  |     |          |                |  |
| AIRCRAFT:<br>Airbus A320 |                                  |     | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 29. Hydraulic            | Power                            |     | <u>I</u> |                |  |
| Sequence No.             | ltem                             | 1   | 2        | 3              | 4 Change<br>Bar  |
| 29-23-01                 | Power Transfer Unit              |     |          |                |  |
| 1)                       | Automatic Activation<br>Function | В   | 1        | 0              | <ul> <li>(O) May be inoperative (PTU runs continuously) provided: <ul> <li>a) System pressure indication on ECAM operates normally,</li> <li>b) Power transfer can be stopped when PTU pb-sw is placed OFF, and</li> <li>c) Operation of the PTU in both directions is verified before first flight of each day.</li> </ul> </li> </ul>                        |
| 29-25-01                 | Yellow System Electric<br>Pump   | С   | 1        | 0              | <ul> <li>(M) May be inoperative provided<br/>associated pb-sw is selected off.</li> <li>NOTE: The AFT and FWD cargo<br/>doors must be operated<br/>manually.</li> </ul>  |
| 29-30-01                 | Pump pb Switch                   |     |          |                |  |
| 1)                       | FAULT Lights                     | С   | 4        | 0              | May be inoperative provided the<br>associated reservoir quantity<br>indication operates normally.<br>NOTE: Illumination of two lights (one<br>from the Blue ELEC PUMP pb<br>and one from ENG 1(2) PUMP<br>pb), with engines off, may be<br>due to a failed engine oil low<br>pressure switch. In this case,<br>the ENG OIL LO PRESS<br>warning is inoperative. |
| 2)                       | OFF Light                        | С   | 3        | 0              | One or more may be inoperative.  |
| 3)                       | ON Light                         | С   | 1        | 0              | May be inoperative.  |

|                             | IMENT OF TRANSPORTA          |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|------------------------------|---|---|----------------|--|
| REVISION NO<br>DATE: 03/03/ |                              |   |   |                | PAGE NO. 29-4  |
| AIRCRAFT:<br>Airbus A320    |                              |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 29. Hydraulic               | Power                        |   | • | 1              |  |
| Sequence No.                | Item                         | 1 | 2 | 3              | 4 Change<br>Bar  |
| 29-30-02<br>1)              | PTU pb Switch<br>FAULT Light | С | 1 | 0              | May be inoperative provided yellow<br>and green reservoir quantity<br>indicators operate normally.   |
| 2)                          | OFF Light                    | С | 1 | 0              | May be inoperative.  |
| 29-30-03                    | ECAM HYD Page<br>Indications |   |   |                |  |
| 1)                          | Reservoir Quantity           | С | 3 | 2              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) The associated reservoir quantity is verified adequate before each departure, and</li> <li>b) Associated RSVR LO LVL caution on ECAM operates normally.</li> </ul>       |
| 2)                          | Fire Valve                   | С | 2 | 0              | One or both may be inoperative.  |
| 3)                          | Yellow Elec Pump             | С | 1 | 0              | May be inoperative.  |
| 4)                          | PTU                          | С | 1 | 0              | May be inoperative.  |
| 5)                          | System Label                 | C | 3 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Associated system pressure<br/>is verified before each<br/>departure, and</li> <li>b) Associated spoilers<br/>availability is verified before<br/>each departure.</li> </ul> |
|                             |                              |   |   |                | (Continued)  |

| _                               | MENT OF TRANSPORTATION   |   |    | MASTER MINIMUM EQUIPMENT LIST |   |
|---------------------------------|--|---|----|-------------------------------|---|
| <b>REVISION NO</b>              | . 30   |   |    |                               | PAGE NO. 29-5   |
| DATE: 03/03/2                   | 023  |   |    |                               |   |
| AIRCRAFT:<br>Airbus A320        |  |   | Т  | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 20. Hydraulia I                 | Dowor  |   |    | т.                            |   |
| 29. Hydraulic I<br>Sequence No. | Item   | 1 | 2  | 3                             | 4 Change  |
| 29-30-03                        | ECAM HYD Page<br>Indications<br>(Cont'd)   |   |    | 3                             | 4 Bar   |
| 6)                              | System Pressure  |   |    |                               |   |
| a)                              | Aircraft without<br>Mod. 31056/MP P7004<br>(DMC V50), or with<br>Mod. 34571/MP P8671<br>(EIS 2 S4-2) | С | 3  | 2                             | (O) One may be inoperative provided associated System Label indication operates normally.   |
| b)                              | Aircraft with<br>Mod. 31056/MP P7004<br>(DMC V50) and without<br>Mod. 34571/MP P8671<br>(EIS 2 S4-2) | С | 3  | 2                             | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Associated System Label indication operates normally, and</li> <li>b) Affected pressure transmitter is deactivated.</li> </ul> |
| 7)                              | Pumps  | С | 3  | 0                             | One or more may be inoperative.   |
| 8)                              | RAT  | С | 1  | 0                             | (O) May be inoperative provided RAT<br>is verified stowed before each<br>departure.   |
| 9)                              | (G/B/Y) HYD SYS Label<br>Vertical Line Links   | С | 12 | 0                             | May be erroneous or missing.  |

|                             | IMENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|--|----|---|----------------|---|
| REVISION NO<br>DATE: 03/03/ |  |    |   | PAGE NO. 29-6  |   |
| AIRCRAFT:<br>Airbus A320    | 2023   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 29. Hydraulic               | Power  |    |   |                |   |
| Sequence No.                | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 29-30-04                    | ECAM Warnings<br>and Cautions  |    |   |                |   |
| 1)                          | RSVR LO AIR PR   |    |   |                |   |
| a)                          | A320 Pre Mod. 23119,<br>A320 Post Mod. 23119<br>and 27189, and<br>A318/A319/A321 | С  | 3 | 2              | (M) One may be inoperative provided<br>air pressure is verified on the<br>reservoir before each departure.  |
| b)                          | A320 Post Mod. 23119<br>and Pre Mod. 27189                                       | С  | 3 | 2              | (M) One may be inoperative for green<br>or yellow system provided air<br>pressure is verified on the reservoir<br>before each departure.  |
| 2)                          | RSVR OVHT  | С  | 3 | 2              | Either green or yellow RSVR OVHT may be inoperative.  |
| 3)                          | ELEC PUMP OVHT   | С  | 2 | 0              | One or both may be inoperative.   |
| 4)                          | PUMP LO PR   |    |   |                |   |
| a)                          | ELEC PUMP LO PR  | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Associated system pressure<br/>indication operates normally,<br/>and</li> <li>b) Operation of electric pumps is<br/>checked before each<br/>departure.</li> </ul> |
| b)                          | ENG PUMP LO PR   | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Associated system pressure<br/>indication operates normally,<br/>and</li> <li>b) Operation of engine pumps is<br/>checked before each<br/>departure.</li> </ul>   |
|                             |  |    |   |                | (Continued)   |

| -                                 |   |   |   |     |   |  |  |  |  |
|-----------------------------------|---|---|---|-----|---|--|--|--|--|
| U.S. DEPARTMENT OF TRANSPORTATION |   |   |   |     | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
| FEDERAL AVIA                      | ATION ADMINISTRATION                      |   |   |     |   |  |  |  |  |
| <b>REVISION NO.</b>               | . 30                                      |   |   |     | PAGE NO. 29-7   |  |  |  |  |
| DATE: 03/03/20                    | 023                                       |   |   |     |   |  |  |  |  |
|                                   |   |   | Т | ABL | E KEY   |  |  |  |  |
| AIRCRAFT:                         |   |   |   |     | REPAIR CATEGORY   |  |  |  |  |
| Airbus A320                       |   |   |   |     | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |  |  |  |  |
|                                   |   |   |   |     | REMARKS OR EXCEPTIONS   |  |  |  |  |
| 29. Hydraulic P                   | Power                                     |   |   |     |   |  |  |  |  |
| Sequence No.                      | ltem                                      | 1 | 2 | 3   | 4 Change<br>Bar   |  |  |  |  |
| 29-30-04                          | ECAM Warnings<br>and Cautions<br>(Cont'd) |   |   |     |   |  |  |  |  |
| 5)                                | RSVR LO LVL                               | С | 3 | 2   | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated reservoir quantity indication operates normally, and</li> <li>b) Quantity is verified adequate before each departure.</li> </ul> </li> <li>NOTE: If blue reservoir is affected, EMER GEN may appear on ECAM STATUS INOP SYS</li> </ul> |  |  |  |  |
|                                   |   |   |   |     | before engines are running.   |  |  |  |  |
| 6)                                | PTU FAULT                                 | С | 1 | 0   | (O) May be inoperative provided the<br>PTU is verified to operate normally<br>before each departure.  |  |  |  |  |
| 7)                                | RAT FAULT                                 | С | 1 | 0   | (M) May be inoperative provided RAT integrity is not affected.  |  |  |  |  |
| 29-30-05                          | LEAK MEASUREMENT<br>VALVE pb Switches     |   |   |     |   |  |  |  |  |
| 1)                                | OFF Lights                                | С | 3 | 0   | One or more may be inoperative.   |  |  |  |  |

| -                        | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIS  | ST  |
|--------------------------|--|----|---|----------------|---|-----|
| REVISION NO              | ). 32  |    |   |                | PAGE NO. 30   | )-1 |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |     |
| 30. Ice and Ra           | in Protection  |    |   |                |   |     |
| Sequence No.             | Item   | 1  | 2 | 3              | 4 Char<br>Ba  |     |
| 30-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |   |                |   |     |
| 1)<br>***                | Fault(s) Indicated by ICE<br>DETECT  | D  | - | -              | NOTE: Dispatch with this MAINT STS<br>message displayed on ECAM<br>is permitted without CFDS<br>interrogation.  |     |
| 2)                       | Fault(s) Indicated by<br>ENG 1(2) A.ICE<br>(A319neo/A320neo/<br>A321neo)                             | С  | - | -              | NOTE: Dispatch with this MAINT STS<br>message displayed on ECAM<br>is permitted without CFDS<br>interrogation.  |     |
| 30-11-01                 | Wing Anti-Ice Control<br>Valves  |    |   |                |   |     |
| 1)                       | A318/A319ceo/A320/<br>A321 except<br>A321neo XLR   | С  | 2 | 1              | <ul> <li>(M)(O) RH valve may be inoperative provided:</li> <li>a) It is secured in open position,</li> <li>b) ENG 1 is started first,</li> <li>c) X BLEED selector is shut when starting ENG 1,</li> <li>d) "CROSS BLEED START" procedure is used when starting ENG 2,</li> <li>e) Alternate procedures are established and used, and</li> <li>f) AFM performance penalties are applied.</li> </ul> |     |
|                          |  | С  | 2 | 0              | <ul> <li>(M) Except for ETOPS beyond  </li> <li>120 minutes, may be inoperative provided: <ul> <li>a) Affected valves are secured in closed position, and</li> <li>b) Aircraft is not operated in known or forecast icing conditions.</li> </ul> </li> <li>(Continued)</li> </ul>   |     |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |   |               |  |  |
|--|---|---|---|---|---|---------------|--|--|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |   | PAGE NC   | ). 30-2       |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>30. Ice and Ra</b>                    | Airbus A320                                 |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |               |  |  |
| Sequence No.   | ltem  | 1 | 2 | 3   | 4   | Change<br>Bar |  |  |
| 30-11-01   | Wing Anti-Ice Control<br>Valves<br>(Cont'd) |   |   |   |   | Bar           |  |  |
| 2)   | A319neo                                     | C | 2 | 1   | <ul> <li>(M)(O) RH valve may be inoperative provided: <ul> <li>a) It is secured in open position,</li> <li>b) ENG 1 is started first,</li> <li>c) X BLEED selector is shut when starting ENG 1,</li> <li>d) "CROSS BLEED START" procedure is used when starting ENG 2,</li> <li>e) Alternate procedures are established and used, and</li> <li>f) AFM performance penalties are applied, and</li> <li>g) F/CTL ALTN LAW caution is not present on ECAM EWD after deactivation.</li> </ul> </li> </ul> |               |  |  |
|  |   | С | 2 | 0   | <ul> <li>(M)(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) Affected valves are secured in<br/>closed position,</li> <li>b) Aircraft is not operated in<br/>known or forecast icing<br/>conditions, and</li> <li>c) F/CTL ALTN LAW caution is<br/>not present on ECAM EWD<br/>after deactivation.</li> </ul> </li> </ul>  |               |  |  |
|  |   |   |   |   | (Continued)   |               |  |  |

| -                        | TMENT OF TRANSPORTAT<br>VIATION ADMINISTRATION      | - |       | MASTER MINIMUM EQUIPMENT LIST   |   |  |  |  |
|--------------------------|---|---|-------|---|---|--|--|--|
| REVISION N               |   |   |       |   | PAGE NO. 30-3   |  |  |  |
| DATE: XX/XX              | X/XXXX  |   |       |   |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   | т<br> | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
|                          | Rain Protection                                     |   |       |   | Change  |  |  |  |
| Sequence No.<br>30-11-01 | Item<br>Wing Anti-Ice Control<br>Valves<br>(Cont'd) | 1 | 2     | 3   | 4 Change<br>Bar   |  |  |  |
| 3)                       | A321neoXLR  | C | 2     | 1   | <ul> <li>(M)(O) RH valve may be inoperative provided:</li> <li>a) It is secured in open position,</li> <li>b) ENG 1 is started first,</li> <li>c) X BLEED selector is shut when starting ENG 1,</li> <li>d) "CROSS BLEED START" procedure is used when starting ENG 2,</li> <li>e) Alternate procedures are established and used, and</li> <li>f) AFM performance penalties are applied.</li> </ul> |  |  |  |
|                          |   | С | 2     | 0   | <ul> <li>(M)(O) Except for ETOPS beyond  </li> <li>120 minutes, may be inoperative  </li> <li>provided: <ul> <li>a) Affected valves are secured in  </li> <li>closed position,  </li> </ul> </li> <li>b) Aircraft is not operated in  </li> <li>known or forecast icing  </li> <li>conditions.  </li> </ul>   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |        |        |                | MASTER MINIMUM EQUIPMENT L  | IST  |
|--|--|--------|--------|----------------|---|------|
| REVISION NC<br>DATE: XX/XX/  | -  |        |        |                | PAGE NO. 3  | 0-4  |
| AIRCRAFT:<br>Airbus A320   |  |        | Т      | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |      |
| 30. Ice and Ra<br>Sequence No.                                       |  | 1      | 2      |                | Ch  | ange |
| 30-11-02<br>1)   | Item<br>Wing Anti-Ice<br>FAULT Light       | С      | 1      | 3<br>0<br>0    | <ul> <li>(O) May be inoperative provided the anti-ice "arrow" on ECAM BLEED page operates normally.</li> <li>(M) Except for ETOPS beyond 120 minutes, may be inoperative provided: <ul> <li>a) Wing anti-ice control valves are deactivated closed and considered inoperative, and</li> <li>b) Airplane is not operated in known or forecast icing conditions.</li> </ul> </li> </ul> | Bar  |
| 2)<br>30-11-03   | ON Light<br>ECAM BLEED Page<br>Indications | С      | 1      | 0              | May be inoperative.   |      |
| 1)<br>2)   | ANTI-ICE<br>ARROW                          | c<br>c | 2<br>2 | 0<br>0         | One or both may be inoperative.<br>One or both may be inoperative.  |      |

| _  |   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|---|----|---|----------------|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 32 |   |    |   |                |  |  |  |  |  |
| DATE: XX/XX/                                       |   |    |   |                | PAGE NO. 30-5  |  |  |  |  |
|  |   |    |   |                | EKEY   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320                           |   |    |   | 1.<br>2.<br>3. | REPAIR CATEGORY  |  |  |  |  |
| 30. Ice and Ra                                     |   |    |   |                | Change   |  |  |  |  |
| Sequence No.<br>30-21-01                           | Item<br>Engine Anti-Ice Valves                                      | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
|  | (A318/A319ceo/<br>A320ceo/A321ceo)                                  | С  | 2 | 1              | (M) Except for ETOPS beyond<br>120 minutes, one may be inoperative<br>secured closed provided airplane is<br>not operated in known or forecast<br>icing conditions.  |  |  |  |  |
|  | (A318/A319ceo/<br>A320ceo/A321ceo with<br>CFM or PW6000<br>engines) | С  | 2 | 0              | (M)(O) May be inoperative open<br>provided AFM performance penalties<br>are applied.   |  |  |  |  |
|  | (A319ceo/A320ceo/<br>A321ceo with<br>IAE engines)                   | С  | 2 | 0              | <ul> <li>(M)(O) May be inoperative open provided:</li> <li>a) AFM performance penalties are applied, and</li> <li>b) OAT is below ISA+35 °C.</li> </ul>  |  |  |  |  |
|  | (A319neo/A320neo/<br>A321neo)                                       | С  | 4 | 2              | (O) Except for ETOPS beyond<br>120 minutes, one or two NAI valves<br>on the same engine may be<br>inoperative in closed position<br>provided aircraft is not operated in<br>known or forecast icing conditions.  |  |  |  |  |
|  | (A319neo/A320neo/<br>A321neo)                                       | С  | 4 | 2              | (M) One NAI valve per engine may<br>be inoperative provided it is<br>deactivated in open position.   |  |  |  |  |
|  | (A319neo/A320neo/<br>A321neo with<br>CFM LEAP1-A Engines)           | С  | 4 | 2              | <ul> <li>(M)(O) Except for ETOPS beyond</li> <li>120 minutes, two may be inoperative</li> <li>on the same engine provided: <ul> <li>a) Affected NAI valves are</li> <li>deactivated in closed position, and</li> </ul> </li> <li>b) Aircraft is not operated in known or forecast icing conditions.</li> </ul> |  |  |  |  |

| -                          | IMENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------|---|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX |   |    |   |                | PAGE NO. 30-6  |
| AIRCRAFT:<br>Airbus A320   |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
|                            | ain Protection  |    |   |                | Change   |
| Sequence No.<br>30-21-02   | Item<br>Engine Anti-Ice   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 1)                         | FAULT Lights  | С  | 2 | 0              | May be inoperative.  |
| 2)                         | ON Lights   | С  | 2 | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
| 30-21-03                   | ANTI-ICE ENG 1(2) CTL<br>FAULT Cautions on<br>ECAM EWD<br>(A319neo/A320neo/<br>A321neo) | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Associated ENG 1(2) A.ICE<br/>VALVE OPEN is displayed on<br/>the EWD, and</li> <li>b) AFM performance penalties<br/>are applied.</li> </ul>  |
|                            |   | С  | 2 | 1              | <ul> <li>Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative provided: <ul> <li>a) Associated ENG 1(2) A.ICE</li> <li>MON FAULT is displayed on the EWD, and</li> <li>b) Aircraft is not operated in known or forecast icing conditions.</li> </ul> </li> </ul> |

| -   | MENT OF TRANSPORTATI                        | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |
|---|---|----|---|---|--|--|--|
| REVISION NO<br>DATE: XX/XX                        |   |    |   |   | PAGE NO. 30-7  |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>30. Ice and Ra</b> | us A320                                     |    |   | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |
| Sequence No.                                      | Item  | 1  | 2 | 3   | 4 Change<br>Bar  |  |  |
| 30-31-01  | Probe Heat Computers                        |    |   |   |  |  |  |
| 1)  | A318/A319/A320/A321                         | С  | 3 | 2   | (M)(O) One may be inoperative<br>provided associated heater is verified<br>to operate normally prior to each<br>flight.  |  |  |
| 2)  | A318/A319/A320/A321<br>(except A321neo XLR) | С  | 3 | 2   | <ul> <li>(M)(O) F/O's may be inoperative provided:</li> <li>a) ADRs, heaters, and failure warnings associated with the operative units are verified to operate normally, and</li> <li>b) Takeoff in CONF 1+F is prohibited (in icing conditions) with ADR 2-OFF.</li> </ul>  |  |  |
|   |   | С  | 3 | 2   | <ul> <li>(M)(O) Except for ETOPS beyond<br/>120 minutes, STBY may be<br/>inoperative provided: <ul> <li>a) ADRs, heaters, and failure<br/>warnings associated with<br/>operative units are verified to<br/>operate normally,</li> <li>b) Airplane is not operated in<br/>visible moisture or known or<br/>forecast icing conditions, and</li> <li>c) Ambient temperature at the<br/>departure airport is above<br/>5 °C when taxiways or<br/>runways are covered with<br/>water or slush.</li> </ul> </li> </ul> |  |  |

| FEDERAL AVIATION ADMINISTRATION |               |   |   |                |  |  |  |  |  |  |
|---------------------------------|---------------|---|---|----------------|--|--|--|--|--|--|
| REVISION NO                     |               |   |   |                | PAGE NO. 30-8  |  |  |  |  |  |
| D/(12. /00/00                   |               |   |   |                | EKEY   |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |               |   |   | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |  |
| 30. Ice and Ra                  | in Protection |   | I |                |  |  |  |  |  |  |
| Sequence No.                    | Item          | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |  |
| 30-31-02                        | Pitot Heaters | B | 3 | 2              | <ul> <li>(M)(O) F/O's may be inoperative provided:</li> <li>a) ADR, heaters, and failure warnings associated with CAPT and STBY probes (pitot static, AOA, TAT) are verified to operate normally, and</li> <li>b) Takeoff in CONF 1+F (CONF 1A+F for A321neo XLR) is prohibited (in icing conditions) with ADR 2-OFF.</li> </ul>   |  |  |  |  |  |
|                                 |               | В | 3 | 2              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, CAPT heater may be inoperative provided: <ul> <li>a) ADR, heaters, and failure warnings associated with F/O and STBY probes (pitot, static, AOA, TAT) are verified to operate normally, and</li> <li>b) Airplane is not operated in visible moisture or in known or forecast icing conditions.</li> </ul> </li> </ul> |  |  |  |  |  |
|                                 |               | В | 3 | 2              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, STBY heater may be inoperative provided: <ul> <li>a) ADR, heaters, and failure warnings associated with CAPT and F/O probes (pitot, static, AOA, TAT) are verified to operate normally, and</li> <li>b) Airplane is not operated in visible moisture or in known or forecast icing conditions.</li> </ul> </li> </ul> |  |  |  |  |  |

| -                        | IENT OF TRANSPORTATIO | NC |    |                | MASTER MINIMUM EQUIPMENT  | LIST          |
|--------------------------|-----------------------|----|----|----------------|---|---------------|
| REVISION NO.             | 32                    |    |    |                | PAGE NO   | . 30-9        |
| DATE: XX/XX/>            | XXXX                  |    |    |                |   |               |
| AIRCRAFT:<br>Airbus A320 |                       |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |
| 30. Ice and Rai          | n Protection          |    |    | 1              |   |               |
| Sequence No.             | ltem                  | 1  | 2  | 3              | 4   | Change<br>Bar |
| 30-31-03                 | Static Port Heaters   | С  | 6  | 5              | One STBY heater may be inoperative.   |               |
|                          |                       | С  | 6  | 4              | <ul> <li>(M)(O) CAPT heaters may be inoperative provided:</li> <li>a) ADR, heaters, and failure warnings associated with the operative units are verified to operate normally, and</li> <li>b) Ambient temperature at the departure airport is greater than 5 °C when runway is contaminated with water or slush.</li> </ul>  |               |
|                          |                       | С  | 6  | 4              | <ul> <li>(M)(O) F/O's heaters may be inoperative provided:</li> <li>a) ADR, heaters, and failure warnings associated with the operative units are verified to operate normally, and</li> <li>b) Takeoff in CONF 1+F (CONF 1A+F for A321neo XLR) is prohibited (in icing conditions) with ADR 2-OFF.</li> </ul>  |               |
|                          |                       | С  | 6  | 4              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, STBY heaters may be inoperative provided: <ul> <li>a) ADR, heaters, and failure warnings associated with operative units are verified to operate normally, and</li> <li>b) Ambient temperature at the departure airport is greater than 5 °C when runway is contaminated with water or slush.</li> </ul> </li> </ul> |               |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |
|--|--|---|---|----------------|--|--|--|
| REVISION NC<br>DATE: XX/XX/  |  |   |   | PAGE NO. 30-10 |  |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>30. Ice and Rain Protection</b>       |  |   |   |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |
| 30-31-04   | Angle of Attack Probe<br>Heaters<br>(except A321neo XLR) | C | 3 | 2              | (M)(O) F/O's heater may be<br>inoperative provided ADR, heaters,<br>and failure warnings associated with<br>CAPT and STBY probes (pitot, static,<br>AOA, TAT) are verified to operate<br>normally once each flight-day.  |  |  |
|  |  | С | 3 | 2              | (M)(O) STBY heater may be<br>inoperative provided ADR, heaters,<br>and failure warnings associated with<br>CAPT and F/O probes (pitot, static,<br>AOA, TAT) are verified to operate<br>normally once each flight-day.  |  |  |
|  |  | С | 3 | 2              | <ul> <li>(M)(O) Except for ETOPS beyond</li> <li>120 minutes, CAPT's heater may be inoperative provided: <ul> <li>a) ADR, heaters, and failure warnings associated with F/O and STBY probes (pitot, static, AOA, TAT) are verified to operate normally once each flight-day, and</li> <li>b) Airplane is not operated in visible moisture or in known or forecast icing conditions.</li> </ul> </li> </ul> |  |  |

| -                        | MENT OF TRANSPORTATIO   | JIN    |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|--------------------------|---|--------|---|-------------------------------|---|--|--|
| <b>REVISION NO</b>       | . 32  |        |   |                               | PAGE NO. 30-11  |  |  |
| DATE: XX/XX/2            | XXXX  |        |   |                               |   |  |  |
| AIRCRAFT:<br>Airbus A320 |   |        |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 30. Ice and Rai          | in Protection   |        | r |                               | Charge  |  |  |
| Sequence No.             | Item  | 1      | 2 | 3                             | 4 Change<br>Bar   |  |  |
| 30-31-05                 | TAT Probe Heaters   | C<br>C | 2 | 1                             | One may be inoperative.<br>Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided airplane is not operated in<br>visible moisture or in known or<br>forecast icing conditions.  |  |  |
| 30-42-01                 | Window Heat Computers   | С      | 2 | 1                             | <ul> <li>(M) Except for ETOPS beyond<br/>120 minutes, one may be inoperative<br/>provided: <ul> <li>a) All heaters and failure<br/>warnings on the front and<br/>sliding windows associated<br/>with operative systems are<br/>verified to operate normally,</li> <li>b) Airplane is not operated in<br/>known or forecast icing<br/>conditions, and</li> <li>c) Approach minimums do not<br/>require its use.</li> </ul> </li> </ul> |  |  |
| 30-42-02                 | Fixed Lateral Window<br>and Sliding Window<br>Heating Systems   | С      | 4 | 0                             | One or more may be inoperative.   |  |  |
| 30-42-03                 | Windshield Heating<br>Systems   | С      | 2 | 1                             | <ul> <li>Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative provided: <ul> <li>a) Airplane is not operated in known or forecast icing conditions, and</li> <li>b) Approach minimums do not require its use.</li> </ul> </li> </ul>  |  |  |
| 1)                       | For aircraft equipped<br>with SGS Windshield: If<br>ISB applied (ref. 56-1022<br>or 56-1023) with<br>findings-Degradation out<br>of allowance | С      | 2 | 1                             | One may be degraded beyond the<br>passed criteria of ISB (ref. 56-1022<br>for CEO or 56-1023 for NEO)<br>provided airplane remains at or below<br>FL 230.   |  |  |

| -                         | TMENT OF TRANSPORTAT                                | - |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|---------------------------|---|---|---|----------------|--|
| REVISION N<br>DATE: XX/XX |   |   |   |                | PAGE NO. 30-12   |
| AIRCRAFT:<br>Airbus A320  |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 30. Ice and R             | ain Protection                                      |   |   |                |  |
| Sequence No.              | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 30-42-04                  | Probes/Window Heat<br>pb-sw                         |   |   |                |  |
| 1)                        | AUTO Control  | С | 1 | 0              | May be inoperative provided<br>PROBES/WINDOW HEAT system is<br>manually selected.  |
| 2)                        | ON Light  | С | 1 | 0              | May be inoperative provided the<br>PROBES/WINDOW HEAT automatic<br>system is operative.  |
| 30-45-01                  | Windshield Wiper<br>Systems                         | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Airplane is not operated in<br/>precipitation within 5 SM of<br/>the airport of takeoff or<br/>intended landing, and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul>  |
|                           |   | С | 2 | 0              | <ul> <li>(M)(O) May be inoperative continuously running provided:</li> <li>a) Airplane is not operated in precipitation within 5 SM of the airport of takeoff or intended landing,</li> <li>b) Approach minimums do not require its use, and</li> <li>c) Affected wiper is deactivated.</li> </ul> |
|                           |   | В | 2 | 1              | One may be inoperative provided associated rain repellent system is installed and operative.   |
| 1)                        | Fast Speed  | С | 2 | 0              | May be inoperative provided slow<br>speed operates normally and<br>approach minimums do not require its<br>use.  |
| 2)                        | Slow Speed  | С | 2 | 0              | May be inoperative provided fast speed operates normally.  |
| 3)<br>***                 | Intermittent Speed<br>(Aircraft with<br>Mod. 20319) | D | 2 | 0              | One or both may be inoperative.  |
|                           |   |   |   |                | (Continued)  |

| FEDERAL AV                 | IATION ADMINISTRATION                    |   |   | MASTER MINIMUM EQUIPMENT LIST |   |
|----------------------------|--|---|---|-------------------------------|---|
| REVISION NO<br>DATE: XX/XX |  |   |   |                               | PAGE NO. 30-13  |
| AIRCRAFT:<br>Airbus A320   |  |   |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
|                            | ain Protection                           | 1 |   |                               |   |
| Sequence No.               | ltem                                     | 1 | 2 | 3                             | 4 Change<br>Bar   |
| 30-45-01                   | Windshield Wiper<br>Systems<br>(Cont'd)  |   |   |                               |   |
| 4)                         | PARK Function                            | С | 2 | 0                             | May be inoperative provided affected<br>wiper can be located in a position that<br>will not obstruct forward vision.  |
|                            |  | С | 2 | 0                             | (M) May be inoperative provided<br>affected wiper is removed and<br>considered inoperative.   |
| 30-45-02<br>***            | Rain Repellant Systems                   | D | 2 | 0                             | One or both may be inoperative.   |
| 30-71-01                   | Waste Water Drain Mast<br>Heating System | С | - | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated lavatory and<br/>galley water supplies are<br/>secured off,</li> <li>b) Associated galley sink and<br/>lavatory washbasin drains are<br/>blocked to prevent their use,<br/>and</li> <li>c) Procedures are established to<br/>periodically monitor<br/>associated galley sinks and<br/>lavatory washbasins to ensure<br/>they remain blocked.</li> </ul>   |
|                            |  | С | - | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Associated galley and<br/>lavatory are not used,</li> <li>b) The pilot in command will<br/>determine if flight duration is<br/>acceptable with a FWD<br/>lavatory unusable, and</li> <li>c) Associated lavatory door(s) is<br/>secured closed and placarded<br/>"INOPERATIVE –<br/>DO NOT ENTER".</li> <li>NOTE: These provisions are not<br/>intended to prohibit<br/>inspections by crewmembers.</li> </ul> |

|                    | MENT OF TRANSPORTATION   |   |   | MASTER MINIMUM EQUIPMENT LIST |                           |
|--------------------|--|---|---|-------------------------------|---------------------------|
| FEDERAL AV         | IATION ADMINISTRATION  |   |   |                               |                           |
| <b>REVISION NC</b> | 0. 32  |   |   |                               | PAGE NO. 30-14            |
| DATE: XX/XX        | /XXXX  |   |   |                               |                           |
|                    |  |   | Т | ABLI                          | E KEY                     |
| AIRCRAFT:          |  |   |   | 1.                            | REPAIR CATEGORY           |
| -                  |  |   |   | 2.                            |                           |
| Airbus A320        |  |   |   | 3.                            | NO. REQUIRED FOR DISPATCH |
|                    |  |   |   | 4.                            | REMARKS OR EXCEPTIONS     |
| 30. Ice and Ra     | in Protection  |   | • |                               |                           |
| Sequence No.       | Item   | 1 | 2 | 3                             | 4 Change<br>Bar           |
| 30-71-02<br>***    | Waste Water Drain Line<br>Protection System                                | D | 1 | 0                             | May be inoperative.       |
| 30-71-03<br>***    | Cargo Compartment<br>Drain Line and Drain<br>Mast Ice Protection<br>System | D | 1 | 0                             | May be inoperative.       |
| 30-81-02<br>***    | Ice Detection System   | D | 1 | 0                             | May be inoperative.       |
| 30-81-03<br>***    | External Visual Ice<br>Indicator Lighting                                  | D | 1 | 0                             | May be inoperative.       |

| -               | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|-----------------|--|---|---|-------------------------------|--|
| REVISION NO     |  |   |   | PAGE NO. 31-1                 |  |
| DATE: XX/XX/    |  |   |   |                               |  |
| AIRCRAFT:       |  |   | Т |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED  |
| Airbus A320     |  |   |   | 3.                            | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 31. Indicating/ | Recording Systems  |   |   |                               |  |
| Sequence No.    | Item   | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 31-00-00        | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |   |   |                               |  |
| 1)<br>***       | Fault(s) Indicated by<br>QAR   | D | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 2)<br>***       | Fault(s) Indicated by<br>DMU   | D | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 3)<br>***       | Fault(s) Indicated by<br>DAR   | D | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 4)              | Faults Indicated by<br>CFDIU   | С | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 5)<br>***       | Faults Indicated by<br>ACMS  | D | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
|                 |  |   |   |                               | (Continued)  |

| -                        | TMENT OF TRANSPORTATI<br>VIATION ADMINISTRATION  | ON |                |   | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|----|----------------|---|--|
| REVISION N<br>DATE: XX/X |  |    |                |   | PAGE NO. 31-2  |
| AIRCRAFT:<br>Airbus A320 |  | Т  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |
|                          | g/Recording Systems  | Γ. |                |   | A Change   |
| Sequence No.<br>31-00-00 | Item<br>CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd) | 1  | 2              | 3   | 4 Change Bar   |
| 6)<br>***                | Faults Indicated by DMC 1/3  |    |                |   |  |
| a)                       | With Mod. 31283/<br>MP P7125   | С  | -              | -   | May be displayed provided DMC 2/3<br>MAINTENANCE message is not<br>displayed simultaneously on ECAM<br>STATUS page.  |
|                          |  |    |                |   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |
| b)                       | With Mod. 151269/<br>MP P11819   | С  | -              | -   | May be displayed on ECAM STATUS page.  |
|                          |  |    |                |   | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |
| 7)<br>***                | Faults Indicated by<br>DMC 2/3<br>(With Mod. 31283/<br>MP P7125 or with<br>Mod. 151269/<br>MP P11819)                    | С  | -              | -   | May be displayed on ECAM STATUS<br>page.<br>NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
|                          |  |    |                |   | (Continued)  |

| U.S. DEPART              | MENT OF TRANSPORTATIO   | ON |    |                |  |
|--------------------------|---|----|----|----------------|--|
| FEDERAL AVI              | ATION ADMINISTRATION  |    |    |                | MASTER MINIMUM EQUIPMENT LIST  |
| <b>REVISION NO</b>       | . 32  |    |    |                | PAGE NO. 31-3  |
| DATE: XX/XX/2            | XXXX  |    |    |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 31. Indicating/          | Recording Systems   |    | 1  |                |  |
| Sequence No.             | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |
| 31-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd)                            |    |    |                |  |
| 8)<br>***                | Faults Indicated by<br>DFDR ACCEL<br>(With Mod. 161365/<br>MP P14629)   | A  | -  | -              | May be displayed on ECAM STATUS<br>page provided FDR Recording<br>Parameters Required by 14 CFR is<br>considered inoperative.<br>NOTE 1: Refer to MMEL<br>item 31-30-02, 1) FDR<br>Recording Parameters<br>Required by 14 CFR.<br>NOTE 2: Dispatch with maintenance<br>status message displayed<br>on ECAM is permitted<br>without CFDS interrogation. |
| 9)<br>***                | Fault(s) Indicated by<br>CVDR2<br>(With Mod. 165565/<br>MP K30988 (CVDR) and<br>with Mod. 166490/<br>MP P21265<br>(FWC H2-F13<br>Standard)) | С  | -  | -              | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |

| -                        | VENT OF TRANSPORTATION                     |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |
|--------------------------|--|---|-------------------------------|----------------|--|--|
| REVISION NO.             | . 32                                       |   |                               |                | PAGE NO. 31-4  |  |
| DATE: XX/XX/X            | XXXX                                       |   |                               |                |  |  |
| AIRCRAFT:<br>Airbus A320 |  |   | Т.                            | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |
|                          | Recording Systems                          |   |                               |                | Change   |  |
| Sequence No.<br>31-21-01 | Item<br>Clock System                       | C | 2                             | 3              | <ul> <li>Change Bar</li> <li>(O) May be inoperative provided:         <ul> <li>a) Time base from CFDIU is available on ECAM, and</li> <li>b) Chrono indication is available on one Navigation Display (ND).</li> </ul> </li> <li>NOTE: For aircraft equipped with P/N APE5100-1 (Mod. 27330/MP P5465), during the entire month of February, intermittent erroneous indications (wrong, over-range or missing digits) of the elapsed time and chronometer functions may occur if the clock is in GPS mode. In that case, the flightcrew must set the clock selector to internal (INT) mode in order to recover the elapsed time and chronometer functions. The clock is considered operative. When the clock is in INT mode, the flightcrew must synchronize the clock with the GPS at least one time per day to comply with the time precision required for ATC data link communication. Refer to FCOM DSC-31-55-20 Operation in Internal Mode.</li> </ul> |  |
| 31-27-01<br>***          | Flight Number Reminder                     | D | 1                             | 0              | May be inoperative.  |  |
| 31-30-01                 | Centralized Fault Display<br>System (CFDS) | С | 1                             | 0              | May be inoperative provided CFDS<br>system is available when required for<br>specified maintenance tasks.  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |             |   |                | MASTER MINIMUM EQUIPMEN  | T LIST  |
|--|---|-------------|---|----------------|--|---------|
| REVISION NO.<br>DATE: XX/XX/X  |   |             |   |                | PAGE NC  | ). 31-5 |
| AIRCRAFT:<br>Airbus A320   |   |             | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |         |
|  | Recording Systems   |             |   |                |  | Change  |
| Sequence No.<br>31-30-02   | Item<br>Flight Data Recorder<br>(FDR) System                                      | 1<br>C<br>Δ | - | 1              | 4<br>Any in excess of those required by<br>14 CFR may be inoperative.  | Bar     |
|  | Includes FDR Function<br>of Combined Voice and<br>Flight Data Recorder<br>(CVFDR) | A           |   | 0              | <ul> <li>May be inoperative provided: <ul> <li>a) Cockpit voice Recorder (CVR) operates normally,</li> <li>b) Airplane is not dispatched from a designated airport as listed in the operator's MEL unless: <ul> <li>1) The FDR failure occurs after pushback but prior to takeoff, or</li> <li>2) The FDR repair was attempted but was not successful.</li> </ul> </li> <li>c) In those cases where repair is attempted but not successful, the aircraft may be dispatched on a flight or series of flights until the next designated airport where repair must be accomplished prior to dispatch, and</li> <li>d) Repairs are made within 3 flight-days.</li> </ul></li></ul> |         |
| 1)   | FDR Recording<br>Parameters Required by<br>14 CFR                                 | A           | - | _              | Up to three parameters may be<br>inoperative provided:<br>a) Cockpit voice recorder (CVR)<br>operates normally, and<br>b) Repairs are made within<br>20 consecutive calendar-days.   |         |
| 2)   | FDR Recording<br>Parameters Not<br>Required by 14 CFR                             | A           | - | -              | May be inoperative provided repairs<br>are made prior to completion of next<br>heavy maintenance visit.  |         |

| _                        | IENT OF TRANSPORTATIO   | ON |   |               | MASTER MINIMUM EQUIPMENT   | LIST          |  |  |
|--------------------------|---|----|---|---------------|--|---------------|--|--|
| REVISION NO.             | 32  |    |   | PAGE NO. 31-6 |  |               |  |  |
| DATE: XX/XX/X            | (XXX  |    | Т |               | EKEY   |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   | 2.<br>3.      | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |
|                          | Recording Systems   |    | 1 | 1             | 1  | 0             |  |  |
| Sequence No.             | ltem  | 1  | 2 | 3             | 4  | Change<br>Bar |  |  |
| 31-30-03                 | Flight Data Interface Unit<br>(FDIU) or Flight Data<br>Interface Function of the<br>Flight Data Interface and<br>Management Unit<br>(FDIMU)<br>(Including Aircraft with<br>STC ST02668LA) | A  | - | 0             | <ul> <li>May be inoperative provided: <ul> <li>a) Cockpit voice Recorder (CVR) operates normally,</li> <li>b) Airplane is not dispatched from a designated airport as listed in the operator's MEL unless: <ul> <li>1) The FDR failure occurs after pushback but prior to takeoff, or</li> <li>2) The FDR repair was attempted but was not successful.</li> </ul> </li> <li>c) In those cases where repair is attempted but not successful, the aircraft may be dispatched on a flight or series of flights until the next designated airport where repair must be accomplished prior to dispatch, and</li> <li>d) Repairs are made within 3 flight-days.</li> </ul></li></ul> |               |  |  |
| 31-30-04<br>***          | Quick Access Recorder   | D  | 1 | 0             | May be inoperative.  |               |  |  |
| 31-30-05<br>***          | Digital AIDS Recorder<br>System   | D  | 1 | 0             | May be inoperative.  |               |  |  |
| 31-30-06<br>***          | Data Management Unit<br>(DMU) or Data<br>Management Function of<br>the FDIMU  | D  | 1 | 0             | May be inoperative.  |               |  |  |
| 31-30-07<br>***          | Printer   | D  | 1 | 0             | May be inoperative.  |               |  |  |

|                             | MENT OF TRANSPORTATION                                      |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|---|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/ |   |   |   |                | PAGE NO. 31-7   |
| AIRCRAFT:<br>Airbus A320    |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 31. Indicating/             | Recording Systems   |   |   |                |   |
| Sequence No.                | Item  | 1 | 2 | 3              | 4 Change<br>Bar   |
| 31-38-01<br>***             | Up and Down Data<br>Loading System<br>Acquisition/Interface |   |   |                |   |
| 1)                          | DATA LOADING<br>SELECTOR                                    | D | 1 | 0              | May be inoperative.   |
| 2)                          | Multipurpose Disk Drive<br>Unit (MDDU)                      | D | 1 | 0              | May be inoperative.   |
| 3)                          | Data Loading Routing<br>Box (DLRB or eDLRB)                 | D | 1 | 0              | May be inoperative.   |
| 4)                          | Airborne Data Loading<br>Unit (ADLU)                        | D | 1 | 0              | May be inoperative.   |
| 5)                          | Data Loading Selector<br>Unit (DLSU)                        | D | 1 | 0              | May be inoperative.   |
| 31-53-01                    | Flight Warning<br>Computers (FWC)                           |   |   |                |   |
| 1)                          | Without Mod. 35542  | В | 2 | 1              | FWC 2 may be inoperative provided approach minimums do not require its use.   |
| 2)                          | With Mod. 35542   | В | 2 | 1              | <ul> <li>FWC 2 may be inoperative provided:</li> <li>a) Steep approach function is<br/>not used, and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul> |
| 31-55-01                    | System Data Acquisition<br>Concentrator Units<br>(SDAC)     | С | 2 | 1              | SDAC 2 may be inoperative.  |

|                          | MENT OF TRANSPORTATI                                | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|----|----------------|--|
| REVISION NO              | ). 32   |    |    |                | PAGE NO. 31-8  |
| AIRCRAFT:<br>Airbus A320 |   |    | T  | 1.<br>2.<br>3. | -  |
| 31. Indicating           | Recording Systems                                   |    |    |                |  |
| Sequence No.             | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |
| 31-56-01<br>1)           | ECAM Control Panel<br>System Page MANUAL<br>CALL pb | с  | 11 | 0              | One or more may be inoperative.  |
| 2)                       | CLR pb  | С  | 2  | 1              | One may be inoperative.  |
| 3)                       | T/O CONFIG pb                                       | С  | 1  | 0              | (O) May be inoperative provided T/O configuration is verified before each departure.   |
| 4)                       | STS pb  | С  | 1  | 0              | (O) May be inoperative.  |
| 31-58-01                 | Master Warn System                                  |    |    |                |  |
| 1)                       | Lights  | С  | 2  | 1              | One may be inoperative.  |
| 2)                       | CANCEL Functions                                    | С  | 2  | 1              | One may be inoperative.  |
| 31-58-02                 | Master Caution System                               |    |    |                |  |
| 1)                       | Lights  | С  | 2  | 1              | One may be inoperative.  |
| 2)                       | CANCEL Functions                                    | С  | 2  | 1              | One may be inoperative.  |
| 31-61-01                 | EIS Switching Systems                               |    |    |                |  |
| 1)                       | ATT HDG   | С  | 1  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) NORM Mode operates<br/>normally, and</li> <li>b) Switch remains in the normal<br/>position.</li> </ul> |
| 2)                       | AIR DATA  | С  | 1  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) NORM Mode operates<br/>normally, and</li> <li>b) Switch remains in the normal<br/>position.</li> </ul> |
| 3)                       | EIS DMC   | С  | 1  | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) NORM Mode operates<br/>normally, and</li> <li>b) Switch remains in the normal<br/>position.</li> </ul> |
|                          |   |    |    |                | (Continued)  |

| -                          | IMENT OF TRANSPORTATI             | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|----------------------------|-----------------------------------|----|---|----------------|--|
| REVISION NO<br>DATE: XX/XX |                                   |    |   |                | PAGE NO. 31-9  |
| AIRCRAFT:<br>Airbus A320   |                                   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
|                            | /Recording Systems                |    | 1 |                |  |
| Sequence No.<br>31-61-01   | EIS Switching Systems<br>(Cont'd) | 1  | 2 | 3              | 4 Change<br>Bar  |
| 4)                         | ECAM/ND XFR                       | С  | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) It operates normally in the<br/>Normal position, and</li> <li>b) Both ECAM DUs operate<br/>normally.</li> </ul>  |
| 5)                         | PFD/ND XFR                        | С  | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) PFD and ND units are operative, and</li> <li>b) PFD to ND automatic switching is checked operative on the flying pilot side before each flight.</li> </ul> |
| 31-63-01                   | Display Units (DU)                |    |   |                |  |
| 1)                         | PFDU 2                            | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) PFDU1, NDU1, E/WDU, SDU,<br/>and NDU2 are operative, and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul>                              |
| 2)                         | NDU 1                             | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) PFDU1, NDU2, E/WDU, SDU,<br/>and PFDU2 are operative,<br/>and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul>                         |
| 3)                         | NDU 2                             | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) PFDU1, NDU1, E/WDU, SDU,<br/>and PFDU2 are operative,<br/>and</li> <li>b) Approach minimums do not<br/>require its use.</li> </ul>                         |
|                            |                                   |    |   |                | (Continued)  |

| -                        | MENT OF TRANSPORTATION                                      | ON |   |                | MASTER MINIMUM EQUIPMENT  | LIST          |
|--------------------------|---|----|---|----------------|---|---------------|
| <b>REVISION NO</b>       | . 32  |    |   |                | PAGE NO.  | 31-10         |
| DATE: XX/XX/             | XXXX  |    |   |                |   |               |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |
| 31. Indicating/          | Recording Systems   |    |   |                |   |               |
| Sequence No.             | Item  | 1  | 2 | 3              | 4   | Change<br>Bar |
| 31-63-01                 | Display Units (DU)<br>(Cont'd)                              |    |   |                |   |               |
| 4)                       | SDU   |    |   |                |   |               |
| a)                       | Without Mod. 36414/<br>MP K11047 or<br>Mod. 38111/MP K11684 | A  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) PFDU1, NDU1, E/WDU,<br/>PFDU2, and NDU2 are<br/>operative,</li> <li>b) AC ESS FEED control is<br/>verified operative once each<br/>day,</li> <li>c) AC ESS FEED FAULT light is<br/>verified operative once each<br/>day, and</li> <li>d) Repairs are made within<br/>3 flight-days.</li> </ul>   | -             |
| b)                       | With Mod. 36414/<br>MP K11047 or<br>Mod. 38111/MP K11684    | A  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) PFDU1, NDU1, E/WDU,<br/>PFDU2, and NDU2 are<br/>operative,</li> <li>b) AC ESS FEED control is<br/>verified operative once each<br/>day,</li> <li>c) AC ESS FEED FAULT light is<br/>verified operative once each<br/>day,</li> <li>d) Repairs are made within<br/>3 flight-days, and</li> <li>e) The CDSS is considered<br/>inoperative.</li> </ul> |               |

| -                        | MENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|---|----------------|--|
| FEDERAL AVI              | ATION ADMINISTRATION  |    |   |                | PAGE NO. 31-11   |
| DATE: XX/XX/             |   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 31. Indicating/I         | Recording Systems   | 1  | 1 |                |  |
| Sequence No.             | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 31-63-02                 | Display Management<br>Computers   |    |   |                |  |
| 1)                       | DMC 1   |    |   |                |  |
| a)                       | Aircraft with Mod. 21678/<br>MP K1806<br>(AC/DC ESS PWR for<br>ETOPS) and without<br>Mod. 34571/MP P8671<br>(EIS2 S4-2), and without<br>Mod. 36725/MP P9824<br>(EIS2 S7)    | С  | 1 | 0              | May be inoperative provided DMC 2<br>and DMC 3 are operative.  |
| b)                       | Aircraft with Mod. 21678<br>MP K1806<br>(AC/DC ESS PWR for<br>ETOPS) and<br>Mod 34571/MP P8671<br>(EIS2 S4-2), or with<br>Mod. 36725/MP P9824<br>(EIS2 S7)                  | С  | 1 | 0              | (O) May be inoperative provided<br>DMC 2 and DMC 3 are operative.  |
| 2)                       | DMC 2   |    |   |                |  |
| a)                       | Aircraft with Mod. 34571/<br>MP P8671 (EIS2 S4-2),<br>or with Mod. 36725/<br>MP P9824 (EIS 2 S7), or<br>without Mod. 37317/<br>MP P10098<br>(AC ESS FEED Auto<br>Switching) | С  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) AC ESS Feed Control is<br/>verified operative once each<br/>flight-day,</li> <li>b) AC ESS Feed Fault Light is<br/>verified operative once each<br/>flight-day, and</li> <li>c) DMC 1 and DMC 3 are<br/>operative.</li> </ul>           |
| b)                       | Aircraft without<br>Mod. 34571/MP P8671<br>(EIS2 S4-2), or without<br>Mod. 36725/MP P9824<br>(EIS2 S7), or with<br>Mod. 37317MP P10098<br>(AC ESS FEED Auto<br>Switching)   | С  | 1 | 0              | <ul> <li>(M) May be inoperative provided: <ul> <li>a) AC ESS Feed Control is verified operative once each flight-day,</li> <li>b) AC ESS Feed Fault Light is verified operative once each flight-day, and</li> <li>c) DMC 1 and DMC 3 are operative.</li> </ul> </li> <li>(Continued)</li> </ul> |

| -                             | IENT OF TRANSPORTATIO  | NC |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------|--|----|---|----------------|--|
| REVISION NO.<br>DATE: XX/XX/X |  |    |   |                | PAGE NO. 31-12   |
| AIRCRAFT:<br>Airbus A320      |  |    | Т | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |
|                               | Recording Systems  |    |   |                |  |
| Sequence No.                  | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 31-63-02                      | Display Management<br>Computers<br>(Cont'd)  |    |   |                |  |
| 3)                            | DMC 3  |    |   |                |  |
| a)                            | Aircraft without<br>Mod. 34571/MP P8671<br>(EIS2 S4-2) and without<br>Mod. 36725/MP P9824<br>(EIS2 S7) | С  | 1 | 0              | May be inoperative provided DMC 1<br>and DMC 2 are operative.  |
| b)                            | Aircraft with Mod. 34571/<br>MP P8671<br>(EIS2 S4-2), or<br>Mod. 36725/MP P9824<br>(EIS2 S7)           | С  | 1 | 0              | (O) May be inoperative provided<br>DMC 1 and DMC 2 are operative.                                      |
| 31-63-03                      | ECAM Memo Messages   | С  | - | 0              | May be inoperative provided affected<br>MEMO message is confirmed to be<br>false or missing.           |
| 31-63-04                      | ECAM Permanent Data<br>Display   | С  | - | 0              | Indications may be inoperative<br>provided TAT or SAT temperature is<br>available.                     |

| 32-00-00   | (XX  | 1 | 2 | 1.<br>2.<br>3.       | PAGE NO<br>E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   | ). 32-1<br>Change<br>Bar |
|--|--|---|---|----------------------|--|--------------------------|
| Airbus A320<br><b>32. Landing Gear</b><br>Sequence No.<br>32-00-00 | Item<br>CLASS II<br>MAINTENANCE<br>MESSAGE DISPLAYED<br>ON ECAM STATUS<br>PAGE OF ECAM | 1 |   | 1.<br>2.<br>3.<br>4. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |                          |
| Sequence No.   | Item<br>CLASS II<br>MAINTENANCE<br>MESSAGE DISPLAYED<br>ON ECAM STATUS<br>PAGE OF ECAM | 1 | 2 | 3                    | 4  |                          |
| 32-00-00   | CLASS II<br>MAINTENANCE<br>MESSAGE DISPLAYED<br>ON ECAM STATUS<br>PAGE OF ECAM         | 1 | 2 | 3                    | 4  |                          |
|  | MAINTENANCE<br>MESSAGE DISPLAYED<br>ON ECAM STATUS<br>PAGE OF ECAM                     |   |   |                      |  |                          |
|  |  |   |   |                      |  |                          |
| 32-11-01<br>***  | Torque Link Dampers  | A | 2 | 0                    | May be inoperative provided repairs are made within 7 flight-legs.   |                          |
| 32-12-01   | MAIN GEAR DOORS  |   |   |                      |  |                          |
| 1)   | Ground Opening Cables  | С | 2 | 0                    | (M) May be broken or missing.  |                          |
| ;  | Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)                          |   |   |                      |  |                          |
| ,  | A318/A319ceo/A320ceo/<br>A321ceo   | A | 1 | 0                    | <ul> <li>(M)(O) LGCIU 2 may be inoperative<br/>for 1 flight-day provided: <ul> <li>a) Both radio altimeter systems<br/>operate normally,</li> <li>b) Both FCU channels operate<br/>normally,</li> <li>c) All ELACs, SECs, ADIRs,<br/>SFCCs, and FACs operate<br/>normally,</li> <li>d) Flex takeoff is not used,</li> <li>e) LGCIU 2 is deactivated,</li> <li>f) The following associated<br/>items are considered<br/>inoperative: <ul> <li>CVR Erase pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear<br/>Detection and Avoidance,</li> <li>Fuel Tank Inerting<br/>System,</li> <li>ENG 2 Minimum Idle on<br/>Ground,</li> </ul> </li> </ul></li></ul> |                          |

| REVISION NO. 32<br>DATE: XX/XXXXX       PAGE NO. 32-2         AIRCRAFT:<br>Airbus A320       TABLE KEY         1. REPAIR CATEGORY       3. NO. REQUIRED FOR DISPATCH         4. REMARKS OR EXCEPTIONS       32. Landing Gear         Sequence No.       tem       1       2       3         32-31-01       Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd)       • Ground External Horn,<br>• External Power Panel<br>ADIRU/AVNCS Vent<br>Caution Light,<br>• Skin Air Outlet Valve,<br>• Cargo Doors Electrical<br>Control,<br>• Engine Bump,<br>• Thrust Reverser Systems<br>on ENG 2.         2)       A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484       A       1       0         3)       Ground Cooling System,<br>• Thrust Reverser Systems<br>on ENG 2.       ) Both radio altimeter systems<br>operate normally,<br>• Flex takeoff is not used,<br>• LOCIU 2 is deactivated,<br>• OAT is below ISA+35 *C. | _  | MENT OF TRANSPORTATION  | ON |   |                      | MASTER MINIMUM EQUIPMEN  | T LIST  |
|---|--|---|----|---|----------------------|--|---------|
| AIRCRAFT:       1. REPAIR CATEGORY         Airbus A320       1       2. No. INSTALLED         32. Landing Gear       3. No. REQURED FOR DISPATCH         Sequence No.       Item       1       2       3         32.31-01       Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)       4       -       -         1)       A318/A319ceo/A320ceo/ A321ceo (Cont'd)       -       -       -       -         1)       A318/A319ceo/A320ceo/ (Cont'd)       -       -       -       -         1)       A318/A319ceo/A320ceo/ (Cont'd)       -       -       -       -         1)       A318/A319ceo/A320ceo/ (Cont'd)       -       -       -       -       -         1)       A318/A319ceo/A320neo/ (Cont'd)       - <t< td=""><td></td><td></td><td></td><td></td><td></td><td>PAGE NC</td><td>). 32-2</td></t<>   |  |   |    |   |                      | PAGE NC  | ). 32-2 |
| <ul> <li>A321ceo<br/>(Cont'd)</li> <li>External Power Panel<br/>ADIRU/AVNCS Vent<br/>Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment<br/>Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical<br/>Control,</li> <li>Engine Bump,</li> <li>Thrust Reverser Systems<br/>on ENG 2.</li> </ul> 2) A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484 A 1 0 (M)(O) LGCIU 2 may be inoperative  <br>for 1 flight-day provided:<br>a) BSCU P/N E21327307 is not<br>installed, b) Both radio altimeter systems<br>operate normally, c) Both FCU channels operate<br>normally, d) All ELACs, SECs, ADIRs,<br>SFCCs, and FACs operate<br>normally, e) Flex takeoff is not used,<br>f) LGCIU 2 is deactivated,   | Airbus A320<br><b>32. Landing Ge</b><br>Sequence No. | Item<br>Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2) | 1  |   | 1.<br>2.<br>3.<br>4. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |         |
| A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484<br>MP P22484<br>MO AIRELACS, SECS, ADIRS,<br>SFCCS, and FACS operate<br>normally,<br>e) Flex takeoff is not used,<br>f) LGCIU 2 is deactivated,   | 1)   | A321ceo   |    |   |                      | <ul> <li>External Power Panel<br/>ADIRU/AVNCS Vent<br/>Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment<br/>Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical<br/>Control,</li> <li>Engine Bump,</li> <li>Thrust Reverser Systems</li> </ul>      |         |
|   | 2)   | A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/    | A  | 1 | 0                    | <ul> <li>for 1 flight-day provided:</li> <li>a) BSCU P/N E21327307 is not<br/>installed,</li> <li>b) Both radio altimeter systems<br/>operate normally,</li> <li>c) Both FCU channels operate<br/>normally,</li> <li>d) All ELACs, SECs, ADIRs,<br/>SFCCs, and FACs operate<br/>normally,</li> <li>e) Flex takeoff is not used,</li> </ul> | I       |

| FEDERAL AVIATION ADMINISTRATION         REVISION NO. 32         DATE: XX/XX/XXXX         TABLE KEY         Airbus A320       TABLE KEY         32-31-01       Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)       1       2       3         2)       A319neo/A320neo/A321neo with Mod 165148/ MP J4604 and without Mod 171984/ MP 22484 (Cont'd)       h) The following ass items are conside inoperative:       • CVR ERASE         MP P22484       • Predictive Win Detection and • Fuel Tank Ine System, • Minimum Idle       • Minimum Idle       • Skin Air Outle         • Skin Air Inlet       • Skin Air Inlet       • Skin Air Inlet       • Avionics Equite                              | 1 EQUIPMENT LIST  |
|---|---|
| DATE: XX/XX/XXXX  AIRCRAFT: Airbus A320  TABLE KEY  I. REPAIR CATEGORY  Z. NO. INSTALLED  3. NO. REQUIRED FOR D  4. REMARKS OR EXCEP  32. Landing Gear  Sequence No. Item I 2 3 4  32-31-01 Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)  2) A319neo/A320neo/ A321neo with Mod 171984/ MP J4604 and without Mod 171984/ (Cont'd)  A32484 (Cont'd)  A344  A34  A34  A34  A34  A34  A34  A  |   |
| AIRCRAFT:       1. REPAIR CATEGORY         Airbus A320       1. REPAIR CATEGORY         32. Landing Gear       3. NO. REQUIRED FOR D         32-31-01       Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)       1       2       3         2)       A319neo/A320neo/A321neo with Mod 165148/ MP J4604 and without Mod 171984/ MP P22484 (Cont'd)       h) The following ass items are conside inoperative:         MIP P22484       CVR TEST pt MIP P22484       Fuel Tank Ine System,         (Cont'd)       Kinimum Idle       Ground Extern         AIRCRAFT:       Kinimum Idle       Skin Air Outle  | PAGE NO. 32-3   |
| AIRCRAFT:       1. REPAIR CATEGORY         Airbus A320       NO. REQUIRED FOR D         32. Landing Gear       3. NO. REQUIRED FOR D         32. Landing Gear       1 2 3 4         32-31-01       Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)       h) The following ass items are conside inoperative:         2)       A319neo/A320neo/A321neo with Mod 165148/ MP J4604 and without Mod 171984/ (Cont'd)       h) The following ass items are conside inoperative:         MP P22484 (Cont'd)       CVR ERASE       CVR TEST pt MP P22484 (Cont'd)         K       Himmun Idle       Fuel Tank Ine System, MINIMUM Idle         ADIRU/AVNOC Caution Light, Kin Air Outle       Kin Air Outle |   |
| Sequence No.       Item       1       2       3       4         32-31-01       Landing Gear Control and Interface Unit No. 2 (LGCIU 2) (Cont'd)       h)       The following assitems are considered inoperative:         2)       A319neo/A320neo/A320neo/A321neo with Mod 165148/ MP J4604 and without Mod 171984/ MP P22484 (Cont'd)       h)       The following assitems are considered inoperative:         MP P22484 (Cont'd)       Fuel Tank Inersystem, Minimum Idle       Fuel Tank Inersystem, Minimum Idle       Skin Air Outle         System, ADIRU/AVNC Caution Light, Skin Air Outle       Skin Air Outle       Skin Air Inlet Yes  |   |
| <ul> <li>32-31-01 Landing Gear Control<br/>and Interface Unit No. 2<br/>(LGCIU 2)<br/>(Cont'd)</li> <li>2) A319neo/A320neo/<br/>A321neo with<br/>Mod 165148/<br/>MP J4604 and without<br/>Mod 171984/<br/>MP P22484<br/>(Cont'd)</li> <li>b) The following ass<br/>items are conside<br/>inoperative:</li> <li>c CVR ERASE</li> <li>CVR TEST pt<br/>Predictive Wir<br/>Detection and</li> <li>Fuel Tank Ine<br/>System,</li> <li>Minimum Idle</li> <li>Ground Extern</li> <li>External Powe<br/>ADIRU/AVNC<br/>Caution Light,</li> <li>Skin Air Outle</li> <li>Skin Air Inlet Y</li> </ul>  |   |
| and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd)<br>2) A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>Mod 165148/<br>Mod 171984/<br>MP P22484<br>(Cont'd)  | Change<br>Bar   |
| A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MP P22484<br>(Cont'd)<br>MOD T71984/<br>MINIMUM Idle<br>Ground External<br>External Power<br>ADIRU/AVNO<br>Caution Light,<br>Skin Air Outle<br>Skin Air Inlet   |   |
| Ground Coolii<br>Brake Fan Sy<br>Cargo Doors<br>Control<br>Engine Bump<br>Thrust Revers<br>on ENG 2.<br>NOTE: The BSCU stands<br>be checked by Al<br>32-46-00-740-003<br>Test of the BSCU<br>Identification.<br>(Continued)   | ered<br>pb<br>b,<br>indshear<br>d Avoidance,<br>erting<br>on Ground,<br>rnal Horn,<br>ver Panel<br>CS Vent<br>t,<br>et Valve,<br>ipment<br>ing System,<br>ystem,<br>Electrical<br>o,<br>ser Systems<br>lard P/N can<br>MM TASK<br>03-A BITE |

|                          | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT   | LIST          |
|--------------------------|---|----|---|----------------|--|---------------|
| REVISION NO              |   |    |   |                | PAGE NO  | . 32-4        |
| DATE: XX/XX              | /XXXX   |    |   |                |  |               |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |
| 32. Landing G            | iear  |    | - | 1              |  |               |
| Sequence No.             | Item  | 1  | 2 | 3              | 4  | Change<br>Bar |
| 32-31-01                 | Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd)   |    |   |                |  |               |
| 3)                       | A319neo/A320neo/<br>A321neo without<br>Mod 165148/<br>MP J4604 or<br>A321neo with<br>Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484 | A  | 1 | 0              | <ul> <li>(M)(O) LGCIU 2 may be inoperative for 1 flight-day provided: <ul> <li>a) Both radio altimeter systems operate normally,</li> <li>b) Both FCU channels operate normally,</li> <li>c) All ELACs, SECs, ADIRs, SFCCs, and FACs operate normally,</li> <li>d) Flex takeoff is not used,</li> <li>e) LGCIU 2 is deactivated,</li> <li>f) OAT is below ISA+35 °C,</li> <li>g) The following associated items are considered inoperative: <ul> <li>CVR ERASE pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear Detection and Avoidance,</li> <li>Fuel Tank Inerting System,</li> <li>Minimum Idle on Ground,</li> <li>Ground External Horn,</li> <li>External Power Panel ADIRU/AVNCS Vent Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Avionics Equipment Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical Control</li> <li>Engine Bump, and</li> <li>Thrust Reverser Systems on ENG 2.</li> </ul> </li> </ul></li></ul> |               |

| m<br>inding Gear Control<br>id Interface Unit No. 2<br>GCIU 2)<br>ont'd)                                | 1  | 2<br>T   | 1.<br>2.<br>3.   | MASTER MINIMUM EQUIPMEN<br>PAGE NO<br>E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |   |
|---|--|--|--|--|---|
| m<br>Inding Gear Control<br>Id Interface Unit No. 2<br>GCIU 2)<br>Font'd)                               | 1  |  | 1.<br>2.<br>3.<br>4.   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  | Change  |
| m<br>Inding Gear Control<br>Id Interface Unit No. 2<br>GCIU 2)<br>Font'd)                               | 1  |  | 1.<br>2.<br>3.<br>4.   | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |   |
| inding Gear Control<br>Id Interface Unit No. 2<br>GCIU 2)<br>Iont'd)                                    | 1  |  | 1.<br>2.<br>3.<br>4.   | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |   |
| inding Gear Control<br>Id Interface Unit No. 2<br>GCIU 2)<br>Iont'd)                                    | 1  | 2  | 3  | 4  |   |
| d Interface Unit No. 2<br>GCIU 2)<br>ont'd)   |  |  |  |  | Dai   |
|   |  |  |  |  |   |
| 821neo with<br>od 163213/<br>P J4530 and<br>od 165148/<br>P J4604 and without<br>od 171984/<br>P P22484 | A  | 1  | 0  | <ul> <li>(M)(O) LGCIU 2 may be inoperative for 1 flight-day provided: <ul> <li>a) BSCU P/N E21327307 is not installed,</li> <li>b) Both radio altimeter systems operate normally,</li> <li>c) Both FCU channels operate normally,</li> <li>d) All ELACs, SECs, ADIRs, SFCCs, FACs operate normally,</li> <li>e) Flex takeoff is not used,</li> <li>f) LGCIU 2 is deactivated,</li> <li>g) OAT is below ISA+35 °C, and</li> <li>h) The following associated items are considered inoperative: <ul> <li>CVR ERASE pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear Detection and Avoidance,</li> <li>Fuel Tank Inerting System,</li> <li>Minimum Idle on Ground,</li> <li>Ground External Horn,</li> <li>External Power Panel ADIRU/AVNCS Vent Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment Ground Cooling System,</li> <li>Brake Fan System,</li> </ul> </li> <li>(Continued)</li> </ul></li></ul> | Ι   |
| F   | P J4530 and<br>od 165148/<br>P J4604 and without<br>od 171984/ | P J4530 and<br>od 165148/<br>P J4604 and without<br>od 171984/ | P J4530 and<br>od 165148/<br>P J4604 and without<br>od 171984/ | P J4530 and<br>od 165148/<br>P J4604 and without<br>od 171984/   | <ul> <li>a) BSCÚ P/N E21327307 is not installed,</li> <li>b) Both radio altimeter systems operate normally,</li> <li>c) Both FCU channels operate normally,</li> <li>d) All ELACs, SECs, ADIRs, SFCCs, FACs operate normally,</li> <li>e) Flex takeoff is not used,</li> <li>f) LGCIU 2 is deactivated,</li> <li>g) OAT is below ISA+35 °C, and</li> <li>h) The following associated items are considered inoperative:</li> <li>CVR ERASE pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear Detection and Avoidance,</li> <li>Fuel Tank Inerting System,</li> <li>Minimum Idle on Ground,</li> <li>Ground External Horn,</li> <li>External Power Panel ADIRU/AVNCS Vent Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical</li> </ul> |

| -                        | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |                | MASTER MINIMUM EQUIPMEN   | T LIST  |
|--------------------------|--|----|---|----------------|---|---------|
| REVISION NO              | . 32   |    |   |                | PAGE NO   | D. 32-6 |
| DATE: XX/XX/             | XXXX   |    |   |                |   |         |
| AIRCRAFT:<br>Airbus A320 |  |    | T | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |         |
| 32. Landing Ge           |  |    |   |                |   | Change  |
| Sequence No.<br>32-31-01 | Item<br>Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd)  | 1  | 2 | 3              | 4   | Bar     |
| 4)                       | A321neo with<br>Mod 163213/<br>MP J4530 and<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484<br>(Cont'd)   |    |   |                | <ul> <li>Engine Bump, and</li> <li>Thrust Reverser Systems<br/>on ENG 2.</li> <li>NOTE: The BSCU standard P/N can<br/>be checked by AMM TASK<br/>32-46-00-740-003-A BITE<br/>Test of the BSCU - LRU<br/>Identification.</li> </ul>  |         |
| 5)                       | A321 with<br>Mod 163213/<br>MP J4530 and without<br>Mod 165148/<br>MP J4604 or<br>A321neo with<br>Mod 163213/<br>MP J4530 and<br>Mod 165148/<br>MP J4604 and<br>Mod 171984/<br>MP P22484 | A  | 1 | 0              | <ul> <li>(M)(O) LGCIU 2 may be inoperative<br/>for 1 flight-day provided: <ul> <li>a) Both radio altimeter systems<br/>operate normally,</li> <li>b) Both FCU channels operate<br/>normally,</li> <li>c) All ELACs, SECs, ADIRs,<br/>SFCCs, and FACs operate<br/>normally,</li> <li>d) Flex takeoff is not used,</li> <li>e) LGCIU 2 is deactivated,<br/>OAT is below ISA+35 °C,</li> <li>f) The following associated<br/>items are considered<br/>inoperative: <ul> <li>CVR ERASE pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear<br/>Detection and Avoidance,</li> <li>Fuel Tank Inerting<br/>System,</li> <li>Minimum Idle on Ground,</li> <li>Ground External Horn,</li> </ul> </li> </ul></li></ul> | Ι       |
|                          |  |    |   |                | (Continued)   |         |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |         |  |  |  |
|--|--|---|---|----------------|---|---------|--|--|--|
| REVISION NO<br>DATE: XX/XX/  |  |   |   |                | PAGE NC   | ). 32-7 |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |         |  |  |  |
| 32. Landing G  | ear  | 1 |   |                |   | Change  |  |  |  |
| <u>Sequence No.</u><br>32-31-01<br>5)                                | Item<br>Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd)<br>A321 with<br>Mod 163213/  | 1 | 2 | 3              | External Power Panel<br>ADIRU/AVNCS Vent  | Bar     |  |  |  |
|  | MP J4530 and without<br>Mod 165148/<br>MP J4604 or<br>A321neo with<br>Mod 163213/<br>MP J4530 and<br>Mod 165148/<br>MP J4604 and<br>Mod 171984/<br>MP P22484<br>(Cont'd) |   |   |                | <ul> <li>Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment<br/>Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical<br/>Control</li> <li>Engine Bump, and</li> <li>Thrust Reverser Systems<br/>on ENG 2.</li> </ul>  |         |  |  |  |
| 6)   | A321neo XLR  | A | 1 | 0              | <ul> <li>(M)(O) LGCIU 2 may be inoperative<br/>for 1 flight-day provided: <ul> <li>a) Both radio altimeter systems<br/>operate normally,</li> <li>b) Both FCU channels operate<br/>normally,</li> <li>c) All ELACs, SECs, ADIRs,<br/>SFCCs, and FMGCs operate<br/>normally,</li> </ul> </li> </ul>  | Ι       |  |  |  |
|  |  |   |   |                | <ul> <li>d) Flex takeoff is not used,</li> <li>e) LGCIU 2 is deactivated,</li> <li>f) OAT is below ISA+35 °C,</li> <li>g) Takeoff is performed in<br/>CONF 2A,</li> <li>h) The following associated<br/>items are considered<br/>inoperative: <ul> <li>CVR ERASE pb</li> <li>CVR TEST pb,</li> <li>Predictive Windshear<br/>Detection and Avoidance,</li> <li>Fuel Tank Inerting<br/>System,</li> </ul> </li> </ul> | Ι       |  |  |  |
|  |  |   |   |                | (Continued)   |         |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |    | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|---|---|---|----|--|--|--|--|
| REVISION NO. 32  |   |   |   |    | PAGE NO. 32-8  |  |  |  |
| DATE: XX/XX/XXXX<br>AIRCRAFT:<br>Airbus A320                         |   |   |   |    | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 22 Londing Co  |   |   |   | 4. | REMARKS OR EACEP HONS  |  |  |  |
| 32. Landing Ge<br>Sequence No.                                       | ltem  | 1 | 2 | 3  | 4 Change   |  |  |  |
| 32-31-01   | Landing Gear Control<br>and Interface Unit No. 2<br>(LGCIU 2)<br>(Cont'd) |   | 2 | 3  | * Bar  |  |  |  |
| 6)   | A321neo XLR<br>(Cont'd)   |   |   |    | <ul> <li>Minimum Idle on Ground,</li> <li>Ground External Horn,</li> <li>External Power Panel<br/>ADIRU/AVNCS Vent<br/>Caution Light,</li> <li>Skin Air Outlet Valve,</li> <li>Skin Air Inlet Valve,</li> <li>Avionics Equipment<br/>Ground Cooling System,</li> <li>Brake Fan System,</li> <li>Cargo Doors Electrical<br/>Control</li> <li>Engine Bump, and</li> <li>Thrust Reverser Systems<br/>on ENG 2.</li> </ul> |  |  |  |
| 32-31-02   | Landing Gear Retraction<br>System<br>(except A321neo XLR)                 | В | 1 | 0  | (M)(O) Except for ETOPS, may be<br>inoperative provided the airplane is<br>operated with landing gear down in<br>accordance with the AFM supplement<br>for gear down flight.   |  |  |  |
| 32-33-01   | Landing Gear Gravity<br>Extension System<br>(except A321neo XLR)          | В | 1 | 0  | (M)(O) Except for ETOPS, may be<br>inoperative provided the airplane is<br>operated with landing gear down in<br>accordance with the AFM supplement<br>for gear down flight.   |  |  |  |

| -                             | MENT OF TRANSPORTA            | - |   |               | MASTER MINIMUM EQUIPMENT LIS   |  |  |  |
|-------------------------------|-------------------------------|---|---|---------------|--|--|--|--|
| REVISION NO                   | D. 32                         |   |   | PAGE NO. 32-9 |  |  |  |  |
| DATE: XX/XX                   | /XXXX                         |   |   |               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320      |                               |   |   |               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 32. Landing G<br>Sequence No. | ltem                          | 1 | 2 | 3             | 4 Chang  |  |  |  |
| 32-41-01                      | Wheel Tie Bolts               | A | - | -             | <ul> <li>(M) One bolt may be broken or missing provided: <ul> <li>a) Affected wheel is removed, checked for broken parts or damage, and replaced if broken parts or damage is found,</li> <li>b) For the main wheel, associated brake is checked for broken parts or damage and is replaced or deactivated if broken parts or damage is found,</li> <li>c) After each landing, wheel is inspected for additional broken or missing tie bolts, and</li> <li>d) Repairs are made within 5 flight-legs.</li> </ul></li></ul>  |  |  |  |
| 32-42-01                      | Main Wheel Braking<br>Systems | C | 4 | 3             | <ul> <li>(M)(O) One brake may be inoperative provided: <ul> <li>a) Minimum runway width is 148 ft. (45 meters),</li> <li>b) Antiskid system operates normally,</li> <li>c) Nose wheel steering operates normally,</li> <li>d) Affected brake is removed or deactivated,</li> <li>e) Both reversers operate normally,</li> <li>f) Green and yellow systems on operative brakes operate normally,</li> <li>g) AFM performance penalties are applied,</li> <li>h) Approach minimums do not require its use, and</li> <li>i) The AUTO/BRK Function is considered inoperative.</li> </ul> </li> </ul> |  |  |  |

| FEDERAL AVIATION ADMINISTRATION     |                      |   |    |   | MASTER MINIMUM EQUIPMENT LIS  |  |
|-------------------------------------|----------------------|---|----|---|---|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |                      |   |    |   | PAGE NO. 32-1   |  |
| AIRCRAFT:<br>Airbus A320            |                      |   | Т. | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |
| 32. Landing Go<br>Sequence No.      | Item                 | 1 | 2  | 3   | 4 Chan  |  |
| 32-42-02                            | Green Braking System | 1 | -  | •   | Bar   |  |
| 1)                                  | Without Mod. 25410   | С | 1  | 1   | <ul> <li>(M)(O) Braking on one wheel may be inoperative provided: <ul> <li>a) Minimum runway width is 148 ft. (45 meters),</li> <li>b) Green hydraulic supply to affected brake is deactivated,</li> <li>c) Antiskid system operates normally,</li> <li>d) Nose wheel steering operates normally,</li> <li>e) Both reversers operate normally,</li> <li>f) Wheel tachometers are verified to operate normally before each flight, and</li> <li>g) AFM performance penalties are applied.</li> </ul> </li> </ul> |  |
| 2)                                  | With Mod. 25410      | С | 1  | 1   | <ul> <li>(M)(O) Braking on one wheel may be inoperative provided: <ul> <li>a) Minimum runway width is 148 ft. (45 meters),</li> <li>b) Green hydraulic supply to affected brake is deactivated,</li> <li>c) Antiskid system operates normally,</li> <li>d) Nose wheel steering operates normally,</li> <li>e) Both reversers operate normally,</li> <li>f) Wheel tachometers are operative, and</li> <li>g) AFM performance penalties are applied.</li> </ul> </li> </ul>                                       |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |                |          | MASTER MINIMUM EQUIPMENT  | T LIST |  |
|--|---|---|----------------|----------|---|--------|--|
| REVISION NO  | . 32  |   | PAGE NO. 32-11 |          |   |        |  |
| DATE: XX/XX/   | XXXX  |   |                |          |   |        |  |
| AIRCRAFT:<br>Airbus A320   |   |   |                |          | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |        |  |
| 32. Landing G  |   | 1 | 2              | <b>_</b> | 4   | Change |  |
| Sequence No.<br>32-42-03   | Item<br>Braking/Steering Control<br>Unit (BSCU)<br>Channels/Systems |   | 2              | 3        | 4   | Bar    |  |
| 1)   | Channel 1/System 1  |   |                |          |   |        |  |
| a)   | Aircraft without<br>Mod. 165148/<br>MP J4604                        | С | 1              | 0        | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Alternate brake system is verified to operate normally before each departure,</li> <li>b) Brake pressure indicators operate normally,</li> <li>c) The affected channel/system is deactivated,</li> <li>d) Prior to each flight, the CFDS does not indicate an L/G SYS DISAGREE caution,</li> <li>e) Channel 2/System 2 is operative, and</li> <li>f) The AUTO/BRK (LO, MED, MAX) pb-sw DECEL lights and the AUTO/BRK (LO, MED, MAX) pb-sw ON lights are considered inoperative.</li> </ul> </li> </ul> |        |  |
|  |   |   |                |          | (Continued)   |        |  |

| -                        | ATION ADMINISTRATION   | JIN |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |  |
|--------------------------|--|-----|---|-------------------------------|--|--|--|--|--|
| REVISION NO. 32          |  |     |   |                               | PAGE NO. 32-12   |  |  |  |  |
| DATE: XX/XX/X            |  |     |   |                               |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |     | Т | 1.<br>2.                      | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |  |
|                          |  |     |   | -                             | REMARKS OR EXCEPTIONS  |  |  |  |  |
| 32. Landing Ge           | ear  |     |   |                               |  |  |  |  |  |
| Sequence No.             | ltem   | 1   | 2 | 3                             | 4 Change<br>Bar  |  |  |  |  |
| 32-42-03                 | Braking/Steering Control<br>Unit (BSCU)<br>Channels/Systems<br>(Cont'd)  |     |   |                               |  |  |  |  |  |
| 1)                       | Channel 1/System 1<br>(Cont'd)   |     |   |                               |  |  |  |  |  |
| b)                       | A318/A319ceo/A320ceo/<br>A321ceo with<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11)<br>or<br>A319neo/A320neo/<br>A321neo with<br>Mod 171984/<br>MP P22484 and either<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11) | С   | 1 | 0                             | <ul> <li>M)(O) May be inoperative provided:</li> <li>a) Alternate brake system is verified to operate normally before each departure,</li> <li>b) Brake pressure indicators operate normally,</li> <li>c) The affected channel/system is deactivated,</li> <li>d) Prior to each flight, the CFDS does not indicate an L/G SYS DISAGREE caution,</li> <li>e) Channel 2/System 2 is operative,</li> <li>f) The AUTO/BRK (LO, MED, MAX) pb-sw DECEL lights and the AUTO/BRK (LO, MED, MAX) pb-sw ON lights are considered inoperative, and</li> <li>g) Landing gear is kept extended for 1 minute after takeoff.</li> </ul> |  |  |  |  |
|                          |  |     |   |                               | (Continued)  |  |  |  |  |

| FEDERAL AVI                    | ATION ADMINISTRATION  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------------|---|---|---|-------------------------------|--|--|--|--|
| REVISION NO. 32                |   |   |   |                               | PAGE NO. 32-13   |  |  |  |
| DATE: XX/XX/                   | XXXX  |   |   |                               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320       |   |   |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 32. Landing Ge<br>Sequence No. | ltem  | 1 | 2 | 3                             | 4 Change   |  |  |  |
| 32-42-03                       | Braking/Steering Control<br>Unit (BSCU)<br>Channels/Systems<br>(Cont'd)   | 1 | 2 | 3                             | 4 Bar  |  |  |  |
| 1)                             | Channel 1/System 1<br>(Cont'd)  |   |   |                               |  |  |  |  |
| с)                             | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11)<br>and without<br>Mod 171984/<br>MP P22484 | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) BSCU P/N E21327307 or P/N E21327308 is not installed,</li> <li>b) Alternate brake system is verified to operate normally before each departure,</li> <li>c) Brake pressure indicators operate normally,</li> <li>d) Affected channel/system is deactivated,</li> <li>e) Prior to each flight, the CFDS does not indicate an L/G SYS DISAGREE caution,</li> <li>f) Channel 2/System 2 is operative,</li> <li>g) The AUTO/BRK (LO, MED, MAX) pb-sw DECEL lights and the AUTO/BRK (LO, MED, MAX) pb-sw ON lights are considered inoperative, and</li> <li>h) Landing gear is kept extended for 1 minute after takeoff.</li> </ul> </li> <li>NOTE: The BSCU standard P/N can be checked by AMM TASK 32-46-00-740-003-A BITE Test of the BSCU - LRU Identification.</li> </ul> |  |  |  |
|                                |   |   |   |                               | (Continued)  |  |  |  |

|                                | MENT OF TRANSPORTATION   | NC |   |          | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--------------------------------|--|----|---|----------|--|--|--|--|
| REVISION NO                    |  |    |   |          |  |  |  |  |
| DATE: XX/XX/                   | -  |    |   |          | PAGE NO. 32-14   |  |  |  |
|                                |  |    | Т |          | E KEY<br>REPAIR CATEGORY   |  |  |  |
| AIRCRAFT:<br>Airbus A320       |  |    |   | 2.<br>3. | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |
|                                |  |    |   | 4.       | REMARKS OR EXCEPTIONS  |  |  |  |
| 32. Landing Ge<br>Sequence No. | ear<br>Item  | 1  | 2 | 3        | 4 Change   |  |  |  |
| 32-42-03                       | Braking/Steering Control<br>Unit (BSCU)<br>Channels/Systems<br>(Cont'd)  |    | 2 | 3        | ₩ Bar  |  |  |  |
| 2)                             | Channel 2/System 2   |    |   |          |  |  |  |  |
| a)                             | Aircraft without<br>Mod 165148/<br>MP J4604  | С  | 1 | 0        | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Alternate brake system is verified to operate normally before each departure,</li> <li>b) Brake pressure indicators operate normally,</li> <li>c) The affected channel/system is deactivated,</li> <li>d) Prior to each flight, the CFDS does not indicate an L/G SYS DISAGREE caution, and</li> <li>e) Channel 1/System 1 is operative.</li> </ul> </li> </ul>   |  |  |  |
| b)                             | A318/A319ceo/A320ceo/<br>A321ceo with<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11)<br>or<br>A319neo/A320neo/<br>A321neo with<br>Mod 171984/<br>MP P22484 and either<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11) | С  | 1 | 0        | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Alternate brake system is verified to operate normally before each departure,</li> <li>b) Brake pressure indicators operate normally,</li> <li>c) The affected channel/system is deactivated,</li> <li>d) Prior to each flight, the CFDS does not indicate an L/G SYS DISAGREE caution,</li> <li>e) Channel 1/System 1 is operative, and</li> <li>f) Landing gear is kept extended for 1 minute after takeoff.</li> </ul></li></ul> |  |  |  |
|                                |  |    |   |          | (Continued)  |  |  |  |

| -  | VENT OF TRANSPORTATION  | ON |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|---|----|---|---|---|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/                  |   |    |   |   | PAGE NO. 32-15  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320<br>32. Landing Gear |   |    |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS   |  |  |  |  |
| Sequence No.                                 | Item  | 1  | 2 | 3 | 4 Change<br>Bar   |  |  |  |  |
| 32-42-03                                     | Braking/Steering Control<br>Unit (BSCU)<br>Channels/Systems<br>(Cont'd)   |    |   |   |   |  |  |  |  |
| 2)   | Channel 2/System 2<br>(Cont'd)  |    |   |   |   |  |  |  |  |
| c)   | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 or<br>Mod 170252/<br>MP J7041 (BSCU L4.11)<br>and without<br>Mod 171984/<br>MP P22484 | С  | 1 | 0 | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) BSCU P/N E21327307 or<br/>P/N E21327308 is not<br/>installed,</li> <li>b) Alternate brake system is<br/>verified to operate normally<br/>before each departure,</li> <li>c) Brake pressure indicators<br/>operate normally,</li> <li>d) Affected channel/system is<br/>deactivated,</li> <li>e) Prior to each flight, the CFDS<br/>does not indicate an L/G SYS<br/>DISAGREE caution,</li> <li>f) Channel 1/System 1 is<br/>operative, and</li> <li>g) Landing gear is kept extended<br/>for 1 minute after takeoff.</li> <li>NOTE: The BSCU standard P/N can<br/>be checked by AMM TASK<br/>32-46-00-740-003-A BITE<br/>Test of the BSCU - LRU<br/>Identification.</li> </ul> |  |  |  |  |

| -                           | MENT OF TRANSPORTATION                          | ON     |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------------------|---|--------|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/ |   |        |   |                | PAGE NO. 32-16   |
| AIRCRAFT:<br>Airbus A320    |   |        | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 32. Landing Go              |   |        |   |                | change   |
| Sequence No.<br>32-42-04    | Item<br>AUTO/BRK Function                       | 1<br>C | 2 | 3<br>0         | <ul> <li>Content of the second se</li></ul> |
| 1)                          | AUTO/BRK Panel Mode<br>Lights<br>(LO, MED, MAX) |        |   |                |  |
| a)                          | ON  | С      | 3 | 0              | May be inoperative provided<br>Autobrake Indications on ECAM<br>WHEEL page normally.   |
|                             |   | С      | 3 | 0              | May be inoperative provided<br>associated Autobrake Mode is not<br>used.   |
| b)                          | DECEL   | С      | 3 | 0              | May be inoperative provided<br>Autobrake indications on ECAM<br>WHEEL page operate normally.   |
|                             |   | С      | 3 | 0              | May be inoperative provided<br>associated Autobrake Mode is not<br>used.   |

| U.S. DEPARTM                    | IENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|---------------------------------|---|----|---|----------------|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |   |                |  |  |  |  |  |
| REVISION NO.                    |   |    |   | PAGE NO. 32-17 |  |  |  |  |  |
| DATE: XX/XX/X                   | XXX   |    |   |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |    |   |                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 32. Landing Ge                  | ar  |    | L |                |  |  |  |  |  |
| Sequence No.                    | Item  | 1  | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 32-42-05                        | Tachometer<br>(Aircraft with<br>Mod. 157591/<br>MP J4030<br>(BSCU STD L4.10)) | C  | 4 | 3              | <ul> <li>(O) One may be inoperative provided: <ul> <li>a) Both LGCIU are operative,</li> <li>b) All SECs are operative,</li> <li>c) All ground spoilers are operative,</li> <li>d) Crosswind component is below 10 kt at departure airport and below 15 kt at arrival airport,</li> <li>e) Takeoff runway state is no more than wet,</li> <li>f) AFM Performance penalties are applied,</li> <li>g) BSCU L4.9B <ul> <li>(P/Ns E21327006/E21327106) has not been installed by interchangeability, and</li> <li>h) Affected brake is considered inoperative.</li> </ul> </li> <li>NOTE: BSCU standard P/N can be checked by BITE Test of BSCU – LRU Identification.</li> </ul></li></ul> |  |  |  |  |
| 32-42-06                        | Nose Wheel Brake Pads<br>(Without Mod. 28482)                                 | С  | 2 | 0              | (M) May be inoperative provided brake pads are removed.  |  |  |  |  |

| -                             | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT   | LIST   |
|-------------------------------|--|----|---|----------------|--|--------|
| REVISION NC<br>DATE: XX/XX/   |  |    |   |                | PAGE NO. 3   | 2-18   |
| AIRCRAFT:<br>Airbus A320      |  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |
| 32. Landing G<br>Sequence No. | ltem   | 1  | 2 | 3              | 4  | Change |
| 32-44-01                      | Yellow Brake System  |    | 2 | 3              |  | Bar    |
| 1)                            | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484  | С  | 1 | 1              | <ul> <li>(M) Braking on one wheel may be inoperative provided: <ul> <li>a) The BSCU P/N E21327307 is not installed,</li> <li>b) Yellow hydraulic supply of affected brake is deactivated, and</li> <li>c) Both reversers operate normally.</li> </ul> </li> <li>NOTE: The BSCU standard P/N can be checked by AMM TASK 32-46-00-740-003-A BITE Test of the BSCU - LRU Identification.</li> </ul> |        |
| 2)                            | A318/A319ceo/A320ceo<br>A321ceo or<br>A319neo/A320neo/<br>A321neo without<br>Mod 165148/<br>MP J4604 or<br>A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>J4604 and with<br>Mod 171984/<br>MP P22484 | С  | 1 | 1              | <ul> <li>(M) Braking on one wheel may be inoperative provided: <ul> <li>a) Yellow hydraulic supply of affected brake is deactivated, and</li> <li>b) Both reversers operate normally.</li> </ul> </li> </ul>   |        |

| _   | TMENT OF TRANSPORTATI<br>/IATION ADMINISTRATION               | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|---|---|----|---|-------------------------------|---|--|--|
| REVISION N<br>DATE: XX/X>                           |   |    |   |                               | PAGE NO. 32-19  |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>32. Landing Gear</b> |   |    |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| Sequence No.  | Item  | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |
| 32-44-02<br>1)                                      | ACCU PRESS Indicator<br>Without Mod. 31441<br>With Mod. 31441 | С  | 1 | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Both brake pressure<br/>indicators operate normally,<br/>and</li> <li>b) Pressure on both brake<br/>pressure indicators is verified<br/>with parking brake on.</li> </ul>                                     |  |  |
| 2)  | With Mod. 31441   |    |   | U                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Both brake pressure<br/>indicators operate normally,<br/>and</li> <li>b) Pressure on both brake<br/>pressure indicators is verified<br/>with parking brake on.</li> </ul>                                     |  |  |
|   |   | С  | 1 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) ACCU PRESS/ACCU ONLY<br/>indication is available on<br/>ECAM WHEEL page, and</li> <li>b) Hydraulic pressure of the<br/>brake accumulator is checked<br/>on ECAM WHEEL page<br/>before each flight.</li> </ul> |  |  |

| -                        | MENT OF TRANSPORTATIO  |   | MASTER MINIMUM EQUIPMENT LIST |                |   |  |  |
|--------------------------|--|---|-------------------------------|----------------|---|--|--|
| FEDERAL AV               | VIATION ADMINISTRATION   |   | PAGE NO. 32-20                |                |   |  |  |
| DATE: XX/XX              | /XXXX  |   |                               |                |   |  |  |
| AIRCRAFT:<br>Airbus A320 |  |   | T.                            | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 32. Landing G            | Gear   |   | <u> </u>                      |                |   |  |  |
| Sequence No.             | ltem   | 1 | 2                             | 3              | 4 Change<br>Bar   |  |  |
| 32-44-03                 | BRAKES Pressure<br>Indicators  |   |                               |                |   |  |  |
| 1)                       | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484  | С | 2                             | 1              | <ul> <li>(O) One may be inoperative provided:</li> <li>a) The BSCU P/N E21327307 is<br/>not installed, and</li> <li>b) Both BSCU channels/systems<br/>operate normally.</li> <li>NOTE: The BSCU standard P/N can<br/>be checked by AMM TASK<br/>32-46-00-740-003-A BITE<br/>Test of the BSCU - LRU<br/>Identification.</li> </ul> |  |  |
| 2)                       | A318/A319ceo/A320ceo/<br>A321ceo or<br>A319neo/A320neo/<br>A321neo without<br>Mod 165148/<br>MP J4604 or<br>A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484 | С | 2                             | 1              | (O) One may be inoperative provided<br>both BSCU channels/systems<br>operate normally   |  |  |
| 32-45-02                 | Parking Brake External<br>Light  | С | 1                             | 0              | May be inoperative provided parking<br>brake status is verified before moving<br>aircraft.  |  |  |
| 32-47-01                 | Brake Temperature<br>Monitoring Unit   | С | 2                             | 0              | (M)(O) May be inoperative provided brake ground cooling time is applied.  |  |  |
| 32-48-01<br>***          | Brake Fan System   | D | 1                             | 0              | May be inoperative.   |  |  |
| 1)                       | Brake Fan  | D | 4                             | 0              | (M) May be inoperative provided affected pair of fans is deactivated.   |  |  |
| 32-48-02<br>***          | BRAKE FAN HOT Light  | D | 1                             | 0              | May be inoperative.   |  |  |

| _                            | MENT OF TRANSPORTATION                  |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |  |
|------------------------------|---|---|-------------------------------|----------------|--|--|--|
| REVISION NO<br>DATE: XX/XX/2 |   |   | PAGE NO. 32-21                |                |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |   | T                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 32. Landing Ge               | ear                                     |   | <u>I</u>                      |                |  |  |  |
| Sequence No.                 | Item                                    | 1 | 2                             | 3              | 4 Change<br>Bar  |  |  |
| 32-48-03<br>***              | BRK FAN ON Light                        | D | 1                             | 0              | NOTE: Brake Fan operation may be<br>checked through the brake fan ECAM<br>MEMO.  |  |  |
| 32-49-01<br>***              | ECAM Tire Pressure<br>Indications       | D | 6                             | 0              | One or more may be inoperative.  |  |  |
| 32-49-02<br>***              | Tire Pressure Monitoring<br>System      | D | 1                             | 0              | (M) May be inoperative on one or<br>more wheels provided the tire<br>pressure on affected wheel(s) is<br>checked every 3 days.   |  |  |
| 32-49-03                     | Warning and Caution on ECAM EWD         |   |                               |                |  |  |  |
| 1)<br>***                    | WHEEL TYRE LO PR<br>Caution on ECAM EWD | D | 1                             | 0              | <ul> <li>(M) May be inoperative on one or more wheels provided: <ul> <li>a) Associated pressure monitoring channel is deactivated if the WHEEL TYRE LO PR caution was triggered erroneously, and</li> <li>b) Tire pressure on affected wheel is checked to be within limits before the first flight and then every 3 calendar-days.</li> </ul> </li> </ul> |  |  |
|                              |   | D | 1                             | 0              | <ul> <li>(M) May be inoperative on all wheels provided:</li> <li>a) The Tire Pressure Indicating Computer (TPIC) is deactivated if the WHEEL TYRE LO PR Caution was triggered erroneously, and</li> <li>b) The tire pressure on each wheel is checked to be within the limits before the first flight and then every 3 calendar-days.</li> </ul>           |  |  |
| 32-51-02                     | PEDALS DISC pb                          | С | 2                             | 0              | (O) May be inoperative in the<br>released position (no disconnection<br>possible and NWS still available by<br>rudder pedals).   |  |  |

| U.S. DEPARTI             | MENT OF TRANSPORTATION   | ON     |                               |                |  |  |
|--------------------------|--|--------|-------------------------------|----------------|--|--|
| FEDERAL AVI              | ATION ADMINISTRATION   |        | MASTER MINIMUM EQUIPMENT LIST |                |  |  |
| REVISION NO              |  |        |                               | PAGE NO. 32-22 |  |  |
| DATE: XX/XX/             | XXXX   |        | L                             |                |  |  |
| AIRCRAFT:<br>Airbus A320 |  |        | T                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |
| 32. Landing G            | ear  |        |                               |                | Change   |  |
| Sequence No.<br>32-51-03 | Item<br>Nose Wheel Steering<br>Control System<br>Deactivation Device<br>(For A/C Towing) | 1<br>C | 2                             | 3<br>0         | 4 Change<br>Bar<br>(O) May be inoperative (no towing<br>Mode when lever in TOWING<br>position).  |  |
|                          |  | С      | 1                             | 0              | (M)(O) May be inoperative provided<br>the NWS electrical deactivation box is<br>deactivated.   |  |
| 32-60-01                 | LDG Gear Indicator<br>Panel<br>(UNLK and/or Down and<br>Locked Triangle<br>Indications)  | В      | 1                             | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both landing gear position<br/>indications (on ECAM wheel<br/>page) for all three landing<br/>gear operate normally, and</li> <li>b) Upper and lower ECAM<br/>display units operate<br/>normally.</li> </ul> |  |
| 32-60-02                 | Gear Not Down<br>Indication  |        |                               |                |  |  |
| 1)                       | Red DOWN Arrow Light   | В      | 1                             | 0              | (M) May be inoperative provided<br>GEAR NOT DOWN caution on ECAM<br>operates normally.   |  |
| 32-60-03                 | ECAM Wheel Page<br>Indications   |        |                               |                |  |  |
| 1)                       | UP LOCK  | С      | 3                             | 0              | One or more may be inoperative.  |  |
| 2)                       | L/G Doors  | С      | 3                             | 0              | May be inoperative provided MAX<br>SPEED is limited to 250 kts/M .60.  |  |
| 3)                       | L/G CTL  | С      | 1                             | 0              | May be inoperative.  |  |
| 4)                       | REL  | С      | 4                             | 0              | One or more may be inoperative.  |  |
| 5)                       | ANTI SKID/ANTI SKID<br>[1,2]   | С      | -                             | 0              | (M) May be inoperative provided antiskid system operates normally.   |  |
|                          |  |        |                               |                | (Continued)  |  |

| -                        | MENT OF TRANSPORTAT                          |   |   | MASTER MINIMUM EQUIPMENT LIST |   |
|--------------------------|--|---|---|-------------------------------|---|
| REVISION NC              | IATION ADMINISTRATION                        |   |   | PAGE NO. 32-23                |   |
| DATE: XX/XX/             | /XXXX  |   |   |                               |   |
| AIRCRAFT:<br>Airbus A320 |  |   |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 32. Landing G            | ear  |   |   | T                             |   |
| Sequence No.             | Item   | 1 | 2 | 3                             | 4 Change<br>Bar   |
| 32-60-03                 | ECAM Wheel Page<br>Indications<br>(Cont'd)   |   |   |                               |   |
| 6)                       | AUTO BRK                                     | С | 1 | 0                             | (O) May by inoperative provided<br>Autobrake Mode Lights operate<br>normally.   |
|                          |  | С | 1 | 0                             | May be inoperative provided<br>AUTO/BRK Function is not used.   |
| 7)                       | Brakes Temperatures                          |   |   |                               |   |
| a)                       | All aircraft except<br>A321neo XLR           | с | 4 | 0                             | (M)(O) May be inoperative provided ground brake cooling time is applied.  |
| b)                       | A321neo XLR                                  | С | 4 | 2                             | (M)(O) One brake temperature<br>indication per landing gear may be<br>inoperative provided ground brake<br>cooling time is applied.                                     |
|                          |  | С | 4 | 0                             | Both brake temperature indications<br>on the same landing gear may be<br>inoperative provided both Brake<br>Temperature Monitoring Units are<br>considered inoperative. |
| 8)                       | L/G Position                                 | С | 6 | 3                             | May be inoperative provided gear<br>position indications are available on<br>landing gear indicator panel.  |
| 9)                       | [Y] N/W STEERING<br>(With Mod. 31441)        | С | 2 | 0                             | One or both may be inoperative.   |
| 10)                      | [G] NORM BRK<br>(With Mod. 31441)            | С | 2 | 0                             | One or both may be inoperative.   |
| 11)                      | [Y] ALTN BRK<br>(With Mod. 31441)            | С | 2 | 0                             | One or both may be inoperative.   |
| 12)                      | ACCU PRESS/ACCU<br>ONLY<br>(With Mod. 31441) | С | 1 | 0                             | May be inoperative.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|--|---|---|----------------|--|--|--|--|
| REVISION NO.<br>DATE: XX/XX/X  |  |   |   |                | PAGE NO. 32-24   |  |  |  |
|  |  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |
| 32-60-04   | Fault(s) Indicated by<br>BRAKES N/WS MINOR<br>FAULT Caution on<br>ECAM EWD   |   |   |                |  |  |  |  |
| 1)   | A318/A319ceo/A320ceo/<br>A321ceo with<br>Mod. 26925/MP P4576<br>(Alt. Braking)<br>and without Mod. 38973/<br>MP P10891<br>(BSCU STD L4.9B) | В |   |                | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Caution BRAKES N/WS</li> <li>MINOR FAULT is confirmed to be caused by a fault on an alternate braking system pressure transducer by troubleshooting,</li> <li>b) BSCU system 1 and system 2 operate normally, and</li> <li>c) It is checked prior to each departure that the following CFDS failure messages related to BRAKES N/WS MINOR FAULT are not displayed: <ul> <li>A fault on the Alternate Braking Control Unit (ABCU),</li> <li>A fault on the Alternate Braking Selector Valve,</li> <li>A fault on the Alternate Braking Selector Valve, or</li> <li>A degraded pressure on an Alternate Servo-valve.</li> </ul> </li> </ul></li></ul> |  |  |  |

| -                        | MENT OF TRANSPORTATION   | NC |                |   | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|----|----------------|---|---|
| REVISION NO              |  |    |                | PAGE NO. 32-25  |   |
| DATE: XX/XX/             | XXXX   |    |                |   |   |
| AIRCRAFT:<br>Airbus A320 |  | T  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |   |
| 32. Landing Ge           |  |    |                |   | A Change  |
| Sequence No.<br>32-60-04 | Item<br>Fault(s) Indicated by<br>BRAKES N/WS MINOR<br>FAULT Caution on<br>ECAM EWD<br>(Cont'd)   | 1  | 2              | 3   | 4 Change<br>Bar   |
| 1)                       | A318/A319ceo/A320ceo/<br>A321ceo with<br>Mod. 26925/MP P4576<br>(Alt. Braking)<br>and without Mod. 38973/<br>MP P10891<br>(BSCU STD L4.9B)<br>(Cont'd) | В  | -              | _   | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) BRAKES pressure indicators operate normally,</li> <li>b) Alternate braking system is checked operative before the first flight of each day, and</li> <li>c) It is checked prior to each departure that the following CFDS failure messages related to BRAKES N/WS MINOR FAULT are not displayed: <ul> <li>A fault on the Alternate Braking Control Unit (ABCU),</li> <li>A fault on the Alternate</li> </ul> </li> </ul></li></ul> |
|                          |  |    |                |   | <ul> <li>Braking Selector Valve,</li> <li>A fault on the Alternate<br/>Braking Servo-valve,</li> <li>A fault on the Alternate<br/>Pressure Transducer, or</li> <li>A degraded pressure on<br/>an Alternate Servo-valve.</li> </ul>  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|---|---|----------------|---|
| REVISION NO.<br>DATE: XX/XX/2  |   |   |   |                | PAGE NO. 32-26  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 32. Landing Ge   | ar  |   |   |                |   |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar   |
| 32-60-04   | Fault(s) Indicated by<br>BRAKES N/WS MINOR<br>FAULT Caution on<br>ECAM EWD<br>(Cont'd)  |   |   |                |   |
| 2)   | A318/A319ceo/A320ceo/<br>A321ceo with<br>Mod. 26925/MP P4576<br>(Alt Braking)<br>and with Mod. 38973/<br>MP P10891<br>(BSCU STD L4.9B) and<br>A319neo/A320neo/<br>A321neo | В | - | -              | <ul> <li>May be inoperative provided:</li> <li>a) Caution BRAKES N/WS<br/>MINOR FAULT is confirmed<br/>to be caused by a fault on an<br/>alternate braking system<br/>pressure transducer by<br/>troubleshooting, and</li> <li>b) BSCU system 1 and system<br/>2 operate normally.</li> </ul>   |
|  |   | В | - | -              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) BRAKES pressure indicators operate normally,</li> <li>b) Alternate braking system is checked operative before the first flight of each day, and</li> <li>c) It is checked prior to each departure that the following CFDS failure message related to BRAKES N/WS MINOR FAULT is not displayed: <ul> <li>A fault on an Alternate Pressure Transducer, or</li> <li>A fault on a Normal Pressure Transducer.</li> </ul> </li> </ul></li></ul> |
| 32-60-07<br>***  | Integral Tire Pressure<br>Indicators  | D | - | 0              | One or more may be inoperative.   |

| -  | VENT OF TRANSPORTATION                          | ON |   |                | MASTER MINIMUM EQUIPMENT LIS  |
|--|---|----|---|----------------|---|
| REVISION NO. 30                              |   |    |   |                | PAGE NO. 33   |
| DATE: 03/03/2023<br>AIRCRAFT:<br>Airbus A320 |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 33. Lights                                   |   |    |   |                |   |
| Sequence No.                                 | Item  | 1  | 2 | 3              | 4 Char  |
| 33-10-01                                     | Cockpit and Instrument<br>Panel Lighting System |    | - |                | Ba  |
| 1)   | Aircraft with Mod. 27620/<br>MP P5638<br>(ISIS) | C  |   |                | <ul> <li>Individual lights may be inoperative provided: <ul> <li>a) Remaining lights are sufficient to clearly illuminate all required instruments, controls, and other devices for which they are provided,</li> <li>b) Remaining lights are positioned so that direct rays are shielded from flight crewmembers' eyes,</li> <li>c) Lighting configuration and intensity is acceptable to the flightcrew, and</li> <li>d) RH dome light is operative.</li> </ul> </li> <li>NOTE 1: RH dome light is considered operative with a minimum of three bulbs illuminated in each incandescent assembly. RH dome light is considered operative with all LED segments operational in LED assembly. The bulbs can be checked by selecting the DOME toggle switch from OFF (LED), to DIM to BRT and ensure all functions operate.</li> <li>NOTE 2: Individual button/switch lights and/or annunciations and indications are excluded from this relief.</li> <li>NOTE 3: Unaided operation (without NVGs) may be permitted with inoperative NVG supplemental lights; cracked or missing filters.</li> </ul> |

| -  |  | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|----|---|---|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 30<br>DATE: 03/03/2023 |  |    |   |   | PAGE NO. 33-2  |  |  |  |  |
|  |  |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 33. Lights   |  |    |   |   |  |  |  |  |  |
| Sequence No.   | ltem   | 1  | 2 | 3 | 4 Change<br>Bar  |  |  |  |  |
| 33-10-01   | Cockpit and Instrument<br>Panel Lighting System<br>(Cont'd)  |    |   |   |  |  |  |  |  |
| 2)   | Aircraft with Mod. 27140/<br>MP P4801<br>(EEPGS)<br>or with Mod. 37329/<br>MP P10166 or with<br>Mod. 37330/MP P10167<br>and without<br>Mod. 27620/MP P5638<br>(ISIS) | C  |   |   | <ul> <li>Individual lights may be inoperative provided: <ul> <li>a) Remaining lights are sufficient to clearly illuminate all required instruments, controls, and other devices for which they are provided,</li> <li>b) Remaining lights are positioned so that direct rays are shielded from flight crewmembers' eyes,</li> <li>c) Lighting configuration and intensity is acceptable to the flightcrew,</li> <li>d) RH dome light is operative, and</li> <li>e) The left section of the center main panel flood light operates normally.</li> </ul> NOTE 1: RH dome light is considered operative with a minimum of three bulbs illuminated in each assembly The bulbs can be checked by selecting the DOME toggle switch from DIM to BRT and ensure both functions operate. NOTE 2: Individual buttons/switch lights and/or annunciations and indications are excluded from this relief. NOTE 3: Unaided operation (without NVGs) may be permitted with inoperative NVG supplemental lights; cracked or missing filters.</li></ul> |  |  |  |  |

| -  |   |   | MASTER MINIMUM EQUIPMENT LIST |                |   |  |  |  |  |
|--|---|---|-------------------------------|----------------|---|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 30 |   |   |                               |                | PAGE NO. 33-3   |  |  |  |  |
| DATE: 03/03/2                                      | 2023  |   |                               |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320                           |   |   | Т                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 33. Lights   |   | 1 |                               |                |   |  |  |  |  |
| Sequence No.                                       | Item  | 1 | 2                             | 3              | 4 Change<br>Bar   |  |  |  |  |
| 33-10-01   | Cockpit and Instrument<br>Panel Lighting System<br>(Cont'd)   |   |                               |                |   |  |  |  |  |
| 3)   | Aircraft without<br>Mod. 27140/MP P4801<br>(EEPGS)<br>or without<br>Mod. 27620/MP P5638<br>(ISIS)<br>or without<br>Mod. 37329/MP P10166<br>or without<br>Mod. 37330/MP P10167 | C |                               |                | <ul> <li>Individual lights may be inoperative provided: <ul> <li>a) Remaining lights are sufficient to clearly illuminate all required instruments, controls, and other devices for which they are provided,</li> <li>b) Remaining lights are positioned so that direct rays are shielded from flight crewmembers' eyes,</li> <li>c) Lighting configuration and intensity is acceptable to the flightcrew,</li> <li>d) Both dome lights are operative, and</li> <li>e) The left section of the center main panel flood light operates normally.</li> </ul> </li> <li>NOTE 1: Dome lights are considered operative with a minimum of three bulbs illuminated in each assembly. The bulbs can be checked by selecting the DOME toggle switch from DIM to BRT and ensure both functions operate.</li> <li>NOTE 2: Individual buttons/switch lights and/or annunciations and indications are excluded from this relief.</li> <li>NOTE 3: Unaided operation (without NVGs) may be permitted with inoperative NVG supplemental lights; cracked or missing filters.</li> </ul> |  |  |  |  |

| -                        | MENT OF TRANSPORTAT  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|--------------------------|--|---|---|-------------------------------|--|
| REVISION NO              |  |   |   | PAGE NO. 33-4                 |  |
| DATE: 03/03/2            |  |   |   |                               |  |
| AIRCRAFT:<br>Airbus A320 |  |   | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 33. Lights               |  |   |   |                               | Change   |
| Sequence No.<br>33-10-02 | Item<br>Annunciator Lights   | 1 | 2 | 3                             | 4 Change<br>Bar  |
|                          | -  |   |   |                               |  |
| 1)                       | Test Function  | В | 1 | 0                             | May be inoperative.  |
| 2)                       | Dim Function   | С | 1 | 0                             | May be inoperative for non-night operations.   |
| 3)                       | Bright Function  | С | 1 | 0                             | May be inoperative:<br>a) For night operations, and<br>b) Non-night operations are not<br>conducted.   |
| 33-20-01                 | Cabin Light System   |   |   |                               |  |
| 1)                       | Passenger<br>Configurations without<br>Photoluminescent<br>Escape Path Marking<br>System | С | - | -                             | (O) Individual lights may be<br>inoperative provided remaining<br>lighting is sufficient for cabin<br>attendants to perform their duties.  |
| 2)                       | Passenger<br>Configurations with<br>Photoluminescent<br>Escape Path Marking<br>System    | C | - | -                             | <ul> <li>(O) Individual lights may be inoperative provided: <ul> <li>a) Remaining lighting is sufficient for cabin attendants to perform their duties, and</li> <li>b) Minimum acceptable lighting levels specified in one of the following documents are maintained: <ul> <li>1) FAA engineering approval letter,</li> <li>2) FAA-approved report or the Type Design holder,</li> <li>3) Limitations and Conditions section of the applicable Supplemental Type Certificate (STC), or</li> <li>4) An FAA-approved report incorporated in the Master Drawing List for the applicable STC.</li> </ul> </li> </ul></li></ul> |

|                          | IENT OF TRANSPORTATION  | ON |   | MASTER MINIMUM EQUIPMENT LIST |  |        |  |  |  |
|--------------------------|---|----|---|-------------------------------|--|--------|--|--|--|
| REVISION NO. 30          |   |    |   |                               | PAGE NO. 33-5  |        |  |  |  |
| DATE: 03/03/20           | 023   |    |   |                               |  |        |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |  |  |  |
| 33. Lights               |   |    |   |                               | 1.   | Change |  |  |  |
| Sequence No.<br>33-20-02 | Item<br>Passenger Lighted<br>Information Signs                                | C  | - | -                             | <ul> <li>4</li> <li>(M) May be inoperative provided:         <ul> <li>a) Associated passenger seat or lavatory is not occupied from which a passenger lighted information sign is not readily legible, and</li> <li>b) Associated seat or lavatory is blocked and placarded "DO NOT OCCUPY".</li> </ul> </li> <li>NOTE: These conditions are not intended to prohibit lavatory use or inspections by crewmembers.</li> </ul> | Bar    |  |  |  |
|                          |   | С  | - | -                             | <ul> <li>(O) May be inoperative and associated passenger seat or lavatory may be occupied provided:</li> <li>a) PA system operates normally, and</li> <li>b) PA system is used to notify passengers and cabin crew when associated sign(s) are placed on or off.</li> </ul>  |        |  |  |  |
| 1)                       | All-Cargo, Authorized<br>Persons/Courier Area<br>Lighted Information<br>Signs | С  | - | -                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used to notify<br>couriers/supernumeraries when<br>associated sign(s) are placed on or<br>off.  |        |  |  |  |
| 33-20-04                 | Passenger Lighted<br>Information Signs AUTO<br>Function                       | С  | 1 | 0                             | (O) May be inoperative provided<br>Manual function operates normally.  |        |  |  |  |
| 33-30-01                 | Cargo and Service<br>Compartment Lighting<br>System                           | D  | 1 | 0                             | May be inoperative.  |        |  |  |  |

| U.S. DEPART                     | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|---------------------------------|--|----|---|----------------|---|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |  |    |   |                |   |  |  |  |  |
| REVISION NC                     |  |    |   |                | PAGE NO. 33-6   |  |  |  |  |
| DATE: 03/03/2                   | 2023   |    |   |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |  |  |  |
| 33. Lights                      |  |    | 1 |                | Change  |  |  |  |  |
| Sequence No.                    | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 33-40-01                        | Navigation Lights<br>Systems   |    |   |                |   |  |  |  |  |
| 1)                              | Aircraft Equipped with<br>One Navigation Light<br>System   | С  | 1 | 0              | Must be operative between sunset and sunrise.   |  |  |  |  |
| a)                              | Forward Navigation<br>Lights LEDs<br>(With Mod. 150780/<br>MPJ3140)  | С  | - | -              | One LED in each Nav Light Assembly may be inoperative.  |  |  |  |  |
| 2)<br>***                       | Aircraft Equipped with<br>Two Navigation Light<br>Systems  | С  | 2 | 1              | NAV 1 or NAV 2 system may be inoperative.   |  |  |  |  |
|                                 |  | С  | 2 | 0              | Must be operative between sunset and sunrise.   |  |  |  |  |
| a)                              | Forward Navigation<br>Lights LEDs<br>(With Mod. 150780/<br>MP J3140)   | С  | - | -              | One LED in each Nav Light Assembly may be inoperative.  |  |  |  |  |
| 3)<br>***                       | Navigation Light System<br>(STC ST10742SC)   | С  | 1 | 0              | Must be operative between sunset and sunrise.   |  |  |  |  |
| a)                              | Forward Navigation<br>Lights LEDs  | С  | 8 | 6              | One LED in each Nav Light Assembly may be inoperative.  |  |  |  |  |
| b)                              | Tail Navigation Light<br>Bulbs   | С  | 2 | 1              | One bulb may be inoperative.  |  |  |  |  |
| 4)<br>***                       | Forward Navigation<br>Lights - Aircraft<br>Equipped With One<br>Navigation Lights<br>System<br>(STC ST03975NY) | С  | 1 | 0              | Must be operative between sunset<br>and sunrise.  |  |  |  |  |
|                                 |  |    |   |                | (Continued)   |  |  |  |  |

| U.S. DEPART                         | MENT OF TRANSPORTATIO   |   |          |                |   |
|-------------------------------------|---|---|----------|----------------|---|
| FEDERAL AVI                         | ATION ADMINISTRATION  |   |          |                | MASTER MINIMUM EQUIPMENT LIST   |
| REVISION NO. 30<br>DATE: 03/03/2023 |   |   |          |                | PAGE NO. 33-7   |
| AIRCRAFT:<br>Airbus A320            |   |   | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                         |
| 33. Lights                          |   |   | <u>.</u> |                |   |
| Sequence No.                        | Item  | 1 | 2        | 3              | 4 Change<br>Bar   |
| 33-40-01                            | Navigation Lights<br>Systems<br>(Cont'd)  |   |          |                |   |
| 5)<br>***                           | Forward Navigation<br>Lights - Aircraft<br>Equipped With Two<br>Navigation Lights<br>Systems<br>(STC ST03975NY) | С | 2        | 1              | NAV 1 or NAV 2 system may be inoperative.   |
| 6)<br>***                           | Forward Navigation<br>Lights – Aircraft<br>Equipped With Two<br>Navigation Lights<br>Systems<br>(STC ST03975NY) | С | 2        | 0              | Must be operative between sunset<br>and sunrise.  |
| 33-40-02                            | Landing Lighting System   |   |          |                |   |
| 1)                                  | Landing Lights  | С | 2        | 1              | One may be inoperative provided taxi and takeoff lights operate normally.   |
|                                     |   | С | 2        | 0              | May be inoperative for non-night operations.  |
| 2)                                  | Extension/<br>Retraction Systems  | С | 2        | 0              | (O) May be inoperative in the<br>extended position provided a 1% fuel<br>penalty is applied for each extended<br>light. |
|                                     |   | С | 2        | 0              | May be inoperative in the retracted position provided that the associated light is considered inoperative.              |
| 33-40-03                            | Runway Turn-Off Light<br>Systems  | С | 2        | 0              | One or both may be inoperative.   |
| 33-40-04                            | Taxi and Takeoff Light<br>Systems   | С | 2        | 0              | One or both may be inoperative.   |
| 33-40-05<br>***                     | Logo Lights   | D | 2        | 0              | One or both may be inoperative.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |          |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|--|--|----------|---|-------------------------------|---|--|--|
| REVISION NO. 30<br>DATE: 03/03/2023                                  |  |          |   |                               | PAGE NO. 33-8   |  |  |
| AIRCRAFT:<br>Airbus A320   |  |          | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 33. Lights   |  | <u> </u> |   |                               | Change  |  |  |
| Sequence No.   | Item   | 1        | 2 | 3                             | 4 Change<br>Bar   |  |  |
| 33-40-06   | Anticollision/<br>Strobe Lighting            |          |   |                               |   |  |  |
| 1)   | Beacon Lights                                | С        | 2 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Strobe lights operate<br/>normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>   |  |  |
| 2)   | Strobe Lights                                | С        | 3 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Beacon Lights operate<br/>normally, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>   |  |  |
| 33-40-07   | Wing Scan Lights                             | С        | 2 | 0                             | (O) May be inoperative provided<br>ground deicing procedures do not<br>require their use.   |  |  |
| 33-50-01   | Exit Signs                                   | С        | - | 0                             | <ul> <li>(O) May be inoperative or missing provided:</li> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul> |  |  |
| 1)   | Wall Mounted Exit<br>(Marking) Signs         | С        | - | -                             | Up to three non-adjacent Bulbs or<br>LEDs may be inoperative in individual<br>signs.  |  |  |
| 2)   | Main Aisle Overhead<br>Exit (Location) Signs | С        | - | -                             | Up to three non-adjacent LEDs may<br>be inoperative in individual signs.<br>NOTE: For main aisle overhead Exit<br>(Location) Signs with Bulbs,<br>all Bulbs must be operative.  |  |  |

|                                     | MENT OF TRANSPORTATION                                     | ON |    |    | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|--|----|----|----|---|
| REVISION NO. 30<br>DATE: 03/03/2023 |  |    |    |    | PAGE NO. 33-9   |
| AIRCRAFT:<br>Airbus A320            | AIRCRAFT:  |    |    |    | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 33. Lights<br>Sequence No.          | ltem   | 1  | 2  | 3  | 4 Change  |
| 33-50-02                            | Overhead Emergency<br>Lights                               | 1  | 2  | 3  | 4 Bar   |
| 1)                                  | A318/A319  | С  | 11 | 9  | A maximum of two non-adjacent<br>overhead emergency lights may be<br>inoperative.   |
| 2)                                  | A320   |    |    |    |   |
| a)                                  | Without Mod. 24399/<br>MP K3756                            | С  | 14 | 11 | A maximum of three non-adjacent<br>overhead emergency lights may be<br>inoperative.   |
| b)                                  | With Mod. 24399/<br>MP K3756                               | С  | 12 | 9  | A maximum of three non-adjacent<br>overhead emergency lights may be<br>inoperative.   |
| 3)                                  | A321   | С  | 19 | 15 | A maximum of four non-adjacent<br>overhead emergency lights may be<br>inoperative.  |
| 33-50-03                            | Floor Proximity<br>Emergency Escape Path<br>Marking System | С  | -  | -  | <ul> <li>(O) May be inoperative or missing provided:</li> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul> |
|                                     |  |    |    |    | (Continued)   |

| U.S. DEPARTI             | IENT OF TRANSPORTATIO   | ON |        |                               |   |  |  |  |
|--------------------------|---|----|--------|-------------------------------|---|--|--|--|
| FEDERAL AVI              | ATION ADMINISTRATION  |    |        | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
| REVISION NO.             |   |    |        |                               | PAGE NO. 33-10  |  |  |  |
| DATE: 03/03/20           | 023   |    |        |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т.<br> | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 33. Lights               |   |    | _      |                               | change  |  |  |  |
| Sequence No.             | Item  | 1  | 2      | 3                             | 4 Change Bar  |  |  |  |
| 33-50-03                 | Floor Proximity<br>Emergency Escape Path<br>Marking System<br>(Cont'd)  |    |        |                               |   |  |  |  |
| 1)                       | Individual Incandescent<br>Bulbs, LEDs,<br>Electroluminescent<br>Lights, or<br>Photoluminescent<br>Components | С  | -      | -                             | <ul> <li>May be inoperative provided minimum acceptable lighting levels (specified in one of the following documents) are maintained: <ul> <li>a) FAA engineering approval letter,</li> <li>b) FAA-approved report of the Type Design holder,</li> <li>c) Limitations and Conditions section of the applicable Supplemental Type Certificate (STC), or</li> <li>d) An FAA-approved report incorporated in the Master Drawing List of the applicable STC.</li> </ul> </li> </ul> |  |  |  |
| 33-50-04<br>***          | Overwing Escape Route<br>Lighting   |    |        |                               |   |  |  |  |
| 1)                       | Overwing Emergency<br>Light   | С  | -      | -                             | May be inoperative for non-night operations.  |  |  |  |
| 2)                       | Overwing Exit Handle<br>Light   | В  | -      | 0                             | One or more may be inoperative.   |  |  |  |
| 33-50-05                 | Escape Slide Lighting   | В  | -      | 0                             | May be inoperative for non-night operations.  |  |  |  |
| 33-50-06<br>***          | Lavatory Auxiliary Lights   | С  | -      | 0                             | One or more may be inoperative.   |  |  |  |
| 33-50-08                 | EMER EXIT LT OFF<br>Light on SIGNS<br>Overhead Panel  | С  | -      | 0                             | May be inoperative.   |  |  |  |

| U.S. DEPARTI                    | MENT OF TRANSPORTAT                                    | ION |   |     | MASTER MINIMUM EQUIPMENT LIST   |
|---------------------------------|--|-----|---|-----|---|
| FEDERAL AVIATION ADMINISTRATION |  |     |   |     |   |
| <b>REVISION NO</b>              | 0. 30  |     |   |     | PAGE NO. 33-11  |
| DATE: 03/03/2                   | 2023   |     |   |     |   |
|                                 |  |     | T | ABL | E KEY   |
| AIRCRAFT:                       |  |     |   |     | REPAIR CATEGORY   |
| Airbus A320                     |  |     |   |     | NO. INSTALLED   |
|                                 |  |     |   |     | NO. REQUIRED FOR DISPATCH   |
|                                 |  |     |   | 4.  | REMARKS OR EXCEPTIONS   |
| 33. Lights                      |  |     |   | -   |   |
| Sequence No.                    | Item   | 1   | 2 | 3   | 4 Change<br>Bar   |
| 33-50-09                        | Interior and Exterior<br>Emergency Lighting<br>Systems | C   | - | 0   | <ul> <li>(O) May be inoperative or missing provided:</li> <li>a) No passengers are carried,</li> <li>b) A maximum of 19 persons authorized by 14 CFR for non-passenger-carrying operations are carried, and</li> <li>c) Alternate procedures are established and used.</li> </ul> |
| 33-51-12                        | BAT TEST pb on the<br>PTP                              | С   | 1 | 0   | <ul> <li>(M) May be inoperative provided that<br/>the batteries are verified correctly<br/>charged.</li> <li>NOTE: Battery tests required by the<br/>carrier's maintenance<br/>program cannot be exceeded.</li> </ul>   |

| -              | MENT OF TRANSPORTATI<br>IATION ADMINISTRATION  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|----------------|--|---|---|-------------------------------|--|
| REVISION NC    | -  |   |   | PAGE NO. 34-1                 |  |
| DATE: XX/XX/   | XXXX   |   |   |                               |  |
| AIRCRAFT:      |  |   | Т |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED  |
| Airbus A320    |  |   |   |                               | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation | 1  |   |   |                               |  |
| Sequence No.   | Item   | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 34-00-00       | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |   |   |                               |  |
| 1)             | Fault(s) Indicated by<br>ADR   | С | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 2)             | Fault(s) Indicated by IR   | С | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 3)             | Fault(s) Indicated by RA 1(2)  | С | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
| 34-00-01       | Autotune Systems   | с | 2 | 1                             |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/  | -  |   |   |                | PAGE NO. 34-2   |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation   |  | 1 | 2 | 3              | 4 Change  |
| Sequence No.<br>34-10-01   | Item<br>ADIRS  | 1 | 2 | 3              | 4 Bar   |
| 1)<br>a)   | IR 1<br>Aircraft with or without<br>Honeywell FMS 2<br>(P1A or Release 1A<br>Standard). Aircraft with<br>Honeywell FMS 2 must<br>not have following mods:<br>35526/MP P9126<br>37311/MP P9823<br>37934/MP P10439<br>150370/MP P11613<br>38779/MP P10763<br>38778/MP P10762 | С | 1 | 0              | <ul> <li>(O) NAV Mode of IR 1 may be<br/>inoperative provided: <ul> <li>a) IR 1 is operated in ATT mode,</li> <li>b) IR 2 and IR 3 are operative,</li> <li>c) GPS 1 is operative,</li> <li>d) Terrain Awareness and<br/>Warning System is<br/>considered inoperative, and</li> <li>e) Approach minimums do not<br/>require its use.</li> </ul> </li> </ul>                      |
|  |  | С | 1 | 0              | <ul> <li>(O) NAV Mode of IR 1 may be<br/>inoperative provided: <ul> <li>a) IR 1 is operated in ATT mode,</li> <li>b) IR 2 and IR 3 are operative,</li> <li>c) Flight remains within radio<br/>navaids,</li> </ul> </li> <li>d) Terrain Awareness and<br/>Warning System is<br/>considered inoperative, and</li> <li>e) Approach minimums do not<br/>require its use.</li> </ul> |
|  |  |   |   |                | (Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--|--|---|---|-------------------------------|--|--|--|--|
| REVISION NO. 32  |  |   |   |                               | PAGE NO. 34-3  |  |  |  |
| DATE: XX/XX/XXXX<br>AIRCRAFT:<br>Airbus A320                         |  |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 34. Navigation<br>Sequence No.                                       | ltem   | 1 | 2 | 3                             | 4 Change   |  |  |  |
| 34-10-01   | ADIRS<br>(Cont'd)  | • | 2 | 3                             | 4 Bar  |  |  |  |
| 1)   | IR 1<br>(Cont'd)   |   |   |                               |  |  |  |  |
| b)   | Aircraft with Honeywell<br>FMS 2 (P1A or Release<br>1A standard) and with<br>any of following Mods:<br>• 35526/MP P9126<br>• 37311/MP P9823<br>• 37934/MP P10439<br>• 150370/MP P11613<br>• 38779/MP P10763<br>• 38778/MP P10762 | A | 1 | 0                             | <ul> <li>(O) NAV Mode of IR 1 may be<br/>inoperative provided: <ul> <li>a) IR 1 is operated in ATT mode,</li> <li>b) IR 2 and IR 3 are operative,</li> <li>c) GPS 1 is operative,</li> <li>d) Terrain Awareness and<br/>Warning System is<br/>considered inoperative,</li> <li>e) Approach minimums do not<br/>require its use,</li> <li>f) FMGC 1 is considered<br/>inoperative, and</li> <li>g) Repairs are made within<br/>3 flight-legs.</li> </ul> </li> </ul>                                    |  |  |  |
|  |  | A | 1 | 0                             | <ul> <li>(O) NAV Mode of IR 1 may be<br/>inoperative provided: <ul> <li>a) IR 1 is operated in ATT mode,</li> <li>b) IR 2 and IR 3 are operative,</li> <li>c) Flight remains within radio<br/>navaids coverage,</li> <li>d) GPWS Terrain Awareness<br/>and Warning System is<br/>considered inoperative,</li> <li>e) Approach minimums do not<br/>require its use,</li> <li>f) FMGC 1 is considered<br/>inoperative, and</li> <li>g) Repairs are made within<br/>3 flight-legs.</li> </ul> </li> </ul> |  |  |  |
|  |  |   |   |                               | (Continued)  |  |  |  |

|                | MENT OF TRANSPORT |   |   |                               |  |               |  |  |
|----------------|-------------------|---|---|-------------------------------|--|---------------|--|--|
|                |                   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |               |  |  |
| REVISION NO    |                   |   |   |                               | PAGE NC  | ) 34_4        |  |  |
| DATE: XX/XX    |                   |   |   |                               | TAGENC   | . 54-4        |  |  |
|                |                   |   | Т |                               | EKEY   |               |  |  |
| AIRCRAFT:      |                   |   | ľ |                               | REPAIR CATEGORY  |               |  |  |
| Airbus A320    |                   |   |   |                               | NO. INSTALLED  |               |  |  |
|                |                   |   |   |                               | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |
| 34. Navigatior | า                 | T |   | 1                             | 1  |               |  |  |
| Sequence No.   | Item              | 1 | 2 | 3                             | 4  | Change<br>Bar |  |  |
| 34-10-01       | ADIRS<br>(Cont'd) |   |   |                               |  |               |  |  |
| 2)             | IR 2              |   |   |                               |  |               |  |  |
| a)             | A321neo XLR       | С | 1 | 0                             | <ul> <li>(O) NAV Mode of IR 2 may be inoperative provided:</li> <li>a) IR 2 is operated in ATT mode,</li> <li>b) IR 1 and IR 3 are operative, and</li> <li>c) Approach minimums do not require its use.</li> </ul>   |               |  |  |
|                |                   | С | 1 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) IR 2 is set to OFF,</li> <li>b) IR 1 and IR 3 are operative,</li> <li>c) ADR 1 and ADR 3 are operative,</li> <li>d) Takeoff in CONF 1A+F is prohibited, and</li> <li>e) Approach minimums do not require its use.</li> </ul> |               |  |  |
|                |                   |   |   |                               | (Continued)  |               |  |  |

|   | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION  | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|---|---|----|---|-------------------------------|---|--|--|
| REVISION NO<br>DATE: XX/XX/2                      |   |    |   |                               | PAGE NO. 34-5   |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigation</b> |   |    | Т | 1.<br>2.<br>3.                | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| Sequence No.                                      | Item  | 1  | 2 | 3                             | 4 Change  |  |  |
| 34-10-01  | ADIRS<br>(Cont'd)   |    | - |                               | ** Bar  |  |  |
| 2)  | IR 2<br>(Conťd)   |    |   |                               |   |  |  |
| b)  | Aircraft with or without<br>Honeywell FMS 2<br>(P1A or Release<br>1A Standard). Aircraft<br>with Honeywell FMS 2<br>must not have following<br>mods:<br>35526/MP P9126<br>37311/MP P9823<br>37934/MP P10439<br>150370/MP P11613<br>38779/MP P10763<br>38778/MP P10762 | C  | 1 | 0                             | <ul> <li>(O) NAV Mode of IR 2 may be inoperative provided:</li> <li>a) IR 2 is operated in ATT mode,</li> <li>b) IR 1 and IR 3 are operative, and</li> <li>c) Approach minimums do not require its use.</li> </ul>  |  |  |
|   |   | С  | 1 | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) IR 2 is set to OFF,</li> <li>b) IR 1 and IR 3 are operative,</li> <li>c) ADR 1 and ADR 3 are operative,</li> <li>d) Takeoff in CONF 1+F is prohibited, and</li> <li>e) Approach minimums do not require its use.</li> </ul> |  |  |
|   |   |    |   |                               | (Continued)   |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |
|--|---|---|---|-------------------------------|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |   |   |   |                               | PAGE NO. 34-6  |  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigation</b>                    |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |
| Sequence No.   | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |  |
| 34-10-01   | ADIRS<br>(Cont'd)   |   |   |                               |  |  |
| 2)   | IR 2<br>(Conťd)   |   |   |                               |  |  |
| c)   | Aircraft with Honeywell<br>FMS 2 (P1A or Release<br>1A Standard) and with<br>any of Following Mods:<br>• 35526/MP P9126<br>• 37311/MP P9823<br>• 37934/MP P10439<br>• 150370/MP P10763<br>• 38779/MP P10762 | A | 1 | 0                             | <ul> <li>(O) NAV Mode of IR2 may be<br/>inoperative provided: <ul> <li>a) IR 2 is operated in ATT mode,</li> <li>b) IR 1 and IR 3 are operative,</li> <li>c) Approach minimums do not<br/>require its use,</li> <li>d) FMGC 2 is considered<br/>inoperative, and</li> <li>e) Repairs are made within<br/>3 flight-legs.</li> </ul> </li> </ul>   |  |
|  |   | A | 1 | 0                             | <ul> <li>(O) May be inoperative provided: <ul> <li>a) IR 2 is set to OFF,</li> <li>b) IR 1 and IR 3 are operative,</li> <li>c) ADR 1 and ADR 3 are operative,</li> <li>d) Takeoff in CONF 1+F is prohibited,</li> <li>e) Approach minimums do not require its use,</li> <li>f) FMGC 2 is considered inoperative, and</li> <li>g) Repairs are made within 3 flight-legs.</li> </ul> </li> </ul> |  |
|  |   |   |   |                               | (Continued)  |  |

|                                     | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION  | ION |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|-------------------------------------|---|-----|---|----------------|--|--|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |     |   |                | PAGE NO. 34-7  |  |  |  |  |
|                                     |   |     |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 34. Navigation<br>Sequence No.      | Item  | 1   | 2 | 3              | 4 Change   |  |  |  |  |
| 34-10-01                            | ADIRS<br>(Cont'd)   |     | 2 | 3              | <del>"Bar Bar Bar Bar Bar Bar Bar Bar Bar Bar </del>   |  |  |  |  |
| 3)                                  | IR 3  | С   | 1 | 0              | <ul> <li>(O) NAV Mode of IR 3 may be inoperative provided:</li> <li>a) IR 3 is operated in ATT mode,</li> <li>b) IR 1 and IR 2 are operative, and</li> <li>c) Approach minimums do not require its use.</li> </ul>                             |  |  |  |  |
|                                     |   | С   | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) IR 3 is set to OFF,</li> <li>b) IR 1 and IR 2 are operative,</li> <li>c) ADR 1 and ADR 2 are operative, and</li> <li>d) Approach minimums do not require its use.</li> </ul>             |  |  |  |  |
| a)                                  | Aircraft with any of<br>following<br>(Honeywell)<br>ADIRU P/Ns:<br>• HG1150AC05<br>(Mod. 21206/<br>MP P1488/<br>SB A320-34-1010),<br>or<br>• HG1150AC06<br>(Mod. 24349/<br>MP P3510/<br>SB A320/34-1084),<br>or<br>• HG1150AC07<br>(Mod. 30652/<br>MP P6739/<br>SB A320-34-1231 | В   | 1 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) IR 3 is set to OFF,</li> <li>b) IR 1 and IR 2 are operative,</li> <li>c) ADR 1 and ADR 2 are operative, and</li> </ul> </li> <li>d) Approach minimums do not require its use.</li> </ul> |  |  |  |  |
|                                     |   |     |   |                | (Continued)  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |
|--|--|---|---|---|---|--|
| REVISION NO<br>DATE: XX/XX   |  |   |   |   | PAGE NO. 34-8   |  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigatio</b> i                   | AFT:<br>A320   |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |
| Sequence No.   | Item   | 1 | 2 | 3   | 4 Change<br>Bar   |  |
| 34-10-01   | ADIRS<br>(Cont'd)  |   |   |   | Dat   |  |
| 4)   | ADR 2<br>(except for<br>A321neo XLR,<br>all aircraft with either<br>IAE Engines,<br>CFM Engines,<br>PW 6000 Engines, or<br>PW 1100G Engines with<br>Mod 165817/<br>MP P21469<br>(FCS 5.0)) | С | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) Enroute operations do not require its use,</li> <li>b) IR 1 and IR 3 are operative,</li> <li>c) ADR 3 is operative,</li> <li>d) Takeoff in CONF 1+F is prohibited, and</li> <li>e) Approach minimums do not require its use.</li> </ul> </li> <li>NOTE: Without Mod. 30416/<br/>MP P6635 or 31528/<br/>MP P7268, RVSM operations are not permitted.</li> </ul> |  |
| 5)   | ADR 3<br>(except A321neo XLR)  | С | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Enroute operations do not<br/>require its use,</li> <li>b) IR 1 and IR 2 are operative,</li> <li>c) ADR 2 is operative, and</li> <li>d) Approach minimums do not<br/>require its use.</li> </ul>   |  |

| U.S. DEPART              | MENT OF TRANSPORTATIO                               | ON |                               |                |  |  |
|--------------------------|---|----|-------------------------------|----------------|--|--|
|                          | IATION ADMINISTRATION                               |    | MASTER MINIMUM EQUIPMENT LIST |                |  |  |
| REVISION NO              |   |    |                               | PAGE NO. 34-9  |  |  |
| DATE: XX/XX              | /XXXX   |    |                               |                |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |
| 34. Navigatio            | n   |    |                               |                |  |  |
| Sequence No.             | Item  | 1  | 2                             | 3              | 4 Change<br>Bar  |  |
| 34-10-02                 | ADIRS CDU<br>(Aircraft Pre Mod. 36743/<br>MP P5253) |    |                               |                |  |  |
| 1)                       | Mode Rotary Selectors                               | С  | 3                             | 2              | (O) ADIRS 2 or 3 selector may be<br>inoperative provided the associated<br>ADIRS is considered inoperative.  |  |
| 2)                       | Data Selector                                       | С  | 1                             | 0              | May be inoperative provided MCDU 1<br>and MCDU 2 operate normally.   |  |
| 3)                       | System Selector                                     | С  | 1                             | 0              | <ul> <li>May be inoperative provided:</li> <li>a) MCDU 1 and MCDU 2<br/>operate normally, and</li> <li>b) IRS initialization is available<br/>through FMGS.</li> </ul> |  |
| 4)                       | Display   | С  | 1                             | 0              | May be inoperative provided MCDU 1<br>and MCDU 2 operate normally.   |  |
| 5)                       | ADR Fault Lights                                    | С  | 3                             | 0              | May be inoperative provided ECAM display operates normally.  |  |
| 6)                       | ADR OFF Lights                                      | С  | 3                             | 0              | May be inoperative provided ECAM display operates normally.  |  |
| 7)                       | IR FAULT Lights                                     | С  | 3                             | 0              | May be inoperative provided ECAM display operates normally.  |  |
| 8)                       | IR ALIGN Lights                                     | С  | 3                             | 0              | May be inoperative provided ECAM display operates normally.  |  |
| 9)                       | ON BAT Light  | С  | 1                             | 0              | May be inoperative.  |  |
| 10)                      | Keyboard  | С  | 1                             | 0              | May be inoperative provided MCDU 1<br>and MCDU 2 operate normally.   |  |
| 11)                      | ADR 2 pb Switch                                     | С  | 1                             | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 2 is operative, and</li> <li>b) ADR 1, ADR 3, IR1, and IR3 are operative.</li> </ul>        |  |
|                          |   |    |                               |                | (Continued)  |  |

| -                             | IENT OF TRANSPORTATIO   | NC |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------|---|----|---|----------------|---|
| FEDERAL AVIA                  | ATION ADMINISTRATION  |    |   |                |   |
| REVISION NO.<br>DATE: XX/XX/X | -   |    |   | PAGE NO. 34-10 |   |
| AIRCRAFT:<br>Airbus A320      |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation                |   |    | • |                |   |
| Sequence No.                  | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 34-10-02                      | ADIRS CDU<br>(Aircraft Pre Mod. 36743/<br>MP P5253)<br>(Cont'd) |    |   |                |   |
| 12)                           | ADR 3 pb Switch   | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 3 is operative, and</li> <li>b) ADR 1, ADR 2, IR1, and IR2 are operative.</li> </ul> |
| 34-10-03                      | ADIRS MSU<br>(Aircraft Post<br>Mod. 36743/<br>MP P5253)         |    |   |                |   |
| 1)                            | Mode Rotary Selectors   | С  | 3 | 2              | (O) ADIRS 2 or 3 selector may be<br>inoperative provided the associated<br>ADIRS is considered inoperative.   |
| 2)                            | IR 2 pb Switch  | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 2 is operative, and</li> <li>b) ADR 1, ADR 3, IR1, and IR3 are operative.</li> </ul> |
| 3)                            | IR 3 pb Switch  | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 3 is operative, and</li> <li>b) ADR 1, ADR 2, IR1, and IR2 are operative.</li> </ul> |
| 4)                            | IR FAULT Lights   | С  | 3 | 0              | May be inoperative provided ECAM display operates normally.   |
| 5)                            | IR OFF Lights   | С  | 3 | 0              | May be inoperative provided ECAM display operates normally.   |
| 6)                            | ADR 2 pb Switch   | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 2 is operative, and</li> <li>b) ADR 1, ADR 3, IR1, and IR3 are operative.</li> </ul> |
|                               |   |    |   |                | (Continued)   |

|                          | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                        | ON |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|---|----|----|----------------|---|
| REVISION NO              | . 32  |    |    |                | PAGE NO. 34-11  |
| DATE: XX/XX/             | XXXX  |    |    |                |   |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3. |   |
| 34. Navigation           |   |    |    |                |   |
| Sequence No.             | Item  | 1  | 2  | 3              | 4 Change<br>Bar   |
| 34-10-03                 | ADIRS MSU<br>(Aircraft Post<br>Mod. 36743/<br>MP P5253)<br>(Cont'd) |    |    |                |   |
| 7)                       | ADR 3 pb Switch   | С  | 1  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Mode Rotary Selector 3 is operative, and</li> <li>b) ADR 1, ADR 2, IR 1, and IR 2 are operative.</li> </ul>                         |
| 8)                       | ADR FAULT Lights  | С  | 3  | 0              | May be inoperative provided ECAM display operates normally.   |
| 9)                       | ADR OFF Lights  | С  | 3  | 0              | May be inoperative provided ECAM display operates normally.   |
| 10)                      | ON BAT Light  | С  | 1  | 0              | May be inoperative.   |
| 34-12-01                 | BKUP SPD/ALT pb-sw<br>ON light<br>(With Mod. 159281/<br>MP P15825)  | D  | 2  | 0              | One or both may be inoperative.   |
| 34-12-02                 | BKUP SPD/ALT pb-sw<br>(With Mod. 159281/<br>MP P15825)              | D  | 2  | 0              | (O) May be inoperative provided<br>Back Up Speed is not used.   |
| 34-12-03                 | Digital Backup Speed<br>(DBUS) (With<br>Mod. 163909/<br>MP P20614)  | D  | 1  | 0              | (O) May be inoperative provided<br>Digital Backup Speed is not used.  |
| 34-13-02                 | Mach Numbers on PFD   | С  | 2  | 1              | One may be inoperative.   |
|                          |   | С  | 2  | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) MMO black and red strips<br/>operate normally on both<br/>PFDs, and</li> <li>b) Airplane remains at or below<br/>FL 250.</li> </ul> |
|                          | (Aircraft with<br>Mod. 27620/<br>MP P5638)                          | С  | 2  | 0              | May be inoperative provided ISIS<br>Mach Number function is operative.  |

| -                           | MENT OF TRANSPORTATIN   | ON |          |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|---|----|----------|----------------|---|
| REVISION NC<br>DATE: XX/XX/ |   |    |          | PAGE NO. 34-12 |   |
| AIRCRAFT:<br>Airbus A320    |   |    | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |
| 34. Navigation              |   |    | <u> </u> |                |   |
| Sequence No.                | Item  | 1  | 2        | 3              | 4 Change<br>Bar   |
| 34-13-05                    | Vertical Speed<br>Indications on PFD  |    |          |                |   |
| 1)                          | Inertial Mode   | С  | 2        | 0              | (O) One or both may be inoperative.   |
| 34-13-07                    | Ground Speed<br>Indications on ND   | С  | 2        | 0              | (O) One or both may be inoperative.   |
| 34-13-08                    | True Airspeed<br>Indications on ND<br>(IAE, CFM, PW 6000<br>Engines and PW 1100G<br>engines with<br>Mod. 165817/<br>MP P21469<br>(FCS 5.0)) | С  | 2        | 0              | (O) One or both may be inoperative.   |
| 34-13-09                    | Wind Indications on ND  | С  | 2        | 0              | (O) One or both may be inoperative.   |
| 34-13-10                    | Radio Navaids<br>Indications on PFD   | С  | -        | 0              | May be inoperative provided<br>operations or procedures do not<br>require its use.              |
| 34-13-11                    | Radio Navaids<br>Indications on ND  | С  | -        | -              | May be inoperative on one ND<br>provided affected indication is<br>operative on second ND.      |
|                             |   | С  | -        | -              | May be inoperative (except VOR and ADF) provided affected indication is operative on PFD.       |
|                             |   | С  | -        | -              | May be inoperative provided VOR,<br>DME, or ADF indication is operative<br>on DDRMI.            |
|                             |   | С  | -        | -              | May be inoperative provided affected system is considered inoperative.                          |
| 34-14-02                    | EIS Heading   | С  | 4        | 3              | (O) One may be inoperative.   |
| 34-14-04                    | Navigation Station<br>Information   | С  | -        | 0              | One or more may be inoperative.   |
| 34-14-05                    | Chrono  | С  | 2        | 0              | One or both may be inoperative.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |               |  |  |
|--|--|---|---|---|---|---------------|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |   | PAGE NO.  | 34-13         |  |  |
| AIRCRAFT:<br>Airbus A320   | AIRCRAFT:  |   |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |               |  |  |
| 34. Navigation   |  | 1 |   | 1   |   |               |  |  |
| Sequence No.   | Item   | 1 | 2 |   | 4   | Change<br>Bar |  |  |
| 34-15-01   | Angle of Attack Indicator  | D | - | 0   | May be inoperative provided operations/procedures do not require its use.   |               |  |  |
| 34-15-02   | NORTH REF pb-sw<br>(With Mod. 35891/<br>MP P9351)  |   |   |   |   |               |  |  |
| 1)   | Outside Polar area   | D | 1 | 0   | May be inoperative provided<br>operations are conducted outside<br>Polar area.  |               |  |  |
| 2)   | Inside Polar area  | С | 1 | 0   | (O) May be inoperative.   |               |  |  |
| 34-21-01   | Standby Airspeed<br>Indicator  |   |   |   |   |               |  |  |
| 1)   | Airspeed Bugs  | D | - | 0   | One or more may be inoperative.   |               |  |  |
| 34-21-02   | Standby Altimeter  |   |   |   |   |               |  |  |
| 1)   | Altitude Bugs  | D | - | -   | One or more may be inoperative.   |               |  |  |
| 34-21-03<br>***  | Standby Metric Altimeter   | D | 1 | 0   | May be inoperative.   |               |  |  |
| 34-22-01   | Standby Horizon<br>(Attitude)<br>(Aircraft with Honeywell<br>ADIRUs or Aircraft with<br>Litton ADIRUs<br>P/N 465020-0303-0316<br>and Mod. 30650<br>or 30872) | В | 1 | 0   | <ul> <li>May be inoperative provided:</li> <li>a) Operations are conducted in<br/>Day VMC only, and</li> <li>b) Operations are not conducted<br/>into known or forecast<br/>over-the-top conditions.</li> </ul> |               |  |  |

| -                                   | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-------------------------------------|--|----|---|----------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |  |    |   |                | PAGE NO. 34-14  |
| AIRCRAFT:<br>Airbus A320            |  |    | Т | 1.<br>2.<br>3. |   |
| 34. Navigation                      |  |    |   |                |   |
| Sequence No.                        | ltem   | 1  | 2 | 3              | 4 Change  |
| 34-22-02                            | Non-Stabilized Magnetic<br>Compass<br>(Standby)<br>(Aircraft Equipped with<br>Honeywell ADIRUs or<br>Aircraft Equipped with<br>Litton ADIRUs<br>P/N 465020-0303-316<br>and Mod. 30650<br>or 30872) | B  | 1 | 0              | <ul> <li>(O) May be inoperative provided:         <ul> <li>a) Three IRs operate normally, and</li> <li>b) ATT/HDG, EIS DMS, and PFD/ND switching capabilities.</li> </ul> </li> </ul>   |
|                                     |  | В  | 1 | 0              | May be inoperative provided:<br>a) Three IRs operate normally,<br>and<br>b) DDRMI operates normally.  |
|                                     |  | В  | 1 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Any combination of two IRs<br/>are operative, and</li> <li>b) Airplane is operated with dual<br/>independent navigation<br/>capability and under positive<br/>radar control by ATC on<br/>enroute portion of flight.</li> </ul> |
| 1)                                  | Lighting<br>(Aircraft Equipped with<br>Honeywell or Litton<br>ADIRUs)  | С  | 1 | 0              | May be inoperative.   |
| 34-22-03                            | Integrated Standby<br>Instrument System  |    |   |                |   |
| 1)                                  | Horizon<br>(Attitude)<br>Function  | В  | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Operations are conducted in<br/>Day VMC only, and</li> <li>b) Operations are not conducted<br/>into known or forecast<br/>over-the-top conditions.</li> </ul>   |
| 2)                                  | ILS Function   | D  | 1 | 0              | May be inoperative.   |
| 3)                                  | Mach Number Function   | D  | 1 | 0              | May be inoperative.   |
| 4)                                  | Bugs Function  | D  | 1 | 0              | May be inoperative.   |

|                          | VENT OF TRANSPORTATION   |   |    | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|--------------------------|--|---|----|-------------------------------|---|--|--|--|
| REVISION NO. 32          |  |   |    |                               | PAGE NO. 34-15  |  |  |  |
| DATE: XX/XX/             | XXXX   |   |    |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |   | T. | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 34. Navigation           |  |   | 1  | 1                             |   |  |  |  |
| Sequence No.             | Item   | 1 | 2  | 3                             | 4 Change<br>Bar   |  |  |  |
| 34-30-01<br>***          | Head-Up Display (HUD)  | D | -  | 0                             | One or more may be inoperative.   |  |  |  |
| 34-30-03                 | GNSS Landing System<br>(GLS) Function<br>(Mod. 39327/MP P8500)           | D | 2  | 0                             | (O) May be inoperative provided<br>approach minimums do not require<br>the use of GLS.  |  |  |  |
| 34-36-01                 | ILS Navigation Systems   | С | 2  | -                             | As required by 14 CFR.  |  |  |  |
|                          |  |   |    |                               | NOTE: GPWS Glideslope Deviation<br>Light(s) will be inoperative<br>with the loss of the ILS 1.  |  |  |  |
| 34-37-01<br>***          | FMS Landing System<br>(FLS)  | С | 2  | 0                             | (O) May be inoperative.   |  |  |  |
| 34-38-01                 | SBAS Landing System<br>(SLS)<br>(Mod. 165088/<br>MP S34829)              | С | 2  | 1                             | One may be inoperative.   |  |  |  |
|                          |  | D | 2  | 0                             | (O) One or both may be inoperative<br>provided approach and landing<br>procedures are not based on use of<br>SLS.   |  |  |  |
| 34-40-07                 | GPWS – G/S pb-sw or<br>PULL UP – GPWS<br>pb-sw or PULL UP – G/S<br>pb-sw | С | 2  | 1                             | (O) One may be inoperative provided<br>aural and visual warnings associated<br>with the GPWS Modes 1-5 and the<br>GPWS Terrain System are checked<br>operative.   |  |  |  |
|                          |  | A | 2  | 0                             | <ul> <li>Both may be inoperative provided:</li> <li>a) GPWS Modes 1-5 and GPWS<br/>Terrain System are<br/>considered inoperative, and</li> <li>b) Repairs are made within<br/>2 flight-days.</li> </ul> |  |  |  |

| FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|---------------------------------|--|---|---|----------------|---|--|--|
| REVISION NO                     |  |   |   | PAGE NO. 34-16 |   |  |  |
| DATE: XX/XX                     | /XXXX  |   |   |                |   |  |  |
| AIRCRAFT:<br>Airbus A320        |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |  |  |
| 34. Navigatior                  | ı  |   |   | I              |   |  |  |
| Sequence No.                    | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |
| 34-40-09                        | Runway End Overrun<br>Warning/Runway End<br>Overrun Protection<br>(ROW/ROP)<br>(Mod. 155269/<br>MP P12511 or<br>Mod. 161514/<br>MP P15323) | D | 1 | 0              | May be inoperative.   |  |  |
| 34-40-10<br>***                 | ROW/ROP pb-sw OFF<br>Light<br>(With Mod. 163910/<br>MP P20767 or<br>Mod. 163425/<br>MP P20473)   | D | 1 | 0              | (O) May be inoperative.   |  |  |
| 34-40-11<br>***                 | ROW/ROP pb-sw<br>(With Mod. 163910/<br>MP P20767 or<br>Mod. 163425/<br>MP P20473)  |   |   |                |   |  |  |
| 1)                              | OFF Position   | С | 1 | 0              | (O) May be inoperative.   |  |  |
| 2)                              | ON Position  | D | 1 | 0              | (O) May be inoperative provided<br>ROW/ROP is considered inoperative.                           |  |  |
| 34-40-12<br>***                 | RWY COND Rotary<br>Selector<br>(With Mod. 163910/<br>MP P20767 or<br>Mod. 163425/<br>MP P20473)  | D | 1 | 0              | May be inoperative provided<br>ROW/ROP is considered inoperative.                               |  |  |
| 34-40-13<br>***                 | ATSAW Function   | D | 1 | 0              | May be inoperative.   |  |  |

|                          | MENT OF TRANSPORTATION                                    | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--------------------------|---|----|---|----------------|---|--|--|--|--|
| REVISION NO. 32          |   |    |   |                | PAGE NO. 34-17  |  |  |  |  |
| DATE: XX/XX/             | XXXX  |    |   |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 34. Navigation           |   |    | 1 | T              |   |  |  |  |  |
| Sequence No.             | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 34-41-01                 | Weather Radar Systems                                     | D  | - | -              | Any in excess of those required by 14 CFR may be inoperative.   |  |  |  |  |
| 1)<br>***                | Transceiver<br>(Aircraft with Dual<br>Transceivers)       | D  | 2 | 1              | May be inoperative.   |  |  |  |  |
| 2)                       | Map Mode  | С  | - | 0              | One or more may be inoperative.   |  |  |  |  |
| 3)                       | Automatic Gain Control<br>(CAL)                           | С  | - | 0              | May be inoperative provided radar<br>gain can be manually tuned to<br>receive satisfactory radar returns.   |  |  |  |  |
| 4)                       | Turbulence Detection<br>Mode                              | С  | 1 | 0              | May be inoperative.   |  |  |  |  |
| 5)                       | Ground Clutter<br>Suppression                             | С  | 1 | 0              | May be inoperative.   |  |  |  |  |
| 6)                       | AUTO TILT Control   | С  | 1 | 0              | May be inoperative provided manual tilt function operates normally.   |  |  |  |  |
| 7)<br>***                | Predictive Windshear<br>Detection and Avoidance<br>System | В  | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |  |
|                          |   |    |   |                | NOTE: Operator's alternate<br>procedures should include<br>reviewing windshear<br>avoidance and windshear<br>recovery procedures.   |  |  |  |  |
|                          |   | С  | - | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) Windshear Warning and<br/>Guidance System (Reactive)<br/>operates normally.</li> </ul> |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |          |   |                | MASTER MINIMUM EQUIPMENT LIS   |        |  |  |  |
|--|--|----------|---|----------------|--|--------|--|--|--|
| <b>REVISION NO</b>   | . 32   |          |   |                | PAGE NO.   | 34-18  |  |  |  |
| DATE: XX/XX/   | XXXX   |          |   |                |  |        |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |          | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |        |  |  |  |
| 34. Navigation   |  | <u> </u> |   |                | I.   | Change |  |  |  |
| Sequence No.<br>34-42-01   | Item<br>Radio Altimeter (RA)<br>Systems                | 1        | 2 | 3              | 4  | Bar    |  |  |  |
| 1)   | Aircraft without<br>Mod 163323/<br>MP P20703 (eRudder) | A        | 2 | 1              | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) Approach minimums do not require its use,</li> <li>b) Both FCU channels operate normally,</li> <li>c) All ELACs, SECs, ADIRS, SFCC, LGCIU, and FACs operate normally, and</li> <li>d) Repairs are made within 2 flight-days for RA 1 and within 3 flight-days for RA 2.</li> </ul> </li> <li>NOTE: For aircraft equipped with TCAS or T2CAS and without Mod 155145/MP P13063, Mod 39146/MP P10960, Mod 152353/MP P18041, or Mod 152920/MP P12603, inoperative RA 1 renders GPWS Modes 1-5 inoperative.</li> </ul> |        |  |  |  |
|  |  |          |   |                | (Continued)  |        |  |  |  |

| -   | MENT OF TRANSPORTATI                                | ON |        | MASTER MINIMUM EQUIPMENT LIST |   |  |  |
|---|---|----|--------|-------------------------------|---|--|--|
| REVISION NO                                       | 0. 32   |    |        |                               | PAGE NO. 34-19  |  |  |
| DATE: XX/XX/                                      | XXXX  |    |        |                               |   |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigation</b> |   |    | Т<br>Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| Sequence No.                                      | ltem  | 1  | 2      | 3                             | 4 Change<br>Bar   |  |  |
| 34-42-01  | Radio Altimeter (RA)<br>Systems<br>(Cont'd)         |    |        |                               |   |  |  |
| 2)  | Aircraft with<br>Mod 163323/<br>MP P20703 (eRudder) | A  | 2      | 1                             | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Approach minimums do not require its use,</li> <li>b) Both FCU channels operate normally,</li> <li>c) All ELACs, SECs, ADIRS, SFCC, LGCIU, and FMGCs operate normally, and</li> <li>d) Repairs are made within 2 flight-days for RA 1 and within 3 flight-days for RA 2.</li> <li>NOTE: For aircraft equipped with TCAS or T2CAS and without Mod 155145/MP P13063, Mod 39146/MP P10960, Mod 152353/MP P18041, or Mod 152920/MP P12603, inoperative RA 1 renders GPWS Modes 1-5 inoperative.</li> </ul> |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                             |   |   |          | MASTER MINIMUM EQUIPMENT LIST  |               |  |  |  |
|--|-----------------------------|---|---|----------|--|---------------|--|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |                             |   |   |          | PAGE NO.   | 34-20         |  |  |  |
| D/(12:7007007  |                             |   |   |          |  |               |  |  |  |
| AIRCRAFT:<br>Airbus A320   |                             |   | 1 | 1.<br>2. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |               |  |  |  |
|  |                             |   |   |          | REMARKS OR EXCEPTIONS  |               |  |  |  |
| 34. Navigation   |                             |   |   |          |  |               |  |  |  |
| Sequence No.   | Item                        | 1 | 2 | 3        | 4  | Change<br>Bar |  |  |  |
| 34-42-02   | Automatic Callout<br>System | С | 1 | 0        | May be inoperative provided approach minimums do not require its use.  | Bai           |  |  |  |
| 34-42-04   | Altitude Alerting System    | A | - | 0        | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Autopilot with altitude hold and altitude capture operates normally,</li> <li>b) Enroute operations (i.e., RVSM) do not require its use,</li> <li>c) Airplane does not depart from a designated airport (as listed in the operator's MEL) where repair or replacement can be made, and</li> <li>d) Repairs are made within 3 flight-days.</li> </ul> </li> </ul> |               |  |  |  |
|  |                             | С | - | 1        | All but one may be inoperative.  |               |  |  |  |
| 1)   | Aural Alert                 | С | - | 0        | <ul> <li>May be inoperative provided:</li> <li>a) Visual alert operates normally, and</li> <li>b) Autopilot with altitude hold and altitude capture operates normally.</li> </ul>  |               |  |  |  |
| 2)   | Visual Alert                | С | - | 0        | <ul> <li>May be inoperative provided:</li> <li>a) Aural alert operates normally, and</li> <li>b) Autopilot with altitude hold and altitude capture operates normally.</li> </ul>   |               |  |  |  |

| -                        | ENT OF TRANSPORTATIO   | ON     |       |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|--|--------|-------|----------------|--|
| REVISION NO. 32          |  |        |       |                | PAGE NO. 34-21   |
| DATE: XX/XX/X            | XXX  |        | Т     |                | EKEY   |
| AIRCRAFT:<br>Airbus A320 |  |        |       | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation           |  |        | 1     |                |  |
| Sequence No.<br>34-43-01 | Item<br>Traffic Alert and Collision<br>Avoidance System<br>(TCAS II) | 1<br>B | 2 1 1 | 3<br>0         | <ul> <li>4 Change Bar</li> <li>(M) May be inoperative provided: <ul> <li>a) System is deactivated and secured, and</li> <li>b) Enroute or approach procedures do not require its use.</li> </ul> </li> <li>NOTE 1: For aircraft equipped with Mod. 34637/MP P8454 (T2CAS), GPWS Modes 1-5 and GPWS Terrain System are also inoperative.</li> <li>NOTE 2: For aircraft equipped with Mod. 150896/MP P11422, ADS-B In function (ATSAW) is considered inoperative.</li> <li>(M) May be inoperative provided: <ul> <li>a) Not required by 14 CFR,</li> <li>b) System is deactivated and secured, and</li> <li>c) Enroute or approach procedures do not require its use.</li> </ul> </li> <li>NOTE 1: For aircraft equipped with Mod. 34637/MP P8454 (T2CAS), GPWS Modes 1-5 and GPWS Terrain System are also inoperative.</li> </ul> |
|                          |  |        |       |                | ADS-B In function (ATSAW)<br>is considered inoperative.<br>(Continued)   |

| U.S. DEPARTM                    | ENT OF TRANSPORTATIO   | ON |          |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|---------------------------------|--|----|----------|----------------|--|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |  |    |          |                |  |  |  |  |  |
| REVISION NO.                    | -  |    |          |                | PAGE NO. 34-22   |  |  |  |  |
| DATE: XX/XX/X                   | XXX  |    | <u> </u> |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |    | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 34. Navigation                  |  |    |          |                | Change   |  |  |  |  |
| Sequence No.                    | Item   | 1  | 2        | 3              | 4 Change<br>Bar  |  |  |  |  |
| 34-43-01                        | Traffic Alert and Collision<br>Avoidance System<br>(TCAS II)<br>(Cont'd)                 |    |          |                |  |  |  |  |  |
| 1)                              | Combined Traffic Alert<br>(TA) and Resolution<br>Advisory (RA) Dual<br>Display System(s) | С  | 2        | 1              | <ul> <li>May be inoperative on the non-flying pilot side provided:</li> <li>a) TA and RA visual display is operative on the flying pilot side, and</li> <li>b) TA and RA audio function is operative on flying pilot side.</li> </ul>                              |  |  |  |  |
| 2)                              | Resolution Advisory (RA)<br>Display System(s)  | С  | 2        | 1              | (O) One may be inoperative on the non-flying pilot side.   |  |  |  |  |
|                                 |  | С  | -        | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) All Traffic Alert (TA) visual display and audio functions are operative,</li> <li>b) TA only Mode is selected by the crew, and</li> <li>c) Enroute or approach procedures do not require its use.</li> </ul> |  |  |  |  |
| 3)                              | Traffic Alert Display<br>System(s)   | С  | -        | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) RA visual display and audio<br/>functions are operative, and</li> <li>b) Enroute or approach<br/>procedures do not require its<br/>use.</li> </ul>   |  |  |  |  |
| 4)                              | Audio Functions  | В  | 1        | 0              | May be inoperative provided enroute<br>or approach procedures do not<br>require use of TCAS.   |  |  |  |  |
| 5)<br>***                       | Airspace Selection<br>Function   | С  | -        | 0              | One or more may be inoperative.  |  |  |  |  |

| _                        | MENT OF TRANSPORTAT                                  | - |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------|--|---|---|----------------|---|
| REVISION NO. 32          |  |   |   |                | PAGE NO. 34-23  |
| DATE: XX/XX              | /XXXX  |   |   |                |   |
| AIRCRAFT:<br>Airbus A320 |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigatio            |  |   |   | <u> </u>       | Change  |
| Sequence No.<br>34-48-01 | Item<br>Ground Proximity<br>Warning System<br>(GPWS) | A | 2 | 3              | <ul> <li>(O) May be inoperative provided:         <ul> <li>a) Alternate procedures are established and used, and</li> <li>b) Repairs are made within 2 flight-days.</li> </ul> </li> <li>NOTE: For aircraft equipped with Mod. 155269/MP P12511, ROW/ROP function is</li> </ul> |
| 1)                       | Modes 1–4  | A | 4 | 0              | <ul> <li>considered inoperative.</li> <li>(O) May be inoperative provided: <ul> <li>a) Alternate procedures are</li> <li>established and used, and</li> <li>b) Repairs are made within</li> <li>2 flight-days.</li> </ul> </li> </ul>   |
| 2)                       | Test Mode  | A | 1 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) GPWS is considered<br/>inoperative, and</li> <li>b) Repairs are made within<br/>2 flight-days.</li> </ul>   |
| 3)                       | Glideslope Deviation<br>(Mode 5)                     | С | 2 | 1              | One may be inoperative.   |
|                          |  | В | 2 | 0              | One or both may be inoperative.   |
| 4)<br>***                | Advisory Callouts                                    | В | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |
|                          |  | С | - | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Advisory callout not required<br/>by 14 CFR, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>  |
|                          |  |   |   |                | (Continued)   |

| -                            | VENT OF TRANSPORTATION  | NC |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|------------------------------|---|----|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/2 |   |    |   | PAGE NO. 34-24 |   |
| AIRCRAFT:<br>Airbus A320     |   |    | т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation               |   |    |   |                |   |
| Sequence No.                 | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 34-48-01                     | Ground Proximity<br>Warning System<br>(GPWS)<br>(Cont'd)  |    |   |                |   |
| 5)<br>***                    | Terrain Awareness and<br>Warning System (TERR)  |    |   |                |   |
| a)                           | Terrain System-Forward<br>Looking Terrain<br>Avoidance (FLTA) and<br>Premature Descent Alert<br>(PDA Functions) | В  | 1 | 0              | <ul> <li>(O) May be inoperative provided<br/>alternate procedures are established<br/>and used.</li> <li>NOTE: For aircraft equipped with<br/>Mod. 155269/MP P12511,<br/>ROW/ROP function is<br/>considered inoperative.</li> </ul> |
| b)                           | Terrain Displays<br>(TERR ON ND)  | С  | 2 | 1              | One may be inoperative.   |
|                              |   | В  | 2 | 0              | Both may be inoperative.  |
| c)                           | TERR on ND pb-sw ON<br>Light  | С  | 2 | 0              | One or both may be inoperative.   |
| 6)<br>***                    | Runway Awareness and<br>Advisory System (RAAS)  | С  | 1 | 0              | May be inoperative.   |
| 34-48-02                     | GPWS SYS pb-sw<br>FAULT Light   | С  | 1 | 0              | May be inoperative.   |
| 34-48-03                     | GPWS SYS pb-sw OFF<br>Light   | A  | 1 | 0              | <ul> <li>May be inoperative provided:  </li> <li>a) GPWS Modes 1-5 and GPWS<br/>Terrain System are<br/>considered inoperative, and</li> <li>b) Repairs are made within<br/>2 flight-days.</li> </ul>                                |
| 34-48-04                     | GPWS G/S MODE pb-<br>sw OFF Light   | A  | 1 | 0              | <ul> <li>May be inoperative provided:  </li> <li>a) GPWS Modes 1-5 are considered inoperative, and</li> <li>b) Repairs are made within 2 flight-days.</li> </ul>  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|----------------|---|
| REVISION NO<br>DATE: XX/XX/  | -  |   |   | PAGE NO. 34-25 |   |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation   |  |   |   |                |   |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |
| 34-48-05   | GPWS FLAP MODE<br>pb-sw OFF Light  | С | 1 | 0              | May be inoperative.   |
| 34-48-06   | GPWS LDG FLAP 3<br>pb-sw ON Light  | С | 1 | 0              | May be inoperative.   |
| 34-48-07<br>***  | GPWS TERR pb-sw<br>FAULT Light   | С | 1 | 0              | May be inoperative.   |
| 34-48-08<br>***  | GPWS TERR pb-sw<br>OFF Light   | С | 1 | 0              | May be inoperative.   |
| 34-51-01   | DME  | С | 2 | -              | Any in excess of those required by 14 CFR may be inoperative.   |
| 34-52-01   | ATC Transponders and<br>Automatic Altitude<br>Reporting Systems                                    | В | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Operations do not require its use, and</li> <li>b) Prior to flight, approval is obtained from ATC facilities having jurisdiction over the planned route of flight.</li> </ul> |
|  |  | D | - | 1              | Any in excess of those required by 14 CFR may be inoperative.   |
| 1)<br>***  | Elementary and<br>Enhanced Downlink<br>Aircraft Reportable<br>Parameters Not<br>Required by 14 CFR | A | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Operations do not require its use, and</li> <li>b) Repairs are made prior to completion of the next heavy maintenance visit.</li> </ul>                                       |
| 34-53-01   | ADF System   | D | - | -              | Any in excess of those required by 14 CFR may be inoperative.   |

|                          | MENT OF TRANSPORTATI  | ON     |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|--------|---|----------------|--|
| REVISION NC              | ). 32   |        |   |                | PAGE NO. 34-26   |
| AIRCRAFT:<br>Airbus A320 | AIRCRAFT:   |        |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 34. Navigation           |   |        |   |                | Change   |
| Sequence No.<br>34-55-01 | Item<br>VOR Navigation  | 1<br>C | 2 | 3              | 4 Change Bar<br>As required by 14 CFR.   |
| 34-55-02                 | Marker Beacon   | D      | - | 0              | May be inoperative provided<br>approach minimums do not require its<br>use.  |
| 34-55-03                 | Long Range Navigation<br>Systems                                | D      | - | -              | Any in excess of those required by 14 CFR may be inoperative.  |
| 34-57-01<br>***          | DDRMI   |        |   |                |  |
| 1)                       | Compass Card  | с      | 1 | 0              | May be inoperative.  |
| 2)                       | VOR Pointers  | С      | - | -              | As required by 14 CFR.   |
| 3)                       | DME Counters  | С      | - | 0              | As required by 14 CFR.   |
| 4)                       | ADF Pointers  | D      | - | 0              | As required by 14 CFR.   |
| 34-57-02<br>***          | Automatic Dependent<br>Surveillance-Broadcast<br>(ADS-B) System | В      | - | 0              | (O) May be inoperative provided prior<br>to flight, authorization is obtained<br>from ATC facilities having jurisdiction<br>over the planned route of flight using<br>an approved authorization process. |
|                          |   |        |   |                | NOTE: Any ADS-B function that<br>operates normally may be<br>used.   |
|                          |   | С      | - | 1              | One may be inoperative.  |
|                          |   | D      | - | 0              | May be inoperative provided:<br>a) Enroute operations do not<br>require its use, and<br>b) It is not required by 14 CFR.   |
|                          |   |        |   |                | NOTE: Any ADS-B function that<br>operates normally may be<br>used.   |
|                          |   |        |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO<br>DATE: XX/XX   |   |   |   | PAGE NO. 34-27 |  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 34. Navigation   |   | 1 |   |                | Change   |
| Sequence No.<br>34-57-02<br>***                                      | Item<br>Automatic Dependent<br>Surveillance-Broadcast<br>(ADS-B) System<br>(Cont'd) | 1 | 2 | 3              | 4 Change<br>Bar  |
| 1)<br>***  | ADS-B Out Extended<br>Squitter Transmissions  | В | - | 0              | (O) May be inoperative provided prior<br>to flight, authorization is obtained<br>from ATC facilities having jurisdiction<br>over the planned route of flight using<br>an approved authorization process. |
|  |   |   |   |                | NOTE: Any ADS-B function that<br>operates normally may be<br>used.   |
|  |   | С | - | 1              | One may be inoperative.  |
|  |   | D | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Enroute operations do not require its use, and</li> <li>b) It is not required by 14 CFR.</li> </ul>  |
|  |   |   |   |                | NOTE: Any ADS-B function that<br>operates normally may be<br>used  |
| 2)<br>***  | ADS-B Out UAT<br>Transmissions  | В | - | 0              | (O) May be inoperative provided prior<br>to flight, authorization is obtained<br>from ATC facilities having jurisdiction<br>over the planned route of flight using<br>an approved authorization process. |
|  |   |   |   |                | NOTE: Any ADS-B Out function that<br>operates normally may be<br>used.   |
|  |   | С | - | 1              | One may be inoperative.  |
|  |   |   |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO  | -   |   |   | PAGE NO. 34-28 |  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigation</b>                    | AIRCRAFT:<br>Airbus A320  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                          |
| Sequence No.   | ltem  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 34-57-02<br>***  | Automatic Dependent<br>Surveillance-Broadcast<br>(ADS-B) System<br>(Cont'd) |   |   |                | Ball   |
| 2)   | ADS-B Out UAT<br>Transmissions<br>(Cont'd)                                  |   |   |                |  |
|  |   | D | - | 0              | May be inoperative provided:<br>a) Enroute operations do not<br>require its use, and<br>b) It is not required by 14 CFR. |
|  |   |   |   |                | NOTE: Any ADS-B Out function that<br>operates normally may be<br>used  |
| 3)<br>***  | ADS-B In Transmissions  | С | - | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                                     |
|  |   |   |   |                | NOTE: Any ADS-B In function that<br>operates normally may be<br>used.  |
|  |   | D | - | 0              | May be inoperative provided operations do not require its use.   |
|  |   |   |   |                | NOTE: Any ADS-B function that<br>operates normally may be<br>used.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|---|---|----------------|--|
| FEDERAL AV   |  |   |   |                | PAGE NO. 34-29   |
| DATE: XX/XX/   | -  |   |   | FAGE NO. 34-29 |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 34. Navigation   |  |   |   |                |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |
| 34-58-01<br>***  | Global Positioning<br>System   |   |   |                |  |
| 1)   | Aircraft not equipped with ADS-B Out Function  |   |   |                |  |
| a)   | Without VOR/MKR<br>function activated on<br>iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844) | С | 2 | 1              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) One DME is operative.</li> </ul>  |
|  |  | D | 2 | 0              | May be inoperative provided procedures do not require its use.   |
| b)   | With VOR/MKR function<br>activated on iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844)       | С | 2 | 1              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both ILS are operative,</li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are<br/>established and used.</li> </ul>          |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>A One VOR is checked<br/>operative,</li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are<br/>established and used.</li> </ul> |
|  |  |   |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT L  | IST.         |
|--|--|---|---|----------------|---|--------------|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |                | PAGE NO. 34   | 1-30         |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |              |
| 34. Navigation   |  | 1 | 1 | 1              |   |              |
| Sequence No.   | Item   | 1 | 2 | 3              |   | hange<br>Bar |
| 34-58-01<br>***  | Global Positioning<br>System<br>(Cont'd)   |   |   |                |   |              |
| 2)   | Aircraft equipped with<br>ADS-B Out Function<br>compliant with DO260 or<br>DO260B  |   |   |                |   |              |
| a)   | Without VOR/MKR<br>function activated on<br>iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844) | С | 2 | 1              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |              |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) One DME is operative.</li> </ul> |              |
|  |  |   |   |                | NOTE: If no GPS is available, ADS-B<br>Transmissions are considered<br>inoperative.   |              |
|  |  | D | 2 | 0              | May be inoperative provided procedures do not require its use.  |              |
|  |  |   |   |                | NOTE: If no GPS is available, ADS-B<br>Transmissions are considered<br>inoperative.   |              |
|  |  |   |   |                | (Continued)   |              |

| U.S. DEPARTI                    | MENT OF TRANSPORTATIO  | ON |    |                               |   |  |  |  |
|---------------------------------|--|----|----|-------------------------------|---|--|--|--|
| FEDERAL AVI                     | ATION ADMINISTRATION   |    |    | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
| REVISION NO. 32                 |  |    |    |                               | PAGE NO. 34-31  |  |  |  |
| DATE: XX/XX/                    | XXXX   |    |    |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |    | Т. | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 34. Navigation                  |  |    |    |                               | A Change  |  |  |  |
| Sequence No.<br>34-58-01<br>*** | Item<br>Global Positioning<br>System<br>(Cont'd)   | 1  | 2  | 3                             | 4 Change<br>Bar   |  |  |  |
| 2)                              | Aircraft equipped with<br>ADS-B Out Function<br>compliant with DO260 or<br>DO260B<br>(Cont'd)                        |    |    |                               |   |  |  |  |
| b)                              | With VOR/MKR function<br>activated on iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844) | С  | 2  | 1                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |  |  |  |
|                                 |  | С  | 2  | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) Both ILS are operative,</li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are<br/>established and used.</li> </ul>           |  |  |  |
|                                 |  |    |    |                               | NOTE: If no GPS is available, ADS-B<br>Transmissions are considered<br>inoperative.   |  |  |  |
|                                 |  | С  | 2  | 0                             | <ul> <li>(O) May be inoperative provided:</li> <li>a) One VOR is checked<br/>operative,</li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are<br/>established and used.</li> </ul> |  |  |  |
|                                 |  |    |    |                               | NOTE: If no GPS is available, ADS-B<br>Transmissions are considered<br>inoperative.   |  |  |  |
|                                 |  |    |    |                               | (Continued)   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|----------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX                                  |  |   |   |                | PAGE NO. 34-32  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 34. Navigation   |  |   |   |                |   |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |
| 34-58-01<br>***  | Global Positioning<br>System<br>(Cont'd)   |   |   |                |   |
| 3)   | Aircraft equipped with<br>ADS-B Out Function<br>compliant with DO260A  |   |   |                |   |
| a)   | Without VOR/MKR<br>function activated on<br>iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844) | С | 2 | 1              | <ul> <li>(O) May be inoperative provided<br/>alternate procedures are established<br/>and used.</li> <li>NOTE: If GPS 1(2) and FMGC 2(1)<br/>are inoperative, ADS-B<br/>Transmissions are considered<br/>inoperative.</li> </ul>  |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided:</li> <li>a) Alternate procedures are<br/>established and used, and</li> <li>b) One DME is operative.</li> <li>NOTE: If GPS 1(2) and FMGC 2(1)<br/>are inoperative, ADS-B<br/>Transmissions are considered<br/>inoperative.</li> </ul> |
|  |  | D | 2 | 0              | May be inoperative provided<br>procedures do not require its use.<br>NOTE: If GPS 1(2) and FMGC 2(1)<br>are inoperative, ADS-B<br>Transmissions are considered<br>inoperative.  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|---|----------------|---|--|--|--|--|
| REVISION NO. 32  |  |   |   |                | PAGE NO. 34-33  |  |  |  |  |
| DATE: XX/XX/   | XXXX   |   |   |                |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 34. Navigation   |  |   |   |                |   |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 34-58-01<br>***  | Global Positioning<br>System<br>(Cont'd)   |   |   |                |   |  |  |  |  |
| 3)   | Aircraft equipped with<br>ADS-B Out Function<br>compliant with DO260A<br>(Cont'd)                                    |   |   |                |   |  |  |  |  |
| b)   | With VOR/MKR function<br>activated on iMMR<br>(Mod 160752/<br>MP P15847) or on<br>GLU2100 (Mod 160749/<br>MP P15844) | С | 2 | 1              | <ul> <li>(O) May be inoperative provided<br/>alternate procedures are established<br/>and used.</li> <li>NOTE: If no GPS is available, ADS-B<br/>Transmissions are considered<br/>inoperative.</li> </ul>   |  |  |  |  |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) Both ILS are operative,</li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are established and used.</li> </ul> </li> <li>NOTE: If no GPS is available, ADS-B Transmissions are considered inoperative.</li> </ul>                                    |  |  |  |  |
|  |  | С | 2 | 0              | <ul> <li>(O) May be inoperative provided: <ul> <li>a) One VOR is checked</li> <li>operative,</li> </ul> </li> <li>b) One DME is operative, and</li> <li>c) Alternate procedures are established and used.</li> </ul> <li>NOTE: If no GPS is available, ADS-B <ul> <li>Transmissions are considered inoperative.</li> </ul></li> |  |  |  |  |

|   | MENT OF TRANSPORTATI | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|---|----------------------|----|---|----------------|---|
| REVISION NO. 32<br>DATE: XX/XX/XXXX               |                      |    |   |                | PAGE NO. 34-34  |
| AIRCRAFT:<br>Airbus A320<br><b>34. Navigation</b> |                      |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| Sequence No.                                      | Item                 | 1  | 2 | 3              | 4 Change<br>Bar   |
| 34-61-01  | Navigation Databases | A  | - | 0              | <ul> <li>May be inoperative provided:</li> <li>a) Operations do not require its use,</li> <li>b) It is not used in a primary navigation system required by 14 CFR,</li> <li>c) Alternate procedures are developed and used,</li> <li>d) The ICAO Flight Plan is updated (as required) to notify ATC of the navigation equipment status of the aircraft, and</li> <li>e) It is repaired within 10 flight-days.</li> <li>NOTE: An out-of-currency or out-of-date navigation database is not authorized MMEL relief per 14 CFR.</li> </ul> |

| -                                   | MENT OF TRANSPORTATION  | ON |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|-------------------------------------|---|----|---|---|--|--|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |    |   |   | PAGE NO. 35-1  |  |
| AIRCRAFT:<br>Airbus A320            |   |    | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |
| 35. Oxygen<br>Sequence No.          | Item  | 1  | 2 | 3   | 4 Change<br>Bar  |  |
| 35-10-04                            | Exterior Oxygen<br>Overpressure Indicator<br>Disc<br>(Green Disc) | С  | - | 0   | (O) May be damaged or missing.   |  |
| 35-13-01                            | Indications on<br>DOOR/OXY ECAM Page                              |    |   |   |  |  |
| 1)                                  | OXY High Pressure<br>Indication                                   |    |   |   |  |  |
|                                     | A318/A319/A320/A321<br>without Mod. 161337/<br>MP K17059          | С  | 1 | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) The oxygen pressure is<br/>verified by direct reading<br/>before each departure,</li> <li>b) The oxygen pressure is<br/>sufficient for the intended<br/>flight, and</li> <li>c) The REGUL LO PR indication<br/>is operative.</li> </ul> |  |
|                                     | A318/A319/A320/A321<br>with Mod. 161337/<br>MP K17059             | С  | 2 | 0   | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) The oxygen pressure is verified by direct reading before each departure,</li> <li>b) The oxygen pressure is sufficient for the intended flight, and</li> <li>c) The REGUL 1(2)(1+2) LO PR indication is operative.</li> </ul>           |  |
|                                     |   |    |   |   | (Continued)  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|---|---|----------------|--|
| REVISION NO<br>DATE: XX/XX/2   | -  |   |   |                | PAGE NO. 35-2  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS         |
| 35. Oxygen   | ltom   | 1 | 2 | 3              | 4 Change   |
| Sequence No.<br>35-13-01   | Item<br>Indications on<br>DOOR/OXY ECAM Page<br>(Cont'd) | 1 | 2 | 3              | 4 Bar  |
| 2)   | REGUL LO PR<br>Indication                                |   |   |                |  |
|  | A318/A319/A320/A321<br>without Mod. 161337/<br>MP K17059 | С | 1 | 0              | (M)(O) May be inoperative provided<br>the oxygen pressure is verified before<br>each departure.                |
| 3)   | REGUL 1(2)(1+2) LO PR<br>Indication                      |   |   |                |  |
|  | A318/A319/A320/A321<br>with Mod. 161337/<br>MP K17059    | С | 3 | 0              | (M)(O) One or more may be<br>inoperative provided the oxygen<br>pressure is verified before each<br>departure. |
| 35-13-02   | Crew Supply pb Switch                                    |   |   |                |  |
| 1)   | OFF Light  | С | 1 | 0              | May be inoperative.  |

|                                     | MENT OF TRANSPORTATION                    | NC |   |          | MASTER MINIMUM EQUIPMEN   | T LIST        |
|-------------------------------------|---|----|---|----------|---|---------------|
| REVISION NO. 32<br>DATE: XX/XX/XXXX |   |    |   |          | PAGE NC   | . 35-3        |
| AIRCRAFT:<br>Airbus A320            |   |    | Т | 1.<br>2. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |               |
|                                     |   |    |   |          | REMARKS OR EXCEPTIONS   |               |
| 35. Oxygen                          |   |    | - |          |   |               |
| Sequence No.                        | Item                                      | 1  | 2 | 3        | 4   | Change<br>Bar |
| 35-21-01                            | Passenger Oxygen<br>Storage               |    |   |          |   |               |
| 1)                                  | Passenger Oxygen<br>Modules               | В  | - | -        | May be inoperative provided<br>associated seats are placarded<br>"DO NOT OCCUPY".   |               |
|                                     |   | В  | - | -        | (O) Modules may be inoperative<br>provided airplane remains at or below<br>FL 250.  |               |
| 2)                                  | Flight Attendant Oxygen<br>Module         | В  | - | -        | May be inoperative provided<br>associated flight attendant seat(s) is<br>considered inoperative.  |               |
|                                     |   | В  | - | -        | (O) Modules may be inoperative<br>provided airplane remains at or below<br>FL 250.  |               |
| 3)<br>***                           | Galley Modules                            | В  | - | -        | (O) May be inoperative and<br>associated galley occupied provided<br>airplane remains at or below FL 250.   |               |
|                                     |   | В  | - | -        | May be inoperative and associated<br>galley occupied provided a portable<br>oxygen bottle and mask are available<br>for the associated galley occupant. |               |
| 35-21-02                            | Lavatory Oxygen Module                    | В  | - | -        | (M) May be inoperative provided<br>lavatory is placarded "INOPERATIVE<br>– DO NOT OCCUPY".  |               |
| 35-23-01                            | Passenger Oxygen<br>Manual Control System | С  | 1 | 0        | (O) May be inoperative provided airplane remains at or below FL 250.  |               |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|---|---|---|----------------|--|--|--|--|
| REVISION NO<br>DATE: XX/XX/  |   |   |   |                | PAGE NO. 35-4  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 35. Oxygen   |   | 1 | 1 | 1              |  |  |  |  |
| Sequence No.   | Item                                    | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |
| 35-23-02   | Passenger Oxygen<br>AUTO Control System | С | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Airplane remains at or below<br/>FL 300, and</li> <li>b) Passenger oxygen manual<br/>control system is verified to<br/>operate normally.</li> </ul> |  |  |  |
|  |   | С | 1 | 0              | (O) May be inoperative provided<br>airplane remains at or below FL 250.  |  |  |  |
| 35-23-03   | PASSENGER SYS ON<br>Light               | С | 1 | 0              | May be inoperative.  |  |  |  |
| 35-23-04<br>***  | HI ALT LANDING pb-sw<br>ON Light        | С | 1 | 0              | May be inoperative.  |  |  |  |
| 35-23-05<br>***  | HI ALT LANDING pb-sw                    | С | 1 | 0              | (M)(O) May be inoperative provided<br>that the passenger oxygen AUTO<br>control is verified operative.   |  |  |  |
|  |   | С | 1 | 0              | May be inoperative provided that the passenger oxygen AUTO control is considered inoperative.  |  |  |  |

| -                        | MENT OF TRANSPORTATION  | ON |          |               | MASTER MINIMUM EQUIPMENT  | LIST          |  |  |
|--------------------------|---|----|----------|---------------|---|---------------|--|--|
| <b>REVISION NO</b>       | REVISION NO. 32   |    |          | PAGE NO. 35-5 |   |               |  |  |
| DATE: XX/XX/             | XXXX  |    |          |               |   |               |  |  |
|                          |   |    | Т        | ABLI          | EKEY  |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    |          | 2.<br>3.      | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |
| 35. Oxygen               |   |    | <u> </u> |               |   |               |  |  |
| Sequence No.             | Item  | 1  | 2        | 3             | 4   | Change<br>Bar |  |  |
| 35-31-01                 | Portable Oxygen Bottles<br>or Units<br>(Including Masks and<br>Hoses) | D  | -        | -             | <ul> <li>(M) Any in excess of those required<br/>by 14 CFR may be inoperative or<br/>removed provided: <ul> <li>a) An inoperative or not properly<br/>serviced portable oxygen<br/>bottle/unit remains in a<br/>certified location until<br/>removed or serviced at the<br/>next suitable maintenance<br/>facility,</li> <li>b) Location placarding is<br/>removed or obscured, and</li> <li>c) Required distribution is<br/>maintained.</li> </ul> </li> <li>NOTE 1: Inoperative portable oxygen<br/>bottles or units, removed<br/>from a certified location or<br/>removed from the aircraft,<br/>are subject to 49 CFR<br/>dangerous goods<br/>regulations.</li> <li>NOTE 2: Medical equipment installed<br/>in the aircraft as part of an<br/>EMS operations is not<br/>considered part of the<br/>normal complement of<br/>equipment. No MMEL relief<br/>applies to that equipment<br/>and 14 CFR maintenance<br/>and inspection requirements<br/>do not apply.</li> </ul> | Bar           |  |  |
| 1)<br>***                | Tamper seals or Tags  | С  | -        | -             | (O) May be inoperative, damaged, or<br>missing provided proper installation<br>and servicing is verified at each<br>preflight.  |               |  |  |

| -                           | MENT OF TRANSPORTATI  | ION |   | MASTER MINIMUM EQUIPMENT LIST |   |         |  |  |
|-----------------------------|---|-----|---|-------------------------------|---|---------|--|--|
| REVISION NO<br>DATE: XX/XX/ | -   |     |   |                               | PAGE NC   | ). 35-6 |  |  |
| AIRCRAFT:<br>Airbus A320    |   |     | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |         |  |  |
| 35. Oxygen                  |   | 1   |   |                               |   | Change  |  |  |
| Sequence No.<br>35-32-01    | Item<br>Portable Protective<br>Breathing Equipment<br>(PBE) | D   | - | -                             | <ul> <li>Any in excess of those required by<br/>14 CFR may be inoperative or<br/>removed provided: <ul> <li>a) Inoperative PBE remains in a<br/>certified location until<br/>removed from the aircraft at<br/>the next suitable maintenance<br/>facility,</li> <li>b) Location placarding is<br/>removed or obscured, and</li> <li>c) Required distribution is<br/>maintained.</li> </ul></li></ul> | Bar     |  |  |
| 1)<br>***                   | Tamper seals or Tags  | С   | - | -                             | <ul> <li>NOTE: Inoperative PBE units<br/>removed from a certified<br/>location, or removed from the<br/>aircraft, are subject to 49 CFR<br/>dangerous goods regulations.</li> <li>(O) May be inoperative, damaged, or<br/>missing provided proper installation<br/>and servicing is verified at each<br/>preflight.</li> </ul>  |         |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|---|----------------|---|
| REVISION NO<br>DATE: 08/13/2   |  |   |   |                | PAGE NO. 36-1   |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic  | >  |   |   |                |   |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |
| 36-00-00<br>1)   | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>Fault(s) Indicated by AIR<br>BLEED |   |   |                |   |
| a)   | A318/A319ceo/A320ceo/<br>A321ceo Aircraft with<br>Mod. 36595/<br>MP P9594 and without<br>Mod. 161397/<br>MP P14826                         | С | - | -              | (M) May be displayed provided it is<br>verified that the CFDS does not<br>report a fault on APU Leak detection<br>loop.   |
|  |  | С | _ | -              | May be displayed provided APU Leak<br>detection loop is considered<br>inoperative.<br>NOTE: Dispatch with this maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation. |
|  |  |   |   |                | (Continued)   |

| FEDERAL AVI                    | ATION ADMINISTRATION   |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------------|--|---|---|----------------|---|
| REVISION NO.<br>DATE: 08/13/20 | -  |   |   |                | PAGE NO. 36-2   |
| AIRCRAFT:<br>Airbus A320       |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic                  |  |   |   |                |   |
| Sequence No.                   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |
| 36-00-00                       | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd) |   |   |                |   |
| 1)                             | Fault(s) Indicated by AIR<br>BLEED<br>(Cont'd)   |   |   |                |   |
| b)                             | A318/A319ceo/A320ceo/<br>A321ceo without<br>Mod. 36595/MP P9594  | С | - | -              | (M) May be displayed provided it is<br>verified that the CFDS does not<br>report a fault on BMC, pylon leak<br>detection loop, or APU Leak<br>detection loop.   |
|                                |  | С | - | -              | <ul> <li>(M) May be displayed provided:</li> <li>a) Verify CFDS does not report<br/>faults on BMC 1, LH pylon<br/>leak detection loop, or the<br/>APU Leak detection loop,</li> <li>b) If CFDS reports a fault on<br/>BMC 2, BMC 2 is considered<br/>inoperative, and</li> <li>c) If CFDS reports a fault on RH<br/>pylon leak detection loop, RH<br/>pylon leak detection loop is<br/>considered inoperative.</li> </ul> |
|                                |  |   |   |                | (Continued)   |

| -                                   | IENT OF TRANSPORTATIO   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|-------------------------------------|---|---|---|-------------------------------|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |   |   |                               | PAGE NO. 36-3  |
| AIRCRAFT:<br>Airbus A320            |   |   | Т | 1.<br>2.<br>3.                | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic                       |   |   |   |                               |  |
| Sequence No.                        | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 36-00-00                            | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd)<br>Eault(s) Indicated by AIP |   |   |                               | Bar  |
| 1)                                  | Fault(s) Indicated by AIR<br>BLEED<br>(Cont'd)  |   |   |                               |  |
| b)                                  | A318/A319ceo/A320ceo/<br>A321ceo without<br>Mod. 36595/MP P9594<br>(Cont'd)   | С | _ | _                             | <ul> <li>(M) May be displayed provided:</li> <li>a) Verify CFDS does not report<br/>faults on BMC 2 or RH pylon<br/>leak detection loop,</li> <li>b) If CFDS reports a fault on<br/>BMC 1, BMC 1 is considered<br/>inoperative,</li> <li>c) If CFDS reports a fault on LH<br/>pylon leak detection loop, LH<br/>pylon leak detection loop is<br/>considered inoperative, and</li> <li>d) If CFDS reports a fault on<br/>APU leak detection loop, APU<br/>leak detection loop is<br/>considered inoperative.</li> </ul> |
| c)                                  | A319neo/A320neo/<br>A321neo or<br>A318/A319ceo/<br>A320ceo/A321ceo<br>aircraft with<br>Mod. 36595/MP P9594<br>and Mod. 161397/<br>MP P14826   | С | - | -                             | NOTE: Dispatch with maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |

|  | ON   |   |  | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|--|---|--|--|--|--|--|
| ATION ADMINISTRATION<br>31<br>024  |  | PAGE NO. 36-4   |  |  |  |  |  |
|  |  | Т   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS    |  |  |  |  |
|  |  | <b>I</b>  |  |  |  |  |  |
| Item   | 1  | 2   | 3  | 4 Change<br>Bar  |  |  |  |
| Bleed Air Supply<br>Systems  |  |   |  |  |  |  |  |
| A318/A319ceo/A320ceo/<br>A321ceo Aircraft with or<br>without Mod. 31283/<br>MP P7125 or<br>A319neo/A320neo/<br>A321neo | С  | 2   | 1  | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative provided: <ul> <li>a) The associated ENG BLEED pb-sw is selected OFF,</li> <li>b) The aircraft is not operated in known or forecast icing conditions,</li> <li>c) Airplane remains at or below FL 310, and</li> <li>d) The X-BLEED valve selector switch is selected OPEN.</li> </ul> </li> </ul>  |  |  |  |
| A318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neo   | С  | 2   | 1  | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, one may be inoperative provided: <ul> <li>a) The associated ENG BLEED pb-sw is selected OFF,</li> <li>b) The aircraft is not operated in known or forecast icing conditions,</li> <li>c) The speedbrakes are operative, and</li> <li>d) The X-BLEED valve selector switch is selected OPEN.</li> </ul> </li> </ul>  |  |  |  |
| A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo  | С  | 2   | 1  | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, one may be inoperative<br/>provided: <ul> <li>a) The associated ENG BLEED<br/>pb-sw is selected OFF,</li> <li>b) The aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>c) Airplane remains at or below<br/>FL 370,</li> <li>d) The speedbrakes are<br/>operative, and</li> <li>e) The X-BLEED valve selector<br/>switch is selected OPEN.</li> </ul> </li> <li>(Continued)</li> </ul>   |  |  |  |
|  | ATION ADMINISTRATION<br>31<br>024<br>Item<br>Bleed Air Supply<br>Systems<br>A318/A319ceo/A320ceo/<br>A321ceo Aircraft with or<br>without Mod. 31283/<br>MP P7125 or<br>A319neo/A320neo/<br>A321neo<br>A318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neo<br>A318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neo | 31D24Item1Bleed Air Supply<br>SystemsCA318/A319ceo/A320ceo/<br>A321ceo Aircraft with or<br>without Mod. 31283/<br>MP P7125 or<br>A319neo/A320neo/<br>A321neoCA318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neoCA318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neoCA318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neoCA318/A320ceo/A321ceo<br>with Mod. 31283/<br>MP P7125 or<br>A320neo/A321neoC | ATION ADMINISTRATION<br>31<br>024<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T<br>T | ATION ADMINISTRATION3131024Image: Strategy stra |  |  |  |

|                               | MENT OF TRANSPORTATI                    |   |   |   |   |        |  |  |
|-------------------------------|---|---|---|---|---|--------|--|--|
|                               | ATION ADMINISTRATION                    |   |   | MASTER MINIMUM EQUIPMENT LIST   |   |        |  |  |
| REVISION NO                   |   |   |   | PAGE NO.  | 36-5  |        |  |  |
| DATE: 08/13/2                 | 2024                                    |   |   |   |   |        |  |  |
| AIRCRAFT:<br>Airbus A320      |   |   | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |        |  |  |
| 36. Pneumatic<br>Sequence No. | ;<br>Item                               | 1 | 2 | 3   | 4   | Change |  |  |
| 36-11-01                      | Bleed Air Supply<br>Systems<br>(Cont'd) |   | 2 |   |   | Bar    |  |  |
| 4)                            | A318 with Mod. 31283/<br>MP P7125       | С | 2 | 1   | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, one may be inoperative<br/>provided: <ul> <li>a) The associated ENG BLEED<br/>pb-sw is selected OFF,</li> <li>b) The aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>c) Airplane remains at or below<br/>FL 350,</li> <li>d) The speedbrakes are<br/>operative, and</li> <li>e) The X-BLEED valve selector<br/>switch is selected OPEN.</li> </ul> </li> </ul> |        |  |  |
| 36-11-02                      | Bleed Valves (PRV)                      | С | 2 | 1   | (M)(O) Except for ETOPS beyond<br>120 minutes, one may be inoperative<br>secured closed provided associated<br>bleed air supply system is considered<br>inoperative.  |        |  |  |

|                              | MENT OF TRANSPORTATIO                                   |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |  |
|------------------------------|---|---|-------------------------------|----------------|--|--|--|
| REVISION NO<br>DATE: 08/13/2 |   |   | PAGE NO. 36-6                 |                |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |   |                               | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 36. Pneumatio                |   | 1 | 1                             | 1              | Change   |  |  |
| Sequence No.<br>36-11-03     | Item<br>Overpressure Valves                             | 1 | 2                             | 3              | 4 Change<br>Bar  |  |  |
| 1)                           | A318/A319ceo/A320ceo<br>A321ceo                         | С | 2                             | 1              | (O) One may be inoperative closed<br>provided associated bleed air supply<br>system is considered inoperative.   |  |  |
|                              |   | С | 2                             | 0              | May be inoperative in open position<br>provided ENG BLEED FAULT or<br>ENG BLEED ABNORM PR cautions<br>were not triggered during previous<br>flight.  |  |  |
| 2)                           | A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines    | С | 2                             | 1              | (O) One may be inoperative in the<br>open position provided associated<br>bleed air supply system is considered<br>inoperative.  |  |  |
|                              |   | С | 2                             | 0              | May be inoperative in open position<br>provided ENG BLEED FAULT or<br>ENG BLEED ABNORM PR cautions<br>were not triggered during previous<br>flight.  |  |  |
| 3)                           | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines | С | 2                             | 1              | (O) One may be inoperative in open<br>position provided associated bleed air<br>supply system is considered<br>inoperative.  |  |  |
|                              |   | С | 2                             | 0              | May be inoperative in open position<br>provided ENG BLEED FAULT or<br>ENG BLEED ABNORM PR cautions<br>were not triggered during previous<br>flight.  |  |  |
|                              |   | С | 2                             | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Affected valve is deactivated<br/>in open position, and</li> <li>b) Associated bleed air supply<br/>system is considered<br/>inoperative.</li> </ul> |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |        |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|--|--------|---|----------------|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   | -  |        |   |                | PAGE NO. 36-7  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |        | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 36. Pneumatic  |  |        |   |                | Change   |  |  |  |
| Sequence No.<br>36-11-04   | Item<br>Fan Air Valves (FAV)               | 1<br>C | 2 | 3              | 4 Change Bar<br>(O) Except for ETOPS beyond<br>120 minutes, one may be inoperative<br>provided associated bleed air supply<br>system is not used.  |  |  |  |
| 36-11-05   | Bleed Air Precooler<br>Exchangers          | С      | 2 | 1              | (O) Except for ETOPS beyond<br>120 minutes, one may be inoperative<br>provided associated bleed air supply<br>system is not used.  |  |  |  |
| 36-11-06   | Intermediate Pressure<br>Check Valves (IP) | С      | 2 | 1              | (O) One may be inoperative provided associated bleed air supply system is considered inoperative.  |  |  |  |
|  |  | С      | 2 | 1              | <ul> <li>(M)(O) One may be inoperative in open position provided:</li> <li>a) Associated HP valve is secured closed, and</li> <li>b) Opposite bleed air supply system is operative.</li> </ul> |  |  |  |
| 36-11-07   | High Pressure Valves<br>(HPV)              | С      | 2 | 1              | (O) One may be inoperative in closed<br>position provided associated bleed air<br>supply system is considered<br>inoperative.  |  |  |  |
|  |  | С      | 2 | 1              | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Affected HP valve is secured closed, and</li> <li>b) Opposite bleed air supply system is operative.</li> </ul>                    |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|---|---|----------------|--|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   |  |   |   | PAGE NO. 36-8  |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 36. Pneumatic  |  |   | I |                |  |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 36-11-08   | Bleed Monitoring<br>Computer (BMC)   |   |   |                | bar  |  |  |  |  |
| 1)   | A318/A319ceo/A320ceo/<br>A321ceo Aircraft Fitted<br>with Mod. 33844/<br>MP P8341 or<br>Mod. 33847/<br>MP P8340 or<br>Mod. 33687/<br>MP P8297 or<br>A319neo/A320neo/<br>A321neo |   |   |                |  |  |  |  |  |
| a)   | BMC 1  | С | 1 | 0              | Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:<br>a) BMC 2 is operative, and<br>b) APU leak detection loop is<br>considered inoperative.  |  |  |  |  |
|  |  | С | 1 | 0              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative<br/>provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated Bleed air supply<br/>system is considered<br/>inoperative,</li> <li>c) APU check valve is removed<br/>and replaced by a blanking<br/>cap, and</li> <li>d) APU air supply system is<br/>considered inoperative.</li> </ul> </li> </ul> |  |  |  |  |
|  |  |   |   |                | (Continued)  |  |  |  |  |

| -                               | IENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|---------------------------------|--|----|---|----------------|---|
| FEDERAL AVIATION ADMINISTRATION |  |    |   |                | · · · · · · · · · · · · · · · · · · ·   |
| REVISION NO.                    |  |    |   |                | PAGE NO. 36-9   |
| DATE: 08/13/20                  | 024  |    |   |                |   |
| AIRCRAFT:<br>Airbus A320        |  |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic                   |  |    |   |                | Change  |
| Sequence No.<br>36-11-08        | Item<br>Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 1)                              | A318/A319ceo/A320ceo/<br>A321ceo Aircraft Fitted<br>with Mod. 33844/<br>MP P8341 or<br>Mod. 33847/<br>MP P8340 or<br>Mod. 33687/<br>MP P8297 or<br>A319neo/A320neo/<br>A321neo<br>(Cont'd) |    |   |                |   |
| a)                              | BMC 1<br>(Cont'd)  | В  | 1 | 0              | <ul> <li>(M) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative</li> <li>provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated Bleed air supply system is considered inoperative,</li> <li>c) APU check valve is checked operative,</li> <li>d) AIR APU BLEED LEAK alert was not displayed during the previous flight, and</li> <li>e) APU air supply system is considered inoperative.</li> </ul> </li> </ul> |
| b)                              | BMC 2  | С  | 1 | 0              | Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided:<br>a) BMC 1 is operative, and<br>b) Associated Bleed air supply<br>system is considered<br>inoperative.<br>(Continued)  |

| U.S. DEPARTM                        | IENT OF TRANSPORTATIO   | ON   |   |   |  |
|-------------------------------------|---|------|---|---|--|
| -                                   | TION ADMINISTRATION   | •••• |   |   | MASTER MINIMUM EQUIPMENT LIST  |
| REVISION NO. 31<br>DATE: 08/13/2024 |   |      |   |   | PAGE NO. 36-10   |
| AIRCRAFT:<br>Airbus A320            |   |      |   |   | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic                       |   |      | - | - |  |
| Sequence No.                        | Item  | 1    | 2 | 3 | 4 Change<br>Bar  |
| 36-11-08                            | Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)  |      |   |   |  |
| 2)                                  | A318/A319ceo/A320ceo/<br>A321ceo Aircraft Fitted<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/<br>MP P8340 or<br>Mod. 33687/MP P8297 |      |   |   |  |
| a)                                  | BMC 1   | С    | 1 | 0 | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated BLEED pb-sw is set to OFF,</li> <li>c) Associated PACK pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) APU bleed leak detection loop is considered inoperative,</li> <li>f) Aircraft is not operated in known or forecast icing conditions, and</li> <li>g) Airplane remains at or below FL 310.</li> </ul> </li> </ul> |
| b)                                  | BMC 2   | С    | 1 | 0 | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative</li> <li>provided: <ul> <li>a) BMC 1 is operative,</li> <li>b) Associated BLEED pb-sw is set to OFF,</li> <li>c) Associated PACK pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) Aircraft is not operated in known or forecast icing conditions, and</li> <li>f) Airplane remains at or below FL 310.</li> </ul> </li> <li>(Continued)</li> </ul>  |

| IENT OF TRANSPORTATI  | ON  |   |  |  |  |  |
|---|---|---|--|--|--|--|
|   | ••••  |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
| • ·   |   | PAGE NO. 36-11  |  |  |  |  |
| RCRAFT:<br>rbus A320  |   |   |  | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
|   |   |   |  |  |  |  |
| ltem  | 1   | 2   | 3  | 4 Change<br>Bar  |  |  |
| Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)  |   |   |  |  |  |  |
| A320ceo/A321ceo<br>Aircraft Fitted with<br>Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340 |   |   |  |  |  |  |
| BMC 1   | С   | 1   | 0  | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated BLEED pb-sw is set to OFF,</li> <li>c) Associated PACK pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) APU bleed leak detection loop is considered inoperative,</li> <li>f) Aircraft is not operated in known or forecast icing conditions, and</li> <li>g) Speedbrakes are operative.</li> </ul> </li> </ul> |  |  |
| BMC 2   | С   | 1   | 0  | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) BMC 1 is operative,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) Aircraft is not operated in<br/>known or forecast icing<br/>conditions, and</li> <li>f) Speedbrakes are operative.</li> </ul> </li> </ul>   |  |  |
|   | ATION ADMINISTRATION<br>31<br>024<br>Item<br>Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)<br>A320ceo/A321ceo<br>Aircraft Fitted with<br>Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340<br>BMC 1 | 31         D24         Item       1         Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)       Image: Computer (BMC)<br>(Cont'd)         A320ceo/A321ceo<br>Aircraft Fitted with<br>Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340       Image: Computer (BMC)<br>BMC 1         BMC 1       C | ATION ADMINISTRATION<br>31<br>024<br>T<br>Memodel Monitoring<br>Computer (BMC)<br>(Cont'd)<br>A320ceo/A321ceo<br>Aircraft Fitted with<br>Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340<br>BMC 1<br>C<br>1 | ATION ADMINISTRATION<br>31<br>024<br>TABLI<br>1.<br>2.<br>3.<br>4.<br><u>Item 1 2 3</u><br>Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)<br>A320ceo/A321ceo<br>Aircraft Fitted with<br>Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340<br>BMC 1 C 1 0  |  |  |

| U.S. DEPARTN                    | IENT OF TRANSPORTATI   | ON |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|---------------------------------|--|----|---|---|---|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |  |    |   |   |   |  |  |  |
| REVISION NO.<br>DATE: 08/13/20  | -  |    |   |   | PAGE NO. 36-12  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |  |    | T | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |  |
| 36. Pneumatic                   |  |    |   |   | -   |  |  |  |
| Sequence No.                    | Item   | 1  | 2 | 3   | 4 Change<br>Bar   |  |  |  |
| 36-11-08                        | Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)   |    |   |   |   |  |  |  |
| 4)                              | A319ceo Aircraft Fitted<br>with Mod. 31283/<br>MP P7125 and<br>without Mod. 33844/<br>MP P8341 or<br>Mod. 33847/MP P8340 |    |   |   |   |  |  |  |
| a)                              | BMC 1  | С  | 1 | 0   | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated BLEED pb-sw is set to OFF,</li> <li>c) Associated PACK pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) APU bleed leak detection loop is considered inoperative,</li> <li>f) Aircraft is not operated in known or forecast icing conditions,</li> <li>g) Airplane remains at or below FL 370, and</li> <li>h) Speedbrakes are operative.</li> </ul> </li> </ul> |  |  |  |
| b)                              | BMC 2  | С  | 1 | 0   | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative</li> <li>provided: <ul> <li>a) BMC 1 is operative,</li> <li>b) Associated BLEED pb-sw is set to OFF,</li> <li>c) Associated PACK pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) Aircraft is not operated in known or forecast icing conditions,</li> <li>f) Airplane remains at or below FL 370, and</li> <li>g) Speedbrakes are operative.</li> </ul> </li> </ul>   |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |   | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |  |
|--|---|---|---|---|--|--|--|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024                                  |   |   |   |   | PAGE NO. 36-13   |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   | FT:   |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |  |
| 36. Pneumatic  |   |   |   |   |  |  |  |  |  |  |
| Sequence No.   | Item  | 1 | 2 | 3 | 4 Change<br>Bar  |  |  |  |  |  |
| 36-11-08   | Bleed Monitoring<br>Computer (BMC)<br>(Cont'd)  |   |   |   |  |  |  |  |  |  |
| 5)   | A318 Aircraft Fitted with<br>Mod. 31283/MP P7125<br>and without Mod. 33844/<br>MP P8341 or<br>Mod. 33687/MP P8297 |   |   |   |  |  |  |  |  |  |
| a)   | BMC 1   | С | 1 | 0 | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) BMC 2 is operative,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU bleed leak detection loop<br/>is considered inoperative,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>g) Airplane remains at or below<br/>FL 350, and</li> <li>h) Speedbrakes are operative.</li> </ul> </li> </ul> |  |  |  |  |  |
| b)   | BMC 2   | С | 1 | 0 | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) BMC 1 is operative,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is<br/>set to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>f) Airplane remains at or below<br/>FL 350, and</li> <li>g) Speedbrakes are operative.</li> </ul> </li> </ul>  |  |  |  |  |  |

| -                           | MENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|-----------------------------|--|----|---|----------------|---|
| REVISION NO<br>DATE: 08/13/ | D. 31  |    |   | PAGE NO. 36-14 |   |
| AIRCRAFT:<br>Airbus A320    | CRAFT:   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumati                | C  |    |   |                |   |
| Sequence No.                | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 36-12-01                    | APU Bleed Air Supply<br>System   | С  | 1 | 0              | <ul> <li>(O) May be inoperative provided APU</li> <li>BLEED switch remains OFF.</li> <li>NOTE: APU can be used for electrical power.</li> </ul>   |
| 36-12-02                    | APU Bleed Valve  |    |   |                |   |
| 1)                          | A318/A319/A320/A321<br>without<br>Mod. 163213/MP J4530                   | С  | 1 | 0              | (M)(O) May be inoperative deactivated<br>in the closed position provided APU<br>bleed switch is selected OFF.   |
|                             |  |    |   |                | NOTE: APU can be used for electrical power.   |
|                             |  | С  | 1 | 0              | (O) May be inoperative in the open<br>position provided APU is not used in<br>flight.   |
| 2)                          | A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335 | С  | 1 | 0              | (M)(O) May be inoperative<br>deactivated in the closed position<br>provided APU bleed switch is<br>selected OFF.  |
|                             |  |    |   |                | NOTE: APU can be used for electrical power.   |
|                             |  | С  | 1 | 0              | <ul> <li>(O) Except for ETOPS, may be inoperative in the open position provided:</li> <li>a) APU is not used in flight, and</li> <li>b) FWD ACT is empty or not installed.</li> </ul>   |
|                             |  | A  | 1 | 0              | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative in</li> <li>the open position provided: <ul> <li>a) APU is not used in flight,</li> <li>b) FWD ACT is empty or not installed, and</li> <li>c) Repairs are made within 4 flight-legs.</li> </ul> </li> </ul> |
|                             |  |    |   |                | (Continued)   |

|                          | MENT OF TRANSPORTATIN   | ON |    |   | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|----|---|--|
| REVISION NO. 31          |   |    |    |   | PAGE NO. 36-15   |
| DATE: 08/13/2            | 024   |    |    |   |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T. | 1.<br>2.<br>3.  | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 36. Pneumatic            |   |    |    |   |  |
| Sequence No.             | Item  | 1  | 2  | 3   | 4 Change<br>Bar  |
| 36-12-02                 | APU Bleed Valve<br>(Cont'd)   |    |    |   |  |
| 3)                       | A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335 | С  | 1  | 0   | <ul> <li>(M)(O) May be inoperative deactivated<br/>in the closed position provided APU<br/>bleed switch is selected OFF.</li> <li>NOTE: APU can be used for electrical<br/>power.</li> </ul>   |
|                          |   | С  | 1  | 0   | <ul> <li>(O) Except for ETOPS, may be inoperative in the open position provided:</li> <li>a) APU is not used in flight, and</li> <li>b) AFT 2 ACT is empty or not installed.</li> </ul>  |
|                          |   | A  | 1  | 0   | <ul> <li>(M)(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative in</li> <li>the open position provided: <ul> <li>a) APU is not used in flight,</li> <li>b) AFT 2 ACT is empty or not installed, and</li> <li>c) Repairs are made within 4 flight-legs.</li> </ul> </li> </ul> |
| 36-12-03                 | APU Bleed Check Valve   | С  | 1  | 0   | (O) May be inoperative closed<br>provided APU bleed switch is<br>selected OFF.   |
|                          | С   | 1  | 0  | <ul> <li>(O) May be inoperative open and<br/>APU used provided: <ul> <li>a) Airplane remains at or below</li> <li>FL 200, and</li> </ul> </li> <li>b) X BLEED selector is selected<br/>SHUT and ENG 1 bleed is<br/>selected OFF if engine bleed<br/>is used.</li> </ul> |  |
|                          |   | С  | 1  | 0   | (O) May be inoperative open provided<br>APU is not used.   |

| -   | MENT OF TRANSPORTATI           | ON |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|---|--------------------------------|----|----|----------------|---|
| REVISION NC                               |                                |    |    | PAGE NO. 36-16 |   |
| DATE: 08/13/2<br>AIRCRAFT:<br>Airbus A320 | 2024                           |    | T. | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 36. Pneumatic                             |                                |    |    |                |   |
| Sequence No.                              | ltem                           | 1  | 2  | 3              | 4 Change<br>Bar   |
| 36-12-04                                  | Cross Bleed Valve              |    |    |                |   |
| 1)  | Automatic Control              | С  | 1  | 0              | (O) May be inoperative provided manual control operates normally.   |
| 2)  | Manual Control                 | С  | 1  | 0              | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative<br/>provided: <ul> <li>a) Automatic control is verified to<br/>operate normally before each<br/>flight,</li> <li>b) APU bleed is operative for<br/>engine start,</li> <li>c) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>d) Both bleed air supply systems<br/>operate normally, and</li> <li>e) Both air conditioning packs<br/>operate normally.</li> </ul> </li> </ul> |
| 36-20-01                                  | ENG BLEED pb Switch            |    |    |                |   |
| 1)  | FAULT Lights                   | С  | 2  | 0              | May be inoperative provided alternate procedures are established and used.  |
| 2)  | OFF Lights                     | С  | 2  | 0              | One or both may be inoperative.   |
| 36-20-02                                  | APU BLEED pb Switch            |    |    |                |   |
| 1)  | FAULT Light                    | с  | 1  | 0              | May be inoperative.   |
| 2)  | On Light                       | с  | 1  | 0              | May be inoperative.   |
| 36-20-03                                  | ECAM BLEED Page<br>Indications |    |    |                |   |
| 1)  | ENG BLEED Pressure             | С  | 2  | 0              | One or both may be inoperative.   |
| 2)  | ENG BLEED<br>Temperature       | С  | 2  | 0              | One or both may be inoperative.   |
| 3)  | ENG BLEED Valve                | С  | 2  | 0              | One or both may be inoperative.   |
| 4)  | ENG HP Valve                   | С  | 2  | 0              | One or both may be inoperative.   |
|   |                                |    |    |                | (Continued)   |

| FEDERAL AVI                  | ATION ADMINISTRATION  | - |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|------------------------------|---|---|---|----------------|---|
| REVISION NO<br>DATE: 08/13/2 |   |   |   | PAGE NO. 36-17 |   |
| AIRCRAFT:<br>Airbus A320     | CRAFT:  |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic                |   |   |   |                |   |
| Sequence No.                 | Item  | 1 | 2 | 3              | 4 Change<br>Bar   |
| 36-20-03                     | ECAM BLEED Page<br>Indications<br>(Cont'd)  |   |   |                |   |
| 5)                           | APU BLEED Valve   | С | 1 | 0              | May be inoperative provided the<br>Cross Bleed valve automatic control<br>is considered inoperative.  |
| 6)                           | X BLEED Valve   | С | 1 | 0              | May be inoperative.   |
| 36-22-15                     | Pylon Leak Detection<br>Loops   |   |   |                |   |
| 1)                           | A318/A319ceo/A320ceo/<br>A321ceo Aircraft with<br>Mod. 33844/MP P8341<br>or<br>Mod. 33847/MP P8340,<br>or<br>Mod. 33687/MP P8297    | С | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated pylon leak<br/>detection loop is deactivated,</li> <li>b) If displayed during previous<br/>flight, <u>AIR</u> ENG 1(2) BLEED<br/>LEAK caution is confirmed to<br/>be false by troubleshooting,<br/>and</li> <li>c) Affected bleed air supply<br/>system is considered<br/>inoperative.</li> </ul>  |
| 2)                           | A318/A319ceo/A320ceo/<br>A321ceo Aircraft without<br>Mod. 33844/MP P8341,<br>or<br>Mod. 33847/MP P8340<br>or<br>Mod. 33687/MP P8297 | С | 2 | 1              | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Associated pylon leak<br/>detection loop is deactivated,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF if LH side is affected,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions, and</li> <li>g) Airplane remains at or below<br/>FL 310.</li> </ul> </li> </ul> |

| -  | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | UN |   |   | MASTER MINIMUM EQUIPMENT LIS   |
|--|--|----|---|---|--|
| REVISION NO                                      | . 31   |    |   |   | PAGE NO. 36-1  |
| DATE: 08/13/2                                    | 024  |    |   |   |  |
| AIRCRAFT:<br>Airbus A320<br><b>36. Pneumatic</b> | FT:<br>320   |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.                                     | Item   | 1  | 2 | 3 | 4 Chang  |
| 36-22-15   | Pylon Leak Detection<br>Loops<br>(Cont'd)  |    | 2 | 3 | 4 Bar  |
| 3)   | A320ceo/A321ceo<br>Aircraft with<br>Mod. 31283/MP P7125<br>and without<br>Mod. 33844/MP P8341<br>or<br>Mod. 33847/MP P8340 | C  | 2 | 1 | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Associated pylon leak<br/>detection loop is deactivated,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF if LH side is affected,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions, and</li> <li>g) Speedbrakes are operative.</li> </ul> </li> </ul>  |
| 4)   | A319ceo Aircraft with<br>Mod. 31283/MP P7125<br>and without<br>Mod. 33844/MP P8341<br>or<br>Mod. 33847/MP P8340            | C  | 2 | 1 | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Associated pylon leak<br/>detection loop is deactivated,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF if LH side is affected,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>g) Speedbrakes are operative,<br/>and</li> <li>h) Airplane remains at or below<br/>FL 370.</li> </ul> </li> </ul> |

| -                             | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------|--|----|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2  | -  |    |   |                | PAGE NO. 36-19   |
| AIRCRAFT:<br>Airbus A320      |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 36. Pneumatic<br>Sequence No. | ltem   | 1  | 2 | 3              | 4 Change   |
| 36-22-15                      | Pylon Leak Detection<br>Loops<br>(Cont'd)  |    |   |                |  |
| 5)                            | A318 Aircraft with<br>Mod. 31283/MP P7125<br>and without<br>Mod. 33844/MP P8341<br>or<br>Mod. 33847/MP P8340,<br>or<br>Mod. 33687/MP P8297 | C  | 2 | 1              | <ul> <li>(M)(O) Except for ETOPS, one may<br/>be inoperative provided: <ul> <li>a) Associated pylon leak<br/>detection loop is deactivated,</li> <li>b) Associated BLEED pb-sw is<br/>set to OFF,</li> <li>c) Associated PACK pb-sw is set<br/>to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF if LH side is affected,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>g) Speedbrakes are operative,<br/>and</li> <li>h) Airplane remains at or below<br/>FL 350.</li> </ul></li></ul> |

| -  | IENT OF TRANSPORTATI<br>ATION ADMINISTRATION | ON     |        |                | MASTER MINIMUM EQUIPMENT L  | .IST         |
|--|--|--------|--------|----------------|---|--------------|
| REVISION NO. 31<br>DATE: 08/13/2024              |  |        |        |                | PAGE NO. 36   | 6-20         |
| AIRCRAFT:<br>Airbus A320<br><b>36. Pneumatic</b> |  |        |        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |              |
| Sequence No.<br>36-22-17                         | Item<br>APU Leak Detection                   | 1<br>C | 2<br>1 | 3<br>0         | (M) May be inoperative provided:  | hange<br>Bar |
|  | Loop   |        |        |                | <ul> <li>a) APU check valve is removed<br/>and replaced by a blanking<br/>cap,</li> <li>b) APU air supply system is<br/>considered inoperative, and</li> <li>c) The BMC 1 is operative.</li> </ul>  |              |
|  |  | В      | 1      | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) APU check valve is checked operative,</li> <li>b) AIR APU BLEED LEAK alert was not displayed during the previous flight,</li> <li>c) APU air supply system is considered inoperative, and</li> <li>d) BMC 1 is operative.</li> </ul>  |              |
|  |  | C      | 1      | 0              | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK alert was not displayed during the previous flight,</li> <li>b) ENG 1 BLEED pb-sw is set to OFF,</li> <li>c) PACK 1 pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) APU BLEED pb-sw is set to OFF,</li> <li>f) Aircraft is not operated in known or forecast icing conditions, and</li> <li>g) Airplane remains at or below FL 310.</li> </ul> </li> </ul> |              |
|  |  |        |        |                | (Continued)   |              |

| -  |   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|---|----|---|----------------|---|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 31<br>DATE: 08/13/2024 |   |    |   |                | PAGE NO. 36-21  |
| AIRCRAFT:<br>Airbus A320   |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic  |   |    |   |                |   |
| Sequence No.   | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 36-22-17   | APU Leak Detection<br>Loop<br>(Cont'd)                            |    |   |                |   |
| 1)   | A320ceo/A321ceo with<br>Mod. 31283/MP P7125<br>or A320neo/A321neo | C  | 1 | 0              | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK alert was not displayed during the previous flight,</li> <li>b) ENG 1 BLEED pb-sw is set to OFF,</li> <li>c) PACK 1 pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to SHUT,</li> <li>e) APU BLEED pb-sw is set to OFF,</li> <li>f) Aircraft is not operated in known or forecast icing conditions, and</li> <li>g) Speedbrakes are operative.</li> </ul> </li> </ul>   |
| 2)   | A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo                 | C  | 1 | 0              | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) AIR APU BLEED LEAK alert<br/>was not displayed during the<br/>previous flight,</li> <li>b) ENG 1 BLEED pb-sw is set to<br/>OFF,</li> <li>c) PACK 1 pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>g) Speedbrakes are operative,<br/>and</li> <li>h) Airplane remains at or below<br/>FL 370.</li> </ul> </li> </ul> |
|  |   |    |   |                | (Continued)   |

| -  | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|----|---|----------------|---|
|  | REVISION NO. 31<br>DATE: 08/13/2024          |    |   |                | PAGE NO. 36-22  |
| AIRCRAFT:<br>Airbus A320<br><b>36. Pneumatic</b> |  |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| Sequence No.                                     | Item   | 1  | 2 | 3              | 4 Change<br>Bar   |
| 36-22-17   | APU Leak Detection<br>Loop<br>(Cont'd)       |    |   |                |   |
| 3)   | A318 with<br>Mod. 31283/MP P7125             | С  | 1 | 0              | <ul> <li>(O) Except for ETOPS beyond<br/>120 minutes, may be inoperative<br/>provided: <ul> <li>a) AIR APU BLEED LEAK alert<br/>was not displayed during the<br/>previous flight,</li> <li>b) ENG 1 BLEED pb-sw is set to<br/>OFF,</li> <li>c) PACK 1 pb-sw is set to OFF,</li> <li>d) X-BLEED selector is set to<br/>SHUT,</li> <li>e) APU BLEED pb-sw is set to<br/>OFF,</li> <li>f) Aircraft is not operated in<br/>known or forecast icing<br/>conditions,</li> <li>g) Speedbrakes are operative,<br/>and</li> <li>h) Airplane remains at or below<br/>FL 350.</li> </ul> </li> </ul> |
| 36-22-18   | AIR APU BLEED LEAK<br>Caution on ECAM EWD    | С  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK</li> <li>caution is confirmed to be</li> <li>false by troubleshooting,</li> </ul> </li> <li>b) APU leak detection loop is deactivated,</li> <li>c) APU check valve is removed and replaced by a blanking cap,</li> <li>d) APU air supply system is considered inoperative, and</li> <li>e) BMC 1 is operative.</li> </ul>   |

|                                     | IENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT  | LIST          |
|-------------------------------------|---|----|---|----------------|---|---------------|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |    |   |                | PAGE NO.  | 36-23         |
| AIRCRAFT:<br>Airbus A320            |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |
| 36. Pneumatic                       |   |    |   |                |   |               |
| Sequence No.<br>36-22-18            | Item<br>AIR APU BLEED LEAK<br>Caution on ECAM EWD<br>(Cont'd) | 1  | 2 | 3              | 4   | Change<br>Bar |
|                                     |   | В  | 1 | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) AIR APU BLEED LEAK<br/>caution is confirmed to be<br/>false by troubleshooting,</li> <li>b) APU leak detection loop is<br/>deactivated,</li> <li>c) APU check valve is checked<br/>operative,</li> <li>d) APU air supply system is<br/>considered inoperative, and</li> <li>e) BMC 1 is operative.</li> </ul>  |               |
|                                     |   | С  | 1 | 0              | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK caution is confirmed to be false by troubleshooting,</li> <li>b) APU leak detection loop is deactivated,</li> <li>c) ENG 1 BLEED pb-sw is set to OFF,</li> <li>d) PACK 1 pb-sw is set to OFF,</li> <li>e) X-BLEED selector is set to SHUT,</li> <li>f) APU BLEED pb-sw is set to OFF,</li> <li>g) Aircraft is not operated in known or forecast icing conditions, and</li> <li>h) Airplane remains at or below FL 310.</li> </ul></li></ul> |               |
|                                     |   |    |   |                | (Continued)   |               |

| TEDERAL AVIATION ADMINISTRATION         REVISION NO. 31         DATE: 08/13/2024         TABLE KEY         AIRCRAFT:         Airbus A320         Emergence No.         Item 1       2       NO. 1         G. Pneumatic         equence No.       Item 1       2       3       4         6. Pneumatic       Emergence         equence No.       Item 1       2       3       4         6. Pneumatic       C       1       0       (M)(0         Gendation on ECAM EWD (Cont'd)       C       1       0       (M)(0       inoper         1)       A320neo/A321ceo with MOd. 31283/MP P7125 or A319neo       C       1       0       (M)(0       inoper         2)       A319ceo with MOd. 31283/MP P7125 or A319neo       C       1       0       (M)(0       inoper <th colspan<="" th=""><th>ΓΑΤΙΟΝ</th><th>ENT OF TRANSPORTATIC</th><th>DEPARTMENT OF TRANSPO</th><th>ION</th><th></th><th>MASTER MINIMUM EQUIPMENT LIST</th></th>  | <th>ΓΑΤΙΟΝ</th> <th>ENT OF TRANSPORTATIC</th> <th>DEPARTMENT OF TRANSPO</th> <th>ION</th> <th></th> <th>MASTER MINIMUM EQUIPMENT LIST</th> | ΓΑΤΙΟΝ              | ENT OF TRANSPORTATIC     | DEPARTMENT OF TRANSPO | ION |  | MASTER MINIMUM EQUIPMENT LIST |
|--|--|---------------------|--------------------------|-----------------------|-----|--|-------------------------------|
| DATE: 08/13/2024         TABLE KEY         AIRCRAFT:         Airbus A320         End of the model of the mode  | ON   | TION ADMINISTRATION | ERAL AVIATION ADMINISTRA |                       |     |  |                               |
| AIRCRAFT:       1. REP/         Airbus A320       1. Rep/         2. NO. 1       3. NO. F         4. REM.       1       2       3         6. Pneumatic       1       2       3       4         66-22-18       AIR APU BLEED LEAK<br>Caution on ECAM EWD<br>(Cont'd)       1       2       3       4         1)       A320ceo/A321ceo with<br>Mod. 31283/MP P7125<br>or A320neo/A321neo       C       1       0       (M)(O<br>inoper<br>a)         2)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)         2)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)         2)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)  |  | -                   |                          |                       |     | PAGE NO. 36-24   |                               |
| equence No.         Item         1         2         3         4           16-22-18         AIR APU BLEED LEAK<br>Caution on ECAM EWD<br>(Cont'd)         I         0         (M)(O<br>inoper<br>a)           1)         A320ceo/A321ceo with<br>Mod. 31283/MP P7125<br>or A320neo/A321neo         C         1         0         (M)(O<br>inoper<br>a)           2)         A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo         I         I         I         I         I         0         (M)(O<br>inoper<br>a)           2)         A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo         C         1         0         (M)(O<br>inoper<br>a)         I   |  |                     |                          |                       |     | <b>BLE KEY</b> <ol> <li>REPAIR CATEGORY</li> <li>NO. INSTALLED</li> <li>NO. REQUIRED FOR DISPATCH</li> <li>REMARKS OR EXCEPTIONS</li> </ol>  |                               |
| 6-22-18       AIR APU BLEED LEAK<br>Caution on ECAM EWD<br>(Cont'd)       C       1       0       (M)(O<br>inoper<br>a)         1)       A320ceo/A321ceo with<br>Mod. 31283/MP P7125<br>or A320neo/A321neo       C       1       0       (M)(O<br>inoper<br>a)         2)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)         2)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)         4       5       5       5       5       5       5         6       6       6       6       6       6       6         6 <td< th=""><th></th><th></th><th>neumatic</th><th></th><th></th><th></th></td<>   |  |                     | neumatic                 |                       |     |  |                               |
| Caution on ECAM EWD<br>(Cont'd)<br>1) A320ceo/A321ceo with<br>Mod. 31283/MP P7125<br>or A320neo/A321neo<br>C 1 0 (M)(O<br>inoper<br>a)<br>C 1 0 (M)(O<br>(c)<br>d)<br>e)<br>f)<br>g)<br>A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo<br>C 1 0 (M)(O<br>inoper<br>a)<br>C 1 (C)<br>C (C) | 1 2  | Item                | nce No. Item             | 1 2                   | 2 3 | 3 4 Change<br>Bar  |                               |
| Mod. 31283/MP P7125<br>or A320neo/A321neo       inoper<br>a)         b)       c)         c)       d)         c)       d)         c)       f)         g)       A319ceo with<br>Mod. 31283/MP P7125<br>or A319neo       C       1       0       (M)(O<br>inoper<br>a)         c)       d)       c)       d)       c)       d)         c)       d)       c)       d)       c)         c)       d)       c)       d)       c)         c)       d)       c)       d)       c)         d)       d)       d)       d)       d)   |  | Caution on ECAM EWD | Caution on ECAM          |                       |     |  |                               |
| Mod. 31283/MP P7125<br>or A319neo<br>b)<br>c)<br>d)<br>e)<br>f)  | 25   | Mod. 31283/MP P7125 | Mod. 31283/MP P7         | C                     | 1 C | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) <u>AIR</u> APU BLEED LEAK caution is confirmed to be false by troubleshooting,</li> <li>b) APU leak detection loop is deactivated,</li> <li>c) ENG 1 BLEED pb-sw is set to OFF,</li> <li>d) PACK 1 pb-sw is set to OFF,</li> <li>e) X-BLEED selector is set to SHUT,</li> <li>f) APU BLEED pb-sw is set to OFF,</li> <li>g) Aircraft is not operated in known or forecast icing conditions, and</li> <li>h) Speedbrakes are operative.</li> </ul> </li> </ul>   |                               |
| i)   |  | Mod. 31283/MP P7125 | Mod. 31283/MP P7         | C                     | 1 C | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK caution is confirmed to be false by troubleshooting,</li> <li>b) APU leak detection loop is deactivated,</li> <li>c) ENG 1 BLEED pb-sw is set to OFF,</li> <li>d) PACK 1 pb-sw is set to OFF,</li> <li>e) X-BLEED selector is set to SHUT,</li> <li>f) APU BLEED pb-sw is set to OFF,</li> <li>g) Aircraft is not operated in known or forecast icing conditions,</li> <li>h) Speedbrakes are operative, and</li> <li>i) Airplane remains at or below FL 370.</li> </ul> </li> </ul> |                               |

| -               | IENT OF TRANSPORTATI<br>ATION ADMINISTRATION          | ON |   |   | MASTER MINIMUM EQUIPMENT LIST  |
|-----------------|---|----|---|---|--|
| REVISION NO. 31 |   |    |   |   | PAGE NO. 36-25   |
| DATE: 08/13/20  | -   |    |   |   |  |
|                 |   |    | Т |   | E KEY  |
| AIRCRAFT:       |   |    | ľ |   | REPAIR CATEGORY  |
| Airbus A320     |   |    |   |   | NO. INSTALLED  |
| / 11000 / 1020  |   |    |   |   | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 36. Pneumatic   |   |    |   |   |  |
| Sequence No.    | Item  | 1  | 2 | 3 | 4 Change<br>Bar  |
| 36-22-18        | AIR APU BLEED LEAK<br>Caution on ECAM EWD<br>(Cont'd) |    |   |   |  |
| 3)              | A318 with<br>Mod. 31283/MP P7125                      | C  | 1 | 0 | <ul> <li>(M)(O) Except for ETOPS, may be inoperative provided: <ul> <li>a) AIR APU BLEED LEAK caution is confirmed to be false by troubleshooting,</li> <li>b) APU leak detection loop is deactivated,</li> <li>c) ENG 1 BLEED pb-sw is set to OFF,</li> <li>d) PACK 1 pb-sw is set to OFF,</li> <li>e) X-BLEED selector is set to SHUT,</li> <li>f) APU BLEED pb-sw is set to OFF,</li> <li>g) Aircraft is not operated in known or forecast icing conditions,</li> <li>h) Speedbrakes are operative, and</li> <li>i) Airplane remains at or below FL 350.</li> </ul> </li> </ul> |

|  | MENT OF TRANSPORTATIO  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|------------------------|----|---|----------------|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 30<br>DATE: 03/03/2023 |                        |    |   |                | PAGE NO. 38-1  |
| AIRCRAFT:<br>Airbus A320   |                        |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 38. Water/Was  | te                     |    |   |                |  |
| Sequence No.   | Item                   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 38-10-01   | Potable Water Systems  | С  | - | -              | <ul> <li>(M) Individual components may be inoperative provided:         <ul> <li>a) Associated components are deactivated or isolated, and</li> <li>b) Associated system components are verified not to have leaks.</li> </ul> </li> <li>NOTE: Any portion of system which operates normally may be used.</li> </ul>                 |
|  |                        | С  | - | -              | <ul> <li>(M) May be inoperative provided:</li> <li>a) System is drained, and</li> <li>b) Procedures are established to ensure that system is not serviced.</li> </ul>  |
| 38-30-01   | Lavatory Waste Systems | С  | - | -              | <ul> <li>(M) Individual components may be inoperative provided:</li> <li>a) Associated components are deactivated or isolated, and</li> <li>b) Associated system components are verified not to have leaks.</li> </ul>   |
|  |                        |    |   |                | NOTE: Any portion of system which<br>operates normally may be<br>used.   |
|  |                        | С  | - | -              | <ul> <li>(M) Associated lavatory system(s)<br/>may be inoperative provided: <ul> <li>a) Associated components are deactivated or isolated to prevent leaks, and</li> <li>b) Associated lavatory door(s) is secured closed and placarded "INOPERATIVE – DO NOT ENTER".</li> </ul> </li> <li>NOTE: These provisions are not</li> </ul> |
|  |                        |    |   |                | intended to prohibit inspections by crewmembers.   |
|  |                        |    |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |          | MASTER MINIMUM EQUIPMENT L   | _IST  |
|--|--|---|---|----------|--|-------|
| REVISION NO<br>DATE: 03/03/2   |  |   |   |          | PAGE NO. 3   | 38-2  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |       |
| 38. Water/Was  | Item                                   | 1 | 2 | 3        | 4 c  | hange |
| Sequence No.<br>38-30-01   | Lavatory Waste Systems<br>(Cont'd)     |   | 2 | 3        | 4  | Bar   |
| 1)   | Vacuum Generator<br>System<br>(Toilet) | С | 1 | 0        | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Vacuum generator is<br/>deactivated, and</li> <li>b) Procedures are established<br/>and used to only allow use of<br/>lavatories at or above<br/>16,000 ft. MSL.</li> </ul> |       |

|                            | MENT OF TRANSPORTATI                    | ION |               | MASTER MINIMUM EQUIPMENT LIST |  |               |  |  |
|----------------------------|---|-----|---------------|-------------------------------|--|---------------|--|--|
| REVISION NO<br>DATE: XX/XX | D. 32                                   |     | PAGE NO. 46-1 |                               |  |               |  |  |
| AIRCRAFT:<br>Airbus A320   |   |     | Т             | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |               |  |  |
| 46. Informatio             | on Systems                              |     |               |                               |  |               |  |  |
| Sequence No.               | Item                                    | 1   | 2             | 3                             | 4  | Change<br>Bar |  |  |
| 46-20-01<br>***            | Electronic Flight Bag<br>Systems (EFBs) |     |               |                               |  |               |  |  |
| 1)<br>***                  | EFB System<br>(Installed EFB System)    | С   | -             | -                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   | <br>          |  |  |
|                            |   |     |               |                               | NOTE: Any function, program, or<br>document which operates<br>normally may be used.  |               |  |  |
|                            |   | D   | -             | 0                             | May be inoperative provided procedures do not require its use.   |               |  |  |
| 2)<br>***                  | Data Connectivity                       | С   | -             | -                             | (O) May be inoperative provided alternate procedures are established and used.   | I             |  |  |
|                            |   | D   | -             | 0                             | May be inoperative provided procedures do not require its use.   |               |  |  |
| 3)<br>***                  | Power Supply/<br>Power Connection       | С   | -             | 0                             | (M)(O) May be inoperative provided alternate procedures are established and used.  | <br>          |  |  |
|                            |   |     |               |                               | NOTE: Depending upon<br>configuration, power<br>supply/power connection may<br>require deactivation by<br>(M) procedure.   | I             |  |  |
|                            |   | D   | -             | 0                             | May be inoperative provided procedures do not require its use.   |               |  |  |
| 4)<br>***                  | Mounting Device                         | С   | -             | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Associated EFB and<br/>hardware is stowed, secured<br/>by an alternate means, or<br/>removed from the aircraft, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul> | Ι             |  |  |
|                            |   |     |               |                               | (Continued)  |               |  |  |

| -                        | MENT OF TRANSPORTATI                                | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |               |  |  |
|--------------------------|---|----|---|-------------------------------|---|---------------|--|--|
| REVISION NO. 32          |   |    |   |                               | PAGE NC   | ). 46-2       |  |  |
| DATE: XX/XX/             | /XXXX   |    |   |                               |   |               |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |
| 46. Informatio           | n Systems   |    |   |                               |   |               |  |  |
| Sequence No.             | ltem  | 1  | 2 | 3                             | 4   | Change<br>Bar |  |  |
| 46-20-01<br>***          | Electronic Flight Bag<br>Systems (EFBs)<br>(Cont'd) |    |   |                               |   |               |  |  |
| 4)<br>***                | Mounting Device<br>(Cont'd)                         | D  | - | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Associated EFB and<br/>hardware is stowed, secured<br/>by an alternate means, or<br/>removed from the aircraft,<br/>and</li> <li>b) Procedures do not require its<br/>use.</li> </ul> |               |  |  |
| 46-21-01<br>***          | Air Traffic Service Unit<br>System (ATSU)           | С  | 1 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |               |  |  |
|                          |   |    |   |                               | NOTE: Any ATSU function or mode<br>which operates normally may<br>be used.  |               |  |  |
|                          |   | D  | 1 | 0                             | May be inoperative provided procedures do not require its use.  |               |  |  |
|                          |   |    |   |                               | NOTE: Any ATSU function or mode<br>which operates normally may<br>be used.  |               |  |  |
| 46-21-02<br>***          | Data Link Control<br>Display Units (DCDU)           | С  | 2 | 1                             | One may be inoperative.   |               |  |  |
|                          |   | С  | 2 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |               |  |  |
|                          |   | D  | 2 | 0                             | (O) May be inoperative provided procedures do not require its use.  |               |  |  |

| FEDERAL AVIATION ADMINISTRATION |   |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |  |
|---------------------------------|---|---|----|----------------|--|--|--|--|--|--|
| REVISION NC                     |   |   |    | PAGE NO. 46-3  |  |  |  |  |  |  |
| DATE: XX/XX                     | XXXX  |   |    |                |  |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS            |  |  |  |  |  |
| 46. Informatio                  | n Systems   |   |    |                |  |  |  |  |  |  |
| Sequence No.                    | Item  | 1 | 2  | 3              | 4 Change<br>Bar  |  |  |  |  |  |
| 46-21-03<br>***                 | ATC Msg. pb-sw  | С | 2  | 1              | One may be inoperative.  |  |  |  |  |  |
|                                 |   | С | 2  | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                       |  |  |  |  |  |
|                                 |   | D | 2  | 0              | (O) May be inoperative provided procedures do not require its use.   |  |  |  |  |  |
| 1)                              | ATC MSG Lights  | D | 2  | 0              | One or both may be inoperative.  |  |  |  |  |  |
| 46-21-04<br>***                 | ATC Datalink  | С | 1  | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used for ATC communication. |  |  |  |  |  |
|                                 |   |   |    |                | NOTE: Any ATC Datalink function or<br>mode that operates normally<br>may be used.                          |  |  |  |  |  |
|                                 |   | D | 1  | 0              | May be inoperative provided procedures do not require its use.   |  |  |  |  |  |
|                                 |   |   |    |                | NOTE: Any ATC Datalink function or mode that operates normally may be used.                                |  |  |  |  |  |
| 46-21-05<br>***                 | COMPANY Datalink  | D | 1  | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                       |  |  |  |  |  |
| 46-21-06<br>***                 | Flight Operations and<br>Maintenance Exchanger<br>(FOMAX) | С | 1  | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.                       |  |  |  |  |  |
|                                 |   | D | 1  | 0              | May be inoperative provided procedures do not require its use.   |  |  |  |  |  |

|                                 | MENT OF TRANSPORTATI  |   |   |               |   |  |  |  |  |
|---------------------------------|---|---|---|---------------|---|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |   |   |               | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
| REVISION NO                     |   |   |   | PAGE NO. 47-1 |   |  |  |  |  |
| DATE: 03/03/2                   |   |   |   |               |   |  |  |  |  |
|                                 |   |   | Т |               | ЕКЕҮ  |  |  |  |  |
| AIRCRAFT:                       |   |   |   | 1.            | REPAIR CATEGORY   |  |  |  |  |
| Airbus A320                     |   |   |   |               |   |  |  |  |  |
|                                 |   |   |   |               | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 47. Inert Gas                   | System  |   |   | 1             | Change -  |  |  |  |  |
| Sequence No.                    | Item  | 1 | 2 | 3             | 4 Change<br>Bar   |  |  |  |  |
| 47-00-00                        | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY                                  |   |   |               |   |  |  |  |  |
| 1)                              | Faults Indicated by<br>FUEL INERT<br>(A318/A319/A320/A321<br>Aircraft Fitted with<br>Mod. 38062/MP J2879)                             | A | - | -             | May be displayed provided repairs<br>are made within 20 flight-days.<br>NOTE: Dispatch with associated<br>MAINT STS message<br>displayed on ECAM is<br>permitted without CFDS<br>interrogation. |  |  |  |  |
| 47-10-01                        | Fuel Tank Inerting<br>System<br>(A318/A319/A320/A321<br>Aircraft Fitted with<br>Mod. 38062/MP J2879<br>and Mod. 151269/<br>MP P11819) | A | 1 | 0             | May be inoperative provided repairs<br>are made within 20 flight-days.  |  |  |  |  |

|                          | MENT OF TRANSPORTATI   | UN |    | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------|--|----|----|-------------------------------|--|--|--|--|
| REVISION NO. 30          |  |    |    |                               | PAGE NO. 49-1  |  |  |  |
| DATE: 03/03/2            | 2023   |    |    |                               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | T. | 1.<br>2.                      | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |
|                          |  |    |    |                               | REMARKS OR EXCEPTIONS  |  |  |  |
| 49. Airborne /           | Auxiliary Power  |    |    |                               |  |  |  |  |
| Sequence No.             | Item   | 1  | 2  | 3                             | 4 Change<br>Bar  |  |  |  |
| 49-00-00                 | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY |    |    |                               |  |  |  |  |
| 1)                       | Fault(s) Indicated by APU  | С  | -  | -                             | NOTE: Dispatch with this maintenance<br>status message displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |  |
| 49-10-01                 | APU System   |    |    |                               |  |  |  |  |
| 1)                       | A318/A319/A320/A321<br>without<br>Mod. 163213/MP J4530   | С  | 1  | 0                             | (O) Except for ETOPS, may be inoperative.  |  |  |  |
|                          |  | A  | 1  | 0                             | (O) Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided repairs are made within<br>4 flights.   |  |  |  |
| 2)                       | A321 with<br>Mod. 163213/MP J4530<br>and without<br>Mod. 162739/MP J4335                             | С  | 1  | 0                             | (O) Except for ETOPS, may be<br>inoperative provided FWD ACT is<br>empty or not installed.   |  |  |  |
|                          |  | A  | 1  | 0                             | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) FWD ACT is empty or not installed, and</li> <li>b) Repairs are made within 4 flights.</li> </ul> </li> </ul> |  |  |  |
|                          |  |    |    |                               | (Continued)  |  |  |  |

|                              | ATION ADMINISTRATION  |   |   |                |  |  |  |
|------------------------------|---|---|---|----------------|--|--|--|
| REVISION NO<br>DATE: 03/03/2 |   |   |   |                | PAGE NO. 49-2  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 49. Airborne A               | uxiliary Power  |   |   |                |  |  |  |
| Sequence No.                 | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |
| 49-10-01                     | APU System<br>(Cont'd)  |   |   |                |  |  |  |
| 3)                           | A321 with<br>Mod. 163213/MP J4530<br>and with<br>Mod. 162739/MP J4335 | С | 1 | 0              | (O) Except for ETOPS, may be<br>inoperative provided AFT 2 ACT is<br>empty or not installed.   |  |  |
|                              |   | A | 1 | 0              | <ul> <li>(O) Except for ETOPS beyond</li> <li>120 minutes, may be inoperative provided: <ul> <li>a) AFT 2 ACT is empty or not installed, and</li> <li>b) Repairs are made within 4 flights.</li> </ul> </li> </ul> |  |  |
| 49-10-02                     | APU Air Intake Flap   | A | 1 | 0              | (M) May be inoperative secured open<br>and APU used provided repairs are<br>made within 10 flight-days.  |  |  |
|                              |   | С | 1 | 0              | May be inoperative closed or partially<br>closed provided APU is considered<br>inoperative.  |  |  |
| 49-30-01                     | APU Fuel Pump   | С | 1 | 0              | Except for ETOPS, may be<br>inoperative provided both engine<br>driven generators are operative.   |  |  |
|                              |   | A | 1 | 0              | Except for ETOPS beyond<br>120 minutes, may be inoperative<br>provided repairs are made within<br>4 flights.   |  |  |
|                              |   |   |   |                | NOTE: APU may be started using<br>A.C. boost pump feeding left<br>fuel manifold.   |  |  |

|                          | TMENT OF TRANSPORTATION      |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------|------------------------------|---|---|-------------------------------|--|--|--|--|
| REVISION N               | O. 30                        |   |   | PAGE NO. 49-3                 |  |  |  |  |
| DATE: 03/03/             | /2023                        |   |   |                               |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |                              |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
|                          | Auxiliary Power              |   |   |                               |  |  |  |  |
| Sequence No.             | Item                         | 1 | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 49-30-02                 | APU LP Valve                 | С | 1 | 0                             | (M) May be inoperative secured closed provided APU is considered inoperative.  |  |  |  |
|                          |                              | С | 1 | 0                             | <ul> <li>(O) May be inoperative in closed position provided:</li> <li>a) Valve is indicated closed on ECAM, and</li> <li>b) APU is considered inoperative.</li> </ul>                              |  |  |  |
| 49-70-01                 | MASTER Switch ON<br>Light    | С | 1 | 0                             | May be inoperative.  |  |  |  |
| 49-70-02                 | MASTER Switch FAULT<br>Light | С | 1 | 0                             | May be inoperative provided N and<br>EGT indications are available on<br>ECAM APU page.  |  |  |  |
| 49-70-03                 | START ON Light               | С | 1 | 0                             | May be inoperative   |  |  |  |
| 49-70-04                 | START/AVAIL Light            | С | 1 | 0                             | May be inoperative provided<br>N indication is available on<br>ECAM APU page.  |  |  |  |
| 49-70-05                 | ECAM APU Page<br>Indications |   |   |                               |  |  |  |  |
| 1)                       | APU Indications              | С | - | 0                             | May be inoperative provided procedures do not require their use.   |  |  |  |
| 2)                       | APU GEN Parameters           | С | - | 0                             | Except for ETOPS, may be<br>inoperative provided both Engine<br>Driven Generators are operative.   |  |  |  |
| 3)                       | LOW OIL LEVEL<br>Message     | В | - | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Oil level is verified before<br/>each refueling, and</li> <li>b) There is no evidence of<br/>abnormal consumption or<br/>leakage.</li> </ul> |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NC<br>DATE: 08/13/2   |   |   |   |                | PAGE NO. 52-1  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 52. Doors<br>Sequence No.  | Item  | 1 | 2 | 3              | 4 Change   |
| 52-10-03   | Passenger Exit Stop<br>Fitting                      | C | - | -              | (O) One per exit may be inoperative<br>provided the airplane is flown in an<br>unpressurized configuration.  |
| 52-10-04   | Emergency Operation<br>Cylinder Damper<br>Functions | С | - | 0              | One or more may be inoperative.  |
| 52-10-06<br>***  | Overwing Emergency<br>Exit Flight Lock Actuator     | С | - | 0              | (O) May be inoperative in the<br>unlocked position provided a cabin<br>attendant in excess of the minimum<br>required number of cabin attendants,<br>or other briefed person employed by<br>the operator is designated to remain<br>seated in the passenger seat nearest<br>the affected exit when the cabin<br>differential pressure is below 4 psi.  |
|  |   | С | - | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Affected flight lock actuator is deactivated, and</li> <li>b) A cabin attendant in excess of the minimum required number of cabin attendants, or other briefed person employed by the operator is designated to remain seated in the passenger seat nearest the affected exit when the cabin differential pressure is below 4 psi.</li> </ul> |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--|--------------------------------|---|---|-------------------------------|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   |                                |   |   |                               | PAGE NO. 52-2  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |                                |   |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 52. Doors<br>Sequence No.  | Item                           | 1 | 2 | 3                             | 4 Change   |  |  |  |
| 52-30-01   | Cargo Door Actuators           |   | 2 | 3                             | 4 Bar  |  |  |  |
| 1)   | Without<br>Mod. 25044/MP K4160 | A | 4 | 2                             | <ul> <li>(M) One per door may be inoperative provided: <ul> <li>a) Integrity of Yellow hydraulic system is not affected,</li> <li>b) Wind velocity does not exceed 30 knots,</li> <li>c) Operation of door with a single actuator is limited to 7 flight-cycles, and</li> <li>d) Inspection Service Bulletin ISB 52-1070 has been successfully performed.</li> </ul> </li> </ul>   |  |  |  |
|  |                                | A | 4 | 2                             | <ul> <li>(M) One per door may be inoperative provided: <ul> <li>a) Affected actuator is deactivated,</li> <li>b) Integrity of Yellow hydraulic system is not affected,</li> <li>c) Wind velocity does not exceed 30 knots,</li> <li>d) Operation of door with a single actuator is limited to seven flight cycles, and</li> <li>e) Inspection Service Bulletin ISB 52-1070 has been successfully performed.</li> </ul> </li> </ul> |  |  |  |
|  |                                |   |   |                               | (Continued)  |  |  |  |

| _                        | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION     | ION |   | MASTER MINIMUM EQUIPMENT LIST<br>PAGE NO. 52-3  |  |  |  |  |
|--------------------------|--|-----|---|---|--|--|--|--|
| REVISION NO              | . 31   |     |   |   |  |  |  |  |
| DATE: 08/13/2            | 024  |     |   |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |     | Т | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |
| 52. Doors                |  |     |   |   |  |  |  |  |
| Sequence No.             | Item   | 1   | 2 | 3   | 4 Change<br>Bar  |  |  |  |
| 52-30-01                 | Cargo Door Actuators<br>(Cont'd)                 |     |   |   |  |  |  |  |
| 1)                       | Without<br>Mod. 25044/MP K4160<br>(Cont'd)       | С   | 4 | 0   | <ul> <li>(M) May be inoperative provided:</li> <li>a) Integrity of Yellow hydraulic<br/>system is not affected, and</li> <li>b) Door(s) is manually closed<br/>and locked.</li> </ul>  |  |  |  |
| 2)                       | With<br>Mod. 25044/MP K4160                      | A   | 4 | 2   | <ul> <li>One per door may be inoperative provided:</li> <li>a) Integrity of yellow hydraulic system is not affected,</li> <li>b) Wind velocity does not exceed 30 knots, and</li> <li>c) Operation of door with a single actuator is limited to 75 flight cycles.</li> </ul>   |  |  |  |
|                          |  | A   | 4 | 2   | <ul> <li>(M) One per door may be inoperative provided: <ul> <li>a) Affected actuator is deactivated,</li> <li>b) Integrity of yellow hydraulic system is not affected,</li> <li>c) Wind velocity does not exceed 30 knots, and</li> <li>d) Operation of door with a single actuator is limited to 75 flight cycles.</li> </ul> </li> </ul> |  |  |  |
|                          |  | С   | 4 | 0   | <ul> <li>(M) May be inoperative provided:</li> <li>a) Integrity of yellow hydraulic<br/>system is not affected, and</li> <li>b) Door(s) is manually closed<br/>and locked.</li> </ul>  |  |  |  |
| 52-30-02                 | Cargo Door Locking<br>Hooks and Spools<br>System | С   | - | -   | <ul> <li>(M)(O) One locking hook or one spool<br/>per door may be inoperative provided:</li> <li>a) The remainder are normal,<br/>and</li> <li>b) The airplane is flown in an<br/>unpressurized configuration.</li> </ul>  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |                                      |    |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--------------------------------------|----|---|----------------|---|
| REVISION NO<br>DATE: 08/13/2   |                                      |    |   |                | PAGE NO. 52-4   |
| AIRCRAFT:<br>Airbus A320   |                                      |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 52. Doors  |                                      | т. | Г |                | Change  |
| Sequence No.<br>52-30-03   | Item<br>Hand Pump                    | C  | 2 | 3<br>0         | 4 Change Bar<br>(M) May be inoperative provided the integrity of the yellow hydraulic system is not affected.   |
| 52-30-04   | Cargo Doors Electrical<br>Control    | С  | - | 0              | <ul> <li>(O) May be inoperative provided<br/>affected cargo door(s) is verified<br/>closed on ECAM door page prior to<br/>each departure.</li> <li>NOTE: Hand pump may be used to<br/>operate cargo door(s). Ensure<br/>cargo door(s) are fully open<br/>during loading and unloading.</li> </ul> |
|  |                                      | С  | - | 0              | <ul> <li>(M) May be inoperative provided: <ul> <li>a) Hand pump operates</li> <li>normally, and</li> </ul> </li> <li>b) Cargo doors are fully open during loading and unloading.</li> </ul> NOTE: Any cargo door control function that operates normally may be used.                             |
| 1)   | Open and Locked<br>(Green)<br>Lights | D  | 2 | 0              | (O) May be inoperative and<br>associated cargo compartment used<br>provided cargo door is fully open<br>during loading and unloading.   |
| 52-30-05   | Cargo Door Drift Pin                 | A  | 4 | 0              | May be inoperative provided repairs are made within 1 flight.   |

|                              | MENT OF TRANSPORTATION  | ON |          |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|----------|----------------|--|
| REVISION NC<br>DATE: 08/13/2 | ). 31   |    |          | PAGE NO. 52-5  |  |
| AIRCRAFT:<br>Airbus A320     |   |    | Т        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 52. Doors                    |   |    | <b>I</b> |                |  |
| Sequence No.                 | Item  | 1  | 2        | 3              | 4 Change<br>Bar  |
| 52-33-01<br>***              | Bulk Cargo Door<br>Balance mechanism  | С  | 1        | 0              | <ul> <li>(M) May be inoperative or damaged provided:</li> <li>a) A safety hold device is used to maintain the door in the open position, and</li> <li>b) A visual check is made to confirm that the door is correctly closed and locked after each use.</li> </ul>   |
| 52-50-01                     | Flight Deck Door Lock<br>Solenoid   | С  | 1        | 0              | <ul> <li>(M) May be inoperative provided:</li> <li>a) Door can be locked and<br/>unlocked manually, and</li> <li>b) Latch shearing function is not<br/>impaired.</li> </ul>  |
| 52-50-02                     | Cockpit Door Locking<br>System<br>(Automatic System)<br>(Mod. 32088 and 32090)<br>14 CFR Part 25,<br>§ 25.795 Compliant | A  | 1        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Automatic locking system is deactivated,</li> <li>b) Door deadbolt operates normally and is used to lock the door,</li> <li>c) Alternate procedures are established and used for locking and unlocking the door using the deadbolt, and</li> <li>d) Repairs are made within 2 flight-days.</li> </ul> |
| 1)                           | Cockpit Door Toggle<br>Switch   |    |          |                |  |
| a)                           | UNLOCK Function   | С  | 1        | 0              | (O) May be inoperative provided<br>alternate procedures are established<br>and used.   |
| b)                           | LOCK Function   | С  | 1        | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) The cockpit door locking<br/>system keypad is deactivated,<br/>and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul>  |
|                              |   |    |          |                | (Continued)  |

| U.S. DEPART                  | MENT OF TRANSPORTATIO   |   |   |                               |   |
|------------------------------|---|---|---|-------------------------------|---|
| FEDERAL AVI                  | ATION ADMINISTRATION  |   |   | MASTER MINIMUM EQUIPMENT LIST |   |
| REVISION NO<br>DATE: 08/13/2 |   |   |   | PAGE NO. 52-6                 |   |
| AIRCRAFT:<br>Airbus A320     |   |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 52. Doors                    |   |   |   |                               |   |
| Sequence No.                 | ltem  | 1 | 2 | 3                             | 4 Change<br>Bar   |
| 52-50-02                     | Cockpit Door Locking<br>System<br>(Automatic System)<br>(Mod. 32088 and 32090)<br>14 CFR Part 25,<br>§ 25.795 Compliant<br>(Cont'd) |   |   |                               |   |
| 2)                           | OPEN Light  | С | 1 | 0                             | May be inoperative.   |
| 3)                           | FAULT Light   | С | 1 | 0                             | (O) May be inoperative provided all<br>LEDs on CKPT DOOR CONT Panel<br>are operative.   |
| 4)                           | Buzzer  | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Keypad is deactivated, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul> |
| 5)                           | Keypad  | С | 1 | 0                             | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Keypad is deactivated, and</li> <li>b) Alternate procedures are<br/>established and used.</li> </ul> |
| a)                           | Green and Red LEDs  | С | 2 | 0                             | (O) May be inoperative provided<br>alternate procedures are established<br>and used.  |
| 6)                           | Pressure Rate Sensors   | С | 2 | 1                             | One may be inoperative.   |
|                              |   | A | 2 | 0                             | May be inoperative provided repairs are made within 2 flight-days.  |
| 7)                           | Door Release Strikes<br>(Catch Spring, Solenoid,<br>Bolt)   | С | 3 | 2                             | One may be inoperative provided that<br>the associated door release strike is<br>failed in the open/unlocked position.  |
|                              |   | С | 3 | 2                             | (M) One may be inoperative provided associated door release strike is deactivated or removed.   |
| 8)                           | Control Unit LEDs   | С | 5 | 0                             | (O) May be inoperative provided<br>associated FAULT light is verified to<br>operate normally.   |

| U.S. DEPARTI                 | MENT OF TRANSPORTATION  | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|----|----------------|--|
| FEDERAL AVI                  | ATION ADMINISTRATION  |    |    |                | MASTER MINIMOM EQUIPMENT LIST  |
| REVISION NO<br>DATE: 08/13/2 | -   |    |    | PAGE NO. 52-7  |  |
| AIRCRAFT:<br>Airbus A320     |   |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 52. Doors                    |   |    |    |                |  |
| Sequence No.                 | Item  | 1  | 2  | 3              | 4 Change<br>Bar  |
| 52-50-03                     | Cockpit Door Secondary<br>Locking System<br>(Deadbolt)<br>(Mod. 33777)<br>14 CFR Part 25,<br>§ 25.795 Compliant | С  | 1  | 0              | May be inoperative provided<br>automatic lock controls operate<br>normally.  |
| 52-60-01<br>***              | Entrance Stairs<br>(With Mod. 23398/<br>MP P3053)   | D  | 1  | 0              | May be inoperative.  |
| 52-70-01                     | ECAM DOOR Page<br>Indications   |    |    |                |  |
| 1)                           | Passenger Doors   |    |    |                |  |
| a)                           | Open Indication   | С  | -  | -              | <ul> <li>(O) May be inoperative provided:</li> <li>a) A visual check is made before<br/>each departure to ensure that<br/>the affected door(s) is closed<br/>and locked, and</li> <li>b) White SLIDE ARMED light on<br/>the affected door does not<br/>illuminate when the door is<br/>closed and locked and slide<br/>armed.</li> </ul> |
|                              |   | С  | -  | -              | (O) May be inoperative for non-night<br>operations provided a visual check is<br>made before each departure to<br>ensure that the affected door(s) is<br>closed and locked.  |
|                              |   | В  | -  | -              | <ul> <li>(O) May be inoperative provided:</li> <li>a) A visual check is made before<br/>each departure to ensure that<br/>the affected door(s) is closed<br/>and locked, and</li> <li>b) White SLIDE ARMED light on<br/>the door remains illuminated<br/>when the door is closed and<br/>locked and slide armed.</li> </ul>              |
|                              |   |    |    |                | (Continued)  |

| -                                   | MENT OF TRANSPORTAT                       | - |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------------|---|---|----|----------------|--|
| FEDERAL AVIATION ADMINISTRATION     |   |   |    |                |  |
| REVISION NO. 31<br>DATE: 08/13/2024 |   |   |    |                | PAGE NO. 52-8  |
| AIRCRAFT:<br>Airbus A320            |   |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 52. Doors                           |   |   | •  |                |  |
| Sequence No.                        | Item                                      | 1 | 2  | 3              | 4 Change<br>Bar  |
| 52-70-01                            | ECAM DOOR Page<br>Indications<br>(Cont'd) |   |    |                |  |
| 1)                                  | Passenger Doors<br>(Cont'd)               |   |    |                |  |
| b)                                  | Closed Indication                         | С | -  | -              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) A visual check is made before<br/>each departure to ensure that<br/>the affected door(s) is closed<br/>and locked, and</li> <li>b) Control circuit of affected door<br/>slide lighting system is verified<br/>to operate normally.</li> </ul>   |
|                                     |   | С | -  | -              | (O) May be inoperative for non-night<br>operations provided a visual check is<br>made before each departure to<br>ensure that the affected door(s) is<br>closed and locked.  |
| 2)<br>***                           | Overwing Emergency<br>Exits               |   |    |                |  |
| a)                                  | Open Indication                           | C | -  | -              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) A visual check is made and<br/>the door is pushed against<br/>before each departure to<br/>ensure that the affected<br/>exit(s) is closed and locked,<br/>and</li> <li>b) SLIDE Indication on ECAM<br/>DOOR page illuminates white<br/>when the exits are closed and<br/>locked.</li> </ul> |
|                                     |   | С | _  | -              | (M)(O) May be inoperative for<br>non-night operations provided a<br>visual check is made and the door is<br>pushed against before each<br>departure to ensure that the affected<br>exit(s) is closed and locked.   |
|                                     |   |   |    |                | (Continued)  |

| -                            | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION                    |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |  |
|------------------------------|---|---|-------------------------------|----------------|--|--|--|
| REVISION NO<br>DATE: 08/13/2 |   |   |                               | PAGE NO. 52-9  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   |   | T                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 52. Doors                    |   | - | -                             | _              | -  |  |  |
| Sequence No.                 | Item  | 1 | 2                             | 3              | 4 Change<br>Bar  |  |  |
| 2)                           | ECAM DOOR Page<br>Indications<br>(Cont'd)<br>Overwing Emergency |   |                               |                |  |  |  |
| ***                          | Exits<br>(Cont'd)   |   |                               |                |  |  |  |
| b)                           | Closed Indication   | С | -                             | -              | (M)(O) May be inoperative for<br>non-night operations provided a<br>visual check is made and the door is<br>pushed against before each<br>departure to ensure that the affected<br>exit(s) is closed and locked.   |  |  |
| 3)                           | Cargo Door  | C | -                             | -              | <ul> <li>(M)(O) Indications may be inoperative provided:</li> <li>a) A visual check is made before each departure to confirm that doors are closed and locked, and</li> <li>b) For bulk cargo door verification, door is also pushed against to ensure it is closed and locked.</li> </ul> |  |  |
| 4)                           | Avionics Compartment<br>Access Door                             | С | _                             | -              | (M)(O) Indications may be inoperative<br>provided a visual check is made<br>before each departure to confirm that<br>doors are closed and locked, to<br>include pushing against inward<br>opening access doors.  |  |  |
| 5)<br>***                    | Airstairs Door  | С | 1                             | 0              | (M)(O) Indication may be inoperative<br>provided a visual check is made<br>before each departure to confirm that<br>door is closed and locked.   |  |  |

| -                  | MENT OF TRANSPORTATI                                |   | MASTER MINIMUM EQUIPMENT LIST |           |  |  |  |
|--------------------|---|---|-------------------------------|-----------|--|--|--|
| FEDERAL AVI        | ATION ADMINISTRATION                                |   |                               |           |  |  |  |
| <b>REVISION NO</b> | . 31  |   |                               |           | PAGE NO. 52-10   |  |  |
| DATE: 08/13/2      | 024   |   |                               |           |  |  |  |
|                    |   |   | Т                             | TABLE KEY |  |  |  |
| AIRCRAFT:          |   |   |                               | 1.        | REPAIR CATEGORY  |  |  |
| -                  |   |   |                               | 2.        | NO. INSTALLED  |  |  |
| Airbus A320        |   |   |                               | 3.        | NO. REQUIRED FOR DISPATCH  |  |  |
|                    |   |   |                               | 4.        | REMARKS OR EXCEPTIONS  |  |  |
| 52. Doors          |   |   |                               |           |  |  |  |
| Sequence No.       | Item  | 1 | 2                             | 3         | 4 Change<br>Bar  |  |  |
| 52-70-02           | CABIN PRESSURE<br>Light<br>(On Doors)               | С | -                             | 0         | (O) May be inoperative provided<br>absence of differential pressure is<br>confirmed before opening of<br>associated door.  |  |  |
| 52-70-03           | Door Residual<br>Differential Pressure<br>Detection | C | 1                             | 0         | <ul> <li>(O) May be inoperative provided:</li> <li>a) All CABIN PRESSURE lights<br/>on cabin doors are placarded<br/>inoperative, and</li> <li>b) Absence of differential<br/>pressure is confirmed before<br/>opening of any cabin door.</li> </ul> |  |  |

| -                                   | MENT OF TRANSPORTATION   | ON |    |   | MASTER MINIMUM EQUIPMENT LIST  |  |
|-------------------------------------|--|----|----|---|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |  |    |    |   | PAGE NO. 71-1  |  |
| AIRCRAFT:<br>Airbus A320            |  |    | T. | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |
| 71. Powerplan                       | t  |    |    |   |  |  |
| Sequence No.                        | Item   | 1  | 2  | 3   | 4 Change<br>Bar  |  |
| 71-00-00                            | CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY                   |    |    |   |  |  |
| 1)                                  | Fault(s) Indicated by<br>ENG (1 and/or 2)<br>FADEC   |    |    |   |  |  |
| a)                                  | Except for CFM56-5B<br>Affected by<br>CFM VSB 73-0241 and<br>without Mod.153169/<br>MP P12877 (FADEC<br>software 5BS2) | A  | -  | -   | May be inoperative provided repairs<br>are made within<br>10 consecutive calendar-days.<br>NOTE: Dispatch with maintenance<br>status messages displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |  |
| b)                                  | For CFM 56-5B Affected<br>by CFM VSB 73-0241<br>and without<br>Mod. 153169/<br>MP P12877 (FADEC<br>software 5bS2) Only | A  | _  | -   | <ul> <li>(M) May be inoperative provided: <ul> <li>a) It is verified before first flight of each day that CFDS does not report any fault on a T12 sensor and,</li> <li>b) Repairs are made with 10 consecutive calendar-days.</li> </ul> </li> <li>NOTE: Dispatch with maintenance status messages displayed on ECAM is permitted without CFDS interrogation.</li> </ul> |  |
|                                     |  | A  | -  | -   | May be inoperative provided repairs<br>are made within 25 flight-hours or<br>3 flight-days, whichever occurs first.<br>NOTE: Dispatch with maintenance<br>status messages displayed on<br>ECAM is permitted without<br>CFDS interrogation.   |  |

|                          | IENT OF TRANSPORTATIO   |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |  |
|--------------------------|---|---|-------------------------------|----------------|--|--|--|
| REVISION NO.             | 31  |   |                               | PAGE NO. 71-2  |  |  |  |
| DATE: 08/13/20           | )24   |   |                               |                |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |   | Т.                            | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 71. Powerplant           |   | _ |                               |                | change   |  |  |
| Sequence No.<br>71-00-00 | Item<br>CLASS II<br>MAINTENANCE<br>MESSAGES<br>DISPLAYED ON ECAM<br>STATUS PAGE OF<br>ECAM SYSTEM<br>DISPLAY<br>(Cont'd)                      | 1 | 2                             | 3              | 4 Change<br>Bar  |  |  |
| 2)                       | Fault(s) Indicated by ENG (1 and/or 2) EIU  | С | -                             | -              | NOTE: Dispatch with maintenance<br>status messages displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |
| 3)                       | Fault(s) Indicated by ENG EVMU  | С | -                             | -              | NOTE: Dispatch with maintenance<br>status messages displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |
| 4)                       | Fault(s) Indicated by<br>ENG ICARE (With<br>Mod. 167039/<br>MP P21513 (iCARE) and<br>with Mod. 166490/<br>MP P21265 (FWC<br>H2-F13 Standard)) | С | -                             | -              | NOTE: Dispatch with maintenance<br>status messages displayed on<br>ECAM is permitted without<br>CFDS interrogation.  |  |  |
| 71-10-01                 | ENG 1(2) FAN COWL<br>NOT CLSD Alert<br>(A319neo/A320neo/<br>A321neo)  | С | 2                             | 0              | (O) May be inoperative provided<br>associated fan cowl door latches are<br>checked closed before each flight.  |  |  |
| 71-13-01                 | Fan Cowl Loss<br>Prevention Mechanical<br>System<br>(A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines)                                 | С | 2                             | 0              | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) The Fan Cowl Loss Prevention<br/>Mechanical system is inhibited<br/>and</li> <li>b) The associated fan cowl<br/>latches are checked closed<br/>before each flight.</li> </ul> |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |     |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |
|--|---|---|-----|----------------|---|--|--|--|
| <b>REVISION NO</b>   | . 31  |   |     |                | PAGE NO. 73-1   |  |  |  |
| DATE: 08/13/2  |   |   |     |                |   |  |  |  |
|  |   |   | - F |                | ΕΚΕΥ  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   |     | 1.<br>2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                    |  |  |  |
| 73. Engine Fue   | and Control   |   |     |                |   |  |  |  |
| Sequence No.   | Item  | 1 | 2   | 3              | 4 Change<br>Bar   |  |  |  |
| 73-10-02   | Fuel Return-to-Tank<br>Valves<br>(V2500 Engines and<br>PW1100G Engines)           | С | 2   | 1              | One may be inoperative in closed<br>position provided APU generator is<br>operative.                      |  |  |  |
| 73-11-01   | Fuel Recirculation<br>System<br>(CFM 56-5B Engines<br>and CFM LEAP-1A<br>Engines) |   |     |                |   |  |  |  |
| 1)   | Valves  | С | 2   | 1              | One may be inoperative in the closed position on one engine provided that the APU generator is operative. |  |  |  |
|  |   | С | 2   | 0              | One or both may be inoperative in the open position provided that the four wing tank pumps are operative. |  |  |  |
| 73-11-02   | Burner Staging Valve<br>System<br>(CFM Engines Only)                              |   |     |                |   |  |  |  |
| 1)   | Valves<br>(Without Mod. 25887,<br>26338, 26577, 27725,<br>or 28307)               | С | 2   | 0              | (M) May be inoperative open.  |  |  |  |

|                              | MENT OF TRANSPORTATION  |        | MASTER MINIMUM EQUIPMENT LIST   |               |  |  |  |
|------------------------------|---|--------|---|---------------|--|--|--|
| REVISION NO<br>DATE: 08/13/2 |   |        |   | PAGE NO. 73-2 |  |  |  |
| AIRCRAFT:<br>Airbus A320     |   | T      | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |               |  |  |  |
| 73. Engine Fue               |   |        |   |               | Change   |  |  |
| Sequence No.<br>73-20-03     | Item<br>Minimum Idle on Ground  | 1<br>C | 2   | <u>3</u><br>0 | 4       Change Bar         (O) May be inoperative provided the Airplane Flight Manual (AFM) performance penalties are applied.         NOTE: Continuous ignition is permanently ON (IAE Engines only).   |  |  |
| 73-20-04                     | EPR Control Modes<br>(IAE Engines Only)   | С      | 2   | 0             | <ul> <li>(O) May be inoperative provided: <ul> <li>a) N₁ rated control Mode</li> <li>operates normally on both</li> <li>engines,</li> </ul> </li> <li>b) Approach minimums do not require their use, and</li> <li>c) AFM performance penalties are applied.</li> </ul> |  |  |
| 73-20-05                     | Flex Temp Function  | С      | 2   | 0             | inoperative.<br>May be inoperative provided takeoff<br>is performed in TOGA or de-rated<br>Mode.   |  |  |
| 73-20-06<br>***              | De-Rated Takeoff Mode   | D      | 2   | 0             | May be inoperative on one or both<br>engines provided takeoff is performed<br>in TOGA or FLX Mode.   |  |  |
| 73-20-09                     | Aircraft 28V Power<br>Supply<br>(IAE Engines Only)                              | С      | 4   | 2             | Channel B power supply may be inoperative on one or both engines.  |  |  |
| 73-20-10<br>***              | Engine Bump   | С      | 2   | 0             | May be inoperative provided benefit<br>of bump is not utilized for<br>determination of takeoff performance.  |  |  |
| 73-20-11                     | Engine Overthrust<br>Protection System<br>(A318 or A319neo/<br>A320neo/A321neo) | A      | 2   | 1             | One may be inoperative for 6 flights.  |  |  |

| -                        | TMENT OF TRANSPORTATION   | UN |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|--------------------------|---|----|---|-------------------------------|---|--|--|--|
| REVISION N               |   |    |   | PAGE NO. 73-3                 |   |  |  |  |
| DATE: 08/13/             | 2024  |    |   |                               |   |  |  |  |
| AIRCRAFT:<br>Airbus A320 |   |    | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
|                          | uel and Control   |    | 1 |                               | Change  |  |  |  |
| Sequence No.<br>73-30-02 | Item<br>Fuel Used Indications   | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 1)                       | Aircraft without<br>Mod. 30368/MP P6578   | С  | 2 | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Associated tank fuel quantity indication system operates normally, and</li> <li>b) Fuel on Board indication operates normally.</li> </ul>   |  |  |  |
| 2)                       | Aircraft with<br>Mod. 30368/MP P6578  | С  | 2 | 0                             | <ul> <li>(M) May be inoperative provided:</li> <li>a) Associated tank fuel quantity indication system operates normally,</li> <li>b) Fuel on Board indication operates normally, and</li> <li>c) F. USED 1+2 indication is considered inoperative.</li> </ul> |  |  |  |
| 73-30-03                 | Fuel Filter Clog Cautions<br>on ECAM EWD  |    |   |                               |   |  |  |  |
| 1)                       | IAE Engines and<br>CFM Engines with<br>Mod. 28397 or<br>Mod. 28398 and<br>CFM LEAP-1A Engines<br>(except A321neo XLR) | С  | 2 | 1                             | (M) One may be inoperative provided<br>associated filter is replaced before<br>the next flight and then once each<br>flight-day.  |  |  |  |
| 2)                       | A321neo XLR with CFM<br>LEAP-1A Engines   | С  | 2 | 1                             | (M) One may be inoperative provided<br>associated filter is replaced before<br>the next flight and then once every<br>100 flight-hours.   |  |  |  |
| 3)                       | PW 6000 Engines   | С  | 2 | 1                             | (M) One may be inoperative provided<br>associated filter is replaced before<br>the next flight and then once each<br>flight-day or every 15 flight-hours,<br>whichever occurs first.  |  |  |  |
|                          |   |    |   |                               | (Continued)   |  |  |  |

|                                     | MENT OF TRANSPORTATIO   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|-------------------------------------|---|---|---|-------------------------------|--|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |   |   |                               | PAGE NO. 73-4  |  |  |  |
| AIRCRAFT:<br>Airbus A320            |   |   |   | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 73. Engine Fue                      | el and Control  |   | 1 |                               | Channe   |  |  |  |
| Sequence No.                        | Item  | 1 | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 73-30-03                            | Fuel Filter Clog Cautions<br>on ECAM EWD<br>(Cont'd)                  |   |   |                               |  |  |  |  |
| 4)                                  | PW 1100G Engines<br>without Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С | 2 | 1                             | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced before next flight and then every 50 flight-hours,</li> <li>b) ENG 1(2) FUEL FILTER DEGRAD caution is not displayed on EWD for opposite engine, and</li> <li>c) ENG 1(2) FUEL SENSOR FAULT caution is not displayed on EWD for opposite engine.</li> </ul> </li> </ul>         |  |  |  |
| 5)                                  | PW 1100G Engines with<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10)    | С | 2 | 1                             | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced before next flight and then every 50 flight-hours,</li> <li>b) ENG 1(2) FUEL FILTER PARTLY CLOGGED caution is not displayed on EWD for opposite engine, and</li> <li>c) ENG 1(2) FUEL SENSOR FAULT caution is not displayed on EWD for opposite engine.</li> </ul> </li> </ul> |  |  |  |
| 73-30-04                            | Fuel Filter Clog<br>Indication on ECAM<br>System Display              | С | 2 | 0                             | One or both may be inoperative.  |  |  |  |
| 73-30-05                            | MINOR FAULT Cautions<br>on ECAM EWD<br>(A319neo/A320neo/<br>A321neo)  | С | 2 | 1                             | One may be inoperative.  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|---|----------------|---|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   |  |   |   |                | PAGE NO. 73-5   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 73. Engine Fue   | and Control  |   |   |                |   |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 73-30-06   | FUEL FILTER DEGRAD<br>or FUEL FILTER<br>PARTLY CLOGGED<br>Cautions on ECAM EWD |   |   |                |   |  |  |  |  |
| 1)   | PW 1100G Engines<br>without Mod. 163016/<br>MP P20522                          | С | 2 | 1              | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced</li> <li>before next flight and then</li> <li>every 50 flight-hours,</li> </ul> </li> <li>b) ENG 1(2) FUEL FILTER</li> <li>CLOG caution is not</li> <li>displayed on EWD for</li> <li>opposite engine, and</li> <li>c) ENG 1(2) FUEL SENSOR</li> <li>FAULT caution is not</li> <li>displayed on EWD for</li> <li>opposite engine.</li> </ul>                          |  |  |  |  |
|  |  | A | 2 | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD for<br/>opposite engine, and</li> <li>b) VSB PW1000G-C-73-00-<br/>0030-00A-930A-D or VSB<br/>PW1000G-C-73-00-0046-<br/>00A-930A-D or<br/>VSB PW1000G-C-73-00-<br/>0047-00A-930A-D is applied<br/>on affected engine, and</li> <li>c) Repairs are made within<br/>8 flights or 16 flight-hours,<br/>whichever occurs first</li> </ul> |  |  |  |  |
|  |  |   |   |                | (Continued)   |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|---|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2   | -  |   |   |                | PAGE NO. 73-6  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 73. Engine Fue   |  |   |   |                | La Change  |
| Sequence No.<br>73-30-06   | Item<br>FUEL FILTER DEGRAD<br>or FUEL FILTER<br>PARTLY CLOGGED<br>Cautions on ECAM EWD<br>(Cont'd) | 1 | 2 | 3              | 4 Bar  |
| 2)   | PW 1100G Engines with<br>Mod. 163016/<br>MP P20522<br>(except A321neo XLR)                         | С | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 50 flight-hours,</li> <li>b) ENG 1(2) FUEL FILTER<br/>CLOG caution is not<br/>displayed on EWD for<br/>opposite engine, and</li> <li>c) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD for<br/>opposite engine.</li> </ul> |
|  |  | A | 2 | 1              | One may be inoperative provided:<br>a) ENG 1(2) FUEL SENSOR<br>FAULT is not displayed on<br>EWD for opposite engine, and<br>b) Repairs are made within<br>8 flights or 16 flight-hours,<br>whichever occurs first.<br>(Continued)  |

| -                                   | MENT OF TRANSPORTATION   | ON |    |                | MASTER MINIMUM EQUIPMENT LIST  |
|-------------------------------------|--|----|----|----------------|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |  |    |    |                | PAGE NO. 73-7  |
| AIRCRAFT:<br>Airbus A320            |  |    | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 73. Engine Fue                      | el and Control   |    |    | _              | _  |
| Sequence No.                        | Item   | 1  | 2  | 3              | 4 Change<br>Bar  |
| 73-30-06                            | FUEL FILTER DEGRAD<br>or FUEL FILTER<br>PARTLY CLOGGED<br>Cautions on ECAM EWD<br>(Cont'd) |    |    |                |  |
| 3)                                  | CFM LEAP-1A Engines<br>(except A321neo XLR)  | A  | 2  | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD for<br/>opposite engine and,</li> <li>b) Repairs are made within<br/>3 flights or 6 flight-hours,<br/>whichever occurs first.</li> </ul>  |
|                                     |  | С  | 2  | 1              | (M) One may be inoperative provided<br>associated filter is replaced before<br>next flight and then every<br>100 flight-hours.   |
| 4)                                  | A321neo XLR with<br>CFM LEAP-1A Engines  | A  | 2  | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD for<br/>opposite engine, and</li> <li>b) Repairs are made within<br/>3 flights or 14 flight-hours,<br/>whichever occurs first.</li> </ul> |
|                                     |  | С  | 2  | 1              | (M) One may be inoperative provided<br>associated filter is replaced before<br>next flight and then every<br>100 flight-hours.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| <b>REVISION NO</b>   | . 31  |   |   |                | PAGE NO. 73-8  |
| DATE: 08/13/2  | 024   |   |   |                |  |
| AIRCRAFT:<br>Airbus A320   |   |   | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 73. Engine Fue   | and Control   |   |   |                |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change   |
| 73-30-07   | FUEL SENSOR FAULT<br>Cautions on ECAM EWD   |   |   |                | * Bar  |
| 1)   | PW 1100G Engines<br>without Mod.163016/<br>MP P20522 and without<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | C | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 50 flight-hours.</li> <li>One may be inoperative provided:</li> <li>a) Associated FUEL FILTER</li> </ul>   |
|  |   |   |   |                | <ul> <li>SENSOR subtitle is displayed<br/>on EWD,</li> <li>ENG 1(2) FUEL FILTER<br/>DEGRAD caution is not<br/>displayed on EWD for<br/>opposite engine,</li> <li>VSB PW1000G-C-73-00-<br/>0030- 00A-930A-D or VSB<br/>PW1000G-C-73-00-0046-<br/>00A- 930A-D or VSB<br/>PW1000G-C- 73-00- 0047-<br/>00A-930A-D is applied on<br/>affected engine, and</li> <li>Repairs are made within<br/>8 flights or 16 flight-hours,<br/>whichever occurs first.</li> </ul> |
|  |   | С | 2 | 0              | May be inoperative provided<br>associated IDG FOC SENSOR<br>subtitle is displayed on EWD.  |
|  |   |   |   |                | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   | MASTER MINIMUM EQUIPMENT LIST |   |               |  |  |
|--|--|---|---|-------------------------------|---|---------------|--|--|
| REVISION NO. 31  |  |   |   |                               | PAGE NC   | ). 73-9       |  |  |
| DATE: 08/13/2  | 024  |   |   |                               |   |               |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |               |  |  |
| 73. Engine Fue   | and Control  |   |   |                               |   |               |  |  |
| Sequence No.   | ltem   | 1 | 2 | 3                             | 4   | Change<br>Bar |  |  |
| 73-30-07   | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd)  |   |   |                               |   |               |  |  |
| 2)   | PW 1100G Engines<br>without Mod.163016/<br>MP P20522 and with<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 50 flight-hours.</li> </ul>   |               |  |  |
|  |  | A | 2 | 1                             | <ul> <li>One may be inoperative provided: <ul> <li>a) Associated FUEL FILTER</li> <li>SENSOR subtitle is displayed on EWD,</li> </ul> </li> <li>b) ENG 1(2) FUEL FILTER PARTLY CLOGGED caution is not displayed on EWD for opposite engine,</li> <li>c) VSB PW1000G-C-73-00-0030-00A-930A-D or VSB PW1000G-C-73-00-0046-00A-930A-D or VSB PW1000G-C-73-00-0047-00A-930A-D is applied on affected engine, and</li> <li>d) Repairs are made within 8 flights or 16 flight-hours, whichever occurs first.</li> </ul> |               |  |  |
|  |  | С | 2 | 0                             | May be inoperative provided<br>associated IDG FOC SENSOR<br>subtitle is displayed on EWD.   |               |  |  |
|  |  |   |   |                               | (Continued)   |               |  |  |

|                                | VENT OF TRANSPORTATION   |   |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
|--------------------------------|--|---|---|-------------------------------|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   | -  |   |   |                               | PAGE NO. 73-10   |  |  |  |
| AIRCRAFT:<br>Airbus A320       |  |   | T | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 73. Engine Fue<br>Sequence No. | Item   | 1 | 2 | 3                             | 4 Change   |  |  |  |
| 73-30-07                       | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd)  | 1 | L | 5                             | 4 Bar  |  |  |  |
| 3)                             | PW 1100G Engines with<br>Mod.163016/<br>MP P20522 and without<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 50 flight-hours.</li> </ul>  |  |  |  |
|                                |  | A | 2 | 1                             | <ul> <li>One may be inoperative provided:</li> <li>a) Associated FUEL FILTER<br/>SENSOR subtitle is displayed<br/>on EWD</li> <li>b) ENG 1(2) FUEL FILTER<br/>DEGRAD caution is not<br/>displayed on EWD for<br/>opposite engine, and</li> <li>c) Repairs are made within<br/>8 flights or 16 flight-hours,<br/>whichever occurs first.</li> </ul> |  |  |  |
|                                |  | С | 2 | 0                             | May be inoperative provided<br>associated IDG FOC SENSOR<br>subtitle is displayed on EWD.<br>(Continued)   |  |  |  |

|                                 | IENT OF TRANSPORTATIO   | NC | MASTER MINIMUM FOURPMENT US |                |  |  |  |  |
|---------------------------------|---|----|-----------------------------|----------------|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |   |    |                             |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
| REVISION NO.                    | 31  |    |                             |                | PAGE NO. 73-11   |  |  |  |
| DATE: 08/13/20                  | )24   |    |                             |                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320        |   |    | Т <i>і</i>                  | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 73. Engine Fue                  |   |    | •                           | 2              | Change   |  |  |  |
| Sequence No.<br>73-30-07        | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd)   | 1  | 2                           | 3              | 4 Change<br>Bar  |  |  |  |
| 4)                              | PW 1100G Engines with<br>Mod.163016/<br>MP P20522 and with<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С  | 2                           | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 50 flight-hours.</li> </ul>  |  |  |  |
|                                 |   | A  | 2                           | 1              | <ul> <li>One may be inoperative provided:</li> <li>b) Associated FUEL FILTER<br/>SENSOR subtitle is displayed<br/>on EWD</li> <li>b) ENG 1(2) FUEL FILTER<br/>PARTLY CLOGGED caution<br/>is not displayed on EWD for<br/>opposite engine, and</li> <li>c) Repairs are made within<br/>8 flights or 16 flight-hours,<br/>whichever occurs first.</li> </ul> |  |  |  |
|                                 |   | С  | 2                           | 0              | May be inoperative provided<br>associated IDG FOC SENSOR<br>subtitle is displayed on EWD.<br>(Continued)   |  |  |  |

| U.S. DEPARTM                   | IENT OF TRANSPORTATIO   | ON |   |          |  |
|--------------------------------|---|----|---|----------|--|
| FEDERAL AVIA                   | ATION ADMINISTRATION  |    |   |          | MASTER MINIMUM EQUIPMENT LIST  |
| REVISION NO.<br>DATE: 08/13/20 |   |    |   |          | PAGE NO. 73-12   |
|                                |   |    | Т | ABLI     | E KEY  |
| AIRCRAFT:<br>Airbus A320       |   |    |   | 2.<br>3. | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 73. Engine Fue                 | I and Control   |    |   |          |  |
| Sequence No.                   | ltem  | 1  | 2 | 3        | 4 Change<br>Bar  |
| 73-30-07                       | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd)                   |    |   |          |  |
| 5)                             | CFM LEAP-1A Engines<br>without Mod.1 62159/<br>MP P20466<br>FWC H2-F10) | С  | 2 | 1        | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER<br/>SENSOR subtitle is displayed<br/>on EWD, and</li> <li>b) Associated filter is replaced<br/>before next flight and then<br/>every 100 flight-hours.</li> </ul>   |
|                                |   | A  | 2 | 1        | <ul> <li>One may be inoperative provided: <ul> <li>a) Associated FUEL STRAINER</li> <li>SENSOR subtitle is displayed on EWD,</li> </ul> </li> <li>b) Associated ENG 1(2) FUEL STRAINER CLOG caution was not displayed on EWD on previous flight,</li> <li>c) ENG 1(2) FUEL FILTER</li> <li>DEGRAD caution and</li> <li>ENG 1(2) FUEL SENSOR</li> <li>FAULT caution are not displayed on EWD for opposite engine, and</li> <li>d) Repairs are made within 3 flights or 6 flight-hours, whichever occurs first.</li> </ul> |
|                                |   | С  | 2 | 1        | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL STRAINER<br/>SENSOR subtitle is displayed<br/>on EWD, and</li> <li>b) Associated filter is replaced.</li> </ul>  |
|                                |   | С  | 2 | 0        | One or both may be inoperative<br>provided:<br>a) Associated TEMP SENSORS<br>subtitle is displayed on EWD,<br>and<br>b) Four wing tank pumps are<br>operative.   |
|                                |   |    |   |          | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |    |                | MASTER MINIMUM EQUIPMENT LIST   |
|--|--|---|----|----------------|---|
| REVISION NO. 31<br>DATE: 08/13/2024                                  |  |   |    |                | PAGE NO. 73-13  |
| AIRCRAFT:<br>Airbus A320   |  |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 73. Engine Fue   | and Control  |   |    |                |   |
| Sequence No.   | Item   | 1 | 2  | 3              | 4 Change<br>Bar   |
| 73-30-07   | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd)  |   |    |                |   |
| 6)   | CFM LEAP-1A Engines<br>with Mod 162159/<br>MP P20466<br>(FWC H2-F10)<br>(except A321neo XLR) | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 100 flight-hours.</li> </ul>  |
|  |  | A | 2  | 1              | <ul> <li>One may be inoperative provided: <ul> <li>a) Associated FUEL STRAINER</li> <li>SENSOR subtitle is displayed on EWD,</li> </ul> </li> <li>b) Associated ENG 1(2) FUEL STRAINER CLOG caution was not displayed on EWD on previous flight,</li> <li>c) ENG 1(2) FUEL FILTER</li> <li>PARTLY CLOGGED caution and ENG 1(2) FUEL</li> <li>SENSOR FAULT caution are not displayed on EWD for opposite engine, and</li> <li>d) Repairs are made within 3 flights or 6 flight-hours, whichever occurs first.</li> </ul> |
|  |  | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL STRAINER</li> <li>SENSOR subtitle is displayed</li> <li>on EWD, and</li> <li>b) Associated filter is replaced.</li> </ul>   |
|  |  | С | 2  | 0              | One or both may be inoperative<br>provided:<br>a) Associated TEMP SENSORS<br>subtitle is displayed on EWD,<br>and<br>b) Four wing tank pumps are<br>operative.<br>(Continued)   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |          |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|--|---|---|----------|----------------|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   |   |   | PAGE NO. |                |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 73. Engine Fue   | el and Control  |   |          |                |  |  |  |  |
| Sequence No.   | Item  | 1 | 2        | 3              | 4 Change<br>Bar  |  |  |  |
| 73-30-07   | FUEL SENSOR FAULT<br>Cautions on ECAM EWD<br>(Cont'd) |   |          |                |  |  |  |  |
| 7)   | A321neo XLR with<br>CFM LEAP-1A Engines               | С | 2        | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL FILTER SENSOR subtitle is displayed on EWD, and</li> <li>b) Associated filter is replaced before next flight and then every 100 flight-hours.</li> </ul>   |  |  |  |
|  |   | A | 2        | 1              | <ul> <li>one may be inoperative provided: <ul> <li>a) Associated FUEL STRAINER</li> <li>SENSOR subtitle is displayed on EWD,</li> </ul> </li> <li>b) Associated ENG 1(2) FUEL STRAINER CLOG caution was not displayed on EWD on previous flight,</li> <li>c) ENG 1(2) FUEL FILTER PARTLY CLOGGED caution and ENG 1(2) FUEL SENSOR FAULT caution are not displayed on EWD for opposite engine, and</li> <li>d) Repairs are made within 3 flights or 14 flight-hours, whichever occurs first.</li> </ul> |  |  |  |
|  |   | С | 2        | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated FUEL STRAINER<br/>SENSOR subtitle is displayed<br/>on EWD, and</li> <li>b) Associated filter is replaced.</li> </ul>  |  |  |  |
|  |   | С | 2        | 0              | <ul> <li>One or both may be inoperative provided:</li> <li>a) Associated TEMP SENSORS subtitle is displayed on EWD, and</li> <li>b) Four wing tank pumps are operative.</li> </ul>   |  |  |  |

| _                                   | MENT OF TRANSPORTATIO  | NC |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|-------------------------------------|--|----|---|---|---|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |  |    |   |   | PAGE NO. 73-15  |  |  |
| AIRCRAFT:<br>Airbus A320            | AIRCRAFT:  |    |   | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |
| 73. Engine Fu                       | el and Control   |    |   |   |   |  |  |
| Sequence No.                        | Item   | 1  | 2 | 3   | 4 Change<br>Bar   |  |  |
| 73-30-08                            | HEAT SYS DEGRAD<br>Cautions on ECAM EWD                                  |    |   |   |   |  |  |
|                                     | (A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines)                   | A  | 2 | 0   | May be inoperative for 2 flights provided APU and APU generator are operative.  |  |  |
|                                     | (A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines)                   | С  | 2 | 1   | <ul> <li>(M) One may be inoperative provided:</li> <li>a) APU and APU generator are operative, and</li> <li>b) CFDS does not report an ENGXD-0720-BDCV TEST ABORT COUNT message.</li> </ul>   |  |  |
|                                     | (A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines)                   | С  | 2 | 0   | Except for ETOPS, may be<br>inoperative provided APU and<br>APU generator are operative.  |  |  |
| 73-30-09                            | FUEL STRAINER CLOG<br>Cautions on ECAM EWD                               |    |   |   |   |  |  |
| 1)                                  | CFM LEAP-1A Engines<br>without Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A  | 2 | 1   | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) FUEL<br/>FILTER DEGRAD caution is<br/>not displayed on EWD,</li> <li>b) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD on<br/>opposite engine, and</li> <li>c) Repairs are made within<br/>10 consecutive calendar-days.</li> </ul>             |  |  |
| 2)                                  | CFM LEAP-1A Engines<br>with Mod. 162159/<br>MP P20466<br>(FWC H2-F10)    | A  | 2 | 1   | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) FUEL<br/>FILTER PARTLY CLOGGED<br/>caution is not displayed on<br/>EWD,</li> <li>b) ENG 1(2) FUEL SENSOR<br/>FAULT caution is not<br/>displayed on EWD on<br/>opposite engine, and</li> <li>c) Repairs are made within<br/>10 consecutive calendar-days.</li> </ul> |  |  |

|               |  | - |   |                               |   |  |  |  |
|---------------|--|---|---|-------------------------------|---|--|--|--|
|               | MENT OF TRANSPORTATIO  |   |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
| FEDERAL AV    | IATION ADMINISTRATION  |   |   |                               |   |  |  |  |
| REVISION NC   | 0. 31  |   |   |                               | PAGE NO. 73-16  |  |  |  |
| DATE: 08/13/2 | 2024   |   |   |                               |   |  |  |  |
|               |  |   | ٦ | TABLE KEY                     |   |  |  |  |
| AIRCRAFT:     |  |   |   |                               | REPAIR CATEGORY   |  |  |  |
| _             | -  |   |   |                               | NO. INSTALLED   |  |  |  |
| Airbus A320   |  |   |   | 3.                            | NO. REQUIRED FOR DISPATCH   |  |  |  |
|               |  |   |   |                               | REMARKS OR EXCEPTIONS   |  |  |  |
| 73. Engine Fu | el and Control   |   |   |                               |   |  |  |  |
| Sequence No.  | Item   | 1 | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 73-30-10      | HP FUEL VALVE<br>Cautions on ECAM EWD<br>(A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines)     | С | 2 | 1                             | One may be inoperative provided:<br>a) Associated HP FUEL VALVE<br>NOT OPEN subtitle is<br>displayed on the EWD, and<br>b) Affected engine can be<br>started.   |  |  |  |
| 73-30-11      | FADEC IDENT FAULT<br>Cautions on ECAM EWD<br>(A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines) | С | 2 | 0                             | (M) One or both may be inoperative<br>provided there is no disagreement<br>between the associated engine<br>identification contained in the FADEC<br>and the identification written on the<br>engine plate. |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 30<br>DATE: 03/03/2023 |  |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|---|--|---|---|---|---|--|--|--|--|
|   |  |   |   |   | PAGE NO. 74-1   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320  |  |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |  |
| 74. Ignition<br>Sequence No.  | Item   | 1 | 2 | 3 | 4 Change  |  |  |  |  |
| 74-31-01  | Ignition Systems   | • | 2 | 3 | <del>4 Bar</del>  |  |  |  |  |
| 1)  | CFM Engines  |   |   |   |   |  |  |  |  |
| a)  | System B<br>(CFM 56-5A Engines<br>with Mod. 22333 or<br>CFM 56-5B Engines or<br>CFM LEAP-1A Engines) | С | 2 | 0 | (O) May be inoperative provided<br>System A is operative.   |  |  |  |  |
| b)  | System B<br>(CFM 56-5A Engines<br>without Mod. 22333   | С | 2 | 0 | <ul> <li>(O) May be inoperative provided:</li> <li>a) Engine relight envelope with<br/>System B inoperative is<br/>observed, and</li> <li>b) System A operates normally.</li> </ul>   |  |  |  |  |
| 2)  | IAE Engines and<br>PW Engines  |   |   |   |   |  |  |  |  |
| a)  | System A   | С | 2 | 1 | (O) Except for ETOPS, may be inoperative on one engine only.  |  |  |  |  |
| b)  | System B   | С | 2 | 0 | (O) May be inoperative provided<br>System A operates normally.  |  |  |  |  |
| c)  | System A and B   | С | 4 | 2 | <ul> <li>(O) Except for ETOPS, two igniters<br/>may be inoperative provided they are<br/>not on the same engine.</li> <li>NOTE: On IAE and PW engines,<br/>system A must be considered<br/>inoperative on both engines if<br/>the common power supply<br/>line from 401XP 115VAC ESS<br/>BUS is inoperative as a result<br/>of either a loss of electrical<br/>continuity or a short circuit<br/>(C/B Engine/1 AND 2<br/>IGN/SYS A (49VUA03)<br/>tripped).</li> </ul> |  |  |  |  |

|                              | MENT OF TRANSPORTATI                        |   |   | MASTER MINIMUM EQUIPMENT LIST |  |
|------------------------------|---|---|---|-------------------------------|--|
| REVISION NO<br>DATE: 03/03/2 |   |   |   | PAGE NO. 74-2                 |  |
| AIRCRAFT:<br>Airbus A320     | RAFT:                                       |   |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS                                |
| 74. Ignition                 |   | 1 |   | r                             | Change   |
| Sequence No.<br>74-31-02     | Item<br>ECAM Indications<br>(Lower Display) | 1 | 2 | 3                             | 4 Change<br>Bar  |
| 1)                           | Selected Igniter                            | С | 4 | 0                             | (M) May be inoperative provided IGN<br>FAULT warning is verified to operate<br>normally on ECAM.                               |
| 74-31-03                     | IGN FAULT Caution on<br>ECAM                |   |   |                               |  |
| 1)                           | CFM Engines                                 | С | 4 | 3                             | (M) One may be inoperative provided<br>associated ignition system is verified<br>to operate normally once each<br>flight-day.  |
|                              |   | С | 4 | 2                             | (M) Two may be inoperative provided<br>associated ignition system is verified<br>to operate normally before each<br>departure. |
| 2)                           | IAE Engines and<br>PW Engines               | С | 4 | 2                             | One or two may be inoperative.   |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |    | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|---|---|----|--|--|--|--|--|
| REVISION NO. 30  |  |   |   |    | PAGE NO. 75-1  |  |  |  |  |
| DATE: 03/03/2023<br>AIRCRAFT:  |  |   |   |    | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED  |  |  |  |  |
| Airbus A320  |  |   |   | 3. | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 75. Bleed Air  |  |   |   | 1  |  |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3  | 4 Change<br>Bar  |  |  |  |  |
| 75-21-01   | HP Turbine Active<br>Clearance Control<br>System                                 |   |   |    |  |  |  |  |  |
| 1)   | (CFM LEAP-1A Engines)  | С | 2 | 0  | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Affected HPTACC valve is deactivated in closed position, and</li> <li>b) Associated engine takeoff EGT margin is above 15°C.</li> </ul>   |  |  |  |  |
| 75-22-01   | LP Turbine Active<br>Clearance Control   |   |   |    |  |  |  |  |  |
| 1)   | (CFM LEAP-1A Engines)  | A | 2 | 0  | <ul> <li>(M)(O) May be inoperative provided:</li> <li>a) Affected LPTACC valve is deactivated in closed position,</li> <li>b) Associated engine takeoff EGT margin is above 5 °C, and</li> <li>c) Repairs are made within 10 flight-legs.</li> </ul> |  |  |  |  |
| 75-22-02   | Buffer Air Check Valve<br>(A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines) | С | 2 | 1  | One may be inoperative in open position.   |  |  |  |  |
| 75-25-01   | TCC/TACC Valve   |   |   |    |  |  |  |  |  |
| 1)   | A318 with PW 6000<br>Engines   | В | 2 | 1  | (O) One may be inoperative in closed<br>position provided the affected engine<br>takeoff EGT margin is greater than<br>18 °C.  |  |  |  |  |
| 2)   | A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines                             | В | 2 | 1  | (O) One may be inoperative in closed<br>position provided the affected engine<br>takeoff EGT margin is greater than<br>16 °C.  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |        |   |               | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|--------|---|---------------|--|
| REVISION NO.<br>DATE: 03/03/20                                       |  |        |   | PAGE NO. 75-2 |  |
| AIRCRAFT:<br>Airbus A320   |  |        | T | 1.<br>2.      | NO. REQUIRED FOR DISPATCH  |
| 75. Bleed Air  | ltem   | 4      | 2 | 2             | 4 Change   |
| Sequence No.<br>75-25-02   | TCA Valve<br>(PW 6000 Engines Only)  | 1<br>C | 2 | 3             | 4 <sub>ваг</sub><br>(M) One may be failed closed<br>provided TCA pipes are verified to<br>have no cracks.                  |
| 75-25-03   | FADEC Blower<br>(A319neo/A320neo/<br>A321neo with CFM<br>LEAP-1A Engines and<br>Mod. 163105/<br>MP P20228) | A      | 2 | 1             | One may be inoperative for a<br>maximum of 10 consecutive<br>calendar-days or 150 flight-hours,<br>whichever occurs first. |

|  | MENT OF TRANSPORTATI   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|----|---|----------------|--|
| <b>REVISION NO</b>                               | D. 30  |    |   |                | PAGE NO. 76-1  |
| DATE: 03/03/2                                    | 2023   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320<br><b>76. Engine Cc</b> | ontrol   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.                                     | Item   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 76-11-01   | Thrust Lever Position<br>Sensor (IAE Engines or<br>CFM Engines or PW<br>6000 Engines only) | A  | 4 | 3              | <ul> <li>One may be inoperative provided:</li> <li>a) A/THR is operative,</li> <li>b) Both LGCIUs are operative,<br/>and</li> <li>c) Repairs are made within<br/>3 flight-days.</li> </ul> |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|--|---|---|----------------|--|
| REVISION NO. 30<br>DATE: 03/03/2023                                  |  |   |   |                | PAGE NO. 77-1  |
| AIRCRAFT:<br>Airbus A320   | AFT:   |   |   | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS |
| 77. Engine Ind   | dicating   | - |   |                |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |
| 77-00-01   | ECAM Indications   |   |   |                |  |
| 1)   | Fuel Flow<br>(Upper Display)   |   |   |                |  |
| a)   | Aircraft without<br>Mod. 30368/MP P6578  | В | 2 | 1              | One may be inoperative.  |
| b)   | Aircraft with<br>Mod. 30368/MP P6578   | В | 2 | 1              | May be inoperative provided the total fuel flow indication is considered inoperative.                  |
| 2)   | Total Fuel Flow<br>Indication<br>(Fuel Page)<br>(With Mod. 30368/<br>MP P6758)                     | В | 1 | 0              | May be inoperative or replaced by XX.  |
| 3)   | Bleed Configuration<br>Indication on the EWD<br>(PACKS, NAI, WAI)<br>(A319neo/A320neo/<br>A321neo) | С | 3 | 0              | May be inoperative.  |
|  |  | D | 3 | 0              | May be inoperative provided procedures do not require its use.   |
| 77-00-02   | ECAM Indications<br>(Lower Display)  |   |   |                |  |
| 1)   | Nacelle Temperature  | С | 2 | 0              | One or both may be inoperative.  |
| 2)   | N <sub>1</sub> Vibration   | С | 2 | 1              | One may be inoperative.  |
| 3)   | N <sub>2</sub> Vibration   | С | 2 | 1              | One may be inoperative.  |

|                                     | IMENT OF TRANSPORTATI                                   | ON |   | MASTER MINIMUM EQUIPMENT LIST |   |  |  |  |
|-------------------------------------|---|----|---|-------------------------------|---|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024 |   |    |   |                               | PAGE NO. 78-1   |  |  |  |
|                                     |   |    |   |                               | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 78. Engine Ex                       |   |    | 1 | -                             | Change  |  |  |  |
| Sequence No.                        |   | 1  | 2 | 3                             | 4 Change<br>Bar   |  |  |  |
| 78-11-09                            | T/R Door Tertiary Lock<br>A318 with PW 6000<br>Engines  | С  | 8 | 4                             | One or more may be failed locked provided the associated T/R is considered inoperative.   |  |  |  |
| 2)                                  | A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines    | С  | 4 | 2                             | One or both on the same engine may<br>be failed locked provided the<br>associated T/R is considered<br>inoperative.   |  |  |  |
|                                     |   | С  | 4 | 0                             | (M)(O) One or more may be<br>inoperative provided the associated<br>thrust reverser door tertiary lock is<br>secured in the open position.  |  |  |  |
| 3)                                  | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines | С  | 2 | 1                             | One may be failed locked provided<br>the associated T/R is considered<br>inoperative.   |  |  |  |
|                                     |   | С  | 2 | 0                             | <ul> <li>(M)(O) One or both may be inoperative provided: <ul> <li>a) Associated thrust reverser door tertiary lock is secured in the open position, and</li> <li>b) ENG 1(2) REV LOCKED alert associated with the affected thrust reverser is not displayed on the EWD after deactivation.</li> </ul> </li> </ul> |  |  |  |
| 78-11-10                            | T/R Tertiary Lock Valve                                 |    |   |                               |   |  |  |  |
| 1)                                  | A318 with PW 6000<br>Engines                            | С  | 2 | 0                             | One or both may be failed open.   |  |  |  |
| 2)                                  | A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines    | С  | 4 | 0                             | One or more may be failed open.   |  |  |  |

| 78-30-01 T<br>S  | 4  | 1<br>C | 2<br>2 | 1.<br>2.<br>3.                   | PAGE NO. 78-2 E KEY REPAIR CATEGORY NO. INSTALLED NO. REQUIRED FOR DISPATCH REMARKS OR EXCEPTIONS 4 Change Bar  |
|--|--|--------|--------|----------------------------------|---|
| Airbus A320<br>78. Engine Exhau<br>Sequence No. It<br>78-30-01 T<br>5<br>1) (A                     | Item<br>Thrust Reverser<br>Systems<br>(A318/A319ceo/ |        | 2      | 1.<br>2.<br>3.<br>4.<br><b>3</b> | REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.         It           78-30-01         T           5         S           1)         (J | Item<br>Thrust Reverser<br>Systems<br>(A318/A319ceo/ |        |        |                                  | 4 Bar   |
| 78-30-01 T<br>S<br>1) (/   | Thrust Reverser<br>Systems<br>(A318/A319ceo/         |        |        |                                  | 4 Bar   |
| 1) (/  | Systems<br>(A318/A319ceo/                            | С      | 2      | 1                                | (M)(O) One may be increasive  |
|  |  | С      | 2      | 1                                | (M)(O) One may be increative  |
|  |  |        |        |                                  | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) Inoperative reverser is deactivated and secured in the stowed position and no operations or procedures require its use,</li> <li>b) All stow and deploy switches on the inoperative reverser operate normally (CFM 56 only),</li> <li>c) Both LVDT on the inoperative reverser are checked operative (IAE only),</li> <li>d) ENG 1 (2) REV INHIBITED caution is displayed on ECAM EWD after deactivation (PW 6000 only),</li> <li>e) ENG 1(2) REV UNLOCKED caution is not present on ECAM EWD after deactivation (PW 6000 only),</li> <li>f) ENG 1(2) REV</li> <li>f) ENG 1(2) REV</li> <li>f) ENG 1(2) REV</li> <li>g) Wheel brake tachometers operate normally,</li> <li>h) Main wheel braking system operates normally,</li> </ul> </li> <li>(Continued)</li> </ul> |

| U.S. DEPART              | MENT OF TRANSPORTATI  | ON |   |   |  |
|--------------------------|---|----|---|---|--|
| -                        | ATION ADMINISTRATION  |    |   |   | MASTER MINIMUM EQUIPMENT LIST  |
| REVISION NO              | ). 31   |    |   |   | PAGE NO. 78-3  |
| DATE: 08/13/2            | 2024  |    |   |   |  |
| AIRCRAFT:<br>Airbus A320 |   |    |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 78. Engine Ex            | haust   |    | I |   |  |
| Sequence No.             | Item  | 1  | 2 | 3 | 4 Change<br>Bar  |
| 78-30-01                 | Thrust Reverser<br>Systems<br>(Cont'd)  |    |   |   |  |
| 1)                       | (A318/A319ceo/<br>A320ceo/A321ceo)<br>(Cont'd)  |    |   |   | <ul> <li>i) Flightcrew is provided with the following statement via appropriate means (e.g., dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>j) Appropriate performance adjustments are applied.</li> </ul> |
| 2)                       | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484 | С  | 2 | 1 | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) The BSCU P/N E21327307 is not installed,</li> <li>b) Inoperative reverser is deactivated and secured in the stowed position and no operations or procedures require its use,</li> <li>c) ENG 1(2) REV INHIBITED caution is displayed on ECAM EWD after deactivation,</li> <li>d) ENG 1(2) REV UNLOCKED caution is not present on ECAM EWD after deactivation,</li> </ul> </li> </ul>              |
|                          |   |    |   |   | (Continued)  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO. 31<br>DATE: 08/13/2024                                  |   |   |   |                | PAGE NO. 78-4  |
| AIRCRAFT:<br>Airbus A320   |   |   |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 78. Engine Exh   | naust   |   |   |                |  |
| Sequence No.   | Item  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 78-30-01   | Thrust Reverser<br>Systems<br>(Cont'd)  |   |   |                |  |
| 2)   | A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484<br>(Cont'd) | C | 2 | 1              | <ul> <li>e) ENG 1(2) REV<br/>PRESSURIZED caution is not<br/>present on ECAM EWD after<br/>deactivation,</li> <li>f) Wheel brake tachometers<br/>operate normally,</li> <li>g) Main wheel braking system<br/>operates normally,</li> <li>h) Flightcrew is provided with the<br/>following statement via<br/>appropriate means (e.g.,<br/>dispatch release, MEL (O)<br/>procedure, etc.): "For a<br/>landing conducted with one<br/>deactivated thrust reverser,<br/>ensure that both engine thrust<br/>levers are retarded to the<br/>IDLE detent for the flare and<br/>the touchdown. Select both<br/>thrust levers to reverse when<br/>applying reverse thrust," and</li> <li>i) Appropriate performance<br/>adjustments are applied.</li> <li>NOTE: The BSCU standard P/N can<br/>be checked by AMM TASK<br/>32-46-00-740-003-A BITE<br/>Test of the BSCU-LRU<br/>Identification.</li> </ul> |
|  |   |   |   |                | (Continued)  |

|                                | IENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST   |
|--------------------------------|---|----|---|----------------|---|
|                                | ATION ADMINISTRATION  |    |   |                |   |
| REVISION NO.<br>DATE: 08/13/20 | -   |    |   |                | PAGE NO. 78-5   |
| DATE: 08/13/20                 | J24   |    |   |                | - 1/->/   |
| AIRCRAFT:<br>Airbus A320       |   |    |   | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 78. Engine Exh                 | aust  |    | - | -              |   |
| Sequence No.                   | Item  | 1  | 2 | 3              | 4 Change<br>Bar   |
| 78-30-01                       | Thrust Reverser<br>Systems<br>(Cont'd)  |    |   |                |   |
| 3)                             | A319neo/A320neo/<br>A321neo without<br>Mod 165148/<br>MP J4604 or<br>A321neo with<br>Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484 | C  | 2 | 1              | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) Inoperative reverser is deactivated and secured in the stowed position and no operations or procedures require its use,</li> <li>b) ENG 1(2) REV INHIBITED caution is displayed on ECAM EWD after deactivation,</li> <li>c) ENG 1(2) REV UNLOCKED caution is not present on ECAM EWD after deactivation,</li> <li>d) ENG 1(2) REV PRESSURIZED caution is not present on ECAM EWD after deactivation,</li> <li>e) Wheel brake tachometers operate normally,</li> <li>f) Main wheel braking system operates normally,</li> <li>g) Flightcrew is provided with the following statement via appropriate means (e.g., dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>h) Appropriate performance adjustments are applied.</li> </ul></li></ul> |

| -  | MENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|----|---|----------------|--|
| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 31 |   |    |   |                | PAGE NO. 78-6  |
| DATE: 08/13/2                                      | 2024  |    |   |                |  |
| AIRCRAFT:<br>Airbus A320                           |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 78. Engine Ex                                      |   | 1  | 2 | 3              | Change   |
| Sequence No.<br>78-30-01                           | Item<br>Thrust Reverser<br>Systems<br>(Cont'd)  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 4)   | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>with Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484 | C  | 2 | 1              | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) The BSCU P/N E21327307 is not installed,</li> <li>b) Inoperative reverser is deactivated and secured in the stowed position and no operations or procedures require its use,</li> <li>c) ENG 1(2) REV INHIBITED caution is displayed on ECAM EWD after deactivation,</li> <li>d) ENG 1(2) REV UNLOCKED caution is not present on ECAM EWD after deactivation,</li> <li>e) The ICV is checked closed before each flight,</li> <li>f) Wheel brake tachometers operate normally,</li> <li>g) Main wheel braking system operates normally,</li> <li>h) Flightcrew is provided with the following statement via appropriate means (e.g., dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>i) Appropriate performance adjustments are applied.</li> </ul></li></ul> |

| FEDERAL AVIATION ADMINISTRATION<br>REVISION NO. 31 |   |   |   |   | PAGE NO. 78-7   |
|--|---|---|---|---|---|
|  |   |   |   |   | FAGE NO. 76-7   |
| AIRCRAFT:<br>Airbus A320                           | IRCRAFT:  |   |   |   | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 78. Engine Exh                                     | naust   |   |   |   |   |
| Sequence No.                                       | Item  | 1 | 2 | 3 | 4 Change<br>Bar   |
| 78-30-01   | Thrust Reverser<br>Systems<br>(Cont'd)  |   |   |   |   |
| 4)   | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>with Mod 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484<br>(Cont'd)   |   |   |   | NOTE: The BSCU standard P/N can<br>be checked by AMM TASK<br>32-46-00-740-003-A BITE<br>Test of the BSCU-LRU<br>Identification.   |
| 5)   | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>without Mod 165148/<br>MP J4604 or<br>A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>with Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484 | C | 2 | 1 | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) Inoperative reverser is deactivated and secured in the stowed position and no operations or procedures require its use,</li> <li>b) ENG 1(2) REV INHIBITED caution is displayed on ECAM EWD after deactivation,</li> <li>c) ENG 1(2) REV UNLOCKED caution is not present on ECAM EWD after deactivation,</li> <li>d) The ICV is checked closed before each flight,</li> <li>e) Wheel brake tachometers operate normally,</li> <li>f) Main wheel braking system operates normally,</li> </ul> </li> </ul> |

| -                            | MENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|---|----------------|--|
| REVISION NC<br>DATE: 08/13/2 | -   |    |   | PAGE NO. 78-8  |  |
| AIRCRAFT:<br>Airbus A320     |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 78. Engine Ex                |   |    |   |                | A Change   |
| Sequence No.<br>78-30-01     | Item<br>Thrust Reverser<br>Systems<br>(Cont'd)  | 1  | 2 | 3              | 4 Change Bar   |
| 5)                           | A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>without Mod 165148/<br>MP J4604 or<br>A319neo/A320neo/<br>A321neo with<br>CFM LEAP-1A Engines<br>with Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484<br>(Cont'd) |    |   |                | <ul> <li>g) Flightcrew is provided with the following statement via appropriate means <ul> <li>(e.g., dispatch release, MEL</li> <li>(O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>h) Appropriate performance adjustments are applied.</li> </ul></li></ul> |
| 78-30-02                     | Thrust Reverser<br>Inhibition Relay Contacts<br>(CFM)<br>(Thrust Reverser<br>Permission Switches<br>(V2500))  | С  | 4 | 2              | (M) Two contacts may be inoperative<br>provided they are on the same<br>engine and the associated reverser is<br>deactivated.  |
| 78-30-07                     | T/R INDICATIONS<br>(IAE, CFM, and<br>PW Engines)  | С  | 2 | 1              | One may be inoperative provided the associated T/R is considered inoperative.  |

| -                        | IENT OF TRANSPORTATIO  | ON |                               |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|--------------------------|--|----|-------------------------------|----------------|---|--|--|
| FEDERAL AVIA             | ATION ADMINISTRATION   |    | MASTER MINIMOM EQUIPMENT LIST |                |   |  |  |
| <b>REVISION NO.</b>      | 31   |    |                               |                | PAGE NO. 78-9   |  |  |
| DATE: 08/13/20           | )24  |    |                               |                |   |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | Т.<br>                        | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |
| 78. Engine Exh           |  |    | <b>I</b> .                    | <b>.</b> .     | 4 Change  |  |  |
| Sequence No.<br>78-31-01 | Item<br>REVERSER CTL FAULT<br>Caution on ECAM EWD  | 1  | 2                             | 3              | 4 Change Bar  |  |  |
| 1)                       | A319neo/A320neo/<br>A321neo with<br>Mod. 165148/<br>MP J4604 and without<br>Mod 171984/<br>MP P22484 | C  | 2                             | 1              | <ul> <li>(O) One may be inoperative provided: <ul> <li>a) The BSCU P/N E21327307 is not installed,</li> <li>b) Wheel brake tachometers operate normally,</li> <li>c) Main wheel braking system operates normally,</li> <li>d) Associated thrust reverser system is considered inoperative,</li> <li>e) Flightcrew is provided with the following statement via appropriate means (e.g., dispatch release, MEL (O) procedure, etc.): "For a landing conducted with one deactivated thrust reverser, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>f) Appropriate performance adjustments are applied.</li> </ul> NOTE: The BSCU standard P/N can be checked by AMM TASK 32-46-00-740-003-A BITE Test of the BSCU-LRU Identification. (Continued)</li></ul> |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |
|--|--|---|---|----------------|---|--|--|
| REVISION NO<br>DATE: 08/13/2   |  |   |   |                | PAGE NO. 78-10  |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>78. Engine Ext</b>                    | RCRAFT:<br>bus A320  |   |   | 1.<br>2.<br>3. | E <b>KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |
| 78-31-01   | REVERSER CTL FAULT<br>Caution on ECAM EWD<br>(Cont'd)  |   |   |                | Bar   |  |  |
| 2)   | A319neo/A320neo/<br>A321neo without<br>Mod. 165148/<br>MP J4604 or<br>A319neo/A320neo/<br>A321neo with<br>Mod 165148/<br>MP J4604 and with<br>Mod 171984/<br>MP P22484 | С | 2 | 1              | <ul> <li>(O) One may be inoperative provided: <ul> <li>a) Wheel brake tachometers operate normally,</li> <li>b) Main wheel braking system operates normally,</li> <li>c) Associated thrust reverser system is considered inoperative,</li> <li>d) Flightcrew is provided with the following statement via appropriate means (e.g., dispatch release, MEL (O) procedure, etc.): "For a landing conducted with REVERSER CTL FAULT on one side, ensure that both engine thrust levers are retarded to the IDLE detent for the flare and the touchdown. Select both thrust levers to reverse when applying reverse thrust," and</li> <li>e) Appropriate performance adjustments are applied.</li> </ul></li></ul> |  |  |
| 78-31-02   | REV MINOR FAULT<br>Caution on ECAM EWD<br>(A319neo/A320neo/<br>A321neo)  | С | 2 | 0              | May be inoperative.   |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST   |  |  |  |  |
|--|--|---|---|----------------|---|--|--|--|--|
| REVISION NO.<br>DATE: 08/13/20                                       |  |   |   | PAGE NO. 79-1  |   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | <b>E KEY</b><br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 79. Engine Oil   |  |   | 1 | 1              | Otana a   |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar   |  |  |  |  |
| 79-20-01   | Air Exchanger Air Valves<br>(V2500 Engines Only) | С | 2 | 1              | (O) One may be inoperative open<br>provided the tank fuel temperature is<br>above -20 °C at takeoff.  |  |  |  |  |
| 79-20-02<br>***  | EMCD Visual Pop-Out<br>Indicator<br>(CFM-5B)     | D | 2 | 0              | One or both may be inoperative.   |  |  |  |  |
| 79-20-03   | Air Oil Cooler Valve<br>(PW 6000 Engines Only)   | С | 2 | 1              | <ul> <li>(O) One may be inoperative in the open position provided: <ul> <li>a) The associated IDG operates normally,</li> <li>b) The inner tank fuel temperature on the affected side is checked above -20 °C before each flight, and</li> <li>c) Appropriate performance adjustments are applied.</li> </ul> </li> </ul> |  |  |  |  |
|  |  | С | 2 | 1              | <ul> <li>(O) One may be inoperative in the open position provided:</li> <li>a) The inner tank fuel temperature on the affected side is checked above -10 °C before each flight, and</li> <li>b) Appropriate performance adjustments are applied.</li> </ul>   |  |  |  |  |
| 79-23-01   | ENG 1(2) BEARING 4<br>OIL SYS Alert              |   |   |                |   |  |  |  |  |
|  | (IAE Engines with<br>Mod. 24871/<br>MP P3704)    | A | 2 | 0              | <ul> <li>May be inoperative provided:</li> <li>a) HI PRESS message is not<br/>displayed under ENG 1(2)<br/>BEARING 4 OIL SYS caution<br/>on ECAM EWD, and</li> <li>b) Repairs are made within<br/>3 flight-days.</li> </ul>   |  |  |  |  |

|                                | IENT OF TRANSPORTATI  |   |   | MASTER MINIMUM EQUIPMENT LIST |   |
|--------------------------------|---|---|---|-------------------------------|---|
| REVISION NO.<br>DATE: 08/13/20 | . 31  |   |   | PAGE NO. 79-2                 |   |
| AIRCRAFT:<br>Airbus A320       |   |   | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |
| 79. Engine Oil                 |   |   |   |                               |   |
| Sequence No.                   | ltem  | 1 | 2 | 3                             | 4 Change<br>Bar   |
| 79-31-01                       | Oil Quantity Indications  | В | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated oil quantity is<br/>verified before each<br/>departure,</li> <li>b) There is no evidence of<br/>abnormal consumption or<br/>leakage, and</li> <li>c) Associated ENG OIL PRESS,<br/>OIL TEMP indications operate<br/>normally.</li> </ul> |
| 79-33-02                       | OIL LO PR Warning on<br>ECAM EWD<br>(IAE or CFM 56 Engines<br>Only)   | С | 2 | 1                             | One may be inoperative.   |
|                                |   | С | 2 | 0                             | May be inoperative provided RCDR<br>GND CTL is verified ON after engines<br>are started.  |
|                                |   |   |   |                               | NOTE: Simultaneous illumination of<br>BLUE ELEC PUMP pb-sw<br>FAULT light and ENG 1(2)<br>PUMP pb-sw FAULT light<br>with engines off may be due<br>to a failed engine oil low<br>pressure switch. In this case,<br>OIL LO PR warning is<br>inoperative, not displayed and<br>dispatch is not possible.        |
| 79-35-01                       | OIL FILTER CLOG<br>Indications on ECAM<br>Engine System Page  |   |   |                               |   |
| 1)                             | CFM or IAE Engines<br>Excluding Those with<br>S/Ns V10600 to V11304<br>and V11315, V11330,<br>V11335<br>(Not Including V11280,<br>V11302) | С | 2 | 1                             | One may be inoperative.   |
|                                |   |   |   |                               | (Continued)   |

| -                        | MENT OF TRANSPORTATION   |   | MASTER MINIMUM EQUIPMENT LIST |                |  |  |  |
|--------------------------|--|---|-------------------------------|----------------|--|--|--|
| <b>REVISION NO</b>       | . 31   |   |                               | PAGE NO. 79-3  |  |  |  |
| DATE: 08/13/2            | 024  |   |                               |                |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |   | T                             | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |
| 79. Engine Oil           |  |   |                               | 1              |  |  |  |
| Sequence No.             | Item   | 1 | 2                             | 3              | 4 Change<br>Bar  |  |  |
| 79-35-01                 | OIL FILTER CLOG<br>Indications on ECAM<br>Engine System Page<br>(Cont'd)   |   |                               |                |  |  |  |
| 2)                       | IAE Engines S/Ns<br>V10600 to V11304 and<br>V11315, V11330,<br>V11335<br>(Not Including V11280,<br>V11302)<br>without #3 FAG Bearing<br>P/N 2A1165 Installed | С | 2                             | 1              | One may be inoperative.  |  |  |
| 3)                       | IAE Engines S/N V10600<br>to V11304 and V11315,<br>V11330, V11335<br>(Not Including V11280<br>V11302)<br>with #3 FAG Bearing<br>P/N 2A1165 Installed         | С | 2                             | 1              | (M) One may be inoperative provided<br>oil filter screen and chip detector on<br>associated engine are checked and<br>verified clear of contaminants once<br>each flight-day.  |  |  |
| 4)                       | PW Engines   | С | 2                             | 1              | One may be inoperative.  |  |  |
| 79-35-02                 | OIL FILTER CLOG<br>Caution on ECAM EWD   |   |                               |                |  |  |  |
| 1)                       | CFM 56-5A Engines  | С | 2                             | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>once each flight-day, and</li> <li>b) Chip detectors are inspected<br/>when the filter is replaced and<br/>do not reveal the presence of<br/>metal chips or other<br/>contaminants.</li> </ul> |  |  |
|                          |  |   |                               |                | (Continued)  |  |  |
|                          |  |   | I                             | I              |  |  |  |

| -              | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION       |   | MASTER MINIMUM EQUIPMENT LIST |          |  |  |  |
|----------------|--|---|-------------------------------|----------|--|--|--|
| REVISION NO    | 0. 31  |   |                               |          | PAGE NO. 79-4  |  |  |
| DATE: 08/13/2  | 2024   |   |                               |          |  |  |  |
|                |  |   | T                             | ABL      | EKEY   |  |  |
| AIRCRAFT:      |  |   |                               | 1.       |  |  |  |
| Airbus A320    |  |   |                               | 2.<br>3. | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |
|                |  |   |                               | -        | REMARKS OR EXCEPTIONS  |  |  |
| 79. Engine Oil |  |   |                               |          |  |  |  |
| Sequence No.   | Item   | 1 | 2                             | 3        | 4 Change<br>Bar  |  |  |
| 79-35-02       | OIL FILTER CLOG<br>Caution on ECAM EWD<br>(Cont'd) |   |                               |          |  |  |  |
| 2)             | CFM 56-5B Engines                                  | С | 2                             | 1        | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>once each flight-day, and</li> <li>b) Visual indicator (pop-out) on<br/>the electrical master chip<br/>detector is inspected when<br/>the filter is replaced and does<br/>not reveal the presence of<br/>metal chips or other<br/>contaminants.</li> </ul> |  |  |
| 3)             | PW 6000 Engines                                    | С | 2                             | 1        | <ul> <li>(M) One may be inoperative provided:</li> <li>a) The associated filter is<br/>changed within the first day<br/>and every 7 calendar-days,<br/>and</li> <li>b) The associated master chip<br/>detector is inspected when<br/>the filter is replaced and does<br/>not reveal the presence of<br/>magnetic chips.</li> </ul>                     |  |  |
|                |  |   |                               |          | (Continued)  |  |  |

|                                 | MENT OF TRANSPORTATI   |   |   |               |  |  |  |  |
|---------------------------------|--|---|---|---------------|--|--|--|--|
| FEDERAL AVIATION ADMINISTRATION |  |   |   |               | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
| <b>REVISION NO</b>              | . 31   |   |   | PAGE NO. 79-5 |  |  |  |  |
| DATE: 08/13/2                   | 024  |   |   |               |  |  |  |  |
|                                 |  |   | Т | ABL           | EKEY   |  |  |  |
| AIRCRAFT:                       |  |   |   |               | REPAIR CATEGORY  |  |  |  |
| Airbus A320                     |  |   |   |               | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH   |  |  |  |
|                                 |  |   |   |               | REMARKS OR EXCEPTIONS  |  |  |  |
| 79. Engine Oil                  |  |   |   |               |  |  |  |  |
| Sequence No.                    | Item   | 1 | 2 | 3             | 4 Change<br>Bar  |  |  |  |
| 79-35-02                        | OIL FILTER CLOG<br>Caution on ECAM EWD<br>(Cont'd)                                       |   |   |               |  |  |  |  |
| 4)                              | PW 1100G and<br>CFM LEAP-1A Engines<br>without Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С | 2 | 1             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and do not<br/>reveal presence of chips.</li> </ul>   |  |  |  |
|                                 |  | С | 2 | 1             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours,</li> <li>b) Associated Oil Debris<br/>Monitoring System is verified<br/>operative when filter is<br/>replaced, and</li> <li>c) Associated ENG 1(2) OIL<br/>CHIP DETECTED caution<br/>was not displayed on EWD<br/>during previous flight.</li> </ul> |  |  |  |
|                                 |  |   |   |               | (Continued)  |  |  |  |

| U.S. DEPARTI                 | MENT OF TRANSPORTATI   | ON |   |                               | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|------------------------------|--|----|---|-------------------------------|--|--|--|--|
| FEDERAL AVI                  | ATION ADMINISTRATION   |    |   | MASTER MINIMUM EQUIPMENT LIST |  |  |  |  |
| REVISION NO<br>DATE: 08/13/2 |  |    |   |                               | PAGE NO. 79-6  |  |  |  |
| AIRCRAFT:<br>Airbus A320     |  |    | Т | 1.<br>2.<br>3.                | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |
| 79. Engine Oil               |  |    |   |                               |  |  |  |  |
| Sequence No.                 | Item   | 1  | 2 | 3                             | 4 Change<br>Bar  |  |  |  |
| 79-35-02                     | OIL FILTER CLOG<br>Caution on ECAM EWD<br>(Cont'd)   |    |   |                               |  |  |  |  |
| 4)                           | PW 1100G and<br>CFM LEAP-1A Engines<br>without Mod. 162159/<br>MP P20466<br>(FWC H2-F10)<br>(Cont'd) |    |   |                               |  |  |  |  |
|                              |  | A  | 2 | 1                             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER DEGRAD caution<br/>was not displayed on EWD<br/>during previous flight, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected and<br/>do not reveal presence of<br/>chips, and</li> <li>c) Repairs are made within<br/>3 calendar-days or<br/>30 flight-hours, whichever<br/>occurs first.</li> </ul>  |  |  |  |
|                              |  | A  | 2 | 1                             | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated ENG 1(2) OIL</li> <li>FILTER DEGRAD caution</li> <li>was not displayed on EWD</li> <li>during previous flight,</li> </ul> </li> <li>b) Associated ENG 1(2) OIL</li> <li>CHIP DETECTED caution</li> <li>was not displayed on EWD</li> <li>during previous flight,</li> <li>c) Associated Oil Debris</li> <li>Monitoring System is verified</li> <li>operative, and</li> <li>d) Repairs are made within</li> <li>3 consecutive calendar-days</li> <li>or 30 flight-hours, whichever</li> <li>occurs first.</li> </ul> |  |  |  |
|                              |  |    |   |                               | (Continued)  |  |  |  |

| FEDERAL AVIATION ADMINISTRATION |   |   |   |               | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |
|---------------------------------|---|---|---|---------------|--|--|--|--|
| <b>REVISION NO</b>              | . 31  |   |   | PAGE NO. 79-7 |  |  |  |  |
| DATE: 08/13/2                   | 024   |   |   |               |  |  |  |  |
|                                 |   |   | Т |               | EKEY   |  |  |  |
| AIRCRAFT:                       |   |   |   |               | REPAIR CATEGORY  |  |  |  |
| Airbus A320                     |   |   |   |               |  |  |  |  |
|                                 |   |   |   |               | NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS   |  |  |  |
| 79. Engine Oil                  |   |   |   |               |  |  |  |  |
| Sequence No.                    | Item  | 1 | 2 | 3             | 4 Change<br>Bar  |  |  |  |
| 79-35-02                        | OIL FILTER CLOG<br>Caution on ECAM EWD<br>(Cont'd)                                    |   |   |               |  |  |  |  |
| 5)                              | PW 1100G and<br>CFM LEAP-1A Engines<br>with Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | С | 2 | 1             | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and do not<br/>reveal presence of chips.</li> </ul>   |  |  |  |
|                                 |   | С | 2 | 1             | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced before next flight and then every 150 flight-hours,</li> <li>b) Associated Oil Debris Monitoring System is verified operative when filter is replaced, and</li> <li>c) Associated ENG 1(2) OIL CHIP DETECTED caution was not displayed on EWD during previous flight.</li> </ul> </li> </ul> |  |  |  |
|                                 |   |   |   |               | (Continued)  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--|---|---|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2   |   |   |   |                | PAGE NO. 79-8  |
| AIRCRAFT:<br>Airbus A320   |   |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 79. Engine Oil   |   | r | r | r              | <b>*</b>   |
| Sequence No.   | ltem  | 1 | 2 | 3              | 4 Change<br>Bar  |
| 79-35-02   | OIL FILTER CLOG<br>Caution on ECAM EWD<br>(Cont'd)  |   |   |                |  |
| 5)   | PW 1100G and<br>CFM LEAP-1A Engines<br>with Mod. 162159/<br>MP P20466<br>(FWC H2-F10)<br>(Cont'd) | A | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER PARTLY CLOGGED<br/>caution was not displayed on<br/>EWD during previous flight,</li> <li>b) Associated magnetic chip<br/>detectors are inspected and<br/>do not reveal presence of<br/>chips, and</li> <li>c) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first.</li> </ul>  |
|  |   | A | 2 | 1              | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated ENG 1(2) OIL</li> <li>FILTER PARTLY CLOGGED</li> <li>caution was not displayed on</li> <li>EWD during previous flight,</li> </ul> </li> <li>b) Associated ENG 1(2) OIL</li> <li>CHIP DETECTED caution</li> <li>was not displayed on EWD</li> <li>during previous flight,</li> <li>c) Associated Oil Debris</li> <li>Monitoring System is verified</li> <li>operative, and</li> <li>d) Repairs are made within</li> <li>3 consecutive calendar-days</li> <li>or 30 flight-hours, whichever</li> <li>occurs first.</li> </ul> |

|   | IENT OF TRANSPORTATIO   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|---|---|----|---|----------------|--|
| REVISION NO. 31<br>DATE: 08/13/2024               |   |    |   |                | PAGE NO. 79-9  |
| AIRCRAFT:<br>Airbus A320<br><b>79. Engine Oil</b> |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| Sequence No.                                      | ltem  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 79-35-03  | OIL FILTER DEGRAD or<br>OIL FILTER PARTLY<br>CLOGGED Caution on<br>ECAM EWD |    |   |                | Bar  |
| 1)  | (PW 1100G and<br>CFM LEAP-1A Engines)                                       | A  | 2 | 1              | One may be inoperative for a<br>maximum of 3 calendar-days or<br>30 flight-hours, whichever occurs<br>first.   |
|   |   | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before the next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>the filter is replaced and<br/>do not reveal the presence of<br/>chips.</li> </ul>   |
|   |   | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before the next flight and then<br/>every 150 flight-hours,</li> <li>b) Associated Oil Debris<br/>Monitoring System is verified<br/>operative when the filter is<br/>replaced, and</li> <li>c) Associated ENG 1(2) OIL<br/>CHIP DETECTED was not<br/>displayed on the EWD during<br/>the previous flight.</li> </ul> |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |  |   |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|--|---|---|----------------|--|--|--|--|--|
| REVISION NO<br>DATE: 08/13/2   | -  |   |   |                | PAGE NO. 79-10   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |  |   | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 79. Engine Oil   |  |   | I |                |  |  |  |  |  |
| Sequence No.   | Item   | 1 | 2 | 3              | 4 Change<br>Bar  |  |  |  |  |
| 79-35-04   | OIL SENSOR FAULT<br>Caution on ECAM EWD                                  |   |   |                | Dat  |  |  |  |  |
| 1)   | CFM LEAP-1A Engines<br>without Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A | 2 | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER DEGRAD caution<br/>was not displayed during<br/>previous flight on EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first.</li> </ul>  |  |  |  |  |
|  |  | С | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and do not<br/>reveal presence of chips.</li> </ul>   |  |  |  |  |
|  |  | С | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours,</li> <li>b) Associated Oil Debris<br/>Monitoring System is verified<br/>operative when filter is<br/>replaced, and</li> <li>c) Associated ENG 1(2) OIL<br/>CHIP DETECTED caution<br/>was not displayed on EWD<br/>during previous flight.</li> </ul> |  |  |  |  |
|  |  |   |   |                | (Continued)  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|---|---|----|----------------|--|--|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024                                  |   |   |    |                | PAGE NO. 79-11   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 79. Engine Oil   |   |   |    |                |  |  |  |  |  |
| Sequence No.   | Item  | 1 | 2  | 3              | 4 Change<br>Bar  |  |  |  |  |
| 79-35-04   | OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)                   |   |    |                |  |  |  |  |  |
| 2)   | CFM LEAP-1A Engines<br>with Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A | 2  | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER PARTLY CLOGGED<br/>caution was not displayed<br/>during previous flight on<br/>EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first.</li> </ul>  |  |  |  |  |
|  |   | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and do not<br/>reveal presence of chips.</li> </ul>   |  |  |  |  |
|  |   | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced before next flight and then every 150 flight-hours,</li> <li>b) Associated Oil Debris Monitoring System is verified operative when filter is replaced, and</li> <li>c) Associated ENG 1(2) OIL CHIP DETECTED caution was not displayed on EWD during previous flight.</li> </ul> </li> </ul> |  |  |  |  |
|  |   |   |    |                | (Continued)  |  |  |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION<br>FEDERAL AVIATION ADMINISTRATION |   |   |    |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|--|---|---|----|----------------|--|--|--|--|--|
| <b>REVISION NO</b>   | . 31  |   |    | PAGE NO. 79-12 |  |  |  |  |  |
| DATE: 08/13/2  | 024   |   |    |                |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320   |   |   | T. | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |  |  |  |  |
| 79. Engine Oil   |   |   | n  |                |  |  |  |  |  |
| Sequence No.   | Item  | 1 | 2  | 3              | 4 Change<br>Bar  |  |  |  |  |
| 79-35-04   | OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)   |   |    |                |  |  |  |  |  |
| 3)   | PW 1100G without Mod.<br>167244/MP P21270<br>(FCS 6.0) and without<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A | 2  | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER DEGRAD caution<br/>was not displayed during<br/>previous flight on EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first</li> </ul>   |  |  |  |  |
|  |   | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and are<br/>confirmed to be within limits<br/>defined in AMM.</li> </ul>  |  |  |  |  |
|  |   | С | 2  | 1              | <ul> <li>(M) One may be inoperative provided: <ul> <li>a) Associated filter is replaced before next flight and then every 150 flight-hours,</li> <li>b) Associated Oil Debris Monitoring System is verified operative when filter is replaced, and</li> <li>c) Associated ENG 1(2) OIL CHIP DETECTED caution was not displayed on EWD during previous flight.</li> </ul> </li> </ul> |  |  |  |  |
|  |   |   |    |                | (Continued)  |  |  |  |  |

| -                            | MENT OF TRANSPORTATION  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|------------------------------|---|----|---|----------------|--|
| REVISION NO<br>DATE: 08/13/2 |   |    |   | PAGE NO. 79-13 |  |
| AIRCRAFT:<br>Airbus A320     |   |    | T | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 79. Engine Oil               |   | 1  |   | <b>_</b>       | Change   |
| Sequence No.<br>79-35-04     | Item<br>OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)   | 1  | 2 | 3              | 4 Change<br>Bar  |
| 4)                           | PW 1100G without<br>Mod. 167244/<br>MP P21270 (FCS 6.0)<br>and with Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A  | 2 | 1              | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER PARTLY CLOGGED<br/>caution was not displayed<br/>during previous flight on<br/>EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first.</li> </ul>  |
|                              |   | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and are<br/>confirmed to be within limits<br/>defined in AMM.</li> </ul>  |
|                              |   | С  | 2 | 1              | <ul> <li>(M) One may be inoperative provided:</li> <li>a) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours,</li> <li>b) Associated Oil Debris<br/>Monitoring System is verified<br/>operative when filter is<br/>replaced, and</li> <li>c) Associated ENG 1(2) OIL<br/>CHIP DETECTED caution<br/>was not displayed on EWD<br/>during previous flight.</li> </ul> |
|                              |   |    |   |                | (Continued)  |

| -                        | MENT OF TRANSPORTATI<br>ATION ADMINISTRATION   | ON |   |   | MASTER MINIMUM EQUIPMENT LIS   |  |  |  |  |
|--------------------------|--|----|---|---|--|--|--|--|--|
| REVISION NO. 31          |  |    |   |   | PAGE NO. 79-14   |  |  |  |  |
| DATE: 08/13/2            |  |    |   |   |  |  |  |  |  |
| AIRCRAFT:<br>Airbus A320 |  |    | Т | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |  |  |  |  |  |
| 79. Engine Oil           |  |    |   |   |  |  |  |  |  |
| Sequence No.             | Item   | 1  | 2 | 3   | 4 Chang<br>Bar   |  |  |  |  |
| 79-35-04                 | OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)  |    |   |   |  |  |  |  |  |
| 5)                       | PW 1100G with<br>Mod. 167244/<br>MP P21270 (FCS 6.0)<br>and without<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10) | A  | 2 | 1   | <ul> <li>One may be inoperative provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER DEGRAD caution<br/>was not displayed during the<br/>previous flight on EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first</li> </ul>   |  |  |  |  |
|                          |  | С  | 2 | 1   | <ul> <li>(M) One may be inoperative provided:</li> <li>a) It is verified before next flight<br/>that CFDS does not report<br/>any fault related to ODM or<br/>PHMU electrical failure,</li> <li>b) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>c) Associated magnetic chip<br/>detectors are inspected when<br/>filter is replaced and are<br/>confirmed to be within limits<br/>defined in AMM.</li> </ul> |  |  |  |  |
|                          |  | С  | 2 | 1   | <ul> <li>(M) One may be inoperative provided:</li> <li>a) It is verified before next flight<br/>that CFDS does not report<br/>any fault related to ODM or<br/>PHMU electrical failure,</li> <li>b) Associated filter is replaced<br/>before next flight and then<br/>every 150 flight-hours, and</li> <li>c) Associated ENG 1(2) OIL<br/>CHIP DETECTED caution<br/>was not displayed on EWD<br/>during previous flight.</li> </ul>                                     |  |  |  |  |
|                          |  |    |   |   | (Continued)  |  |  |  |  |

|                          | MENT OF TRANSPORTATI  | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |
|--------------------------|---|----|---|----------------|--|
| REVISION NO. 31          |   |    |   |                | PAGE NO. 79-15   |
| DATE: 08/13/2            |   |    |   |                |  |
| AIRCRAFT:<br>Airbus A320 |   |    | Т | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS  |
| 79. Engine Oil           |   |    |   |                |  |
| Sequence No.             | ltem  | 1  | 2 | 3              | 4 Change<br>Bar  |
| 79-35-04                 | OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)   |    |   |                |  |
| 5)                       | PW 1100G with<br>Mod.167244/<br>MP P21270 (FCS 6.0)<br>and without<br>Mod. 162159/<br>MP P20466<br>(FWC H2-F10)<br>(Cont'd) |    |   |                |  |
|                          |   | С  | 2 | 1              | <ul> <li>(M) One may be displayed provided:</li> <li>a) It is verified before next flight<br/>that CFDS does not report<br/>any fault related to oil filter<br/>delta pressure sensor, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected<br/>before next flight and then<br/>every 75 flight-hours and are<br/>confirmed to be within limits<br/>defined in AMM.</li> </ul> |
| 6)                       | PW 1100G with<br>Mod. 167244/<br>MP P21270 (FCS 6.0)<br>and with Mod. 162159<br>/MP P20466<br>(FWC H2-F10)                  | A  | 2 | 1              | <ul> <li>One may be displayed provided:</li> <li>a) Associated ENG 1(2) OIL<br/>FILTER PARTLY CLOGGED<br/>caution was not displayed<br/>during previous flight on<br/>EWD, and</li> <li>b) Repairs are made within<br/>3 consecutive calendar-days<br/>or 30 flight-hours, whichever<br/>occurs first.</li> </ul>  |
|                          |   |    |   |                | (Continued)  |

|   | IENT OF TRANSPORTATION   | ON |   |                | MASTER MINIMUM EQUIPMENT LIST  |  |  |  |  |
|---|--|----|---|----------------|--|--|--|--|--|
| REVISION NO. 31<br>DATE: 08/13/2024   |  |    |   |                | PAGE NO. 79-16   |  |  |  |  |
| AIRCRAFT:<br>Airbus A320<br><b>79. Engine Oil</b><br>Sequence No.<br>79-35-04 | Item<br>OIL SENSOR FAULT<br>Caution on ECAM EWD<br>(Cont'd)  | 1  | 2 | 1.<br>2.<br>3. | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS<br>4 Change<br>Bar   |  |  |  |  |
| 6)  | PW 1100G with Mod.<br>167244/MP P21270<br>(FCS 6.0) and with<br>Mod. 162159/MP P2046<br>6 (FWC H2-F10)<br>(Cont'd) | С  | 2 | 1              | <ul> <li>(M) One may be displayed provided: <ul> <li>a) It is verified before next flight that CFDS does not report any fault related to ODM or PHMU electrical failure,</li> <li>b) Associated filter is replaced before next flight and then every 150 flight-hours, and</li> <li>c) Associated magnetic chip detectors are inspected when filter is replaced and are confirmed to be within limits defined in AMM.</li> </ul> </li> </ul> |  |  |  |  |
|   |  | С  | 2 | 1              | <ul> <li>(M) One may be displayed provided: <ul> <li>a) It is verified before next flight that CFDS does not report any fault related to ODM or PHMU electrical failure,</li> <li>b) Associated filter is replaced before next flight and then every 150 flight-hours, and</li> <li>c) Associated ENG 1(2) OIL CHIP DETECTED caution was not displayed on EWD during previous flight.</li> </ul> </li> </ul>                                 |  |  |  |  |
|   |  | С  | 2 | 1              | <ul> <li>(M) One may be displayed provided:</li> <li>a) It is verified before next flight<br/>that CFDS does not report<br/>any fault related to oil filter<br/>delta pressure sensor, and</li> <li>b) Associated magnetic chip<br/>detectors are inspected<br/>before next flight and then<br/>every 75 flight-hours and are<br/>confirmed to be within limits<br/>defined in AMM.</li> </ul>   |  |  |  |  |

|                              | MENT OF TRANSPORTATION  |   | MASTER MINIMUM EQUIPME |     |   |  |  |  |
|------------------------------|---|---|------------------------|-----|---|--|--|--|
| REVISION NO<br>DATE: 08/13/2 |   |   |                        |     | PAGE NO. 79-1   |  |  |  |
|                              |   |   | Т                      | ABL | E KEY   |  |  |  |
| AIRCRAFT:                    |   |   |                        |     | REPAIR CATEGORY   |  |  |  |
| Airbus A320                  |   |   |                        |     | NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH  |  |  |  |
|                              |   |   |                        |     | REMARKS OR EXCEPTIONS   |  |  |  |
| 79. Engine Oil               |   |   |                        |     |   |  |  |  |
| Sequence No.                 | Item  | 1 | 2                      | 3   | 4 Chang<br>Bar  |  |  |  |
| 79-35-05                     | OIL CHIP DETECTED<br>Caution on ECAM EWD                        |   |                        |     |   |  |  |  |
| 1)                           | PW 1100G Engines<br>without Mod. 167244/<br>MP P21270 (FCS 6.0) | A | 2                      | 1   | One may be displayed on EWD for a<br>maximum of 5 flights or<br>10 flight-hours, whichever occurs<br>first.   |  |  |  |
|                              |   | A | 2                      | 1   | (M) One may be displayed on EWD<br>for a maximum of 3 calendar days or<br>30 flight-hours, whichever occurs<br>first, provided it is verified before next<br>flight and then once each flight-day,<br>that CFDS does not report any fault<br>related to oil debris overlimit<br>detection.  |  |  |  |
|                              |   | С | 2                      | 1   | <ul> <li>(M) One may be displayed on EWD provided: <ul> <li>a) It is verified before next flight and then once each flight-day, that CFDS does not report any fault related to oil debris overlimit detection, and</li> <li>b) Associated magnetic chip detectors are inspected before next flight and then every 75 flight-hours, and are confirmed to be within the limits defined in AMM.</li> </ul> </li> </ul> |  |  |  |
|                              |   |   |                        |     | (Continued)   |  |  |  |

|                          | IENT OF TRANSPORTATIO  |   |   | MASTER MINIMUM EQUIPMEN | T LIST  |               |
|--------------------------|--|---|---|-------------------------|---|---------------|
| REVISION NO.             | . 31   |   |   |                         | PAGE NO.  | 79-18         |
| DATE: 08/13/20           | 024  |   |   |                         |   |               |
| AIRCRAFT:<br>Airbus A320 |  |   |   |                         | E KEY<br>REPAIR CATEGORY<br>NO. INSTALLED<br>NO. REQUIRED FOR DISPATCH<br>REMARKS OR EXCEPTIONS             |               |
| 79. Engine Oil           |  |   | n |                         |   |               |
| Sequence No.             | Item   | 1 | 2 | 3                       | 4   | Change<br>Bar |
| 79-35-05                 | OIL CHIP DETECTED<br>Caution on ECAM EWD<br>(Cont'd)         |   |   |                         |   |               |
| 2)                       | PW 1100G Engines with<br>Mod. 167244/<br>MP P21270 (FCS 6.0) | A | 2 | 1                       | One may be displayed on EWD for a<br>maximum of 5 flights or<br>10 flight-hours, whichever occurs<br>first. |               |

|                              | MENT OF TRANSPORTAT   | ION |   | MASTER MINIMUM EQUIPMENT LIST   |   |  |  |
|------------------------------|---|-----|---|---|---|--|--|
| REVISION NO<br>DATE: 08/13/2 |   |     |   |   | PAGE NO. 80-1   |  |  |
| AIRCRAFT:<br>Airbus A320     |   |     | Т | <b>TABLE KEY</b> 1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |  |
| 80. Starting                 |   |     | - |   | -   |  |  |
| Sequence No.                 | Item  | 1   | 2 | 3   | 4 Change<br>Bar   |  |  |
| 80-11-01                     | Start Valve System  |     |   |   |   |  |  |
| 1)                           | Valves  |     |   |   |   |  |  |
| a)                           | CFM/IAE Engines   | С   | 2 | 1   | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Valve is manually closed after engine start, and</li> <li>b) Associated igniter system operates normally.</li> </ul>   |  |  |
| b)                           | PW 6000 Engines   | С   | 2 | 1   | <ul> <li>(M)(O) One may be inoperative provided: <ul> <li>a) Valve is manually closed after engine start,</li> <li>b) Associated igniter system operates normally, and</li> <li>c) Associated ENG 1(2) START VALVE FAULT START VALVE FAULT START VALVE NOT CLOSED caution is not displayed on ECAM EWD after engine start.</li> </ul> </li> </ul> |  |  |
| c)                           | PW 1100G Engines<br>without Mod. 167039/<br>MP P21513 (iCARE) | С   | 2 | 1   | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Required shutdown time is checked before starting affected engine, and</li> <li>b) Valve is manually closed after engine start.</li> </ul>   |  |  |
|                              |   |     |   |   | (Continued)   |  |  |

| U.S. DEPARTMENT OF TRANSPORTATION                 |   |   |   |   |   |  |
|---|---|---|---|---|---|--|
| FEDERAL AVIATION ADMINISTRATION                   |   |   |   | MASTER MINIMUM EQUIPMENT LIST   |   |  |
| REVISION NO. 31 PAGE NO. 80-2<br>DATE: 08/13/2024 |   |   |   |   |   |  |
| AIRCRAFT:<br>Airbus A320                          |   |   | T | TABLE KEY1. REPAIR CATEGORY2. NO. INSTALLED3. NO. REQUIRED FOR DISPATCH4. REMARKS OR EXCEPTIONS |   |  |
| 80. Starting                                      |   |   |   |   |   |  |
| Sequence No.                                      | ltem  | 1 | 2 | 3   | 4 Change<br>Bar   |  |
| 80-11-01  | Start Valve System<br>(Cont'd)  |   |   |   |   |  |
| 1)  | Valves<br>(Cont'd)  |   |   |   |   |  |
| d)  | PW 1100G Engines with<br>Mod. 167039/<br>MP P21513 (iCARE)  | С | 2 | 1   | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) Required shutdown time is checked before starting affected engine, and</li> <li>b) Valve is manually closed after engine start.</li> </ul>   |  |
|   |   | С | 2 | 1   | <ul> <li>(M)(O) One may be inoperative provided:</li> <li>a) APU bleed air supply system is operative,</li> <li>b) Start Valve Manual Override function is checked operative, and</li> <li>c) Valve is manually closed after engine start.</li> </ul> |  |
| 80-11-02  | ENG MAN START<br>Controls   | С | 2 | 0   | One or both may be inoperative.   |  |
| 80-11-03  | FAULT Light on ENGINE<br>MASTER Panel   | С | 2 | 0   | One or both may be inoperative.   |  |
| 80-11-04  | ECAM Start Valve<br>Position Indicators<br>(Lower Display)  | С | 2 | 0   | (M) May be inoperative provided start valve is verified closed after engine start.  |  |
| 80-11-05  | AUTOSTART Controls  | С | 2 | 0   | (O) May be inoperative provided manual start procedures are used.   |  |
| 80-11-06  | DUAL COOLING Control<br>(A319neo/A320neo/<br>A321neo with<br>PW 1100G Engines and<br>Mod. 161854/<br>MP P15967) | D | 1 | 0   | May be inoperative.   |  |