

### **Lost Link/Mission Procedures**

Loss of the RC link while flying in RC mode will automatically transfer control to the 900 MHz control link. This link can then be used to operate the aircraft via the GCS laptop or by using a manual controller.

Loss of the both the RC link and the 900 MHz control link results in the aircraft being operated normally using the Iridium SATCOM control link.

Loss of all links will cause the aircraft to return to and circle the home waypoint which is the takeoff/landing location.