

Lost Communications

The PIC and observers are co-located at the launch/land location.

If the handheld VHF is malfunctioning and unable to monitor Unicom/ATC, the PIC will land the aircraft immediately.