

APP CRS 332°	Rwy Idg TDZE Apt Elev	3530 571 578
------------------------	-----------------------------	---

RNAV (GPS) RWY 32
STINSON MUNI (SSF)

RNP APCH-GPS.		MISSED APPROACH: Climb to 1100 then climbing right turn to 2500 direct GANLE and hold.			
 	Rwy 32 helicopter visibility reduction below ¾ SM NA. Circling Rwy 10 NA at night.				
ATIS 128.8	SAN ANTONIO APP CON 125.7 290.225	STINSON TOWER ★ 118.2 (CTAF) 379.9	GND CON 121.7 379.9	CLNC DEL 121.7 (When twr closed)	UNICOM 122.95

PROTOTYPE-NOT FOR NAVIGATION

Procedure NA for arrivals at
BRAUN on V68 northeast bound.

