

LOC/DME I-RTT <b>108.55</b> Chan <b>22 (Y)</b>	APP CRS <b>211°</b>	Rwy Ldg TDZE Apt Elev	<b>5003</b> <b>470</b> <b>473</b>
--	------------------------	-----------------------------	---

# LOC RWY 21

FLORA MUNI (F<sub>0</sub>A)

DME required. RADAR required for procedure entry at LASDE.		MISSED APPROACH: Climb to 1200 then climbing right turn to 2300 direct BIB VORTAC and hold.
<p>▼ Rwy 21 helicopter visibility reduction below ¾ SM NA. Circling NA to Rwy 15 and 33. VDP NA when using OLY altimeter setting. When local altimeter setting not recieved, use OLY altimeter setting and increase all MDAs 40 feet and Circling visibility Cat C ¼ SM.</p> <p>▲ NA</p>	AWOS-3 <b>120.175</b>	KANSAS CITY CENTER <b>127.7 351.825</b>
		UNICOM <b>122.7 (CTAF) 0</b>

