



PROTOTYPE-
NOT FOR NAVIGATION

SOCAL DEP CON
124.6 298.85
D-ATIS
134.5
CLNC DEL
118.0 348.6
CPDLC

VAN NUYS
113.1 VNY
Chan 78

EDWARDS
116.4 EDW
Chan 111

PALMDALE
115.55 PMD
Chan 102(Y)

LAKE HUGHES
114.35 LHS
Chan 90(Y)

GORMAN
116.1 GMN
Chan 108

FILLMORE
112.5 FIM
Chan 72

AVENAL
117.1 AVE
Chan 118

VENTURA
116.55 VTU
Chan 112(Y)

LOS ANGELES
113.6 LAX
Chan 83

DAGGETT
113.2 DAG
Chan 79

R-2515

ETHER

BOGET

SLAPP

LANGE

LAX

CASTA
8300

TWINE

IPIHO

COREZ

326°T
9800
*10100

9000
*6400
058°
(61)

6000
*6300
046°
(9)

6000
*5300
046°
(9)

5000
255°
(270°T)

5000
255°
(270°T)

5000
255°
(270°T)

5000
255°
(270°T)

310°
(35)

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100

326°T
9800
*10100



DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 8: Climbing right turn heading 213°

TAKEOFF RUNWAY 15: Climbing right turn heading 213°

TAKEOFF RUNWAY 26: Climbing right turn heading 293°

TAKEOFF RUNWAY 33: Climbing left turn heading 273°

. . . .For RADAR vector to VNY VOR/DME, then on transition or assigned route.

Maintain ATC assigned altitude.

AVENAL TRANSITION (VNY4.AVE): From over VNY VOR/DME on VNY R-255 and LAX R-323 to TWINE, then on LAX R-323 and GMN R-142 to GMN VORTAC, then on GMN R-310 and AVE R-086 to AVE VOR/DME.

DAGGETT TRANSITION (VNY4.DAG): From over VNY VOR/DME on VNY R-255 and LAX R-323 to TWINE, then on VTU R-046 and PMD R-218 to PMD VORTAC, then on PMD R-067 and DAG R-238 to DAG VORTAC.

FILLMORE TRANSITION (VNY4.FIM): From over VNY VOR/DME on VNY R-255 to SUANA, then on FIM R-120 to FIM VORTAC.

GORMAN TRANSITION (VNY4.GMN): From over VNY VOR/DME on VNY R-255 and LAX R-323 to TWINE, then on LAX R-323 and GMN R-142 to GMN VORTAC.

PALMDALE TRANSITION (VNY4.PMD): From over VNY VOR/DME on VNY R-255 and LAX R-323 to TWINE, then on VTU R-046 and PMD R-218 to PMD VORTAC.

TWINE TRANSITION (VNY4.TWINE): From over VNY VOR/DME on VNY R-255 and LAX R-323 to TWINE.

PROTOTYPE-NOT FOR NAVIGATION