

VOR/DME SHB 112.0 Chan 57	APP CRS 142°	Rwy Idg TDZE Apt Elev N/A N/A 912
---	------------------------	---

VOR-A
GREENSBURG MUNI (I34)

▲ Use Columbus Muni altimeter setting; if not received, use Indianapolis Intl altimeter setting and increase all MDA's 40 feet.
▲ NA MISSED APPROACH: Climb to 2000 then climbing right turn to 2700 via SHB R-142 to APODD INT/SHB 18 DME/RADAR and hold.

BAK AWOS-3 119.75	INDIANAPOLIS APP CON 127.15	CTAF 122.90
-----------------------------	---------------------------------------	-----------------------

▲ 1542

ADF, DME or RADAR REQUIRED

IAF
SHELBYVILLE
112.0 SHB
Chan 57

Procedure NA for arrival on SHB VOR/DME airway radials 124 CW 171.

