

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON  
 125.1 307.0  
 BAZ ATIS  
 119.325  
 KRND ATIS\*  
 290.525  
 KSKF ATIS  
 120.45 273.5  
 SAT D-ATIS  
 118.9  
 SSF ATIS  
 128.8

NOTE: Jet and turboprop aircraft only.

PRTZY

9000  
 \*3700  
 154°  
 (176)

MUGSY

9000  
 \*3700  
 154°  
 (271)

11 NM

PPNUT  
FL220

DILLO  
FL220

9000  
 \*3700  
 172°  
 (411)

10 NM

293°  
 113°

TRVLL

9000  
 \*3700  
 113°  
 (63)

POPPO  
10000

See following page for arrival routes

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS