

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON  
 125.1 307.0  
 BAZ ATIS  
 119.325  
 KRND ATIS\*  
 290.525  
 KSKF ATIS  
 120.45 273.5  
 SAT D-ATIS  
 118.9  
 SSF ATIS  
 128.8

NOTE: Jet and turboprop aircraft only.

PRTZY

15.41°  
17.6  
9000  
\*3700

MUGSY

9000  
\*3700  
15.4  
127.1

11 NM

PPNUT  
FL220

DILLO  
FL220

9000  
\*3700  
17.2  
(41)

10 NM

293°  
113°

TRVLL

9000  
\*3700  
11.3  
(6.3)

POPPO  
10000

See following page  
for arrival routes

DILLO TRANSITION (DILLO.POPPO1)

PPNUT TRANSITION (PPNUT.POPPO1)

PRTZY TRANSITION (PRTZY.POPPO1)

TRVLL TRANSITION (TRVLL.POPPO1)

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

# POPPO ONE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS