

VOR/DME or TACAN RWY 26
WENDOVER (ENV)

MISSED APPROACH: Climbing left turn to 9000 direct BVL VORTAC and on BVL VORTAC R-072 to BAGGI/10 DME and hold, continue climb-in-hold to 9000.

UNICOM
122.8 (CTAF) 



VOR/DME or TACAN RWY 26