




DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 3: Climb heading 030° and ITO R-355 to SAPDE INT, thence. . . .

TAKEOFF RUNWAY 8: Climb heading 079° to ITO VORTAC and ITO R-355 to SAPDE INT, thence. . . .

TAKEOFF RUNWAY 21: Climbing left turn direct ITO VORTAC and ITO R-355 to SAPDE INT, or climb in visual conditions to cross ITO VORTAC northbound at or above 1200 MSL, then via R-355 to SAPDE INT, thence. . . .

TAKEOFF RUNWAY 26: Climbing right turn via heading 045° and ITO R-355 to SAPDE INT, or climb in visual conditions to cross ITO VORTAC northbound at or above 1200 MSL, then via R-355 to SAPDE INT, thence. . . .

. . . . proceed via UPP R-082 to PARIS INT.