

VORTAC SZW
117.5
Chan **122**

APP CRS
353°

Rwy Idg
TDZE
Apt Elev
7000
62
83

VOR or TACAN RWY 36
TALLAHASSEE INTL (TLH)

DME required.

T

For inop ALS, increase VOR Cat E visibility to RVR 6000.
For inop ALS, increase TACAN Cat E visibility to RVR 6000.

ASR

MALSR

AS

MISSED APPROACH: Climb to 4000 direct SZW VORTAC and on SZW VORTAC R-288 to QUILL/SZW 11.8 DME and hold, continue climb-in-hold to 4000.

ATIS	TALLAHASSEE APP CON*	TALLAHASSEE TOWER*	GND CON	CLNC DEL	UNICOM
119.45 239.25	135.8 317.4	118.7(CTAF) 257.8	121.9 348.6	126.65 275.8	123.075

