

VOR/DME VCT	APP CRS	Rwy Idg	9111
109.0	127°	TDZE	115
Chan 27		Apt Elev	115

VOR RWY 13
VICTORIA RGNL (VCT)

For inop ALS, increase Cat C/D/E visibility to 1 3⁄8 SM.		MALSR	MISSED APPROACH: Climbing left turn to 2200 direct VCT VOR/DME and hold, continue climb-in-hold to 2200.	
ATIS	HOUSTON CENTER	VICTORIA TOWER ★	GND CON	UNICOM
119.025	135.05 353.6	126.075 (CTAF) 0 257.95	120.525 239.25	122.7

