

VOR RWY 17L
WILEY POST (PWA)

MISSED APPROACH: Climb to 1700 then climbing left turn to 3000 direct IRW VORTAC and hold.



Procedure NA for arrival on IRW
VORTAC airway radials 292 CW 045.

