

VORTAC SNS 117.3 Chan 120	APP CRS 314°	Rwy Idg TDZE Apt Elev N/A N/A 163
---	------------------------	---

VOR-A

WATSONVILLE MUNI (WVI)

⚠ ⚠ Circling NA west of Rwy 2-20. When local altimeter setting not received, use Monterey altimeter setting and increase all MDAs 80 feet. DME required. Circling Rwy 27 NA at night.	MISSED APPROACH: Climbing left turn to 5000 direct SNS VORTAC and hold, continue climb-in-hold to 5000.
--	---

ASOS 132.275	NORCAL APP CON 127.15 307.125	UNICOM 122.8 (CTAF) 0
------------------------	---	--

