

APP CRS	Rwy Idg	3244
004°	TDZE	125
	Apt Elev	125

RNAV (GPS) RWY 36

WATTS-WOODLAND (O41)

▼ NA DME/DME RNP- 0.3 NA. Procedure NA at night. Use Sacramento Intl altimeter setting; when not received, use Sacramento Exec altimeter setting and increase all MDA 20 feet. MISSED APPROACH: Climbing left turn to 3000 direct CEVIT and hold.

TRAVIS APP CON 126.6 281.45	UNICOM 122.8 (CTAF) 0
--------------------------------	--------------------------

