

VORTAC BRO

116.3

Chan 110

APP CRS

311°

Rwy Ldg

7257

TDZE

36

Apt Elev

36

VOR Y or TACAN RWY 31

VALLEY INTL (HRL)

DME required.

When local altimeter setting not received, use Port Isabel altimeter setting and increase all MDAs 60 feet.

MALSR

MISSED APPROACH: Climbing right turn to 2000 on BRO R-311 to ZOCKE/12 DME and hold.

|                |                               |                                         |                  |                  |
|----------------|-------------------------------|-----------------------------------------|------------------|------------------|
| ATIS<br>124.85 | VALLEY APP CON<br>120.7 279.5 | HARLINGEN TOWER ★<br>119.3 (CTAF) 317.6 | GND CON<br>121.7 | UNICOM<br>122.95 |
|----------------|-------------------------------|-----------------------------------------|------------------|------------------|

