

ILS RWY 26R (CAT II & III)
ONTARIO INTL (ONT)

MISSED APPROACH: Climb to 2800 then climbing left turn to 5400 direct PDZ VORTAC and hold, continue climb-in-hold to 5400.

Procedure NA for arrival on PDZ VORTAC
airway radials 012 CW 078.

2800 5400 PDZ

VGS1 and ILS glidepath not coincident
(VGS1 Angle 3.00/TCH 75).

ZEBLU INT
I-ONT 10.6

EDDSO INT
I-ONT 8.5

3000 258° 3400

3000

GS 3.00°
TCH 60

1163 6.3 NM 2.1 NM

CATEGORY	A	B	C	D
S-ILS 26R	CAT II RA 100/12 100 DA 1032			
S-ILS 26R	CAT III RVR 03			

CATEGORY II & III ILS - SPECIAL AIRCREW & AIRCRAFT CERTIFICATION REQUIRED