

VORTAC SZW  
**117.5**  
Chan **122**

APP CRS  
**353°**

Rwy Idg  
TDZE  
Apt Elev  
**7000**  
**62**  
**83**

VOR or TACAN RWY 36  
TALLAHASSEE INTL (TLH)

DME required.

T

For inop ALS, increase VOR Cat E visibility to RVR 6000.  
For inop ALS, increase TACAN Cat E visibility to RVR 6000.

ASR

MALSR

AS

MISSED APPROACH: Climb to 4000 direct SZW VORTAC and on SZW VORTAC R-288 to QUILL/SZW 11.8 DME and hold, continue climb-in-hold to 4000.

|               |                      |                    |             |              |         |
|---------------|----------------------|--------------------|-------------|--------------|---------|
| ATIS          | TALLAHASSEE APP CON* | TALLAHASSEE TOWER* | GND CON     | CLNC DEL     | UNICOM  |
| 119.45 239.25 | 135.8 317.4          | 118.7(CTAF) 257.8  | 121.9 348.6 | 126.65 275.8 | 123.075 |

