

LOC I-SBN	APP CRS	Rwy Ldg
109.3	274°	8412
		TDZE 774
		Apt Elev 798

ILS or LOC RWY 27L

SOUTH BEND INTL (SBN)

ADF and RADAR required.		MALSR AS	MISSED APPROACH: Climb to 1500 then climbing right turn to 3000 direct MISHA LOM/RADAR and hold, continue climb-in-hold to 3000.	
Circling Rwy 27R NA at night. * RVR 1800 authorized with use of FD or AP or HUD to DA.				
ATIS 120.675	SOUTH BEND APP CON★ 118.55 257.8	SOUTH BEND TOWER★ 135.675 (CTAF) 0 257.8		GND CON 121.7
				CLNC DEL 121.9

