

VOR RWY 1
JACKSON HOLE (JAC)

MISSED APPROACH: Climb to 14000 direct JAC VOR/DME and on JAC R-017 to NALSI INT/JAC 16.5 DME and right turn on DNW R-267 to DNW VOR/DME and hold, continue climb-in-hold to 14000.



A diagram of a cable-stayed bridge. A cable is shown with a slope of 0.5% Up and an angle of 008°. A point on the cable is labeled 'P' and another point is labeled 'A'. A tower is labeled 'TWR' with a star symbol. The cable is labeled '6300 X 130'.