

|                                                 |                        |                                                 |              |
|-------------------------------------------------|------------------------|-------------------------------------------------|--------------|
| LOC/DME I-PVO<br><b>109.1</b><br>Chan <b>28</b> | APP CRS<br><b>128°</b> | Rwy Ldg<br>TDZE <b>75</b><br>Apt Elev <b>75</b> | <b>10001</b> |
|-------------------------------------------------|------------------------|-------------------------------------------------|--------------|

COPTER ILS or LOC/DME RWY 13  
ATLANTIC CITY INTL (ACY)

|                       |       |                                                                                                                     |
|-----------------------|-------|---------------------------------------------------------------------------------------------------------------------|
| RADAR required.<br>NA | MALSR | MISSED APPROACH: Climb to 600 then climbing left turn to 2000 on ACY VORTAC R-090 to SMITS INT/ACY 11 DME and hold. |
|-----------------------|-------|---------------------------------------------------------------------------------------------------------------------|

|                               |                                               |                                           |                               |                                   |
|-------------------------------|-----------------------------------------------|-------------------------------------------|-------------------------------|-----------------------------------|
| ATIS<br><b>125.725 316.15</b> | ATLANTIC CITY APP CON<br><b>124.6 327.125</b> | ATLANTIC CITY TOWER<br><b>120.3 239.0</b> | GND CON<br><b>121.9 284.6</b> | CLNC DEL<br><b>127.85 353.775</b> |
|-------------------------------|-----------------------------------------------|-------------------------------------------|-------------------------------|-----------------------------------|

