

VORTAC BRO 116.3 Chan 110	APP CRS 311°	Rwy Ldg 7257 TDZE 36 Apt Elev 36
---	------------------------	---

VOR Y or TACAN RWY 31
VALLEY INTL (HRL)

DME required.

T When local altimeter setting not received, use Port Isabel
A altimeter setting and increase all MDAs 60 feet.



MISSED APPROACH: Climbing right turn to 2000 on BRO R-311 to ZOCCKE/12 DME and hold.

ATIS 124.85	VALLEY APP CON 120.7 279.5	HARLINGEN TOWER ★ 119.3 (CTAF) 0 317.6	GND CON 121.7	UNICOM 122.95
-----------------------	--------------------------------------	--	-------------------------	-------------------------