


ILS Z or LOC Z RWY 19  
RUTLAND/SOUTHERN VERMONT RGNL (RUT)

MALCD



**MISSED APPROACH:** Climb to 1900 then climbing right turn to 5700 on heading 360° and CAM VOR/DME R-033 to KOPVE/I-RUT 16.31 DME and hold. If unable to meet climb gradient, see ILS Y or LOC Y Rwy 19. # Missed approach requires minimum climb of 425 feet per NM to 3200.

UNICOM  
122.8 (CTAF) **L**

One Minute Holding Pattern

KOPVE  
I-RUT 16.3

UWAGU  
I-RUT 13.1

CEKRA  
I-RUT 10

YUKUT  
I-RUT 7.4

SEYOB  
I-RUT 4.3

\*LOC only

7000 ← 014°  
5700 194° →

4800

3900

\*3040

\*1980

2900

GS 3.20°  
TCH 54

3.2 NM 3.2 NM 2.5 NM 3.1 NM 2 NM

| CATEGORY   | A                         | B                         | C                       | D                       |
|------------|---------------------------|---------------------------|-------------------------|-------------------------|
| S-ILS 19 # | 1451-1½ 664 (700-1½)      |                           |                         |                         |
| S-LOC 19 # | 1520-½                    | 733 (800-½)               | 1520-1½                 | 733 (800-1½)            |
| CIRCLING   | 2160-1¼<br>1373 (1400-1¼) | 2160-1½<br>1373 (1400-1½) | 2520-3<br>1733 (1800-3) | 2760-3<br>1973 (2000-3) |

