


ILS or LOC RWY 7
FRANCISCO C ADA/SAIPAN INTL (GSN)(PGSN)

MISSED APPROACH: Climb to 1600 then climbing right turn to 2800 direct SN NDB and hold.

GND CON
121.8



DME REQUIRED

