

|         |          |      |
|---------|----------|------|
| APP CRS | Rwy Ldg  | 3219 |
| 184°    | TDZE     | 19   |
|         | Apt Elev | 21   |

RNAV (GPS) RWY 18

TAMPA EXEC (VDF')

|                                                                                                                                                                                                                                                                       |                              |                                                                                       |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------|---------------------------------------------------------------------------------------|
| RNP APCH. <div><div>▼</div><div>▲</div>When local altimeter not received, use Tampa Intl altimeter setting and increase all MDA 40 feet. Straight-in Rwy 18 NA at night, Circling Rwy 18, 36 NA at night. Rwy 18 helicopter visibility reduction below 1 SM NA.</div> |                              | MISSED APPROACH: Climb to 3000 direct COLUD and hold, continue climb-in-hold to 3000. |
| AWOS-3<br>121.125                                                                                                                                                                                                                                                     | TAMPA APP CON<br>119.9 290.3 | UNICOM<br>122.7 (CTAF) 0                                                              |

