

LOC I-SBN 109.3	APP CRS 274°	Rwy Ldg TDZE 774 Apt Elev 798	ILS RWY 27L (SA CAT I & II) SOUTH BEND INTL (SBN)
---------------------------	------------------------	---	---

ADF and RADAR required.	MALSR 	MISSED APPROACH: Climb to 1500 then climbing right turn to 3000 direct MISHA LOM/RADAR and hold, continue climb-in-hold to 3000.
 Procedure NA when tower closed. Requires specific OPSPEC, MSPEC, or LOA approval.		

ATIS 120.675	SOUTH BEND APP CON ★ 118.55 257.8	SOUTH BEND TOWER ★ 135.675 (CTAF) 257.8	GND CON 121.7	CLNC DEL 121.9
------------------------	---	---	-------------------------	--------------------------

