

VOR/DME VCT	APP CRS	Rwy Ldg	9111
109.0	307°	TDZE	106
Chan 27		Apt Elev	115

VOR RWY 31
VICTORIA RGNL (VCT)

DME required.



MISSED APPROACH: Climb to 2000 direct VCT VOR/DME and hold.

ATIS 119.025	HOUSTON CENTER 135.05 353.6	VICTORIA TOWER ★ 126.075 (CTAF) 257.95	GND CON 120.525 239.25	UNICOM 122.7
-----------------	--------------------------------	---	---------------------------	-----------------

