

|                                                                                                                              |                                                                                                   |
|------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| <div><div>▼</div><div>NA</div></div> <div>DME required. Procedure NA at night.<br/>Use Fayetteville altimeter setting.</div> | MISSED APPROACH: Climbing left turn to 3000 on<br>FAY VOR/DME R-271 to RAEFO/FAY 25 DME and hold. |
| FAYETTEVILLE APP CON<br>127.8 290.25                                                                                         | UNICOM<br>123.0 (CTAF)                                                                            |

