

VOR RWY 10R
OAKLAND SAN FRANCISCO BAY (OAK)

MISSED APPROACH: Climb to 5300 on OAK VOR/DME R-093 to HAYZE INT/OAK 9 DME and hold, continue climb-in-hold to 5300.

Procedure NA for arrivals at MICRA on V107-301 westbound.

(IAF) MICRA 4000 108° (8.6)

(IF) COMMO OAK 15.6 108° (4.6)

DATTS INT OAK 11 1800

ENCLOS INT OAK 6 1800

YEGGU OAK 0.8

OAKLAND 116.8 OAK 115 Chan 115

SAN FRANCISCO 115.8 SFO 105 Chan 105

MSA OAK 25 NM

3800 5100

170° 350°

ELEV 9 TDZE 9

108°

337.6 23

OAKLAND, CALIFORNIA
Amdt 10A 15SEP16

37°43'N-122°13'W

OAKLAND SAN FRANCISCO BAY (OAK)
VOR RWY 10R