

TEEKY THREE ARRIVAL (RNAV) Transition Routes FORT LAUDERDALE, FLORIDA

MIAMI APP CON
133.775 371.9
FLL D-ATIS
135.0
FXE ATIS
119.85
PMP ATIS
120.55

NOTE: Jet aircraft only.
NOTE: Do not file PCOCK, FEDRR,
or CLEOO Transitions - to be
assigned by ATC.
NOTE: SABEE Transition for TPA
area airports only.

ACORI TRANSITION (ACORI.TEEKY3)
CLEOO TRANSITION (CLEOO.TEEKY3)
DEFUN TRANSITION (DEFUN.TEEKY3)
ENEME TRANSITION (ENEME.TEEKY3)
FEDRR TRANSITION (FEDRR.TEEKY3)
MARCI TRANSITION (MARCI.TEEKY3)
PCOCK TRANSITION (PCOCK.TEEKY3)
SABEE TRANSITION (SABEE.TEEKY3)
VNECK TRANSITION (VNECK.TEEKY3)
ZPLEN TRANSITION (ZPLEN.TEEKY3)

NOTE: Expect "descend via" clearance and landing direction (east or west) by ARTCC. For vertical navigation planning, landing east, select Rwy 10R, landing west, select Rwy 28R.

(NARRATIVE ON FOLLOWING PAGE)
(CONTINUED ON FOLLOWING PAGE)

See following
page for
arrival routes.

NOTE: Chart not to scale.