

VOR RWY 14
MOBILE INTL (BFM)

MISSED APPROACH: Climb to 440 then climbing right turn to 2000 on BFM VORTAC R-242 to SAINT INT/ BFM 9.2 DME and hold, continue climb-in-hold to 2000.

UNICOM
122 95