

BAF VORTAC 113.0 Chan 77	APP CRS 208°	Rwy Ldg 8919 TDZE 270 Apt Elev 270
--	------------------------	---

VOR RWY 20
WESTFIELD-BARNES RGNL (BAF)

For inoperative MALSR, increase Cat A/B visibility to RVR 5000. Night landing: Rwy 15 NA.

MALSR

MISSED APPROACH: Climb to 1200, then climbing right turn to 4000 direct CTR VOR/DME and hold, continue climb in hold to 4000.

ATIS 127.1 263.15	BRADLEY APP CON 125.35 281.5	WESTFIELD TOWER ★ 125.075 (CTAF) 0 251.1	GND CON 121.7 289.4
----------------------	---------------------------------	---	------------------------

