

DEPARTURE ROUTE DESCRIPTION  
(CONTINUED)HOBOZ TRANSITION (NQI4.HOBOZ):

Rwys 13L/R and 35L/R: ...turn left to intercept NQI 7 DME arc and arc NW. Turn right to intercept NQI R-339 to HOBOZ.

Rwys 17L/R and 31L/R: ...turn right to intercept NQI 7 DME arc and arc NW. Turn left to intercept NQI R-339 to HOBOZ.

JUBAK TRANSITION (NQI4.JUBAK): \*

Rwys 13L/R and 17L/R: ...turn left to intercept NQI 7 DME arc and arc SE. Turn right to intercept NQI R-125 to JUBAK.

Rwys 31L/R and 35L/R: ...turn right to intercept NQI 7 DME arc and arc SE. Turn left to intercept NQI R-125 to JUBAK.

RICTO TRANSITION (NQI4.RICTO): \*

Rwy 13L/R and 17L/R: ...turn right to intercept NQI 7 DME arc and arc SW. Turn left to intercept NQI R-225 to RICTO.

Rwy 31L/R and 35L/R: ...turn left to intercept NQI 7 DME arc and arc SW. Turn right to intercept NQI R-225 to RICTO.

\* RICTO and JUBAK transitions are for local use for Special Use Airspace entry only.

LOST COMMUNICATIONS: If no transmissions are received one minute after departure, climb to assigned altitude, proceed direct assigned NAVAID or intercept NQI TACAN 7 DME arc, arc to respective departure radial then via departure radial to assigned departure fix. Then via assigned transition or route. Once established on departure radial climb to filed altitude.