

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON
 125.1 307.0
 BAZ ATIS
 119.325
 KRND ATIS ★
 290.525
 SAT D-ATIS
 118.9
 SKF ATIS
 120.45 273.5
 SSF ATIS
 128.8

PRTZY

NOTE: Jet and turboprop aircraft only.

9000
 *3800
 1514°
 (17.6)

MUGSY

DILLO TRANSITION (DILLO.POPPO2)
PPNUT TRANSITION (PPNUT.POPPO2)
PRTZY TRANSITION (PRTZY.POPPO2)
TRVLL TRANSITION (TRVLL.POPPO2)

9000
 *3700
 1514°
 (12.1)

11 NM

PPNUT
FL220

DILLO
FL220

9000
 *3700
 1514°
 (3.1)

9000
 *3700
 1772°
 (4.1)

10 NM

TRVLL

293°
 113°

9000
 *3700
 113°
 (6.3)

POPPO
10000

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

See following page for arrival routes.

SC-3, 19 FEB 2026 to 19 MAR 2026

SC-3, 19 FEB 2026 to 19 MAR 2026

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS