

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

- SAN ANTONIO APP CON 125.1 307.0
- BAZ ATIS 119.325
- KRND ATIS ★ 290.525
- SAT D-ATIS 118.9
- SKF ATIS 120.45 273.5
- SSF ATIS 128.8

PRTZY

NOTE: Jet and turboprop aircraft only.

9000
*3800
154°
(176)

MUGSY

9000
*3700
154°
(127)

DILLO TRANSITION (DILLO.POPPO2)
PPNUT TRANSITION (PPNUT.POPPO2)
PRTZY TRANSITION (PRTZY.POPPO2)
TRVLL TRANSITION (TRVLL.POPPO2)

11 NM
332°

PPNUT
FL220

DILLO
FL220

9000
*3700
154°
(151)

9000
*3700
172°
(41)

10 NM
293°
113°

TRVLL

9000
*3700
113°
(63)

POPPO
10000

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

See following page for arrival routes.

SC-3, 19 MAR 2026 to 16 APR 2026

SC-3, 19 MAR 2026 to 16 APR 2026

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS