

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON
 125.1 307.0
 BAZ ATIS
 119.325
 KRND ATIS ★
 290.525
 SAT D-ATIS
 118.9
 SKF ATIS
 120.45 273.5
 SSF ATIS
 128.8

PRTZY

NOTE: Jet and turboprop aircraft only.

9000
 *3800
 154°
 (176)

MUGSY

DILLO TRANSITION (DILLO.POPPO2)
PPNUT TRANSITION (PPNUT.POPPO2)
PRTZY TRANSITION (PRTZY.POPPO2)
TRVLL TRANSITION (TRVLL.POPPO2)

9000
 *3700
 154°
 (121)

11 NM
 334°
 PPNUT
 FL220

DILLO
 FL220

9000
 *3700
 154°
 (151)

9000
 *3700
 172°
 (41)

10 NM
 293°
 113°

TRVLL

9000
 *3700
 113°
 (63)

POPPO
 10000

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

See following page for arrival routes.

SC-3, 16 APR 2026 to 14 MAY 2026

SC-3, 16 APR 2026 to 14 MAY 2026

POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS