

# POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

RNAV 1 - DME/DME/IRU or GPS.

RADAR required.

SAN ANTONIO APP CON  
 125.1 307.0  
 BAZ ATIS  
 119.325  
 KRND ATIS ★  
 290.525  
 SAT D-ATIS  
 118.9  
 SKF ATIS  
 120.45 273.5  
 SSF ATIS  
 128.8

PRTZY

NOTE: Jet and turboprop aircraft only.

9000  
 \*3800  
 1514°  
 (176)

MUGSY

DILLO TRANSITION (DILLO.POPPO2)  
PPNUT TRANSITION (PPNUT.POPPO2)  
PRTZY TRANSITION (PRTZY.POPPO2)  
TRVLL TRANSITION (TRVLL.POPPO2)

9000  
 \*3700  
 1514°  
 (127)

11 NM  
 332°

PPNUT FL220

DILLO FL220

9000  
 \*3700  
 1514°  
 (111)

9000  
 \*3700  
 1772°  
 (41)

10 NM

293°  
 113°

TRVLL

9000  
 \*3700  
 113°  
 (63)

POPPO 10000

NOTE: Chart not to scale. (CONTINUED ON FOLLOWING PAGE)

See following page for arrival routes.

SC-3, 14 MAY 2026 to 11 JUN 2026

SC-3, 14 MAY 2026 to 11 JUN 2026

# POPPO TWO ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS