

WAAS
CH **61328**
W13A

APP CRS
134°

Rwy Idg
TDZE
Apt Elev

4001
616
616

RNAV (GPS) RWY 13
TRI-TOWNSHIP (SFY)

⚠

When local altimeter setting not received, use Sterling/Rockfalls altimeter setting and increase all MDA 80 feet. Procedure NA at night. DME/DME RNP-0.3 NA. Helicopter visibility reduction below 1 SM NA.

⚠

MISSED APPROACH: Climb to 1020 then climbing right turn to 3000 direct CONAT and hold.

AWOS-3PT 118.650	QUAD CITY APP CON★ 125.95 257.8	UNICOM 122.7 (CTAF) 0
----------------------------	---	---------------------------------

The chart displays the RNAV (GPS) RWY 13 approach for Savanna, Illinois. The approach path starts at a 3000-foot altitude, turns right to 134 degrees, and then left to 314 degrees. Key navigational aids include the (IAF) NORPY, (IAF) TROST, (IF/IAF) CONAT, (FAF) ACEMI, and ZITSA. The final approach segment is 2.5 NM to RWY 13. The chart also shows the holding pattern at 3000 feet, the missed approach procedure, and the MSA (Minimum Safe Altitude) for RWY 13. The chart is labeled with various altitudes, distances, and bearings.

4 NM Holding Pattern

Visual Segment - Obstacles.

1020 3000 CONAT

3000 ← 314° 134° → 134°

ACEMI

ZITSA 2.5 NM to RWY 13

2400 1440 RWY 13

5 NM 3 NM 2.5 NM

CATEGORY	A	B	C	D
LP MDA	940-1	324 (400-1)	NA	
LNAV MDA	960-1	344 (400-1)	NA	
CIRCLING	1160-1 544 (600-1)	1220-1 604 (700-1)	NA	

ELEV 616 TDZE 616

134° 31°

4001 X 75

MIRL Rwy 13-31 0

SAVANNA, ILLINOIS

Orig-D 30DEC21

42°03'N-90°06'W

TRI-TOWNSHIP (SFY)

RNAV (GPS) RWY 13