

▼	DEPARTURE ROUTE DESCRIPTION
	Fly assigned heading for RADAR vectors to appropriate route. Maintain ATC assigned altitude. <u>BELCHER TRANSITION (DALL4.EIC)</u>: From over TTT VOR/DME on TTT R-094 to POTEN, then on EIC R-259 to EIC VORTAC. <u>LITTLE ROCK TRANSITION (DALL4.LIT)</u>: From over TTT VOR/DME on TTT R-064 to ORTRO, then on LIT R-237 to LIT VORTAC. <u>SOLDO TRANSITION (DALL4.SOLDO)</u>: From over TTT VOR/DME on TTT R-084 to SOLDO. <u>TEXARKANA TRANSITION (DALL4.TXK)</u>: From over TTT VOR/DME on TTT R-074 to SHERO, then on TXK R-244 to TXK VORTAC.