TOP ALTITUDE: ASSIGNED BY ATC

RNAV 1 - DME/DME/IRU or GPS.
RADAR required.

NOTE: Turbojet departures at/above 10000, maintain 280K until advised by ATC.
NOTE: For use by aircraft filed at or below FL220, or as assigned by ATC.
NOTE: CAUTION: Parachute jumping 6 NM SW of BROZZ, 3 NM radius of Napoleon Airport (3NP) at or below 17999 (SR-SS).

NOTE: Chart not to scale.

SELFRIDGE DEP CON★ 119.6 391.9
ATIS 125.325 270.1
CLNC DEL 128.3 275.8
GND CON 128.3 275.8
SELFRIDGE TOWER★ 120.15 225.4

TAKEOFF MINIMUMS:
Rwy 1: Standard.
Rwy 19: Standard with minimum climb of 235' per NM to 1500.

DEPARTURE ROUTE DESCRIPTION

TAKEOFF RUNWAY 1; Climb on heading 007° or as assigned by ATC, thence....
TAKEOFF RUNWAY 19; Climb on heading 187° or as assigned by ATC, thence....

....for RADAR vectors to BROZZ, then on track 279° to CCOBB, then on (transition).
Maintain ATC assigned altitude, expect filed altitude 10 minutes after departure.

ZEGBI TRANSITION (CCOBB3.ZEGBI):

CCOBB THREE DEPARTURE (RNAV)
(CCOBB3.CCOBB) 16MAY24
MOUNT CLEMENTS, MICHIGAN
SELFRIDGE ANGB (KMTC)