QERVO THREE ARRIVAL (RNAV) Transition Routes

(MARCS.QERVO3) 27NOV25

SAN ANTONIO, TEXAS

SAN ANTONIO APP CON
127.1 269.1
BAZ ATIS
119.325
KRND ATIS ★
290.525
SAT D-ATIS
118.9
SKF ATIS
120.45 273.5
SSF ATIS
128.8

RNAV 1-DME/DME/IRU or GPS.
RADAR required.

ANNGY TRANSITION (ANNGY.QERVO3)
BLEWE TRANSITION (BLEWE.QERVO3)
CAAGE TRANSITION (CAAGE.QERVO3)
MOLLR TRANSITION (MOLLR.QERVO3)
WAILN TRANSITION (WAILN.QERVO3)
WINDU TRANSITION (WINDU.QERVO3)

N

WINDU
13000
*3600
195°
(20)

BLEWE
13000
*3600
195°
(52)

OUTLW
13000
*2800
207°
(34)

MARCS
15000
13000

See following page for arrival routes.

13000
*2800
270°
(22)

RODIO
091°
10 NM

13000
*2800
271°
(18)

HOSAY
FL240

13000
*2800
271°
(27)

WAILN

13000
*2800
271°
(20)

WEEED
091°
12 NM
271°

ANNGY
13000
*2800
219°
(112)

CAAGE
13000
*2800
253°
(45)

MOLLR
13000
*2800
275°
(48)

NOTE: Jet and turboprop aircraft only.
NOTE: WAILN Transition for Houston terminal area departures only.

NOTE: Chart not to scale.

(CONTINUED ON FOLLOWING PAGE)

(MARCS.QERVO3) 25331

QERVO THREE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

AL-369 (FAA)