

|                                              |                        |                             |                                         |
|----------------------------------------------|------------------------|-----------------------------|-----------------------------------------|
| VORTAC SAF<br><b>110.6</b><br>Chan <b>43</b> | APP CRS<br><b>158°</b> | Rwy Ldg<br>TDZE<br>Apt Elev | <b>N/A</b><br><b>N/A</b><br><b>6349</b> |
|----------------------------------------------|------------------------|-----------------------------|-----------------------------------------|

VOR/DME-A  
SANTA FE RGNL (SAF)

**T** When control tower closed, obtain local altimeter setting on UNICOM;  
**A** when not received, use Los Alamos altimeter setting: increase all  
MDAs 160 feet.

**MISSED APPROACH:** Climb to 9000 direct  
SAF VORTAC and hold, continue climb-in-hold  
to 9000.

|                |                                    |                                          |                  |                  |
|----------------|------------------------------------|------------------------------------------|------------------|------------------|
| ATIS<br>128.55 | ALBUQUERQUE CENTER<br>132.8 346.35 | SANTA FE TOWER ★<br>119.5 (CTAF) 0 239.3 | GND CON<br>121.7 | UNICOM<br>122.95 |
|----------------|------------------------------------|------------------------------------------|------------------|------------------|

