

|            |         |          |      |
|------------|---------|----------|------|
| VORTAC FWA | APP CRS | Rwy Ldg  | 8001 |
| 117.8      | 145°    | TDZE     | 802  |
| Chan 125   |         | Apt Elev | 815  |

VOR or TACAN RWY 14  
FORT WAYNE INTL (FWA)

|                                                            |  |                                                                           |                                   |                        |
|------------------------------------------------------------|--|---------------------------------------------------------------------------|-----------------------------------|------------------------|
| DME required.                                              |  | MISSED APPROACH: Climb to 3000 on FWA R-134 to OSBER/FWA 22 DME and hold. |                                   |                        |
| <div><div><div></div><div></div></div><div>ASR</div></div> |  |                                                                           |                                   |                        |
|                                                            |  |                                                                           |                                   |                        |
| ATIS<br>121.25 360.825                                     |  | FORT WAYNE APP CON<br>127.2 284.6                                         | FORT WAYNE TOWER<br>119.1 269.325 | GND CON<br>121.9 348.6 |

