

VORTAC FWA
117.8
Chan **125**

APP CRS
224°

Rwy Ldg
TDZE **799**
Apt Elev **815**

VOR or TACAN RWY 23
FORT WAYNE INTL (FWA)

▼

▲

ASR

DME required.

MISSED APPROACH: Climbing left turn to 3000 on FWA VORTAC R-134 to OSBER/FWA 22 DME and hold.

ATIS
121.25 360.825

FORT WAYNE APP CON
127.2 284.6

FORT WAYNE TOWER
119.1 269.325

GND CON
121.9 348.6

Diagram illustrating the approach procedure for Fort Wayne International (FWA) VOR or TACAN RWY 23. The diagram shows the following elements:

- Fort Wayne VORTAC:** 117.8 FWA, Chan 125.
- Waypoints and Altitudes:**
 - YILUC FWA 1.1
 - LUERS FWA 5
 - ZOLNR FWA 11 (IF/IAF)
 - OSBER FWA 22
- Altitudes and Gradients:**
 - 3000 (224°)
 - 2300 (224°)
 - 6000 (044°)
 - 3000 (224°)
- Gradients:** 3.04° TCH 55
- Missed Approach:** Climbing left turn to 3000 on FWA VORTAC R-134 to OSBER/FWA 22 DME and hold.
- Diagram Labels:** R-112, R-134, R-044, HOLD, 1 min, 110.4 OLK, MSA FWA 25 NM, 2700, 224°, 044°, 314°, 134°.

ELEV 815 D TDZE 799

224°

8002 X 150

0.35° DOWN

4001 X 75

27

32

TWR

TDZL/RCLS Rwy 5

REIL Rwys 14 and 23

HIRL Rwys 5-23 and 14-32

FAF to MAP 3.9 NM

Knots

60

90

120

150

180

Min:Sec

3:54

2:36

1:57

1:34

1:18

3000

OSBER

FWA R-134

YILUC FWA 1.1

LUERS FWA 5

ZOLNR FWA 11

OSBER FWA 22

One Minute Holding Pattern

0.6

0.8

3.2 NM

6 NM

2300

6000

3000

044°

224°

3.04° TCH 55

VGSI and descent angles not coincident (VGSI Angle 3.00/TCH 76).

CATEGORY	A	B	C	D	E
S-23	1300/55	501 (500-1)	1300-1 ³ / ₈	501 (500-1 ³ / ₈)	
CIRCLING	1300-1	485 (500-1)	1360-1 ¹ / ₂ 545 (600-1 ¹ / ₂)	1520-2 ¹ / ₄ 705 (800-2 ¹ / ₄)	1520-2 ¹ / ₂ 705 (800-2 ¹ / ₂)

FORT WAYNE, INDIANA

Amtd 15 14MAY26

40°59'N-85°12'W

FORT WAYNE INTL (FWA)

VOR or TACAN RWY 23