QERVO THREE ARRIVAL (RNAV) Transition Routes

(MARCS.QERVO3) 27NOV25

SAN ANTONIO, TEXAS

SAN ANTONIO APP CON
127.1 269.1
BAZ ATIS
119.325
KRND ATIS ★
290.525
SAT D-ATIS
118.9
SKF ATIS
120.45 273.5
SSF ATIS
128.8

RNAV 1-DME/DME/IRU or GPS.
RADAR required.

ANNGY TRANSITION (ANNGY.QERVO3)
BLEWE TRANSITION (BLEWE.QERVO3)
CAAGE TRANSITION (CAAGE.QERVO3)
MOLLR TRANSITION (MOLLR.QERVO3)
WAILN TRANSITION (WAILN.QERVO3)
WINDU TRANSITION (WINDU.QERVO3)

N

WINDU
13000 *3600 195° (20)
BLEWE
13000 *3600 195° (52)
OUTLW
13000 *2800 207° (34)
MARCS
15000
13000
See following page for arrival routes.
13000 *2800 270° (22)
RODIO
091° 10 NM
13000 *2800 271° (18)
HOSAY FL240
13000 *2800 271° (27)
WAILN
13000 *2800 271° (20)
WEEED
091° 12 NM
271°
ANNGY
13000 *2800 219° (112)
CAAGE
13000 *2800 253° (45)
MOLLR
13000 *2800 275° (48)

NOTE: Jet and turboprop aircraft only.
NOTE: WAILN Transition for Houston terminal area departures only.

NOTE: Chart not to scale.

(CONTINUED ON FOLLOWING PAGE)

(MARCS.QERVO3) 25331

QERVO THREE ARRIVAL (RNAV) Transition Routes

SAN ANTONIO, TEXAS

AL-369 (FAA)