

U.S. DEPARTMENT OF TRANSPORTATION – FEDERAL AVIATION ADMINISTRATION
TAKEOFF MINIMUMS AND OBSTACLE DEPARTURE PROCEDURES (ODP)

Bearings, headings, courses, tracks and radials are magnetic. Elevation and altitudes are in feet MSL. Altitudes are minimum altitudes unless otherwise indicated.
Ceilings are in feet above airport elevation. Distances are in nautical miles. Visibilities are in statute miles or feet RVR unless otherwise indicated.

City, State	Airport	Effective Date	Amdt. No.
BROWNSVILLE, TX	BROWNSVILLE/SOUTH PADRE ISLAND INTL	20 OCT 2011	ORIG

TAKEOFF MINIMUMS:

RWY 13, 17, 31, 35, STANDARD.

TEXTUAL DEPARTURE PROCEDURES:

TAKEOFF OBSTACLE NOTES:

NOTE: RWY 13, TREES AND BUSHES BEGINNING 32 FT FROM DER, 399 FT LEFT OF CENTERLINE, UP TO 30 FT AGL/50 FT MSL. TREES, BUSHES, POLE, AND BUILDING BEGINNING 751 FT FROM DER, 191 FT RIGHT OF CENTERLINE, UP TO 44 FT AGL/64 FT MSL.

NOTE: RWY 17, TREES AND POLE BEGINNING 56 FT FROM DER, 61 FT LEFT OF CENTERLINE, UP TO 53 FT AGL/78 FT MSL. TREES AND POLES BEGINNING 1011 FT FROM DER, 96 FT RIGHT OF CENTERLINE, UP TO 44 FT AGL/69 FT MSL.

NOTE: RWY 31, AIRPLANES ON TAXIWAY BEGINNING 371 FT FROM DER, 563 FT RIGHT OF CENTERLINE, UP TO 45 FT AGL/64 FT MSL. TREES BEGINNING 1141 FT FROM DER, 567 FT RIGHT OF CENTERLINE, UP TO 37 FT AGL/52 FT MSL.

NOTE: RWY 35, POLE AND TREES BEGINNING 695 FT FROM DER, 140 FT RIGHT OF CENTERLINE, UP TO 56 FT AGL/71 FT MSL. TREES BEGINNING 719 FT FROM DER, 84 FT LEFT OF CENTERLINE, UP TO 63 FT AGL/78 FT MSL.

CONTROLLING OBSTACLES: