

**RNAV - STANDARD
INSTRUMENT APPROACH PROCEDURE
TITLE 14 CFR PART 97.33**

Bearings, headings, courses, and radials are magnetic. Elevations and altitudes are in feet, MSL, except HAT, HAA, TCH, and RA. Altitudes are minimum altitudes unless otherwise indicated. Ceilings are in feet above airport elevation. Distances are in nautical miles unless otherwise indicated, except visibilities which are in statute miles or in feet RVR.

TERMINAL ROUTES

MISSED APPROACH

FROM	TO	COURSE AND DISTANCE	ALTITUDE	
FITIK (IF/IAF)	WEMBU (FB)	000.51 / 6.00	1900	RW36
WEMBU (FAF)	RW36 (MAP) (FO)	000.50 / 4.86		
RW36 (MAP)	729 MSL	000.50		
729 MSL	FITIK (FO)		3000	
CLIMBING LEFT TURN TO 3000 DIRECT FITIK AND HOLD.				
ADDITIONAL FLIGHT DATA: FAS OBST: 509 AAO 364438N/0774650W CHART CIRCLING ICON. CHART PROFILE NOTE: VISUAL SEGMENT - OBSTACLES. CHART R-6602.				

- PT SIDE OF COURSE OUTBOUND FT WITHIN MILES OF (IAF)
- HOLD S FITIK, RT, 000.51 INBOUND, 2800 FT. IN LIEU OF PT (IAF)**
- FAC: 000.50 FAF: WEMBU DIST FAF TO MAP: 4.86 THLD:
- MIN. ALT: **FITIK 2800, WEMBU 1900**
- DIST TO THLD FROM OM: MM: IM: 150 HAT: 100 HAT: GS ANT:
- MIN GS INCPT: GS ALT AT: OM: MM: IM:
- GS ANGLE: TCH:
- MSA FROM:

MAG VAR: **8W** EPOCH YEAR: **1985**

MINIMUMS

TAKEOFF: <u> </u> SEE FAA FORM 8260-15A FOR THIS AIRPORT	ALTERNATE: <u>NA</u>	@ <u> </u>													
CATEGORY <u>=====</u>	A			B			C			D			E		
	DH/MDA	VIS	HAT/HAA	DH/MDA	VIS	HAT/HAA	DH/MDA	VIS	HAT/HAA	DH/MDA	VIS	HAT/HAA	DH/MDA	VIS	HAT/HAA
CIRCLING	1340	3	1011	1340	3	1011		NA			NA				

NOTES:
 CHART NOTE: CIRCLING NA TO RWYS 6 AND 24. @ NA WHEN LOCAL WEATHER NOT AVAILABLE.
 CHART NOTE: DME/DME RNP-0.3 NA. @ CAT A, B 1100-3
 CHART NOTE: PROCEDURE NA AT NIGHT.
 CHART NOTE: HELICOPTER VISIBILITY REDUCTION BELOW 1 SM NOT AUTHORIZED.
 (CONTINUED ON PAGE 2)



CITY AND STATE LAWRENCEVILLE, VA	ELEVATION: 329 TDZE: AIRPORT NAME: LAWRENCEVILLE/BRUNSWICK MUNI	FACILITY IDENTIFIER: RNAV	PROCEDURE NO./AMDT NO./EFFECTIVE DATE: RNAV (GPS)-B, ORIG 15 SEPTEMBER 2016	SUP: AMDT: NONE DATED:
--	---	-------------------------------------	--	-------------------------------------

US DEPARTMENT OF TRANSPORTATION - FEDERAL AVIATION ADMINISTRATION
RNAV - STANDARD
INSTRUMENT APPROACH PROCEDURE - TITLE 14 CFR PART 97.33

Bearings, headings, courses, and radials are magnetic. Elevations and altitudes are in feet, MSL, except HAT, HAA, TCH, and RA. Altitudes are minimum altitudes unless otherwise indicated. Ceilings are in feet above airport elevation. Distances are in nautical miles unless otherwise indicated, except visibilities which are in statute miles or in feet RVR.

NOTES, (CONT.):

CHART NOTE: WHEN LOCAL ALTIMETER SETTING NOT RECEIVED, USE SOUTH HILL ALTIMETER SETTING AND INCREASE ALL MDA 60 FEET.

TAA

	<u>FROM</u>	<u>TO</u>	<u>ALT</u>
1.	271/30 CW 091/30 (NOPT)	FITIK (IF/IAF) (FB)	2800
2.	091/30 CW 271/30	FITIK (IF/IAF) (FO)	2800



CITY AND STATE LAWRENCEVILLE, VA	ELEVATION: 329 AIRPORT NAME: LAWRENCEVILLE/BRUNSWICK MUNI	TDZE:	FACILITY IDENTIFIER: RNAV	PROCEDURE NO./AMDT NO./EFFECTIVE DATE: RNAV (GPS)-B, ORIG 15 SEPTEMBER 2016	SUP:
					AMDT: NONE
					DATED:

U.S. DEPARTMENT OF TRANSPORTATION - FEDERAL AVIATION ADMINISTRATION
RNAV (GPS) STANDARD INSTRUMENT APPROACH PROCEDURE
 FLIGHT STANDARDS SERVICES - TITLE 14 CFR PART 97.33

Bearings, headings, courses, and radials are magnetic. Elevations and altitudes are in feet, MSL, except HAT, HAA, TCH, and RA. Altitudes are minimum altitudes unless otherwise indicated. Ceilings are in feet above airport elevation. Distances are in nautical miles unless otherwise indicated, except visibilities which are in statute miles or in feet RVR.

ARINC SUMMARY - KLVL

ROUTES

TRANSITION	WPT SEQ	WPT NAME	LEG TYPE	FB/FO	RNP	MAG CRS	REC NAV	ANGLE	TURN DIR	CENTER FIX	TURN RADIUS	ALTITUDE DESCRIPTION & VALUE	SPEED LIMIT DESCRIPTION & VALUE	WPT DESCRIPTION CODE
FITIK	010	FITIK	HF	FO		000.5			R			AA 02800		EE A
	010	FITIK	IF	FB								AA 02800		E I
	020	WEMBU	TF	FB	1.0	000.5						AA 01900		E F
	030	RW36	TF	FO	0.3	000.5		2.95				AT 00351		GY M
	040		CA	FB		000.5						AA 00729		M
	050	FITIK	DF	FO					L			AA 03000		EY
	060	FITIK	HM	FO		000.5			R			AA 02800		EE

POINTS

POINT NAME	LATITUDE	LONGITUDE
FITIK	N363526.97	W0774549.44
WEMBU	N364124.20	W0774647.78

RUNWAYS

RUNWAY	THRESHOLD LATITUDE	THRESHOLD LONGITUDE	THRESHOLD ELEVATION	PROCEDURE TCH
RW36	N364613.86	W0774735.19	00311	40



CITY AND STATE LAWRENCEVILLE, VA	ELEVATION: 329	TDZE:	FACILITY IDENTIFIER:	PROCEDURE NO. / AMDT NO. / EFFECTIVE DATE:	SUP:
	AIRPORT NAME: LAWRENCEVILLE/BRUNSWICK MUNI		RNAV	RNAV (GPS)-B, ORIG	AMDT: NONE
				15 SEPTEMBER 2016	DATED: