

AIRPORT DIAGRAM

AL-432 (FAA)


TULSA INTL (TUL)
TULSA, OKLAHOMA

D-ATIS
124.9 377.2
TULSA TOWER
121.2 310.8 (RWYS 18L-36R, 08-26)
118.7 257.8 (RWY 18R-36L)
GND CON
121.9 348.6
CLNC DEL
134.05 284.7

OKLAHOMA
ANG

36°13'N

JANUARY 2020
ANNUAL RATE OF CHANGE
0.1° W



SC-1, 16 JUL 2020 to 13 AUG 2020

SC-1, 16 JUL 2020 to 13 AUG 2020

36°12'N

36°11'N

RWY 08-26
PCN 68 R/B/W/T
S-75, D-200, 2D-350

RWY 18L-36R
PCN 88 R/B/W/T
S-75, D-200, 2D-400

RWY 18R-36L
PCN 47 F/C/X/T
S-60, D-100

CAUTION: BE ALERT TO RUNWAY
CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING
INSTRUCTIONS IS REQUIRED.

95°54'W

95°53'W

AIRPORT DIAGRAM

TULSA, OKLAHOMA
TULSA INTL (TUL)