

AIRPORT DIAGRAM

AL-268 (FAA)

MOBILE INTL (BFM)
MOBILE, ALABAMA

ATIS 135.575
INTERNATIONAL TOWER ★ 118.8 (CTAF) 251.1
GND CON 121.7 239.3

VAR 2.8° N
JANUARY 2025
ANNUAL RATE OF CHANGE 0.1° W

TERMINAL

FIELD
ELEV
26

TWR

FIRE STATION

81
ELEV
25

(d)

182.8°

7800 X 150

8° 28'

002.8°

ELEV
36

25

HS 1

RUN-UP
PAD

ELEV
19

32

321.6°

A5

9

A6

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

32

RWY 14-32
PCN 72 F/B/X/T
S-75, D-185, 2D-325
RWY 18-36
PCN 34 R/B/X/T
S-76, D-150, 2D-320

HIRL Rwy 14-32
MIRL Rwy 18-36
REIL Rwy 14
TDZ/CL Rwy 32

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

88°05'W

88°04'W

AIRPORT DIAGRAM

MOBILE, ALABAMA
MOBILE INTL (BFM)